

Pressure jet burner



CODE	MODEL	TYPE
3473784	PRESS GW	605 T80

Thermal power	107 / 178 - 350 kW - 92.000 / 153.000 - 301.000 kcal/h
Output	9/15 - 30 kg/h
Fuel	Gas oil, max. viscosity at 20 °C: 6 mm ² /s (1.5 °E)
Electrical supply	Single-phase 220V +10% -10% ~ 60Hz
Motor	1.85 A / 220V
Capacitor	8 µF
Ignition transformer	Primary: 1.8 A / 220V - Secondary: 1x 8 kV - 30 mA
Absorbed electrical power	0.4 kW






Fig. 1



- 1 - Suction line fitting
- 2 - Return line fitting
- 3 - Suction gauge fixing point (G 1/8)
- 4 - Pressure gauge fixing point (G 1/8)
- 5 - Pump pressure adjuster
- 6 - Wiring terminal board
- 7 - Combustion head control shaft
- 8 - Fair leads
- 9 - Control box reset button with signal of lock-out

Quantity	Accessories
2	Flexibles oil-lines
2	Connectors for flexibles
2	Gasket for flexibles
1	Flange gasket
4	Screws
1	Pipe fitting
1	Pipe fitting gasket


DIMENSIONS (mm)



* Length available with special blast tube to be separately required.

PRESSURE IN THE COMBUSTION CHAMBER - OUTPUT


(in compliance with DIN 4787)



The burner is drawn for on-off operation and high-low operation.

Minimum firing-rate at on-off operation is 15 kg/h (two nozzles) and 9 kg/h (one nozzle) with high-low operation.



DIMENSIONS OF THE TEST COMBUSTION-CHAMBER (DIN 4787)



D = Boiler diameter in mm


P = Position of the mobile back in mm

Specific thermal test load



HYDRAULIC SYSTEM


Gravity feed from the bottom of the oil storage tank



The dimension P should not exceed 10 m, to avoid breakage of pump seals.

H meters	L meters	
	I.D. 8 mm	I.D. 10 mm
0.5	5	10
1	10	20
1.5	15	30
2	20	40


Gravity feed over the top of the oil storage tank



The dimension P should not exceed 10 m, to avoid breakage of pump seals.

H meters	L meters	
	I.D. 8 mm	I.D. 10 mm
0	32	70
0.5	28	62
1	24	55
1.5	20	48
2	16	40
3	7	25
3.5	-	10

Suction feed



Oil lines must be perfectly sealed. The use of copper pipe is therefore recommended. The pump suction must not exceed 4 m w.c. (30 cm Hg) because beyond this value the pump becomes noisy.

The return line must terminate at the same level as the foot valve; otherwise the pump may become air-locked.


H = Difference in height;

L = The total length of the suction line, including the vertical section.

The copper pipes of 8 mm and 10 mm I.D., as shown on the tables above, may be replaced by steel pipes of 1/4" or 3/8" Gas.

BURNER ELECTRICAL WIRING

(carried out by the factory)




2463

KEY TO LAYOUT

C	Capacitor	TA	Ignition transformer
FR	Photocell	TB	Burner ground (earth) connection
MB	Wiring terminal block	V1	1 st stage solenoid valve
MV	Fan motor	V2	2 nd stage solenoid valve
RMO	Control box		

ELECTRICAL CONNECTIONS TO THE WIRING TERMINAL BLOCK (to be carried out by the installer)



2646

KEY TO LAYOUT

H	Remote lock - out signal	TL	Limit control device system
MB	Wiring terminal block	TR	High - low mode control device system
PS	Lock - out reset button	TS	Safety control device system
TB	Burner ground (earth) connection		

NOTICE


- The electric wiring carried out by the installer must be in compliance with the rules in force in the Country.
- Leads minimal section 1 mm².

FLAME MODULATION

The flame modulation is obtainable through the thermostat, controlling the second valve, connected to the terminals 8 and 9, removing the existing bridge.

FIXING OF THE ELECTRICAL WIRES

All the electrical wires, which are to be connected to the terminal block 6) (fig. 1) shall pass through the fair leads 8) (fig. 1) as per this scheme.



1 - Single phase supply: fair lead Pg 13.5

2 - Adjustment thermostat: fair lead Pg 13.5

3 - Safety thermostat: fair lead Pg 13.5

4 - 2nd stage thermostat: fair lead Pg 13.5

5 - 6 - 7 - Pre-sheared holes

Further prospective signals or controls can be connected to the burner wiring terminal board by removing the metal weldnuts from the pre-sheared holes and inserting a common fair lead for the passage and the clamping of the leads.

NOTES

- Do not exchange the neutral wire with the phase (avoid the plug-pin connection).
- Carry out a safe earth connection.
- Verify the burner stop by opening the boiler thermostat and the burner lock-out by darkening the photo-resistance.

ACCESSORIES

• RADIO DISTURBANCE PROTECTION KIT

If the burner is installed in places particularly subject to radio disturbance (emission of signals exceeding 10 V/m) owing to the presence of an INVERTER, or in applications where the length of the thermostat connections exceeds 20 metres, a protection kit is available as an interface between the control box and the burner.

Code	3010386
------	---------

BURNER ADJUSTMENT

Establish, on the basis of the output desired, and in accordance with the table and the diagram underneath:


- the type of nozzle;
- the pump pressure;
- the combustion head setting.

EXAMPLE

The burner has to be matched with a boiler of 210 kW.

Assuming an efficiency of 90%, we need to develop approximately 233 kW i.e. burning roughly 20 kg/h.

In the output column we find, corresponding to 20, on the left, the required nozzles (2 of 2.50 GPH at 60°) the pump pressure (12 bar), and on the right the correct position of the combustion head (3 set-points).



(1) Nozzles of the major existing makers may be used.

It might well be possible however, that for certain specific outputs, one type of nozzle is less suitable than others. It is recommended not to change the atomizing angle.

(2) It is recommended not to goes down to the 10 bar, otherwise the jack controlling the air damper will open with difficulty.


The pump pressure may be varied by acting on the screw 5) (fig. 1) and it can be controlled by placing a pressure switch on the pressure gauge 4) (fig. 1).

(3) The indicated outputs are drawn from the average statistical data of our tests.

Real output may well vary by $\pm 5\%$.

(4) The rear level of the control-shaft (7) (fig. 1) must line-up with the set-point number, indicated by the diagram.

In the sketch on the right, the shaft is shown, in the position required by the example on page 7.




AIR DAMPER ADJUSTMENT

Air damper adjustment for the first flame

Loosen the screw (1), the nut (3) and move the graduated scale (2) so that the pointer (4) lines-up with the set-point desired; then tighten the screw (1) and the nut (3). A sufficiently exact control, valid for 12 bar and for the different boilers pressurizations is given by the following table:

Nozzle (GPH)	N°Set-point
2.00	1.5
2.25	1.5
2.50	2
3.00	2.5
3.50	3
4.00	3



On the sketch the graduated scale is shown, in the position required by the example on page 7.


NOTE

For any necessary combustion adjustment, at the first flame stage, remove the bridge or the second stage thermostat (see page 5).

Regulation of the air damper for the second flame

Loosen the threaded locking-ring (1) and tighten the hexagon (2) in order to reduce flow; slacken the hexagon to increase flow.

This adjustment shall be modified, from time to time, in relation to the various combustion chambers pressurizations.



All burner controls are clearly indicated into the instruction.


Only the air damper adjustment for the second flame, is determined at the place of installation, depending on the boiler pressure.

ATTENTION

At the first ignition, passing from the first to the second flame, the oil pressure decrease noticeably because of the filling of the second nozzle line - this decreasing can cause the burner shutdown, sometimes with strong pulsations.

PUMP

SUNTEC AN67



		AN 67
Min. delivery rate at 12 bar pressure	kg/h	65
Delivery pressure range	bar	10 - 18
Max. suction depression	bar	0,45
Viscosity range	cSt	2 - 75
Light oil max. temperature	°C	60
Max. suction and return pressure	bar	2
Pressure calibration in the factory	bar	12
Filter mesh width	mm	0,150

Key to Figure (A)

Pump	AN
1 - Suction	G 1/4"
2 - Return	G 1/4"
3 - Pressure gauge attachment	G 1/8"
4 - Vacuum meter attachment	G 1/8"
5 - Pressure adjustment screw:	
Right rotation =	pressure increases
Left rotation =	pressure decreases

G = cylindrical thread

The connector to be screwed into the cylindrical thread G must be equipped with a sealing washer.

Do not screw a connector with a conical thread (NPTF) into the cylindrical thread G.

NOTE

- The pumps are equipped with a by-pass that connects return line and suction line. The pumps are installed on the burner with the by-pass closed by screw accessible from the return connector 2).

When single-pipe fuel supply systems without degassing units are used, this screw, accessible from the return connector 2), must be removed. In this way, the excess in the delivery discharged by the pressure regulator into the return line passes into the suction line.

The pump will break immediately if it is run with the return line closed and the by-pass screw inserted.

- The vacuum meter attachment is located upstream from the pump filter and consequently it is not able to detect a clogged filter.


- The pump is delivered from the factory already full of fuel and with its return and suction connections plugged. This stops the gear unit rusting and permits the pump to prime upon first starting.

- Water must be prevented from accumulating on the bottom of the tank, due to infiltration or condensation, and subsequently reaching the pump. Water in the pump will lead to rusting and eventually the pump will have to be renewed.

OPERATING FAULT DIAGNOSTICS

The control box has a self-diagnostic system, which easily allows identifying the operating faults (**RED LED** signal).
 To use this function, wait at least ten seconds from the safety lock out, and then press the reset button for a minimum of 3 seconds.

After releasing the button, the RED LED starts flashing as shown in the diagram below.



The pulses of the LED constitute a signal spaced by approximately 3 seconds.

The number of pulses will provide the information on the possible faults, according to the table below:

SIGNAL	PROBABLE CAUSE
2 flashes ● ●	The flame does not stabilise at the end of the safety time: – faulty photocell; – faulty or soiled oil valves; – neutral/phase exchange; – faulty ignition transformer – poor burner regulation (insufficient gas oil).
3 flashes ● ● ●	Min. air pressure switch (if installed) does not close: – air pressure switch faulty; – air pressure switch incorrectly regulated; – max. air pressure switch triggered (if installed).
4 flashes ● ● ● ●	Min. air pressure switch (if installed) does not open or light in the chamber before firing: – air pressure switch faulty; – air pressure switch incorrectly regulated.
7 flashes ● ● ● ● ● ● ● ●	Loss of flame during operations: – poor burner regulation (insufficient gas oil); – faulty or soiled oil valves; – short circuit between photocell and earth.
8 flashes ● ● ● ● ● ● ● ●	– Not used.
10 flashes ● ● ● ● ● ● ● ● ● ●	– Wiring error or internal fault. – Presence of electromagnetic disturbance. Use the radio disturbance protection kit

RIELLO

RIELLO S.p.A.
I-37045 Legnago (VR)
Tel.: +39.0442.630111
[http:// www.riello.it](http://www.riello.it)
[http:// www.rielloburners.com](http://www.rielloburners.com)