

GB **Dual fuel light oil/ gas burners**

Progressive two-stage or modulating operation gas side/
two-stage light oil side

CE**UK
CA****EAC**

| CODE | MODEL | TYPE |
|----------|--------------|------|
| 20205590 | RLS 68/M MX | 779T |
| 20205707 | RLS 68/M MX | 779T |
| 20205592 | RLS 120/M MX | 780T |
| 20208605 | RLS 120/M MX | 780T |



Original instructions

| | | |
|----------|--|-----------|
| 1 | Declarations | 3 |
| 2 | Information and general warnings | 4 |
| 2.1 | Information about the instruction manual | 4 |
| 2.2 | Guarantee and responsibility | 5 |
| 3 | Safety and prevention | 6 |
| 3.1 | Introduction | 6 |
| 3.2 | Personnel training | 6 |
| 4 | Technical description of the burner | 7 |
| 4.1 | Burner designation | 7 |
| 4.2 | Models available | 7 |
| 4.3 | Burner categories - Countries of destination | 8 |
| 4.4 | Technical data | 8 |
| 4.5 | Electrical data | 8 |
| 4.6 | Maximum dimensions | 9 |
| 4.7 | Firing rate | 10 |
| 4.8 | Test boiler | 10 |
| 4.9 | Commercial boilers | 11 |
| 4.10 | Burner equipment | 11 |
| 4.11 | Burner description | 12 |
| 4.12 | Electrical panel description | 13 |
| 4.13 | Flame control (LFL...) | 14 |
| 4.14 | Servomotor (SQN31...) | 15 |
| 4.15 | Calibration of the thermal relay | 16 |
| 4.16 | Motor rotation | 16 |
| 5 | Installation | 17 |
| 5.1 | Notes on safety for the installation | 17 |
| 5.2 | Handling | 17 |
| 5.3 | Preliminary checks | 17 |
| 5.4 | Operating position | 18 |
| 5.5 | Preparing the boiler | 18 |
| 5.6 | Securing the burner to the boiler | 19 |
| 5.7 | Electrode position | 19 |
| 5.8 | Choice of nozzles for the 1st and 2nd stage | 20 |
| 5.9 | Nozzle installation | 21 |
| 5.10 | Combustion head adjustment | 22 |
| 5.11 | Light oil supply | 23 |
| 5.12 | Gas supply | 26 |
| 5.13 | Electrical connections | 29 |
| 6 | Start-up, calibration and operation of the burner | 30 |
| 6.1 | Notes on safety for the first start-up | 30 |
| 6.2 | Servomotor adjustment | 30 |
| 6.3 | Adjustments prior to ignition (light oil) | 30 |
| 6.4 | Burner start-up (light oil) | 31 |
| 6.5 | Burner ignition (light oil) | 31 |
| 6.6 | Burner adjustment (light oil) | 31 |
| 6.7 | Adjustments prior to ignition (gas) | 32 |
| 6.8 | Burner start-up (gas) | 32 |
| 6.9 | Burner ignition (gas) | 32 |

| | | |
|----------|--|-----------|
| 6.10 | Burner adjustment (gas) | 33 |
| 6.11 | Change of fuel..... | 34 |
| 6.12 | Pressure switch adjustment | 35 |
| 6.13 | Operation sequence of the burner (gas) | 37 |
| 6.14 | Final checks (with burner operating)..... | 38 |
| 7 | Maintenance | 39 |
| 7.1 | Notes on safety for the maintenance | 39 |
| 7.2 | Maintenance programme | 39 |
| 7.3 | Opening the burner | 42 |
| 7.4 | Closing the burner..... | 42 |
| 8 | Faults - Possible causes - Solutions..... | 43 |
| 8.1 | Light oil operation..... | 44 |
| 8.2 | Gas operation | 46 |
| A | Appendix - Accessories | 48 |
| B | Appendix - Electrical panel layout..... | 49 |

1 Declarations

Declaration of Conformity A.R. 8/1/2004 & 17/7/2009 – Belgium

| | | | |
|--|---|----------------------|--------------------|
| Manufacturer/Distributed by: | RIELLO S.p.A. 37045 Legnago (VR) Italy Tel. ++39.0442630111 www.riello.com | | |
| This document certifies that the series of devices specified below is in compliance with the model described in the EC Declaration of Conformity and has been manufactured and distributed in compliance with the requirements defined in the Legislative Decree of January 8th 2004 and July 17th 2009. | | | |
| Type of product: | Dual fuel Light Oil/Gas Burner | | |
| Model: | RLS 68/M MX - RLS 120/M MX | | |
| Regulation applied: | EN 267/676 and A.R. of January 8th 2004 - July 17th 2009 | | |
| Controlling organisation: | TÜV Industrie Service GmbH TÜV SÜD Gruppe Ridlerstrase, 65 80339 München DEUTSCHLAND | | |
| Values measured: | | OIL | GAS |
| | RLS 68/M MX | CO max: 12 mg/kWh | CO max: 8 mg/kWh |
| | | Max. NOx: 110 mg/kWh | NOx max: 70 mg/kWh |
| | RLS 120/M MX | CO max: 6 mg/kWh | CO max: 7 mg/kWh |
| | | Max. NOx: 130 mg/kWh | NOx max: 64 mg/kWh |

2 Information and general warnings

2.1 Information about the instruction manual

2.1.1 Introduction

The instruction manual supplied with the burner:

- is an integral and essential part of the product and must not be separated from it; it must therefore be kept carefully for any necessary consultation and must accompany the burner even if it is transferred to another owner or user, or to another system. If the manual is lost or damaged, another copy must be requested from the Technical Assistance Centre of the area;
- is designed for use by qualified personnel;
- offers important indications and instructions relating to the installation safety, start-up, use and maintenance of the burner.

Symbols used in the manual

In some parts of the manual you will see triangular DANGER signs. Pay great attention to these, as they indicate a situation of potential danger.

2.1.2 General dangers

The **dangers** can be of **3 levels**, as indicated below.



Maximum danger level!
This symbol indicates operations which, if not carried out correctly, cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause damage to the machine and/or injury to people.

2.1.3 Other symbols



DANGER: LIVE COMPONENTS
This symbol indicates operations which, if not carried out correctly, lead to electric shocks with lethal consequences.



DANGER: FLAMMABLE MATERIAL
This symbol indicates the presence of flammable materials.



DANGER: BURNING
This symbol indicates the risks of burns due to high temperatures.



DANGER: CRUSHING OF LIMBS
This symbol indicates the presence of moving parts: danger of crushing of limbs.



WARNING: MOVING PARTS
This symbol indicates that you must keep limbs away from moving mechanical parts; danger of crushing.



DANGER: EXPLOSION

This symbol signals places where an explosive atmosphere may be present. An explosive atmosphere is defined as a mixture - under atmospheric conditions - of air and flammable substances in the form of gases, vapours, mist or dust in which, after ignition has occurred, combustion spreads to the entire unburned mixture.



PERSONAL PROTECTION EQUIPMENT

These symbols indicate the equipment that must be worn and kept by the operator for protection against threats against safety and/or health while at work.



OBLIGATION TO ASSEMBLE THE COVER AND ALL THE SAFETY AND PROTECTION DEVICES

This symbol signals the obligation to reassemble the cover and all the safety and protection devices of the burner after any maintenance, cleaning or checking operations.



ENVIRONMENTAL PROTECTION

This symbol gives indications for the use of the machine with respect for the environment.



IMPORTANT INFORMATION

This symbol indicates important information that you must bear in mind.

- This symbol indicates a list.

Abbreviations used

| | |
|------|---------|
| Ch. | Chapter |
| Fig. | Figure |
| Page | Page |
| Sec. | Section |
| Tab. | Table |

2.1.4 Delivery of the system and the instruction manual

When the system is delivered, it is important that:

- the instruction manual is delivered to the user by the system manufacturer, with the recommendation to keep it in the room where the heat generator is to be installed.
- The instruction manual shows:
 - the serial number of the burner;

.....

- the address and telephone number of the nearest Assistance Centre;

.....

- The system supplier must carefully inform the user about:
 - the use of the system;
 - any further tests that may be required before activating the system;
 - maintenance, and the need to have the system checked at least once a year by a representative of the manufacturer or another specialised technician.
 To ensure a periodic check, the manufacturer recommends the drawing up of a Maintenance Contract.

2.2 Guarantee and responsibility

The manufacturer guarantees its new products from the date of installation, in accordance with the regulations in force and/or the sales contract. At the moment of the first start-up, check that the burner is integral and complete.



ATTENTION

Failure to observe the information given in this manual, operating negligence, incorrect installation and carrying out of non authorised modifications will result in the annulment by the manufacturer of the guarantee that it supplies with the burner.

In particular, the rights to the guarantee and the responsibility will no longer be valid, in the event of damage to things or injury to people, if such damage/injury was due to any of the following causes:

- incorrect installation, start-up, use and maintenance of the burner;
- improper, incorrect or unreasonable use of the burner;
- intervention of unqualified personnel;
- carrying out of unauthorised modifications on the equipment;
- use of the burner with safety devices that are faulty, incorrectly applied and/or not working;
- installation of untested supplementary components on the burner;
- powering of the burner with unsuitable fuels;
- faults in the fuel supply system;
- continuation of use of the burner when a fault has occurred;
- repairs and/or overhauls incorrectly carried out;
- modification of the combustion chamber with inserts that prevent the regular development of the structurally established flame;
- insufficient and inappropriate surveillance and care of those burner components most likely to be subject to wear and tear;
- use of non-original components, including spare parts, kits, accessories and optional;
- force majeure.

The manufacturer furthermore declines any and every responsibility for the failure to observe the contents of this manual.

3 Safety and prevention

3.1 Introduction

The burners have been designed and built in compliance with current regulations and directives, applying the known technical safety rules and envisaging all the potential danger situations.

It is necessary, however, to bear in mind that the imprudent and clumsy use of the equipment may lead to situations of death risk for the user or third parties, as well as the damaging of the burner or other items. Inattention, thoughtlessness and excessive confidence often cause accidents; the same applies to tiredness and sleepiness.

It is a good idea to remember the following:

- The burner must only be used as expressly described. Any other use should be considered improper and therefore dangerous.

Specifically:

it can be applied to boilers operating with water, steam, diathermic oil, and to other uses expressly named by the manufacturer;

the type and pressure of the fuel, the voltage and frequency of the electrical power supply, the minimum and maximum deliveries for which the burner has been regulated, the pressurisation of the combustion chamber, the dimensions of the combustion chamber and the ambient temperature must all be within the values indicated in the instruction manual.

- Modification of the burner to alter its performance and destinations is not allowed.
- The burner must be used in exemplary technical safety conditions. Any disturbances that could compromise safety must be quickly eliminated.
- Opening or tampering with the burner components is not allowed, apart from the parts requiring maintenance.
- Only those parts envisaged by the manufacturer can be replaced.



The manufacturer guarantees safety and proper operation only if all burner components are intact and correctly positioned.

3.2 Personnel training

The user is the person, body or company that has acquired the machine and intends to use it for the specific purpose. He is responsible for the machine and for the training of the people working around it.

The user:

- undertakes to entrust the machine exclusively to suitably trained and qualified personnel;
- undertakes to inform his personnel in a suitable way about the application and observance of the safety instructions. With that aim, the user undertakes to ensure that everyone knows the use and safety instructions for his own duties;
- Personnel must observe all the danger and caution indications shown on the machine.
- Personnel must not carry out, on their own initiative, operations or interventions that are not within their province.
- Personnel must inform their superiors of every problem or dangerous situation that may arise.
- The assembly of parts of other makes, or any modifications, can alter the characteristics of the machine and hence compromise operating safety. The manufacturer therefore declines any and every responsibility for any damage that may be caused by the use of non-original parts.


In addition:



- must take all the measures necessary to prevent unauthorised people gaining access to the machine;
- the user must inform the manufacturer if faults or malfunctioning of the accident prevention systems are noticed, along with any presumed danger situation;
- personnel must always use the personal protective equipment envisaged by legislation and follow the indications given in this manual.

4 Technical description of the burner

4.1 Burner designation



4.2 Models available

| Designation | Voltage | Start-up | Code |
|---------------------|----------|----------|----------|
| RLS 68/M MX TC FS1 | 3/400/50 | Direct | 20205590 |
| RLS 68/M MX TL FS1 | 3/400/50 | Direct | 20205707 |
| RLS 120/M MX TC FS1 | 3/400/50 | Direct | 20205592 |
| RLS 120/M MX TL FS1 | 3/400/50 | Direct | 20208605 |

Tab. A

4.3 Burner categories - Countries of destination

| Country of destination | Gas category |
|--|---|
| SE - FI - AT - GR - DK - ES - GB - IT - IE - PT - IS - CH - NO | I _{2H} |
| DE | I _{2ELL} |
| NL | I _{2L} - I _{2E} - I ₂ (43.46 ÷ 45.3 MJ/m ³ (0°C)) |
| FR | I _{2Er} |
| BE | I _{2E(R)B} |
| LU - PL | I _{2E} |

Tab. B

4.4 Technical data

| Model | | | RLS 68/M MX | RLS 120/M MX |
|----------------------------|------------------------|------------|---|------------------------|
| Output (1) Delivery (1) | 2nd stage min - max | kW kg/h | 350 - 860 30 - 73 | 600 - 1200 50 - 101 |
| | 1st stage min | kW kg/h | 200 17 | 300 25 |
| Fuels | | | Light oil, max. viscosity at 20 °C: 6 mm ² /s (1.5 °E - 6 cSt) Natural gas: G20 (methane gas) - G25 | |
| Operation | | | <ul style="list-style-type: none"> - Intermittent FS1(min. 1 stop in 24 hours) /Continuous FS2 - Oil: two-stage (high and low flame) and one-stage (all - nothing) - Gas: progressive two-stage or modulating by kit (see ACCESSORIES) | |
| Nozzles | | number | 2 | |
| Standard applications | | | Boilers: water, steam, diathermic oil | |
| Ambient temperature | | °C | 0 - 40 | |
| Combustion air temperature | | °C max | 60 | |
| Pump | output (at 20 bar) | kg/h | 220 | |
| | pressure range | bar | 10 - 20 | |
| | fuel temperature | °C max | 60 | |
| Noise levels (2) | Sound pressure | dB(A) | 76 | 79 |
| | Sound power | | 87 | 90 |
| Weight | | kg | 115 | 120 |
| CE | | | CE-0085BP0175 | |

Tab. C

(1) Reference conditions: Ambient temperature 20°C - Gas temperature 15°C - Barometric pressure 1013 mbar - Altitude 0 m a.s.l.

(2) Sound pressure measured in manufacturer's combustion laboratory, with burner operating on test boiler and at maximum output. The sound power is measured using the "Free Field" method, required by EN 15036 standard, and according to an "Accuracy: Category 3" measurement, as described in EN ISO 3746.

4.5 Electrical data

| Model | | RLS 68/M MX | RLS 120/M MX |
|-------------------------------------|---|----------------------------|--------------|
| Main electrical supply | | 3 ~ 230-400V - 50Hz +/-10% | |
| Auxiliary circuit electrical supply | | 1N ~ 230V - 50Hz | |
| Max. absorbed electric power | W | 2900 | 3700 |
| Protection level | | IP 44 | |

Tab. D

4.6 Maximum dimensions

The dimensions of the burner are given in Fig. 1.

Bear in mind that inspection of the combustion head requires the burner to be opened and the rear part turned on the hinge.

The maximum dimensions of the open burner are indicated by the L and R positions.

The I position is reference for the refractory thickness of the boiler door.




Fig. 1

| mm | B | C | D | E | F | G | H | I* - I (1) | L | M | N | P | T - T (1) | U - U (1) |
|--------------|-----|-----|-----|-----|----|-----|-----|------------|-----|-----|-----|-----|-----------|-----------|
| RLS 68/M MX | 214 | 134 | 189 | 430 | 2" | 296 | 555 | 200-335 | 691 | 395 | 221 | 840 | 260-395 | 1161-1300 |
| RLS 120/M MX | 214 | 134 | 189 | 430 | 2" | 338 | 555 | 200-335 | 733 | 395 | 221 | 840 | 260-395 | 1161-1300 |

Tab. E

(*) Blast tube: short-long

4.7 Firing rate

During operation, burner output varies between:

- **Maximum output**
- The **minimum output** must not be lower than the minimum limit of the diagram

RLS 68/M MX = 200 kW

RLS 120/M MX = 300 kW



The firing rate value (Fig. 2) has been obtained considering an ambient temperature of 20 °C, an atmospheric pressure of 1013 mbar (approx. 0 m a.s.l.), and with the combustion head adjusted as shown on page 22.




Fig. 2

4.8 Test boiler

The firing rates were obtained in special test boilers, according to EN 676 standard.

In (Fig. 3) you can see the diameter and length of the test combustion chamber.

Example:

Output 650 kW - diameter 60 cm
length 2 m

MODULATING RATIO

The modulating ratio, obtained in the test boilers, according to standard (EN 676 for gas, EN 267 for light oil), is of

- 3 : 1 (gas);
- 2 : 1 (light oil).

In case of gas operation, it is possible to use the burner with a different modulating ratio according to the application; for further information contact the manufacturer.




Fig. 3

4.9 Commercial boilers

Burners are suitable for operating on both flame inversion boilers (*) as well as on boilers with a combustion chamber with run-off from the bottom (three flue passes) on which the best results for low NO_x emissions are obtained.

The boiler front door maximum thickness must not exceed 250 mm (Fig. 4).

Although combination is guaranteed when boiler has a CE type-approval, preliminary tests are recommended for boilers or furnaces having a combustion chamber size much different than the one specified in the diagram (Fig. 3).

(*) For flame inversion boilers, a kit is available to reduce the CO, if necessary.





Fig. 4

4.10 Burner equipment

| | |
|--|-------|
| Flange for gas train | No. 1 |
| Seal for flange | No. 1 |
| Screws M10x35 to fix the gas flange | No. 4 |
| Thermal flange gasket | No. 1 |
| Screws M12x35 to fix the burner flange to the boiler | No. 4 |
| Flexible hoses | No. 2 |
| Fittings for flexible hoses | No. 2 |
| Seals | No. 2 |
| Instruction | No. 1 |
| Spare parts list | No. 1 |



It is recommended to tighten the screws of the gas flange with a tightening torque of **30 Nm ±10%**.



Tighten the nuts gradually (first to 30%, then to 60% up to 100%) according to the cross pattern shown in the figure.

4.11 Burner description





Fig. 5

- | | |
|---|---|
| <ul style="list-style-type: none"> 1 Flame stability disc 2 Ignition electrodes 3 Combustion head 4 Gas pressure test point and head fixing screw 5 Screws to secure fan to pipe coupling 6 Pump motor 7 Pump 8 Slide bars for opening the burner and inspecting the combustion head 9 Flame control with lockout pilot light and reset button 10 Air damper 11 Air inlet to fan 12 Gas input pipe 13 Air pressure test point 14 Screw for combustion head adjustment 15 Pipe coupling with flange for fixing to the boiler and the gas butterfly valve 16 Maximum gas pressure switch 17 Safety valve | <ul style="list-style-type: none"> 18 Servomotor controlling the gas butterfly valve and the air damper, by means of a variable profile cam mechanism. When the burner is not operating the air damper is fully closed in order to reduce heat dispersion from the boiler due to the flue draught, which draws air from the fan suction inlet. 19 Fan motor 20 Extensions for slide bars 8) 21 1st and 2nd stage valves 22 Flame inspection window |
|---|---|

4.12 Electrical panel description



- 1 Ignition transformer
- 2 A switch for:
automatic-manual-off operation
A button for:
output increase - decrease
- 3 Motor contactor and thermal relay with reset button
- 4 Bracket for application of RWF kit
- 5 Filter to protect against radio disturbance
- 6 Terminal board for electric connection
- 7 Cable grommets for external connections (to be carried out
by the installer)
- 8 Air pressure switch (differential type)
- 9 Flame control base
- 10 Oil - gas switch
- 11 Flame sensor
- 12 Relay
- 13 Relay

NOTE

Burner lockout may occur:

Flame control lockout: if the flame control 9)(Fig. 5) push-button lights up, it indicates that the burner is in lockout. Press the push button to reset.

Fig. 6

4.13 Flame control (LFL...)

Important notes



ATTENTION

To avoid accidents, material or environmental damage, observe the following instructions!

The flame control LFL1... is a safety device! Avoid opening or modifying it, or forcing its operation. Riello S.p.A. cannot assume any responsibility for damage resulting from unauthorised interventions!

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Before modifying the wiring in the LFL1... flame control connection area, fully disconnect the system from the power supply (omnipolar separation).
- Protection against electrocution from the flame control and all connected electric components is obtained with the correct assembly.
- Before any intervention (assembly and installation operations, assistance, etc.), ensure the wiring is in order and that the parameters are correctly set, then make the safety checks.
- Falls and collisions can negatively affect the safety functions. In this case, the flame control must not be operated, even if it displays no evident damage.
- **Do not press the reset button or the remote reset button of the flame control for more than 10 seconds because this will damage the internal relay.**

For safety and reliability, comply with the following instructions:

- Avoid conditions that can favour the development of condensate and humidity. Otherwise, before switching on again, make sure that the entire flame control is perfectly dry!
- Static charges must be avoided since they can damage the flame control's electronic components when touched.

Use

The LFL1... flame control is a control and supervision system of medium and large capacity forced draft burners for intermittent operation (at least one controlled shutdown every 24 hours).

Installation notes

- Check the electrical wiring inside the boiler complies with the national and local safety regulations.
- Do not confuse the powered conductors with the neutral ones.
- Ensure that spliced wires cannot get into contact with neighbouring terminals. Use adequate ferrules.
- Arrange the H.V. ignition cables separately, as far as possible from the flame control and the other cables.
- When wiring the unit, make sure that AC 230 V mains voltage cables are run strictly separate from extra low-voltage cables to avoid risks of electrical shock hazard.




Fig. 7

Electrical wiring of the flame detector

It is important for signal transmission to be almost totally free of any disturbances or loss:

- Always separate the detector cables from the other cables:
 - The capacitive reactance of the line reduces the size of the flame signal.
 - Use a separate cable.
- Respect the allowed cable lengths.
- The ionisation probe is not protected against the risk of electrocution. When connected to the electricity supply, the ionisation probe must be protected against any accidental contact.
- Position the ignition electrode and the ionisation probe so that the ignition spark cannot form an arc on the probe (risk of electric overcharge).

Technical data

| | |
|---------------------------------|---|
| Mains voltage | AC 230 V -15 % / +10 % |
| Mains frequency | 50 / 60 Hz ±6 % |
| Fuse (Internal) | T6.3H250V |
| Primary fuse (external) | max. 10 A |
| Weight | approx. 1 kg |
| Power absorption | approx. AC 3.5 VA |
| Protection level | IP40 |
| Safety class | II |
| Input current at terminal 1 | max. 5 A continuous (peaks of 20 A / 20 ms) |
| Load on the control terminals | max. 4 A continuous (peaks of 20 A / 20 ms) |
| Environmental conditions | |
| Operation | DIN EN 60721-3-1 |
| Climatic conditions | Class 1K3 |
| Mechanical conditions | Class 1M2 |
| Temperature range | -20...+60°C |
| Humidity | < 95% RH |

Tab. F

4.14 Servomotor (SQN31...)

Important notes



To avoid accidents, material or environmental damage, observe the following instructions!

Avoid opening, modifying or forcing the actuators.

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Before modifying the wiring in the connection area of the servomotor, fully disconnect the burner control device from the power supply (omnipolar separation).
- To avoid the risk of electrocution, protect the connection terminals in a suitable manner and correctly fix the cover.
- Check the wiring is in order.
- Falls and collisions can negatively affect the safety functions. In this case, the servomotor must not be operated, even if it displays no evident damage.

Assembly notes

- Check the relevant national safety standards are respected.
- When assembling the servomotor and connecting the damper, the gears can be disengaged by means of a lever, allowing the drive shaft to be easily adjusted in both directions of rotation.



20160309

Fig. 8

Technical data

| | |
|--|--|
| Operating voltage | AC 220...240 V - 15% / +10% AC 100...110 V - 15% / +10% |
| Mains frequency | 50...60 Hz ± 6% |
| Switching capacity of auxiliary devices and limit switches | 10 (3) A, AC 24...250 V |
| Angle positioning | up to 160° (full scale) |
| Assembly position | option |
| Protection level | IP 54, DIN 40050 |
| Safety class | I |
| Weight | approx. 0.8 kg |
| Actuator motor | synchronous motor |
| Power absorption | 6.5 VA |
| Environmental conditions: | |
| Operation | DIN EN 60 721-3-1 |
| Climatic conditions | Class 1K2 |
| Mechanical conditions | Class 1M2 |
| Temperature range | -20...+60°C |
| Humidity | < 95% RH |

Tab. G

4.15 Calibration of the thermal relay

The thermal relay (Fig. 9) serves to avoid damage to the motor due to an excessive absorption increase or if a phase is missing. For calibration 2), refer to the table indicated in the electrical layout (electrical wiring by the installer).

To reset, in case of thermal relay activation, press the "RESET" button 1). The button "STOP" 3) opens the NC contact (95-96) and stops the motor. Insert a screwdriver in the window "TEST/TRIP" 4) and move it in the arrow direction (to the right) to carry out the thermal relay test.




Fig. 9



The automatic reset can be dangerous. This operation is not foreseen in the burner operation.

4.16 Motor rotation

As soon as the burner starts, place yourself in front of the cooling fan of the fan motor and check that it turns anticlockwise (Fig. 10).

If this is not the case:

- put the switch of the burner to "0" (off) and wait until the flame control carries out the switching off phase.



Disconnect the electrical supply from the burner by means of the system main switch.

- Invert the phases on the three-phase motor power supply.




Fig. 10

5.4 Operating position



- The burner is designed to operate only in positions **1**, **2**, **3** and **4** (Fig. 12).
- Installation **1** is preferable, as it is the only one that allows the maintenance operations as described in this manual.
- Installations **2**, **3** and **4** allow operation but make maintenance and inspection of the combustion head more difficult.



- Any other position could compromise the correct operation of the appliance.
- The installation **5** is prohibited for safety reasons.




Fig. 12

5.5 Preparing the boiler

5.5.1 Boring the boiler plate

Pierce the closing plate of the combustion chamber, as in Fig. 13.

The position of the threaded holes can be marked using the thermal insulation screen supplied with the burner.

| mm | A | B | C |
|--------------|-----|-----------|------|
| RLS 68/M MX | 195 | 275 - 325 | M 12 |
| RLS 120/M MX | 195 | 275 - 325 | M 12 |




Fig. 13

5.5.2 Blast tube length

The length of the blast tube must be selected according to the indications provided by the manufacturer of the boiler, and in any case it must be greater than the thickness of the boiler door complete with its fettling.

| RLS 68-120/M MX | A |
|-----------------|-----|
| Standard | 260 |
| Elongated | 395 |

For boilers with front flue passes 15)(Fig. 14 on page 19), or flame inversion chamber, a protection in refractory material 13) must be inserted between the boiler fettling 14) and the blast tube 12).

This protection must not compromise the extraction of the blast tube.

For boilers with a water-cooled front piece, a refractory lining 13)-14)(Fig. 14 on page 19) is not necessary, unless expressly requested by the boiler manufacturer.

5.6 Securing the burner to the boiler

Provide an adequate lifting system.

Separate the combustion head from the rest of the burner,

Fig. 14:

- disconnect the light oil pipes unscrewing the two unions 6).
- Disengage the articulated coupling 7) from the graduated sector 8).
- Loosen the 4 screws 3) and remove the hood 1).
- Remove the screws 2) from the two slide bars 5).
- Remove the two screws 4) and pull the burner back on slide bars 5) by about 100 mm.

- Disconnect the electrode cables, then completely unthread the burner from the slide bars. Fix the pipe coupling with the flange 11)(Fig. 14) to the boiler plate interposing the insulating gasket 9)(Fig. 14) supplied with the equipment. Use the 4 screws, also supplied, after protecting their thread with an anti-locking product.



The seal between burner and boiler must be airtight.




Fig. 14

5.7 Electrode position



Position the ignition electrode according to the dimensions shown in Fig. 15.




Fig. 15

5.8 Choice of nozzles for the 1st and 2nd stage

Both nozzles must be chosen from among those listed in Tab. H.

The first nozzle determines the delivery of the burner at the 1st stage.

The second nozzle works together with the 1st nozzle to determine the delivery of the burner in the 2nd stage.

The outputs of the 1st and 2nd stage have to be within the value range indicated in Tab. C.

Use nozzles with a 60° spray angle at the recommended pressure of 12 bar.

Generally the two nozzles have the same flow rate but the nozzle of the 1st stage can have an output that is 50% lower than the total output, when you want to reduce the back pressure peak on ignition (the burner provides good combustion values also with 40 - 100% ratios between the 1st and 2nd stage).

Example:

Boiler power = 900 kW - efficiency 90%

Burner requested output = 900: 0.9=1000 kW;

1000: 2=500 kW per nozzle

so two equal nozzles of 60°, 12 bar are required:

➤ 1° = 10 GPH

➤ 2° = 10 GPH

or the following two different nozzles:

➤ 1° = 12 GPH

➤ 2° = 8 GPH

| GPH | kg/h | | | kW 12 bar |
|------|--------|--------|--------|--------------|
| | 10 bar | 12 bar | 14 bar | |
| 5.00 | 19.2 | 21.2 | 23.1 | 251.4 |
| 5.50 | 21.1 | 23.3 | 25.4 | 276.3 |
| 6.00 | 23.1 | 25.5 | 27.7 | 302.4 |
| 6.50 | 25.0 | 27.6 | 30.0 | 327.3 |
| 7.00 | 26.9 | 29.7 | 32.3 | 352.3 |
| 7.50 | 28.8 | 31.8 | 34.6 | 377.2 |
| 8.00 | 30.8 | 33.9 | 36.9 | 402.1 |
| 8.30 | 31.9 | 35.2 | 38.3 | 417.5 |
| 8.50 | 32.7 | 36.1 | 39.2 | 428.2 |
| 9.00 | 34.6 | 38.2 | 41.5 | 453.1 |
| 9.50 | 36.5 | 40.3 | 43.8 | 478.0 |
| 10.0 | 38.4 | 42.4 | 46.1 | 502.9 |
| 10.5 | 40.4 | 44.6 | 48.4 | 529.0 |
| 11.0 | 42.3 | 46.7 | 50.7 | 553.9 |
| 12.0 | 46.1 | 50.9 | 55.3 | 603.7 |
| 12.3 | 47.3 | 52.2 | 56.7 | 619.1 |
| 13.0 | 50.0 | 55.1 | 59.9 | 653.5 |
| 13.8 | 53.1 | 58.5 | 63.3 | 693.8 |
| 14.0 | 53.8 | 59.4 | 64.5 | 704.5 |
| 15.0 | 57.7 | 63.6 | 69.2 | 754.3 |
| 15.3 | 58.8 | 64.9 | 70.5 | 769.7 |
| 16.0 | 61.5 | 67.9 | 73.8 | 805.3 |
| 17.0 | 65.4 | 72.1 | 78.4 | 855.1 |
| 17.5 | 67.3 | 74.2 | 80.7 | 880.0 |
| 18.0 | 69.2 | 76.4 | 83.0 | 906.1 |
| 19.0 | 73.0 | 80.6 | 87.6 | 956.0 |
| 19.5 | 75.0 | 82.7 | 89.9 | 980.9 |
| 20.0 | 76.9 | 84.8 | 92.2 | 1005.8 |
| 21.5 | 82.7 | 91.2 | 99.1 | 1081.7 |
| 22.0 | 84.6 | 93.3 | 101.4 | 1106.6 |
| 22.5 | 86.5 | 95.5 | 103.7 | 1132.6 |
| 23.0 | 88.4 | 97.6 | 106.0 | 1157.5 |
| 23.5 | 90.4 | 99.7 | 108.3 | 1182.4 |
| 24.0 | 92.2 | 101.8 | 110.6 | 1207.3 |

Tab. H

5.9 Nozzle installation

The burner complies with the emission requirements of the EN 267 standard. In order to guarantee that emissions do not vary, recommended and/or alternative nozzles specified by Riello in the Instruction and warning booklet should be used.



It is advisable to replace the nozzle once a year during periodical maintenance.



The use of nozzles other than those specified by Riello S.p.A. and inadequate regular maintenance may result into emission limits non-conforming to the values set forth by the regulations in force, and in extremely serious cases, into potential hazards to people and objects.

The manufacturing Company shall not be liable for any such damage arising from non-observance of the requirements contained in this manual.

Remove the screw 1)(Fig. 16) and extract the internal part 2)(Fig. 16). Assemble the two nozzles with the socket spanner 1)(Fig. 17) (16 mm), after removing the plastic plugs 2)(Fig. 17), passing through the central opening of the flame stability disc. Alternatively, loosen the screws 1)(Fig. 18), remove the disc 2)(Fig. 18), and replace the nozzles using the spanner 3)(Fig. 18).




Fig. 16

Do not use any sealing products such as: gaskets, tape or sealants. Be careful to avoid damaging the nozzle sealing seat. The nozzle must be screwed into place tightly but not to the maximum torque value provided by the wrench.

The nozzle for the 1st stage of operation is the one beneath the ignition electrodes, Fig. 15.

Check that the electrodes are placed as in Fig. 15.

Reassemble the burner on the guides 3)(Fig. 19) at about 100 mm from the pipe coupling 4)(Fig. 19); see in the position shown in Fig. 14.

Insert the electrode cables and then slide the burner up to the pipe coupling, the burner in the position indicated in Fig. 19.

Refit screws 2) on slide bars 3)(Fig. 19).

Fix the burner to the pipe coupling with screws 1)(Fig. 19).

Reconnect the light oil pipes by screwing the two fittings 6)(Fig. 14). Reconnect the articulated coupling 7) to the graduated sector 5)(Fig. 19).



- Do not use any sealing products such as: gaskets, tape or sealants.
- Be careful to avoid damaging the nozzle sealing seat.
- The nozzle must be screwed into place tightly but not to the maximum torque value provided by the wrench.
- On closing the burner on the two guides it is advisable to gently pull the high voltage wires outwards until they are under slight tension.




Fig. 17




Fig. 18




Fig. 19

5.10 Combustion head adjustment

The adjustment of the combustion head depends only on the maximum output of the burner.

Turn the screw 5)(Fig. 20) until the notch indicated in diagram (Fig. 21) corresponds with the front part of the flange 6)(Fig. 20).



ATTENTION

To facilitate the adjustment, loosen the screw 1)(Fig. 16), adjust, then block.

Example: Burner RLS 68/M MX

Burner maximum output = 650 kW.

The diagram (Fig. 21) shows that for this output, the adjustment of the combustion head is carried out on notch 2.




Fig. 20




Fig. 21

5.11 Light oil supply



Explosion danger due to fuel leaks in the presence of a flammable source.

Precautions: avoid knocking, attrition, sparks and heat.

Make sure the fuel shut-off valve is closed before performing any operation on the burner.



ATTENTION

The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.

5.11.1 Double-pipe circuit

The burner is equipped with a self-priming pump which is capable of supplying itself within the limits listed in the Tab. I.

Tank higher than burner A (Fig. 22)

Distance P must not exceed 10 meters in order to avoid straining the pump's seal; distance V must not exceed 4 meters in order to allow the self-priming of the pump even when the tank is almost empty.

Tank lower than burner B (Fig. 22)

The pump depression value must not exceed 0.45 bar (35 cm Hg). Because at higher levels gas is released from the fuel; the pump becomes noisy and its lifetime is shortened. It is good practice to ensure that the return and suction lines enter the burner from the same height; the suction line is more difficult to disconnect.

5.11.2 Loop circuit

The loop circuit is composed of a duct starting from the tank and going back to it, in which an auxiliary pump makes the pressurised fuel flow.

A branch from the loop supplies the burner.

This circuit is extremely useful whenever the burner pump does not succeed in self-priming because the tank distance and/or height difference are higher than the values listed in Tab. I.

| H (m) | L (m) | | |
|-------|--------|-----|-----|
| | Ø (mm) | | |
| | 12 | 14 | 16 |
| 4 | 71 | 138 | 150 |
| 3 | 62 | 122 | 150 |
| 2 | 53 | 106 | 150 |
| 1 | 44 | 90 | 150 |
| 0.5 | 40 | 82 | 150 |
| 0 | 36 | 74 | 137 |
| -0.5 | 32 | 66 | 123 |
| -1 | 28 | 58 | 109 |
| -2 | 19 | 42 | 81 |
| -3 | 10 | 26 | 53 |
| -4 | - | 10 | 25 |

Tab. I




Fig. 22

Key (Fig. 22)

- H = Pump/Foot valve height difference
- L = Piping length
- Ø = Inside pipe diameter
- 1 = Burner
- 2 = Pump
- 3 = Filter
- 4 = Manual on/off valve
- 5 = Suction line

- 6 = Foot valve
- 7 = Quick closing manual valve with remote control (Italy only)
- 8 = On/off solenoid valve (Italy only). See electrical diagram. Connections to be carried out by the installer (SV).
- 9 = Return line
- 10 = Check valve (Italy only)

5.11.3 Hydraulic connections

The pumps are equipped with a by-pass that connects return line with suction line.

They are installed on the burner with the by-pass closed by screw 6)(Fig. 24).

It is therefore necessary to connect both hoses to the pump.

The pump will break down immediately if it is run with the return line closed and the by-pass screw inserted.

Remove plugs from suction and return connectors of the pump.

Insert the hose connections with the supplied seals into the connections and screw them down.

During the installation, hoses must not be stressed with twisting.

Position hoses so that they cannot be stepped on or get into contact with hot parts of the boiler and so that they allow burner opening.

Connect, finally, the other end of the flexible hoses to the suction and return lines using nipples supplied with the equipment.




Fig. 23

5.11.4 Hydraulic circuit diagram




Fig. 24

Key (Fig. 24)

- 1 Pump suction line
- 2 Filter
- 3 Pump
- 4 Pump pressure regulator
- 5 Return pipe
- 6 Bypass screw
- 7 Pump return line
- 8 Safety valve
- 9 1st stage valve
- 10 2nd stage valve
- 11 Filter
- M Pressure gauge
- V Vacuumometer connection

5.11.5 Operation

- **Pre-purging phase:** valves 5), 6), 13) and 14) closed.
- **Ignition and operation phase:** valves 5), 6), 13) and 14) open.
- **Stop:** all valves closed.

5.11.6 Pump

Technical data

PUMP AJ6 CC

| | |
|---------------------------------------|--------------|
| Min. delivery rate at 12 bar pressure | 220 kg/h |
| Delivery pressure range | 10 - 20 bar |
| Max. suction depression | 0.45 bar |
| Viscosity range | 2.8 - 75 cSt |
| Max. light oil temperature | 60 °C |
| Max. suction and return pressure | 2 bar |
| Pressure calibration in the factory | 12 bar |
| Filter mesh width | 0.150 mm |

Tab. J




Fig. 25

Key (Fig. 25)

- 1 Suction line G 1/4"
- 1 Return line G 1/4"
- 1 Pressure switch connection G 1/8"
- 1 Vacuumeter connection G 1/8"
- 1 Pressure adjuster
- 1 By-pass screw

5.11.7 Pump adjustment

No adjustment of gas delivery is required.

The pump leaves the factory set at 12 bar, a pressure to be checked and eventually modified after the burner has been started. In this phase, therefore, limit to apply a pressure gauge on the specific pump connector.

It may be necessary to adjust the pump to:

10 bar in order to reduce fuel delivery.

It is possible only if the ambient temperature remains above 0 °C;

14 bar in order to increase fuel delivery or to ensure firings even at temperatures of less than 0 °C.

5.11.8 Priming pump



Before starting the burner, make sure that the tank return line is not clogged.

Obstructions in the line could cause the sealing organ located on the pump shaft to break. (The pump leaves the factory with the by-pass closed).

- Make sure that the valves on the suction line are open and that there is fuel in the tank.
- In order for self-priming to take place the screw 3) (Fig. 25) of the pump (Fig. 25) must be loosened in order to bleed off the air contained in the suction line.
- Start the burner by closing the control devices, with the switch 1)(Fig. 26) in "MAN" position and switch 10)(Fig. 6) in "OIL" position.
- The pump can be considered primed when the light oil starts coming out of the screw 3)(Fig. 25). Stop the burner: set switch 1)(Fig. 26) to "OFF" and tighten the screw 3)(Fig. 25).
- The time required for this operation depends upon the diameter and length of the suction tubing. If the pump fails to prime at the first starting of the burner and the burner locks out, wait approx. 15 seconds, reset the burner, and then repeat the starting operation as often as required. And so on.
After 5 or 6 starting operations allow 2 or 3 minutes for the transformer to cool.
- Do not light the UV cell in order to prevent the burner lockout; the burner locks out in any case about ten second after its start.



The above-mentioned operation is possible because the pump is already full of fuel when it leaves the factory.

If the pump has been drained, fill it with fuel through the opening on the vacuum meter prior to starting; otherwise, the pump will seize.

Whenever the length of the suction piping exceeds 20-30 meters, the supply line must be filled using a separate pump.




Fig. 26

5.12 Gas supply



Explosion danger due to fuel leaks in the presence of a flammable source.
 Precautions: avoid knocking, attrition, sparks and heat.
 Make sure the fuel shut-off valve is closed before performing any operation on the burner.



The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.

5.12.1 Gas feeding line (Example) - Please refer to the gas train documentation for more information




Fig. 27

Key (Fig. 27)

- 1 Manually operated shut-off valve
- 2 Pressure gauge
- 3 Filter
- 4 Governor
- 5a Low pressure protection device
- 5b Maximum gas pressure switch
- 6 1st safety shut-off device
- 7 2nd safety shut-off device
- 8 Ignition device
- 15 Valve leak detection control system
- L Gas train (supplied separately)
- L1 Responsibility of the installer
- L2 Burner
- M1 Pressure test point
- M2 Pressure test point
- M3 Pressure test point

5.12.2 Gas train

Type-approved in accordance with EN 676 and supplied separately from the burner.

5.12.3 Gas train installation



Disconnect the power supply using the system main switch.



Check that there are no gas leaks.



Pay attention when handling the train: danger of crushing of limbs.



Make sure that the gas train is properly installed by checking for any fuel leaks.



The operator must use the required equipment during installation.

- The gas train must be connected to the gas connection 1) (Fig. 28), using the flange 2), the gasket 3) and the screws 4) supplied with the burner.
- The train can enter the burner from the right or left side, depending on which is the most convenient, see Fig. 28.
- The gas solenoids must be as close as possible to the burner to ensure that the gas reaches the combustion head within the safety time of 3s.
- Make sure that the pressure governor calibration range (colour of the spring) includes the pressure required by the burner.




Fig. 28

5.12.4 Gas pressure

Tab. K indicates the pressure drops of the combustion head and gas butterfly valve depending on the burner operating output.

| | kW | (mbar) | | |
|--------------|------|--------|------|------|
| | | G 20 | G 25 | G 31 |
| RLS 68/M MX | 350 | 2.9 | 4.3 | 3.7 |
| | 407 | 3.8 | 5.7 | 5.0 |
| | 463 | 4.8 | 7.2 | 6.3 |
| | 520 | 5.9 | 8.8 | 7.6 |
| | 577 | 7.0 | 10.4 | 9.0 |
| | 633 | 8.1 | 12.1 | 10.5 |
| | 690 | 9.2 | 13.8 | 12.0 |
| | 747 | 10.5 | 15.6 | 13.6 |
| | 803 | 11.7 | 17.4 | 15.2 |
| RLS 120/M MX | 860 | 13.0 | 19.4 | 16.9 |
| | 600 | 4.9 | 7.3 | 6.4 |
| | 667 | 6.6 | 9.9 | 8.6 |
| | 733 | 8.3 | 12.4 | 10.8 |
| | 800 | 10.0 | 15.0 | 13.0 |
| | 867 | 11.7 | 17.6 | 15.3 |
| | 933 | 13.5 | 20.1 | 17.5 |
| | 1000 | 15.2 | 22.7 | 19.8 |
| | 1067 | 17.0 | 25.4 | 22.2 |
| | 1133 | 18.7 | 28.0 | 24.5 |
| | 1200 | 20.5 | 30.6 | 26.8 |

Tab. K



Data of head thermal power and gas pressure refer to operation with gas butterfly valve fully open (90°).

The values shown in Tab. K refer to:

- Natural gas G 20 NCV 9.45 kWh/Sm³ (8.2 Mcal/Sm³)
- Natural gas G 25 NCV 8.13 kWh/Sm³ (7.0 Mcal/Sm³)

The adjacent table shows the minimum pressure drops along the gas supply line depending on the maximum burner output.

Combustion head pressure drop.

Gas pressure measured at test point 1)(Fig. 29), with:

- combustion chamber at 0 mbar;
- combustion head adjusted as in the diagram Fig. 21.

Calculate the approximate maximum output of the burner in this way:

Subtract the combustion chamber pressure from the gas pressure measured at test point 1)(Fig. 29).

Find in Tab. K the pressure value closest to the result of the subtraction.

Read the corresponding output on the left.

Example with natural gas G20 - RLS 68/M MX:
Operation at maximum modulating output: 860 kW

$$\begin{aligned} \text{Gas pressure at test point 1)(Fig. 29)} &= 16.0 \text{ mbar} \\ \text{Pressure in combustion chamber} &= 3.0 \text{ mbar} \\ 16.0 - 3.0 &= 13.0 \text{ mbar} \end{aligned}$$

A pressure of 13.0 mbar corresponds in Tab. K to an output of 860 kW.

This value serves as a rough guide; the effective output must be measured at the gas meter.

To calculate the required gas pressure at test point 1) (Fig. 29), set the maximum output required from the burner operation:

Find in Tab. K the output value closest to the desired value.

Read, on the right, the pressure at test point 1)(Fig. 29).

Add this value to the estimated pressure in combustion chamber.

Example with natural gas G20 - RLS 68/M MX:

Operation at maximum modulating output: 860 kW

Gas pressure at test point 1)(Fig. 29) = 13.0 mbar

Pressure in combustion chamber = 3.0 mbar

$13.0 + 3.0 = 16.0$ mbar




Fig. 29

5.13 Electrical connections

Notes on safety for the electrical wiring



- The electrical wiring must be carried out with the electrical supply disconnected.
- Electrical wiring must be made in accordance with the regulations currently in force in the country of destination and by qualified personnel. Refer to the wiring diagrams.
- The manufacturer declines all responsibility for modifications or connections different from those shown in the wiring diagrams.
- Check that the electrical supply of the burner corresponds to that shown on the identification label and in this manual.
- The burner has been type-approved for intermittent use.
This means they should compulsorily be stopped at least once every 24 hours to enable the flame control to perform checks of its own start-up efficiency. Normally, burner stopping is guaranteed by the boiler's thermostat/pressure switch.
- If this is not the case, a time switch should be fitted in series to TL to stop the burner at least once every 24 hours. Refer to the wiring diagrams.
- The electrical safety of the device is obtained only when it is correctly connected to an efficient earthing system, made according to current standards. It is necessary to check this fundamental safety requirement. In the event of doubt, have the electrical system checked by qualified personnel. Do not use the gas tubes as an earthing system for electrical devices.
- The electrical system must be suitable for the maximum power absorption of the device, as indicated on the label and in the manual, checking in particular that the section of the cables is suitable for that level of power absorption.
- For the main power supply of the device from the electricity mains:
 - do not use adapters, multiple sockets or extensions;
 - make provisions for an omnipolar switch with a gap between the contacts of at least 3 mm (over-voltage category III), as required by current safety regulations.
- Do not touch the device with wet or damp body parts and/or in bare feet.
- Do not pull the electric cables.

Before carrying out any maintenance, cleaning or checking operations:



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.




Avoid condensate, ice and water leaks from forming.

If the cover is still present, remove it and proceed with the electrical wiring according to the wiring diagrams.

Use flexible cables according to EN 60 335-1 standard.

5.13.1 Supply cables and external connections passage

All the cables to be connected to the burner terminal board 6)(Fig. 30) must be threaded through cable grommets, as shown in Fig. 30.



20160037

Fig. 30

Key (Fig. 30)

- 1 Pg 13.5 Three-phase power supply
- 2 Pg 13.5 Single-phase power supply
- 3 Pg 16 Enabling signals/Adjustments
- 4 Pg 13.5 Gas pressure switch or valve leak detection control device
- 5 Drill if you wish to add a union



After carrying out maintenance, cleaning or checking operations, reassemble the cover and all the safety and protection devices of the burner.

6 Start-up, calibration and operation of the burner

6.1 Notes on safety for the first start-up



The first start-up of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



Check the correct working of the adjustment, command and safety devices.



Before starting up the burner, refer to section “Safety test - with no gas supply” on page 39.

6.2 Servomotor adjustment

The servomotor provides simultaneous adjustment for the air damper, by means of the adjustable profile cam and the gas butterfly valve.

The servomotor rotates by 130° in 42 s.

Do not alter the factory setting for the 5 cams; just check that they are as specified below:

- Cam I : 130°**
Limits rotation toward maximum position.
When the burner is operating at MAX output, the gas butterfly valve must be fully open: 90°.
- Cam II : 0°**
Limits rotation toward minimum position.
When the burner is shut down, the air damper and gas butterfly valve must be closed: 0°.
- Cam III : 30° (gas)**
Adjusts the ignition position and the MIN output.
- Cam IV : 30° (oil)**
Adjusts the ignition position and the output of the 1st stage.
- Cam V : 90°** Determines when the 2nd stage light oil valve opens.




Fig. 31

6.3 Adjustments prior to ignition (light oil)



It is recommended to adjust first the light oil burner and then the gas burner.
Carry out the fuel change with burner off.

The optimum calibration of the burner requires an analysis of the flue gases at the boiler outlet and interventions on the following points.

1st and 2nd stage nozzles

See information on page 20.

Combustion head

The adjustment of the combustion head already carried out needs not to be altered unless the 2nd stage output of the burner is changed.

Pump pressure

12 bar: this is the factory-calibrated pressure, which is usually enough for most applications.

Sometimes, this pressure must be adjusted to:

10 bar: in order to reduce fuel delivery.
This adjustment is possible only if the surrounding ambient temperature remains above 0 C.

14 bar: To increase fuel flow rate or ensure the ignition also at temperatures lower than 0°C. To adjust pump pressure use screw 5)(Fig. 20 on page 22).

1st and 2nd stage fan damper valve

See “Servomotor adjustment” on page 30.

6.4 Burner start-up (light oil)

Feed electricity to the burner via the disconnecting switch on the boiler panel.

Close the thermostats/pressure switches and turn the switch in Fig. 32 to position "MAN".

As soon as burner starts, check the fan rotation direction through the flame inspection window.



Check that the lamps or testers connected to the solenoid valves, or the pilot lights on the solenoid valves, indicate that no voltage is present. If they indicate the presence of voltage, stop the burner **immediately** and check the electric connections.




Fig. 32

6.5 Burner ignition (light oil)

Turn switch 1)(Fig. 32) to "MAN" position.

During the first firing, during the passage from the 1st to the 2nd stage, there is a momentary lowering of the fuel pressure caused by the filling of the 2nd stage nozzle.

This lowering of the fuel pressure can cause the burner to lockout and can sometimes give rise to pulsations.

Once the following adjustments have been made, the firing of the burner must generate a noise similar to the noise generated during operation.

6.6 Burner adjustment (light oil)

It is recommended to adjust first the light oil burner and then the gas burner.



Carry out the fuel change with burner off.

6.6.1 Ignition

Put the switch 1)(Fig. 26) on "MAN".

During the first firing, during the passage from the 1st to the 2nd stage, there is a momentary lowering of the fuel pressure caused by the filling of the 2nd nozzle tubing. This lowering of the fuel pressure can cause the burner to lockout and can sometimes give rise to pulsations. When first ignited, the burner should make a noise to show it is operating.

6.6.2 Operation

The optimum calibration of the burner requires an analysis of the flue gases at the boiler outlet and interventions on the following points.

- **1st and 2nd stage nozzles**
See information on page 20.
- **Combustion head**
The adjustment of the head that has already been carried out as on page 22 does not require any modifications unless the burner output in the 2nd stage is changed.
- **Pump pressure:**
In order to change pump pressure, act on screw 5) (Fig. 25).
See information on page 25.
- **1st and 2nd stage fan damper**
See servomotor adjustment on page 30.

6.7 Adjustments prior to ignition (gas)

Combustion head adjustment is already described on page 22.

In addition, the following adjustments must also be made:

- Slowly open the manual valves situated upstream of the gas train.
- Adjust the minimum gas pressure switch to the start of the scale.
- Adjust the maximum gas pressure switch to the end of the scale.
- Adjust the air pressure switch to the start of the scale.
- Purge the air from the gas line.
We recommend using a plastic tube routed outside the building and to purge air until gas is smelt.
- Fit a U-type pressure gauge or a differential pressure gauge (Fig. 33), with socket (+) on the gas pressure of the pipe coupling and (-) in the combustion chamber.

The manometer readings are used to calculate MAX burner output using the Tab. K.

- Connect two lamps or testers to the two gas line solenoid valves to check the exact moment in which voltage is supplied.
This operation is not required if each of the two solenoid valves is equipped with a pilot light that signals voltage passing through.



Before starting up the burner, it is good practice to adjust the gas train so that ignition takes place in conditions of maximum safety, i.e. with gas delivery at the minimum.




Fig. 33

6.8 Burner start-up (gas)

Turn off the remote controls and set the switch 1)(Fig. 32) to "MAN".

As soon as the burner starts, check the direction of rotation of the fan impeller, looking through the flame inspection window 22) (Fig. 5).

Check that the lamps or testers connected to the solenoid valves, or the pilot lights on the solenoid valves, indicate that no voltage is present.

If they indicate the presence of voltage, stop the burner immediately and check the electric connections.

6.9 Burner ignition (gas)

It is recommended to adjust first the light oil burner and then the gas burner.

Once ignition has taken place, proceed with burner global calibration operations.



Carry out the fuel change with burner off.

Having completed the checks indicated in the previous heading, ignition of the burner should be achieved.

If the motor starts but the flame does not appear and the flame control goes into lockout, reset and wait for a new ignition attempt.

If ignition is still not achieved, it may be that gas is not reaching the combustion head within the safety time period of 3 seconds. In this case, increase gas ignition delivery.

The arrival of gas to the sleeve is indicated by the U-type pressure gauge (Fig. 33).

6.10 Burner adjustment (gas)

The optimum adjustment of the burner requires an analysis of flue gases at the boiler outlet.

Adjust in sequence:

- 1 Ignition output
- 2 Maximum output
- 3 Minimum output
- 4 Intermediate outputs between the two
- 5 Air pressure switch
- 6 Maximum gas pressure switch
- 7 Minimum gas pressure switch

6.10.1 Ignition output



ATTENTION

For safety purposes and correct product operation, the ignition output, if it is adjustable, must be carried out by authorized personnel and in compliance with the standards and regulations of the laws in force.

Air adjustment

The air is adjusted by changing the angle of cam III) (Fig. 31 on page 30) and by using the selector 2)(Fig. 32).

To adjust the cam of the servomotor, see Fig. 31.

6.10.2 Maximum output

The MAX output must be set within the firing rate indicated in Fig. 2 on page 10.

In the above instructions we left the burner running at the MIN output.

Now press the "increase output" button 2)(Fig. 32), and keep it pressed until the servomotor has opened the air damper and the gas butterfly valve.

Adjustment of gas delivery

Measure the gas delivery on the meter.

A rough indication can be obtained from Tab. K on page 27, just read the gas pressure on the "U" pressure gauge (see Fig. 33 on page 32) and follow the indications.

- If delivery needs to be reduced, diminish outlet gas pressure; if it is already very low, slightly close the VR adjustment valve.
- If delivery needs to be increased, increase the adjuster outlet gas pressure.

Air adjustment

The air is adjusted by varying the angle of cam I) (Fig. 31 on page 30) and by using the selector 2)(Fig. 32 on page 31).

To adjust the cam of the servomotor, see Fig. 31.

6.10.3 Minimum output

MIN output must be selected within the firing rate range indicated on Fig. 2 on page 10. Press button 2)(Fig. 35) "Output decrease" and keep it pressed until the servomotor reaches (Fig. 35) the factory adjustment.

Air adjustment

Progressively adjust the end profile of the mechanical cam 4) (Fig. 34), using the screws 5)(Fig. 34).




Fig. 34

Key (Fig. 34)

- 1 Servomotor
- 2 Servomotor 1) - cam 4): fastened
- 3 Servomotor 1) - cam 4): unfastened
- 4 Variable profile cam
- 5 Screws for adjusting the adjustable profile
- 6 Screws for fixing adjustment
- 7 Screws for adjusting the end profile
- 8 Gas butterfly valve graduated sector
- 9 Index of graduated sector 8




Fig. 35

For example, calibrate the minimum output to 800 kW, check the emissions and if necessary increase or decrease the opening of the air damper ("Air adjustment" on page 34).

Bring the output to 800 kW using the screws 5) of the mechanical cam (Fig. 34) and check the emissions.

Adjustment of gas delivery

The air is adjusted by changing the angle of cam III) of the servomotor (Fig. 35) and by using the selector 2)(Fig. 35). To adjust the cam of the servomotor, see Fig. 35.

NOTE:

The servomotor follows the adjustment of cam III only when the angle of the cam is reduced.

If it is necessary to increase the angle of the cam, you must first increase the angle of the servomotor by means of the "output increase" key, then increase the angle of cam III, and finally bring the servomotor to the position of MIN output, with the "Output reduction" key.

To adjust cam III, see Fig. 35.

6.10.4 Intermediate outputs

Adjustment of gas delivery

No adjustment is required

Air adjustment

After adjusting the maximum and minimum output of the burner, carry out air adjustment on higher intermediate positions of the servomotor.

The passage from one position to the next one is obtained by pressing the button 2) on the symbol (+) or (-) (Fig. 32). Press button 2)(Fig. 32) "Output increase" briefly so that the servomotor rotates by about 20°, see servomotor graduated index Fig. 35 and air damper graduated index 5) (Fig. 34 on page 33).

Screw or unscrew the screw 5) of the mechanical cam (Fig. 34 on page 33) to increase or decrease the gas output so as to adjust it to the corresponding air output, to obtain optimal combustion.

6.11 Change of fuel

There are two change of fuel options:

- 1 with selector 10)(Fig. 6 on page 13);
- 2 with a remote selector connected to the main terminal board. Positioning the selector 10)(Fig. 6 on page 13) to "EXT" activates the remote selection of the fuel.



ATTENTION

Change the fuel only when the burner is off.

Proceed in the same way with the other screws.



ATTENTION

Take care that the cam profile variation is progressive.

Switch off the burner using switch 1)(Fig. 32), OFF position, release the mechanical cam I)(Fig. 34) to separate the gears of the servomotor, pressing and moving downwards button 3)(Fig. 35), then manually rotate the mechanical cam I)(Fig. 35) backwards and forwards a few times to check that the movement is smooth and without any hindrance.



ATTENTION

It is recommended that the mechanical cam 5)(Fig. 34) be bound again to the servomotor by shifting button 3)(Fig. 35) upwards.

As far as is possible, try not to move those screws at the ends of the mechanical cam that were previously adjusted for the opening of the gas butterfly valve to MAX and MIN output.

NOTE:

Once "MAX - MIN - INTERMEDIATE" outputs have been adjusted, recheck the ignition: its noise must be equal to the one of the following operation.

If you notice any sign of pulsations, reduce the ignition stage delivery.

6.12 Pressure switch adjustment

6.12.1 Air pressure switch

Adjust the air pressure switch after performing all other burner adjustments with the air pressure switch set to the start of the scale (Fig. 36).

With the burner operating at MIN output, increase adjustment pressure by slowly turning the relevant knob clockwise until the burner locks out.

Then turn the knob anticlockwise by about 20% of the set point and repeat burner start-up to ensure it is correct.

If the burner locks out again, turn the knob slightly anticlockwise.



ATTENTION

In conformity with the standard, the air pressure switch must prevent the air pressure falling below 80% of the adjusted value and the CO in the flue gases exceeding 1% (10,000 ppm).

To check this, insert a combustion analyser in the flue, slowly reduce the burner air setting (for example with a piece of cardboard) and verify that the burner locks out before the CO value in the flue gases exceeds 1%.

The incorporated air pressure switch can work in a 'differential' mode if connected with two pipes.

If a strong depression in the combustion chamber during the pre-purging phase does not allow the air pressure switch to switch, this can be obtained by applying a second tube between the air pressure switch and the suction inlet of the fan. In this way, the pressure switch will work in differential mode.



ATTENTION

The use of the air pressure switch with differential operation is only allowed in industrial applications and where standards enable the air pressure switch to control only fan operation, without any reference to CO limit.



ATTENTION

Connecting the air pressure switch in differential mode, the burner will no longer be certified according to the EN 676 standard.

6.12.2 Maximum gas pressure switch

Adjust the maximum gas pressure switch (Fig. 37) after making all other burner adjustments with the maximum gas pressure switch set to the end of the scale.

To calibrate the maximum gas pressure switch, open the tap and then connect a pressure gauge to its pressure test point.

The maximum gas pressure switch must be regulated to a value no higher than 30% of the measurement read on the gauge when the burner is working at maximum output.

After making the adjustment, remove the pressure gauge and close the tap.




Fig. 36




Fig. 37

6.12.3 Minimum gas pressure switch

The purpose of the minimum gas pressure switch is to prevent the burner from operating in an unsuitable way due to too low gas pressure.

Adjust the minimum gas pressure switch (Fig. 38) after having adjusted the burner, the gas valves and the gas train stabiliser.

With the burner operating at maximum output:

- install a pressure gauge downstream of the gas train stabiliser (for example at the gas pressure test point on the burner combustion head);
- choke slowly the manual gas cock until the pressure gauge detects a decrease in the pressure read of about 0.1 kPa (1 mbar). In this phase, verify the CO value which must always be less than 100 mg/kWh (93 ppm).
- Increase the adjustment of the gas pressure switch until it intervenes, causing the burner shutdown;
- remove the pressure gauge and close the cock of the gas pressure test point used for the measurement;
- open completely the manual gas cock.




Fig. 38



ATTENTION

1 kPa = 10 mbar

6.13 Operation sequence of the burner (gas)

6.13.1 Burner start-up

- 0s: Control remote control TL closes.
Fan motor start-up.
- 6s: Servomotor start-up: turn to the right by 130°, i.e. until the contact intervenes on cam I (Fig. 31 on page 30). The air damper is positioned to MAX output.
- 48s: Pre-purging stage with MAX output air delivery. Duration 32 s.
- 80s: The servomotor turns to the left to reach the angle set on cam III (Fig. 31 on page 30) for the MIN output.
- 112s: The air damper and the gas butterfly valve reach the MIN output position (with cam III) (Fig. 31 on page 30) at 30°.
- 113s: Ignition electrode strikes a spark.
- 119s: The safety valve VS and the adjustment valve VR open (quick opening). The flame ignites with a small output - point A.
The output gradually increases, and the VR valve slowly opens, until the MIN output is reached - point B.
- 122s: The spark goes out.
- 135s: The start-up cycle ends.




Fig. 39

6.13.2 Steady state operation

Burner without output regulator RWF

At the end of the start-up cycle, the servomotor control switches to TR remote control that controls the pressure or temperature in the boiler, point C. (The flame control carries on checking the presence of the flame and the correct position of the air and gas maximum pressure switches).

- If the temperature or pressure is low (so the TR remote control is closed), the burner progressively increases the output up to the MAX value (section C-D).
- If the temperature or pressure then increases until the TR opens, the burner progressively decreases its output to the MIN value (section E-F). And so on.
- The burner locks out when the heat request is less than the heat supplied by the burner at MIN output, (section G-H). The TL remote control opens, the servomotor returns to angle 0° limited by the contact of cam II (Fig. 31 on page 30). The air damper closes completely to reduce heat losses to a minimum.

With each change of output, the servomotor automatically modifies the gas output (butterfly valve) and the air flow rate (fan damper).

Burner with output regulator RWF

See the manual supplied with the regulator.

6.13.3 Ignition failure

If the burner does not ignite, it locks out within 3s after the gas valve opens, and the post-purging phase starts lasting 17s, i.e. 122s from TL closure.

Burner flame goes out during operation

If the flame goes out during operation, the burner will lock out within 1s.











Fig. 40

6.14 Final checks (with burner operating)

| | | |
|---|---|---|
| <ul style="list-style-type: none"> ➤ Open the thermostat/pressure switch TL ➤ Open the thermostat/pressure switch TS |  | The burner must stop |
| <ul style="list-style-type: none"> ➤ Turn the knob of the gas maximum pressure switch to the minimum end of scale position ➤ Turn the air pressure switch knob to the maximum end of scale position |  | The burner must stop in lockout |
| <ul style="list-style-type: none"> ➤ Turn off the burner and cut off the power ➤ Disconnect the minimum gas pressure switch connector |  | The burner must not start |
| <ul style="list-style-type: none"> ➤ Disconnect flame detection sensor electrical connections |  | The burner must stop in lockout due to ignition failure |
| <ul style="list-style-type: none"> ➤ Obscure the flame sensor |  | The burner must stop in lockout due to ignition failure |
| <ul style="list-style-type: none"> ➤ Turn off the burner and cut off the power ➤ Disconnect the maximum gas pressure switch connector |  | The burner must not start |
| <ul style="list-style-type: none"> ➤ Turn off the burner and cut off the power ➤ Disconnect the minimum oil pressure switch connector |  | The burner goes into lockout because the oil valves do not open |

Tab. L



ATTENTION

Make sure that the mechanical locking systems on the adjustment devices are fully tightened.

7 Maintenance

7.1 Notes on safety for the maintenance

The periodic maintenance is essential for the good operation, safety, yield and duration of the burner.

It allows you to reduce consumption and polluting emissions and to keep the product in a reliable state over time.



The maintenance interventions and the calibration of the burner must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

Before carrying out any maintenance, cleaning or checking operations:



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.



Wait for the components in contact with heat sources to cool down completely.

7.2 Maintenance programme

7.2.1 Maintenance frequency



The gas combustion system should be checked at least once a year by a representative of the manufacturer or another specialised technician.

7.2.2 Safety test - with no gas supply

To perform commissioning in safety conditions, it is very important to check correct wiring between gas valves and burner.

For this purpose, after checking that connections comply with the burner wiring diagrams, it is necessary to carry out a start-up cycle with gas cock closed (dry test).

- 1 The manual gas valve must be closed using the locking/unlocking device ("Lock-out / tag out" procedure).
- 2 Ensure that burner limit electrical contacts are closed
- 3 Ensure that minimum gas pressure switch contact is closed
- 4 Try to start the burner

The start-up cycle must occur according to the following steps:

- Fan motor start-up for pre-purging
- Gas valve leak detection control, if applicable
- Pre-purging completion
- Achievement of the ignition point
- Power supply of the ignition transformer
- Supply of gas valves

As gas is closed, the burner cannot ignite and its flame control will switch to stop or safety lockout condition.

The actual supply of gas valves can be checked by inserting a tester; some valves are equipped with lights (or closing/opening position indicators) that activate as soon as they are powered.



IF POWER SUPPLY OF GAS VALVES OCCURS IN UNEXPECTED MOMENTS, DO NOT OPEN THE MANUAL VALVE, DISCONNECT POWER SUPPLY, CHECK WIRINGS, CORRECT THE ERRORS AND CARRY OUT THE WHOLE TEST AGAIN.

7.2.3 Checking and cleaning



The operator must use the required equipment during maintenance.

Combustion

Carry out an analysis of the combustion flue gases. Significant differences with respect to the previous measurements indicate the points where most care should be exercised during maintenance.

Combustion head

Open the burner and make sure that all components of the combustion head are in good condition, not deformed by the high temperatures, free of impurities from the surroundings and correctly positioned.

Burner

Check for excess wear or loose screws in the mechanisms controlling the air damper and the gas butterfly valve. Also make sure that the screws securing the electrical leads in the burner terminal block are fully tightened. Clean the outside of the burner, taking special care with the articulated couplings and the cam 4)(Fig. 34 on page 33).

Fan

Check to make sure that no dust has accumulated inside the fan or on its impellers, as this condition will cause a reduction in the air flow rate and provoke polluting combustion.

Servomotor

Release cam 4)(Fig. 34) from the servomotor, by pressing and shifting button 3)(Fig. 35) to the right. Manually rotate it backwards and forwards to make sure it moves smoothly. Now engage the cam again by shifting the button 2)(Fig. 35) to the left.

Boiler

Clean the boiler as indicated in its accompanying instructions in order to maintain all the original combustion characteristics intact, especially: the flue gas temperature and combustion chamber pressure.

Flame inspection window

Clean the glass of the flame inspection window (Fig. 41).




Fig. 41

Electrical current to flame sensor (Fig. 42)

Clean the glass cover from any dust that may have accumulated. To remove the sensor pull it outwards with force; it is inserted only by pressure.

Min. value for a good work: 70 μ A.

If the value is lower, it could be due to:

- exhausted sensor
- low voltage (lower than 187 V)
- bad regulation of the burner

In order to measure the current, use a microammeter of 100 μ A d.c., connected in series to the sensor, as in the scheme, with a capacitor of 100 μ F - 1V d.c. at the same level of the instrument.




Fig. 42

7.2.4 Safety components

The safety components must be replaced at the end of their life cycle indicated in Tab. M.

The specified life cycles do not refer to the warranty terms indicated in the delivery or payment conditions.

| Safety component | Life cycle |
|--|--------------------------------------|
| Flame control | 10 years or 250.000 operation cycles |
| Flame sensor | 10 years or 250.000 operation cycles |
| Gas valves (solenoid) | 10 years or 250.000 operation cycles |
| Pressure switches | 10 years or 250.000 operation cycles |
| Pressure adjuster | 15 years |
| Servomotor (electronic cam) (if present) | 10 years or 250.000 operation cycles |
| Oil valve (solenoid)(if present) | 10 years or 250.000 operation cycles |
| Oil regulator (if present) | 10 years or 250.000 operation cycles |
| Oil pipes/ couplings (metallic) (if present) | 10 years |
| Fan impeller | 10 years or 500.000 start-ups |

Tab. M

LIGHT OIL OPERATION

GAS OPERATION

Filters (Fig. 43)

Check the filtering baskets on line 1) and at nozzle 2) present in the system.

Clean or replace if necessary.

If rust or other impurities are observed inside the pump, use a separate pump to lift any water and other impurities that may have deposited on the bottom of the tank.




Fig. 43

Pump

The delivery pressure must comply with Tab. J on page 25.

The depression must be less than 0.45 bar.

Unusual noise must not be evident during pump operation.

If the pressure is unstable, or the pump runs noisily, the flexible hose must be detached from the line filter and the fuel must be sucked from a tank located near the burner. This measure permits the cause of the anomaly to be traced to either the suction piping or the pump.

If the problem lies in the suction line, check the filter is clean and that air is not entering the piping.

Nozzles

It is advisable to replace nozzles once a year during periodical maintenance.

Do not clean the nozzle openings.

Flexible hoses

Check to make sure that the hoses are still in good condition.

Fuel tank

Approximately every 5 years, suck any water on the bottom of the tank using a separate pump.

Combustion

If the combustion values measured before starting maintenance do not comply with applicable Standards or do not indicate efficient combustion, consult the table below or contact our Technical Support Service to implement the necessary adjustments.

Gas leaks

Make sure that there are no gas leaks on the pipe between the gas meter and the burner.

Gas filter

Change the gas filter when it is dirty.

Combustion

If the combustion values measured before starting maintenance do not comply with applicable Standards or do not indicate efficient combustion, consult the table below or contact our Technical Support Service to implement the necessary adjustments.

| EN 676 | | Air excess | | |
|--------|--|-----------------------------------|-----------------|-----------------------------------|
| | | Max. output $\lambda \leq 1.2$ | | Min. output $\lambda \leq 1.3$ |
| GAS | Theoretical max CO ₂ 0 % O ₂ | Calibration CO ₂ % | | CO mg/kWh |
| | | $\lambda = 1.2$ | $\lambda = 1.3$ | |
| G 20 | 11.7 | 9.7 | 9.0 | ≤ 100 |
| G 25 | 11.5 | 9.5 | 8.8 | ≤ 100 |
| G 30 | 14.0 | 11.6 | 10.7 | ≤ 100 |
| G 31 | 13.7 | 11.4 | 10.5 | ≤ 100 |

| EN 267 | Air excess | | |
|---|-----------------------------------|-----------------|-----------------------------------|
| | Max. output $\lambda \leq 1.2$ | | Min. output $\lambda \leq 1.3$ |
| Theoretical max CO ₂ 0 % O ₂ | CO ₂ % Calibration | | CO mg/kWh |
| | $\lambda = 1.2$ | $\lambda = 1.3$ | |
| 15.2 | 12.6 | 11.5 | ≤ 100 |

7.3 Opening the burner



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.



Wait for the components in contact with heat sources to cool down completely.

- Loosen the screws 1) and remove the hood 2)(Fig. 44).
- Disconnect the light oil pipes 7)(Fig. 44).
- Disengage the articulated coupling 8) from the graduated sector 9).
- Remove the screws 10) from the two slide bars 4).
- Assemble the two extensions on the sliding bars 4).
- Refit the screws 10) on the extensions.
- Remove the screws 3) and move the burner backwards by about 100 mm on the slide bars 4)(Fig. 44).
Disconnect the electrode cables, then completely retract the burner.

At this point it is possible to extract the inner part 5) after having removed the screw 6)(Fig. 44).




Fig. 44

7.4 Closing the burner

Refit following the steps described but in reverse order; refit all burner components as they were originally assembled.



After carrying out maintenance, cleaning or checking operations, reassemble the cover and all the safety and protection devices of the burner.

8 Faults - Possible causes - Solutions

The LFL1... flame control is equipped with a lockout indicator (Fig. 45) that turns during the start-up programme, and is visible from the small lockout window.

When the burner does not start or stops, due to a failure, the symbol that appears on the indicator indicates the type of interruption.

The positions of the lockout indicator are shown in Fig. 46.



Lockout indicator

- a-b Start-up sequence
- b(b') Idle stages (without contact confirmation)
- b(b')-a Post-purging programme

Fig. 45




Fig. 46

Fuse replacement

The fuse 2)(Fig. 47) is in the rear part of the flame control. A spare fuse 1) is also available: it can be extracted after breaking the panel tab A) that houses it. In the event that fuse 2) has been tripped, replace it as shown in Fig. 47.

Find a list of faults, causes and possible solutions for a set of failures that may occur and result in irregular burner operation or no functioning at all.

If a burner malfunction is detected, first of all:

- check that the electrical wiring is adequately connected;
- check whether fuel is delivered;
- check that every adjustment parameter is adequately set.



ATTENTION

In the event the burner stops, in order to prevent any damage to the installation, do not unblock the burner more than twice in a row. If the burner locks out for a third time, contact the customer service.



DANGER

In the event there are further lockouts or faults with the burner, the maintenance interventions must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.




Fig. 47

8.1 Light oil operation

| Symbol | Problem | Probable cause | Suggested remedy |
|------------------------------------|---|---|---|
| ◀ | The burner does not start | Limiter or safety control device open | Adjust or replace |
| | | Flame control lockout | Release |
| | | Fan motor lockout | Release the thermal relay |
| | | No electrical power supply | Close all switches - check connections |
| | | No light oil | Check the light oil supply circuit |
| | | Flame control fuse interrupted | Replace |
| | The burner does not come on and the lockout appears | Pump is jammed | Replace |
| | | Faulty motor remote control switch | Replace |
| | | Defective flame control | Replace |
| | | Faulty electrical motor | Replace |
| | | Defective safety solenoid valve | Replace |
| | | Flame simulation | Replace the flame control |
| ▲ | The burner starts but stops at maximum air damper setting | Flame sensor short circuit | Replace flame sensor |
| | | Two-phase electrical supply, thermal relay steps in | Reset the thermal relay at return of the three phases |
| | | The servomotor contact does not intervene | Adjust cam or replace servomotor |
| P | The burner starts and then goes into lockout | Air pressure switch poorly adjusted | Adjust it |
| | | Pressure switch pressure point pipe blocked | Clean |
| ■ | The burner starts and then goes into lockout | Failure to the flame detection circuit | Replace flame control |
| ▼ | The burner remains in pre-purging phase | The servomotor contact III does not intervene | Adjust cam or replace servomotor |
| 1 | Once the pre-purging and the safety time has elapsed the burner goes into lockout without the flame appearing | No fuel in the tank, or water on the bottom | Refill with fuel, or remove the water |
| | | Bad head and damper adjustments | Adjust |
| | | High voltage cable defective or grounded | Replace |
| | | High voltage cable deformed by high temperature | Replace and protect |
| | | Bad electrical wiring on valves or transformer | Check |
| | | Pump unprimed | Prime it |
| | | Pump suction line connected to return line | Correct connection |
| | | Soiled filters (nozzle line) | Clean |
| | | Valves up-line from pump closed | Open them |
| | | Opposite motor rotation | Change electrical wiring to the motor |
| | | Light oil solenoid valves do not open | Check connections and solenoids |
| | | Pilot burner does not work | Check |
| | | Defective flame control | Replace |
| | | Ignition electrode incorrectly adjusted | Adjust it |
| | | Electrode grounded due to broken insulation | Replace |
| | | Motor/pump coupling broken | Replace |
| | Faulty ignition transformer | Replace | |
| | The flame ignites regularly but the burner goes into lock out at the end of the safety time | Faulty flame sensor or defective flame control | Replace flame sensor or flame control |
| | | Dirty flame sensor | Clean |
| | Smoke in flame (dark Bacharach) | Little air | Adjust the fan head and damper |
| Incorrect pump pressure | | Adjust | |
| Nozzle filter clogged | | Clean or replace | |
| Boiler room air vents insufficient | | Increase | |
| Dirty or worn nozzle | | Replace | |
| Smoke in flame (yellow Bacharach) | Flame disk soiled, loose or deformed | Clean it, tighten it or replace it | |
| | Too much air | Adjust head and air dampers | |

| Symbol | Problem | Probable cause | Suggested remedy |
|--------|---|---|---|
| | Ignition with pulses or flame failure, delayed ignition | Poorly adjusted head | Adjust |
| | | Incorrectly adjusted fan air damper: too much air | Adjust |
| | | Nozzle not fit for burner or boiler | See nozzle table |
| | | Defective nozzle | Replace |
| | | Unsuitable pump pressure | Adjust |
| | | Ignition electrode not adjusted correctly or soiled | Adjust it |
| | | Output during ignition phase is too high | Reduce |
| | The burner does not pass to the 2nd stage | Remote control device TR fails to close | Adjust or replace |
| | | Defective flame control | Replace |
| | Uneven fuel supply | Understand whether the cause lies in the pump or the fuel supply system | Supply fuel to the burner from a tank positioned near the burner itself |
| | Pump rusty on the inside | Water in the tank | Remove the water with a pump |
| | Noisy pump, unstable pressure | Air has entered the suction line | Block the couplings |
| | | Depression value too high (higher than 35 cm Hg): | |
| | | Excessive difference of level between burner and tank | Power the burner from a loop circuit |
| | | Piping diameter too small | Increase |
| | | Dirty suction line filters | Clean |
| | | Suction line valves closed | Open them |
| | | The paraffin solidifies due to the low temperature | Put additive in the light oil |
| | Pump unprimes after prolonged pause | Return pipe not immersed in fuel | Bring it to the same height as the suction line |
| | | Air in the suction line | Block the couplings |
| | Pump leaks light oil | Loss of sealing organ | Replace the pump |
| | Dirty combustion head | Dirty nozzle or nozzle filter | Replace |
| | | Unsuitable nozzle delivery or angle | See recommended nozzles |
| | | Loose nozzle | Block it |
| | | Environmental impurities on flame stability disc | Clean |
| | | Incorrect head adjustment, or little air | Adjust it, opening the damper |
| | | Blast tube length not suitable for the boiler | Contact the boiler manufacturer |
| I | Burner goes into lockout during operation | Flame sensor faulty or dirty | Replace it or clean it |
| | | Air pressure switch faulty | Replace |

Tab. N

8.2 Gas operation

| Symbol | Problem | Probable cause | Suggested remedy |
|--------|---|--|--|
| ◀ | The burner does not start | No electrical power supply | Close all switches and check connections |
| | | A limit or safety thermostat/pressure switch open | Adjust or replace |
| | | Flame control lockout | Release the flame control |
| | | Flame control fuse interrupted | Replace it (2) |
| | | Incorrect electrical wiring | Check |
| | | Defective flame control | Replace |
| | | No gas supply | Open the manual valves between meter and train |
| | | Mains gas pressure insufficient | Contact your GAS COMPANY |
| | | Minimum gas pressure switch fails to close | Adjust or replace |
| | | Air pressure switch in operating position | Adjust or replace |
| | | The servomotor contact does not intervene (closure cam 0°) | Adjust the closure cam 0° or replace the servomotor |
| | The burner does not come on and the lockout appears | Flame simulation | Replace the flame control |
| | | Faulty motor remote control switch | Replace |
| | | Defective electrical motor | Replace |
| ▲ | The burner starts but stops at maximum air damper setting | Motor lockout | Release the thermal relay |
| | | The servomotor contact does not intervene (maximum cam opening) | Cam adjustment (maximum opening) or replace the servomotor |
| P | The burner starts and then goes into lockout | Air pressure switch does not switch owing to lack of air pressure: | |
| | | Air pressure switch poorly adjusted | Adjust or replace |
| | | Pressure switch pressure point pipe clogged | Clean |
| | | Poorly adjusted head | Adjust |
| | | Dirty fan | Clean |
| ■ | The burner turns on and then remains in lockout mode | High depression in the furnace | Contact our Technical Department |
| | | Failure to the flame detection circuit | Replace the flame control |
| ▼ | The burner remains in pre-purging phase | The servomotor contact does not intervene (minimum cam) | Cam adjustment (minimum) or replace the servomotor |

| Symbol | Problem | Probable cause | Suggested remedy |
|--|---|---|--|
| 1 | Once the pre-purging and the safety time has elapsed the burner goes into lockout without the flame appearing | The GAS solenoid valve lets too little gas through | Increase |
| | | The GAS solenoid valve does not open | Replace the coil or the rectifier panel |
| | | Gas pressure too low | Increase pressure at governor |
| | | Ignition electrode incorrectly adjusted | Adjust it |
| | | Electrode grounded due to broken insulation | Replace |
| | | High voltage cable defective or grounded | Replace |
| | | High voltage cable deformed by high temperature | Replace and protect |
| | | Faulty ignition transformer | Replace |
| | | Incorrect valve or ignition transformer connections | Redo them |
| | | Defective flame control | Replace |
| | | A closed valve upstream the gas train | Open |
| | | Air in pipework | Bleed air |
| | | Lockout with flame appearing | The GAS solenoid valve lets too little gas through |
| | Dirty flame sensor | | Check, replace flame sensor |
| Faulty connection | Check, replace flame sensor | | |
| Insufficient detection current (min.70 µA) | Measure current, replace flame sensor | | |
| Flame sensor exhausted, faulty | Replace | | |
| Maximum gas pressure switch intervention | Adjust or replace | | |
| Defective flame control | Replace | | |
| | The burner continues to repeat the start-up cycle without lockout | The gas pressure in the gas mains lies very close to the value to which the gas pressure switch has been set. The sudden drop in pressure after valve opening causes temporary opening of the pressure switch itself, the valve immediately closes and the burner stops. Pressure increases again, the pressure switch closes again and the ignition cycle is repeated. And so on. | Reduce the intervention pressure of the minimum gas pressure switch. Replace the gas filter cartridge |
| | Lockout without symbol indication | Flame simulation | Replace the flame control |
| | Burner goes into lockout during operation | Faulty flame sensor | Replace worn parts |
| | | Air pressure switch faulty | Replace |
| ◀ | Lockout when the burner stops | Permanent flame in the combustion head or flame simulation | Eliminate permanency of flame or replace the flame control |
| | Ignition with pulsations | Poorly adjusted head | Adjust |
| | | Ignition electrode incorrectly adjusted | Adjust it |
| | | Incorrectly adjusted fan air damper: too much air | Adjust |
| | | Output during ignition phase is too high | Reduce |

Tab. O

A Appendix - Accessories

Output regulator kit for modulating gas/two-stage oil operation

With modulating operation, the burner continuously adjusts its output to the heat request, thereby ensuring a great stability of the controlled parameter: temperature or pressure.

The parts to be ordered are two:

- output regulator to be installed to the burner;
- probe to be installed to the heat generator.

| Parameter to be controlled | | Probe | | Output regulator | |
|----------------------------|---------------------------|---------------------------|--------------------|------------------|----------|
| | Adjustment field | Type | Code | Type | Code |
| Temperature | - 100...+ 500°C | PT 100 | 3010110 | RWF55.5 | 20099657 |
| Pressure | 0...2.5 bar 0...16 bar | Output probe 4...20 mA | 3010213 3010214 | | |

Extended head kit

| Burner | Standard head length (mm) | Extended head length (mm) | Code |
|-----------------|---------------------------|---------------------------|---------|
| RLS 68-120/M MX | 260 | 395 | 3010360 |

Soundproofing box kit

| Burner | Code | Type | Reduction of noise levels |
|-----------------|---------|------|---------------------------|
| RLS 68-120/M MX | 3010404 | C4/5 | 10 [dB(A)] |

Spacer kit

| Burner | Thickness (mm) | Code |
|-----------------|----------------|---------|
| RLS 68-120/M MX | 102 | 3000722 |

Continuous purging kit

| Burner | Code |
|-----------------|---------|
| RLS 68-120/M MX | 3010094 |

Differential switch kit

| Burner | Code |
|-----------------|----------|
| RLS 68-120/M MX | 20098337 |

Clean contacts kit

| Burner | Code |
|-----------------|----------|
| RLS 68-120/M MX | 20123294 |

Potentiometer kit

| Burner | Code |
|-----------------|---------|
| RLS 68-120/M MX | 3010416 |

Head kit for boilers with flame inversion

| Burner | Code |
|--------------|----------|
| RLS 68/M MX | 20006401 |
| RLS 120/M MX | 20006402 |


Gas trains in compliance with EN 676


Please refer to manual.

B

Appendix - Electrical panel layout

| | |
|----------|---|
| 1 | Index of layouts |
| 2 | Indication of references |
| 3 | Functional layout |
| 4 | Functional layout LFL ... |
| 5 | Functional layout LFL ... |
| 6 | Functional layout LFL ... |
| 7 | Functional layout |
| 8 | Electrical wiring that is the responsibility of the installer |
| 9 | Functional diagram RWF55.5... |


2 Indication of references



RLS 68/M MX

BU = BLU / BLEU / BLEU / BLAU
 BK = NERO / BLACK / NOIR / SCHWARZ
 BN = MARRONE / BROWN / MARRON / BRAUN
 YE = GIALLO / YELLOW / JAUNE / GELB
 GN = VERDE / GREEN / VERT / GRÜN
 RD = ROSSO / RED / ROUGE / ROT
 WH = BIANCO / WHITE / BLANC / WEISS
 OG = ARANCIO / ORANGE / ORANGE / ORANGE
 VT = VIOLETTO / VIOLET / VIOLET / VIOLETT
 GR = GRIGIO / GREY / GRIS / GRAU
 PK = ROSA / PINK / ROSE / ROSA
 GO = ORO / GOLD / OR / GOLD
 TO = TURCHESE / TURKHOISE / TURKHOISE / TURKISBLAU
 SR = ARGENTO / SILVER / ARGENT / SILBER
 GNTE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN

SCHEMA FUNZIONALE
 OPERATIONAL LA YOUT
 SCHEMA FONCTIONNEL
 Sheet : 3





RLS 120/M MX

| | | | | |
|---|---------------------------------------|--|----------------------------------|---|
| F | BU = BLEU / BLUE / BLEU / BLAU | WH = BIANCO / WHITE / BLANC / WEISS | GY = GRIGIO / GREY / GRIS / GRAU | TO = TURCHESE / TURKHOISE / TURKHOISE / TURKISBLAU |
| | BK = NERO / BLACK / NOIR / SCHWARZ | OG = ARANCIO / ORANGE / ORANGE / ORANGE | PK = ROSA / PINK / ROSE / ROSA | SR = ARGENTO / SILVER / ARGENT / SILBER |
| | BN = MARRONE / BROWN / MARRON / BRAUN | VT = VIOLETT / VIOLET / VIOLET / VIDLETT | GD = ORO / GOLD / OR / GOLD | GRYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRUN |

SCHEMA FUNZIONALE OPERATIONAL LAYOUT FUNKTIONSSCHEMA SCHEMA FONCTIONNEL

Sheet : 3





TO= TURCHESE / TURQUOISE / TURQUOISE / TURQUOISE / TURKISBLAU
 SR= ARGENTO / SILVER / ARGENT / SILBER
 GNYE= GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN

GY= GRIGIO / GREY / GRIS / GRAU
 PK= ROSA / PINK / ROSE / ROSA
 GB= ORO / GOLD / OR / GOLD


WH= BIANCO / WHITE / BLANC / WEISS
 OG= ARANCIO / ORANGE / ORANGE / ORANGE
 VT= VIOLETT / VIOLET / VIOLET / VIOLETT

YE= GIALLO / YELLOW / JAUNE / GELB
 GM= VERDE / GREEN / VERT / GRÜN
 RO= ROSSO / RED / ROUGE / ROT

BU= BLU / BLUE / BLEU / BLAU
 BK= NERO / BLACK / NOIR / SCHWARZ
 BN= MARRONE / BROWN / MARRON / BRAUN


SCHEMA FUNZIONALE
 OPERATIONAL LAYOUT
 FUNKTIONSSCHEMA
 SCHEMA FONCTIONNEL


Sheet : 5





BU = BLU / BLEU / BLEU / BLAU
 BK = NERO / BLACK / NOIR / SCHWARZ
 BN = MARRONE / BROWN / MARRON / BRAUN
 GR = GRIGIO / GREY / GRIS / GRAU
 PK = ROSA / PINK / ROSE / ROSA
 GD = ORO / GOLD / OR / GOLD
 WH = BIANCO / WHITE / BLANC / WEISS
 OG = ARANCIO / ORANGE / ORANGE / ORANGE
 VY = VIOLETTA / VIOLET / VIOLET / VIOLETT
 YE = GIALLO / YELLOW / JAUNE / GELB
 GN = VERDE / GREEN / VERT / GRÜN
 RD = ROSSO / RED / ROUGE / ROT
 TO = TURCHESE / TURQUOISE / TURQUOISE / TURKISBLAU
 SR = ARGENTO / SILVER / ARGENT / SILBER
 GNYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN

SCHEMA FUNZIONALE
 OPERATIONAL LAYOUT
 FUNKTIONSSCHEMA
 SCHEMA FONCTIONNEL
 Sheet : 6









Wiring layout key

| | |
|-------|--|
| A1 | Flame control |
| B | Filter to protect against radio disturbance |
| BP | Pressure probe |
| BT | Temperature probe |
| F1 | Thermal relay |
| FU | Three-phase power supply fuses |
| G1 | RWF55.5 output power regulator |
| H | Remote lockout signal |
| KM | Fan motor contactor |
| K0 | Relay |
| K1 | Relay |
| K01 | Relay |
| K02 | Relay |
| MV | Fan motor |
| MP | Pump motor |
| Q1 | Three-phase line disconnecting switch |
| Q2 | Single-phase line disconnecting switch |
| SM | Servomotor |
| PA | Air pressure switch |
| PGmin | Minimum gas pressure switch |
| PGM | Maximum gas pressure switch |
| TL | Limit remote control: shuts down the burner when the temperature or pressure in the boiler reaches the pre-set value. |
| TR | Adjustment remote control: controls 1st and 2nd stage operation. |
| TS | Safety remote control: intervenes in the event of TL failure. |
| IN | Burner manual stop electric switch |
| RS | Reset button |
| S1 | Operating mode switch: MAN = manual AUT = automatic OFF = off |
| S2 | Button for - = output reduction + = output increase |
| S3 | Oil/gas selector switch |
| TA | Ignition transformer |
| X1 | Burner terminal strip |
| XPE | Flame control earth |
| XPGM | Maximum gas pressure switch connector |
| XTB | Burner earth |
| XVOS | Safety valve connector (light oil) |
| XVO1 | 1st stage adjustment valve connector (light oil) |
| XVO2 | 2nd stage adjustment valve connector (light oil) |
| UV | Flame sensor |
| VS | Safety valve (gas) |
| VR | 1st stage adjustment valve (gas) |
| VOS | Safety valve (light oil) |
| VO1 | 1st stage adjustment valve (light oil) |
| VO2 | 2nd stage adjustment valve (light oil) |
| Y | Gas adjustment valve + gas safety valve |
| YVPS | Gas valve leak detection device |

RIELLO

RIELLO S.p.A.
I-37045 Legnago (VR)
Tel.: +39.0442.630111
[http:// www.riello.it](http://www.riello.it)
[http:// www.riello.com](http://www.riello.com)