

GB **Heavy oil burners**

Progressive two-stage or modulating operation

CE

**UK
CA**

CODE	MODEL
20206097 - 20208707	P 140 P/N
20205676 - 20208709	P 200 P/N
20205723	P 300 P/N
20205790	P 300 P/N
20208710	P 450 P/N
20208711	P 450 P/N



Translation of the original instructions

1	Information and general warnings.....	3
1.1	Information about the instruction manual	3
1.2	Guarantee and responsibility	4
2	Safety and prevention.....	5
2.1	Introduction.....	5
2.2	Personnel training	5
3	Technical description of the burner	6
3.1	Burner designation	6
3.2	Models available.....	6
4	Technical description of the burner	7
4.1	Technical data	7
4.2	Electrical data	7
4.3	Overall dimensions	8
4.4	Standard equipment	8
4.5	Firing rates	9
4.6	Test boiler.....	10
4.7	Burner description	11
4.8	Electrical panel description.....	12
4.9	Flame control.....	13
4.10	Servomotor SQM40	14
5	Installation	15
5.1	Notes on safety for the installation	15
5.2	Handling	15
5.3	Preliminary checks	15
5.4	Operating position	16
5.5	Boiler plate	16
5.6	Blast tube length.....	16
5.7	Securing the burner to the boiler	17
5.8	Nozzle assembly	17
5.9	Electrodes adjustment.....	17
5.10	Nozzle installation	18
5.11	Fuel oil supply	21
5.12	Pump	23
5.13	Electrical connections.....	24
5.14	Calibration of the thermal relay	25
5.15	Motor rotation	25
6	Start-up, calibration and operation of the burner	26
6.1	Notes on safety for the first start-up	26
6.2	Adjustments prior to ignition	26
6.3	Maximum fuel flow rate adjustment.....	26
6.4	Pressure variator adjustment	27
6.5	Combustion head adjustment.....	28
6.6	Air damper setting	29
6.7	Atomising temperature setting.....	30
6.8	Servomotor adjustment	31
6.9	Pressure switch adjustment	32
6.10	Operation sequence of the burner.....	33
6.11	Final checks	33
7	Maintenance.....	34
7.1	Notes on safety for the maintenance.....	34
7.2	Maintenance programme	34
7.3	Opening the burner	35
7.4	Closing the burner	35

8	Faults - Possible causes - Solutions.....	36
8.1	Light oil operation.....	37
A	Appendix - Accessories	39
B	Appendix - Electrical panel layout.....	41

1 Information and general warnings

1.1 Information about the instruction manual

1.1.1 Introduction

The instruction manual supplied with the burner:

- is an integral and essential part of the product and must not be separated from it; it must therefore be kept carefully for any necessary consultation and must accompany the burner even if it is transferred to another owner or user, or to another system. If the manual is lost or damaged, another copy must be requested from the Technical Assistance Centre of the area;
- is designed for use by qualified personnel;
- offers important indications and instructions relating to the installation safety, start-up, use and maintenance of the burner.

Symbols used in the manual

In some parts of the manual you will see triangular DANGER signs. Pay great attention to these, as they indicate a situation of potential danger.

1.1.2 General dangers

The **dangers** can be of **3 levels**, as indicated below.



Maximum danger level!
This symbol indicates operations which, if not carried out correctly, cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause damage to the machine and/or injury to people.

1.1.3 Other symbols



DANGER: LIVE COMPONENTS
This symbol indicates operations which, if not carried out correctly, lead to electric shocks with lethal consequences.



DANGER: FLAMMABLE MATERIAL
This symbol indicates the presence of flammable materials.



DANGER: BURNING
This symbol indicates the risks of burns due to high temperatures.



DANGER: CRUSHING OF LIMBS
This symbol indicates the presence of moving parts: danger of crushing of limbs.



WARNING: MOVING PARTS
This symbol indicates that you must keep limbs away from moving mechanical parts; danger of crushing.



DANGER: EXPLOSION

This symbol signals places where an explosive atmosphere may be present. An explosive atmosphere is defined as a mixture - under atmospheric conditions - of air and flammable substances in the form of gases, vapours, mist or dust in which, after ignition has occurred, combustion spreads to the entire unburned mixture.



PERSONAL PROTECTION EQUIPMENT

These symbols indicate the equipment that must be worn and kept by the operator for protection against threats against safety and/or health while at work.



OBLIGATION TO ASSEMBLE THE COVER AND ALL THE SAFETY AND PROTECTION DEVICES

This symbol signals the obligation to reassemble the cover and all the safety and protection devices of the burner after any maintenance, cleaning or checking operations.



ENVIRONMENTAL PROTECTION

This symbol gives indications for the use of the machine with respect for the environment.



IMPORTANT INFORMATION

This symbol indicates important information that you must bear in mind.

This symbol indicates important information that you must bear in mind.

- This symbol indicates a list.

Abbreviations used

Ch.	Chapter
Fig.	Figure
Page	Page
Sec.	Section
Tab.	Table

1.1.4 Delivery of the system and the instruction manual

When the system is delivered, it is important that:

- the instruction manual is delivered to the user by the system manufacturer, with the recommendation to keep it in the room where the heat generator is to be installed.
- The instruction manual shows:
 - the serial number of the burner;

.....

- the address and telephone number of the nearest Assistance Centre;

.....

.....

.....

- The system supplier must carefully inform the user about:
 - the use of the system;
 - any further tests that may be required before activating the system;
 - maintenance, and the need to have the system checked at least once a year by a representative of the manufacturer or another specialised technician.
 To ensure a periodic check, the manufacturer recommends the drawing up of a Maintenance Contract.

1.2 Guarantee and responsibility

The manufacturer guarantees its new products from the date of installation, in accordance with the regulations in force and/or the sales contract. At the moment of the first start-up, check that the burner is integral and complete.

**ATTENTION**

Failure to observe the information given in this manual, operating negligence, incorrect installation and carrying out of non authorised modifications will result in the annulment by the manufacturer of the guarantee that it supplies with the burner.

In particular, the rights to the guarantee and the responsibility will no longer be valid, in the event of damage to things or injury to people, if such damage/injury was due to any of the following causes:

- incorrect installation, start-up, use and maintenance of the burner;
- improper, incorrect or unreasonable use of the burner;
- intervention of unqualified personnel;
- carrying out of unauthorised modifications on the equipment;
- use of the burner with safety devices that are faulty, incorrectly applied and/or not working;
- installation of untested supplementary components on the burner;
- powering of the burner with unsuitable fuels;
- faults in the fuel supply system;
- continuation of use of the burner when a fault has occurred;
- repairs and/or overhauls incorrectly carried out;
- modification of the combustion chamber with inserts that prevent the regular development of the structurally established flame;
- insufficient and inappropriate surveillance and care of those burner components most likely to be subject to wear and tear;
- use of non-original components, including spare parts, kits, accessories and optional;
- force majeure.

The manufacturer furthermore declines any and every responsibility for the failure to observe the contents of this manual.

2 Safety and prevention

2.1 Introduction

The burners have been designed and built in compliance with current regulations and directives, applying the known technical safety rules and envisaging all the potential danger situations.

It is necessary, however, to bear in mind that the imprudent and clumsy use of the equipment may lead to situations of death risk for the user or third parties, as well as the damaging of the burner or other items. Inattention, thoughtlessness and excessive confidence often cause accidents; the same applies to tiredness and sleepiness.

It is a good idea to remember the following:

- The burner must only be used as expressly described. Any other use should be considered improper and therefore dangerous.

Specifically:

it can be applied to boilers operating with water, steam, diathermic oil, and to other uses expressly named by the manufacturer;

the type and pressure of the fuel, the voltage and frequency of the electrical power supply, the minimum and maximum deliveries for which the burner has been regulated, the pressurisation of the combustion chamber, the dimensions of the combustion chamber and the ambient temperature must all be within the values indicated in the instruction manual.

- Modification of the burner to alter its performance and destinations is not allowed.
- The burner must be used in exemplary technical safety conditions. Any disturbances that could compromise safety must be quickly eliminated.
- Opening or tampering with the burner components is not allowed, apart from the parts requiring maintenance.
- Only those parts envisaged by the manufacturer can be replaced.



The manufacturer guarantees safety and proper operation only if all burner components are intact and correctly positioned.

2.2 Personnel training

The user is the person, body or company that has acquired the machine and intends to use it for the specific purpose. He is responsible for the machine and for the training of the people working around it.

The user:

- undertakes to entrust the machine exclusively to suitably trained and qualified personnel;
- undertakes to inform his personnel in a suitable way about the application and observance of the safety instructions. With that aim, he undertakes to ensure that everyone knows the use and safety instructions for his own duties;
- Personnel must observe all the danger and caution indications shown on the machine.
- Personnel must not carry out, on their own initiative, operations or interventions that are not within their province.
- Personnel must inform their superiors of every problem or dangerous situation that may arise.
- The assembly of parts of other makes, or any modifications, can alter the characteristics of the machine and hence compromise operating safety. The manufacturer therefore declines any and every responsibility for any damage that may be caused by the use of non-original parts.


In addition:



- must take all the measures necessary to prevent unauthorised people gaining access to the machine;
- the user must inform the manufacturer if faults or malfunctioning of the accident prevention systems are noticed, along with any presumed danger situation;
- personnel must always use the personal protective equipment envisaged by legislation and follow the indications given in this manual.

3 Technical description of the burner

3.1 Burner designation



3.2 Models available

Designation	TC	FS1	Voltage	Start-up	Code
PRESS 140 P/N	TC	FS1	3/230-400/50	Direct	20206097
PRESS 140 P/N	TL	FS1	3/230-400/50	Direct	20208707
PRESS 200 P/N	TC	FS1	3/230-400/50	Direct	20205676
PRESS 200 P/N	TL	FS1	3/230-400/50	Direct	20208709
PRESS 300 P/N	TC	FS1	3/230-400/50	Direct	20205723
PRESS 300 P/N	TC	FS1	3N/400/50	Star/Triangle	20205790
PRESS 450 P/N	TC	FS1	3N/400/50	Star/Triangle	20208710
PRESS 450 P/N	TL	FS1	3N/400/50	Star/Triangle	20208711

4 Technical description of the burner

4.1 Technical data

MODEL		PRESS 140 P/N	PRESS 200 P/N	PRESS 300 P/N	PRESS 450 P/N
Output ⁽¹⁾	kW	400-1600	570-2280	683-3420	1140-5130
Delivery ⁽¹⁾	kg/h	35-140	50-200	60-300	100-450
Fuel		Heavy oil			
- max viscosity at 50 °C	mm ² /s	50 (7°E) up to 500 (65°E) with kit			
Operation		<ul style="list-style-type: none"> • Intermittent (min. 1 stop every 24 hours). • Progressive two-stage (modulating by kit). 			
Nozzle	number	1 (nozzle with return line)			
Standard applications		Boilers: water, steam, diathermic oil			
Ambient temperature	°C	0 - 40			
Combustion air temperature	°C max	60			
Pump flow rate	kg/h	310	470	690	940
pressure range	bar	25	25	25	25
fuel temperature	°C max	120	140	140	140
Weight of the burner (complete with packaging)	kg	180	220	238	300

Tab. A

⁽¹⁾ Reference conditions: Room temperature 20°C - Barometric pressure 1000 mbar – Altitude 100 m above sea level.

4.2 Electrical data

MODEL		PRESS 140 P/N	PRESS 200 P/N
CODE		20206097 - 20208707	20205676 - 20208709
Electrical power supply	V Hz	3N ~ 230/400 50	
Absorbed electrical power	kW max	17.8	18.8
Protection level	IP	40	

MODEL		PRESS 300 P/N	PRESS 300 P/N
CODE		20205723	20205790
Electrical power supply	V Hz	3N ~ 230/400 50	3N ~ 400 50
Absorbed electrical power	kW max	30.5	
Protection level	IP	40	

MODEL		PRESS 450P/N
CODE		20208710 - 20208711
Electrical power supply	V Hz	3N ~ 400 50
Absorbed electrical power	kW max	36.7
Protection level	IP	40

Tab. B

4.3 Overall dimensions

The dimensions of the burner are given in Fig. 1.

Bear in mind that inspection of the combustion head requires the burner to be opened and the rear part drawn back on the slide bars.




Fig. 1

mm	A	B	C	D	E	F - F ₍₁₎	H	I	O - O ₍₁₎
PRESS 140 P/N	796	396	400	99	910	323 - 433	222	467	1233 - 1343
PRESS 200 P/N	796	396	400	99	910	352 - 462	250	467	1262 - 1372
PRESS 300 P/N	858	447	411	128	1020	376 - 506	295	496	1396 - 1526
PRESS 450 P/N	950	508	442	128	1090	435 - 565	336	525	1525 - 1655

Tab. C

(1) Head: short - long

4.4 Standard equipment

Flexible hoses	No. 2
Grommet	No. 5
Screws.....	No. 4
Thermal flange gasket.....	No. 1
Nipples	No. 2
Extensions (for TL versions only).....	No. 2
Starter (PRESS 300-450 P/N model only)	No. 1
Installer booklet	No. 1
Spare parts list	No. 1

4.5 Firing rates

During operation, burner output varies within a minimum and a maximum limit.

MINIMUM OUTPUT: can drop down to:

- PRESS 140 P/N** 35 kg Maximum modulating ratio is 1 - 3 (46 - 140 kg/h)
- PRESS 200 P/N** 50 kg Maximum modulating ratio is 1 - 3 (66 - 200 kg/h)
- PRESS 300 P/N** 60 kg Maximum modulating ratio is 1 - 3 (90 - 300 kg/h)
- PRESS 450 P/N** 100 kg Maximum modulating ratio is 1 - 3 (150 - 450 kg/h)

MAXIMUM OUTPUT must be within the firing rate (Fig. 2).



ATTENTION

The FIRING RATE was obtained with an ambient temperature of 20°C and a barometric pressure of 1000 mbar (approx. 100m above sea level), with the combustion head adjusted as shown on page 28.




Fig. 2

4.6 Test boiler

The burner/boiler combination does not pose any problems if the boiler is EC approved and its combustion chamber dimensions are similar to those indicated in the diagram (Fig. 3).

If the burner must be combined with a boiler that has not been EC approved and/or its combustion chamber dimensions are clearly smaller than those indicated in the diagram, consult the manufacturer.

The firing rates were obtained in special test boilers, according to EN 267 standard.

In Fig. 3 you can see the diameter and length of the test combustion chamber.

Example:

Output 650 Mcal/h (407 kW): diameter 60 cm - length 2 m.

MODULATING RATIO

The modulating ratio, obtained in test boilers according to standard (EN 267) is 4:1.




Fig. 3

4.7 Burner description

20172325




Fig. 4

- 1 Suction connection
- 2 Pump pressure regulator
- 3 Return connection
- 4 Pressure gauge connection (PRESS 140 - G 1/8)
Pressure gauge connection (PRESS 200-300-450 - G 1/4)
- 5 Vacuum connection (PRESS 140 - G 1/2)
Vacuum connection (PRESS 200-300-450 - G 1/4)
- 6 Maximum temperature thermostat
- 7 Minimum temperature thermostat
- 8 Flame control reset button with lockout signal
- 9 Fan motor
- 10 Setting thermostat
- 11 Air adjustment cam
- 12 Servomotor
- 13 Modulator (only for modulating units)
- 14 Nozzle rod opening magnet
- 15 Pressure adjustment eccentric on return line
- 16 Pressure switch
- 17 Return pressure gauge
- 18 Delivery pressure gauge
- 19 Combustion head adjustment screw
- 20 Filter

4.8 Electrical panel description




Fig. 5

- 1 Fan motor thermal relay and contactor (for direct starter version only)
- 2 Ignition transformer
- 3 Filter to protect against radio disturbance
- 4 Servomotor connector
- 5 Pre-heater contactor
- 6 Terminal board for electric connection
- 7 Relay
- 8 Timed relay
- 9 Relay
- 10 Electronic thermostat
- 11 Flame control base
- 12 Flame sensor
- 13 Oil valve coils
- 14 Suppressor (PRESS 300-450 P/N models only)
- 15 Cable grommets for external connections (to be carried out by the installer)
- 16 Modular rectifier

4.9 Flame control

Important notes



To avoid accidents, material or environmental damage, observe the following instructions!

The flame control is a safety device! Avoid opening or modifying it, or forcing its operation. Riello S.p.A. cannot assume any responsibility for damage resulting from unauthorised interventions!

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Before modifying the wiring in the flame control connection area, fully disconnect the system from the power supply (omnipolar separation).
- Protection against electrocution from the flame control and all connected electric components is obtained with the correct assembly.
- Before any intervention (assembly and installation operations, assistance, etc.), ensure the wiring is in order and that the parameters are correctly set, then make the safety checks.
- Falls and collisions can negatively affect the safety functions. In this case, the flame control must not be operated, even if it displays no evident damage.
- **Do not press the reset button or the remote reset button of the flame control for more than 10 seconds because this will damage the internal relay.**

For safety and reliability, comply with the following instructions:

- Avoid conditions that can favour the development of condensate and humidity. Otherwise, before switching on again, make sure that the entire flame control is perfectly dry!
- Static charges must be avoided since they can damage the flame control's electronic components when touched.

Use

The flame control is a control and supervision system of medium and large capacity forced draft burners for intermittent operation (at least one controlled shutdown every 24 hours).

Installation notes

- Check the electrical wiring inside the boiler complies with the national and local safety regulations.
- Do not confuse the powered conductors with the neutral ones.
- Ensure that spliced wires cannot get into contact with neighbouring terminals. Use adequate ferrules.
- Arrange the H.V. ignition cables separately, as far as possible from the flame control and the other cables.
- When wiring the unit, make sure that AC 230 V mains voltage cables are run strictly separate from extra low-voltage cables to avoid risks of electrical shock hazard.




Fig. 6

Electrical wiring of the flame detector

It is important for signal transmission to be almost totally free of any disturbances or loss:

- Always separate the detector cables from the other cables:
 - The capacitive reactance of the line reduces the size of the flame signal.
 - Use a separate cable.
- Respect the allowed cable lengths.
- The ionisation probe is not protected against the risk of electrocution. When connected to the electricity supply, the ionisation probe must be protected against any accidental contact.
- Position the ignition electrode and the ionisation probe so that the ignition spark cannot form an arc on the probe (risk of electric overcharge).

Technical data

Mains voltage	AC 230 V -15 % / +10 %
Mains frequency	50 / 60 Hz ±6 %
Fuse (Internal)	T6.3H250V
Primary fuse (external)	max. 10 A
Weight	approx. 1 kg
Power absorption	approx. AC 3.5 VA
Protection level	IP40
Safety class	II
Input current at terminal 1	max. 5 A continuous (peaks of 20 A / 20 ms)
Load on the control terminals	max. 4 A continuous (peaks of 20 A / 20 ms)
Environmental conditions	
Operation	DIN EN 60721-3-1
Climatic conditions	Class 1K3
Mechanical conditions	Class 1M2
Temperature range	-20...+60°C
Humidity	< 95% RH

Tab. D

4.10 Servomotor SQM40 ...

Important notes



ATTENTION

To avoid accidents, material or environmental damage, observe the following instructions!

Avoid opening, modifying or forcing the servomotor.

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Falls and collisions can negatively affect the safety functions. In this case, the servomotor must not be operated, even if it displays no evident damage.
- Fully disconnect the burner from the mains when working near terminals and servomotor connections.
- Condensation and exposure to water are not allowed.
- For safety reasons, the servomotor must be checked after long periods of non-use.



S8907

Fig. 7

Technical data

Mains voltage	230 V -15% +10%
Mains frequency	50 / 60 Hz
Power absorption	10 VA
Motor	Synchronous
Drive angle	Varying between 0° and 135°
Protection level	Max. IP 66, with appropriate cable entry
Cable entry	2 x M20
Cable connection	terminal board for 0.5mm ² (min.) and 2.5mm ² (max.)
Rotation direction	Anticlockwise
Rated torque (max.)	10 Nm
Holding torque	5 Nm
Operation time	30 s. at 90°
Weight	approx. 2 kg
Environmental conditions:	
Operation	-20...+60° C
Transport and storage	-20...+60° C

Tab. E

5 Installation

5.1 Notes on safety for the installation

After carefully cleaning all around the area where the burner is to be installed, and arranging for the environment to be illuminated correctly, proceed with the installation operations.



All the installation, maintenance and disassembly operations must be carried out with the electricity supply disconnected.



The installation of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



The combustion air inside the boiler must be free from hazardous mixes (e.g.: chloride, fluoride, halogen); if present, it is highly recommended to carry out cleaning and maintenance more frequently.

5.2 Handling

The burner packaging includes a wooden platform, it is therefore possible to handle the burner (still packaged) with a pallet truck or fork lift truck.



Burner handling operations can be highly dangerous if not carried out with the greatest attention: distance unauthorised personnel, check integrity and suitability of the means available. Check also that the area in which you are working is empty and that there is an adequate escape area (i.e. a free, safe area to which you can quickly move if the burner should fall). During handling, keep the load at no more than 20-25 cm from the ground.



After positioning the burner near the installation point, correctly dispose of all residual packaging, separating the various types of material.



Before proceeding with the installation operations, carefully clean all around the area where the burner will be installed.

5.3 Preliminary checks

Checking the consignment



After removing all the packaging, check the integrity of the contents. In the event of doubt, do not use the burner; contact the supplier.



The packaging elements (wooden cage or cardboard box, nails, clips, plastic bags, etc.) must not be abandoned as they are potential sources of danger and pollution; they should be collected and disposed of in the appropriate places.

Check the identification label of the burner, showing:

- the model (see **A** in Fig. 8) and the type of burner (**B**);
- the year of manufacture, in cryptographic form (**C**);
- the serial number (**D**);
- the absorbed electrical power (**E**);
- the types of fuel used and the relative supply pressures (**F**);
- the minimum and maximum possible output data of the burner (**G**) (see Firing rate).

D2582

N.	D	TIPO/TYP	A - B	C	V-50 Hz	E	kW
⊕ ⊖		kg/h		G		kW	
Combust. Heizöl/Fuel		F max. visc. @	°C	mm ² /s (E)		RBL	
REGOLAZIONE			X →	<input type="checkbox"/> DUE STADI PROGRESSIVI GLEITEND ZWEISTUFIG			
LEISTUNGSREGELUNG			X →	<input type="checkbox"/> MODULANTE MODULIEREND			

Fig. 8



A burner label that has been tampered with, removed or is missing, along with anything else that prevents the definite identification of the burner makes any installation or maintenance work difficult.

5.4 Operating position



- The burner is designed to work only in positions 1 and 4 (Fig. 9).
- Installation 1 is preferable, as it is the only one that allows the maintenance operations as described in this manual.
- The installation 4 permits the operation but makes the maintenance and inspection operations of the combustion head more difficult.



- Any other position could compromise the correct operation of the appliance.
- The installation 5 is prohibited for safety reasons.




Fig. 9

5.5 Boiler plate

Pierce the closing plate of the combustion chamber, as in (Fig. 10). The position of the threaded holes can be marked using the thermal insulation screen supplied with the burner.

For the combustion head protrusion follow the indications provided by the boiler manufacturer.

MODEL	L	M	N	P
PRESS 140 P/N	260	230	M 14	225
PRESS 200 P/N	260	-	M 16	255
PRESS 300 P/N	-	260	M 18	300
PRESS 450 P/N	-	310	M 20	350

Tab. F




Fig. 10

5.6 Blast tube length

The length of the blast tube must be selected according to the indications provided by the manufacturer of the boiler, and in any case it must be greater than the thickness of the boiler door complete with its fettling.

MODEL	MIN	MAX
PRESS 140 P/N TC	180	300
PRESS 200 P/N TC	200	340
PRESS 300 P/N TC	200	350
PRESS 450 P/N TC	250	400
PRESS 140 P/N TL	290	410
PRESS 200 P/N TL	310	450
PRESS 300 P/N TL	330	480
PRESS 450 P/N TL	380	530

Tab. G




Fig. 11

5.7 Securing the burner to the boiler



Provide an adequate lifting system.



Be careful as some drops of fuel may leak out during this phase.

To separate the burner from the cast iron blast tube, proceed as follows:

- remove the cover 1)(Fig. 12), the split pin and pin 2), the nuts 3) and the screws 4).
- Pull out the blast tube from the burner by approx. 100÷120 mm and release the driving fork of the head 6) by removing the split pins 5).
- At this point, it is possible to fully pull out the blast tube from the pins 7).
- Fix the blast tube to the boiler by inserting the insulating seal 8) in-between.
- After fitting the selected nozzle, fit the burner on the pins 7) leaving it open by approx. 100 ÷ 120 mm.
- Refit the fork 6) fixing it with the split pins 5).
- Completely close the burner fastening it with screws 4), fit the nuts 3), the pin and split pin 2).




Fig. 12



The seal between burner and boiler must be airtight.

5.8 Nozzle assembly

At this installation stage the burner is still separated from the blast tube; therefore it is possible to fit the nozzle with a 24mm wrench 3)(Fig. 13) after removing the screws 1) and the turbulator 2).

Do not use any sealing products such as: gaskets, tape or sealants. Be careful to avoid damaging the nozzle sealing seat.



ATTENTION

- Do not use any sealing products such as: gaskets, tape or sealants.
- Be careful to avoid damaging the nozzle sealing seat.
- The nozzle must be screwed into place tightly but not to the maximum torque value provided by the wrench.




Fig. 13

5.9 Electrodes adjustment



ATTENTION

Check that the electrodes are positioned correctly, as in Fig. 14, complying with the dimensions indicated.




Fig. 14

5.10 Nozzle installation

The burner complies with the emission requirements of the EN 267 standard. In order to guarantee that emissions do not vary, recommended and/or alternative nozzles specified by Riello in the Instruction and warning booklet should be used.



It is advisable to replace the nozzle once a year during periodical maintenance.

The use of nozzles other than those specified by Riello S.p.A. and inadequate regular maintenance may result into emission limits non-conforming to the values set forth by the regulations in force, and in extremely serious cases, into potential hazards to people and objects.



The manufacturing Company shall not be liable for any such damage arising from non-observance of the requirements contained in this manual.

5.10.1 Nozzle selection

If you want a delivery somewhere between the two values shown in the diagram (Fig. 15 on page 19), select a nozzle with a higher flow rate. The reduction in the flow rate is obtained with the pressure variator.

AVAILABLE NOZZLES

Bergonzo B5	
kg/h	
140	150
	125
	100
	90
	80
	70
200	200
	175
	150
	125
	100
300	300
	275
	250
	225
	200
	175
	150
	125
450	450
	400
	350
	325
	300
	275
	250
	225

Tab. H

NOZZLES RECOMMENDED:

- Bergonzo type B5

To calibrate the delivery range of the nozzle, adequately adjust the fuel maximum and minimum pressure on the nozzle return line, as shown in diagrams (Fig. 15, Fig. 16, Fig. 17 and Fig. 18 on page 20).

- After fitting the nozzle, remove the servomotor protection cover, and turn the burner on.
- After turning on the burner, immediately disconnect the servomotor from the power supply by opening the connector located in the electrical control panel. In this way the burner remains in minimum flow rate operating mode.
- Unlock the motor cam of the servomotor by pressing the release.
- Manually and slowly rotate the variable profile cam, integrally connected to the eccentric. The pressure and the flow output of the nozzle are at their minimum level when the servomotor is at the 20° position. The pressure and the flow output of the nozzle are at their maximum when the servomotor is at the 130° position. The return line pressure corrections are possible by changing the eccentric and the nut with the lock nut.

5.10.2 Indicative relation between: nozzle type and flow rate - return line pressure

PRESS 140 P/N




Fig. 15

PRESS 200 P/N




Fig. 16

Diagrams relating to nozzles:

BERGONZO type B5 - 50° with 25 bar delivery pressure.

- 50° recommended atomisation angles
- For narrow combustion chambers use nozzles at 35°.

PRESS 300 P/N

D3432




Fig. 17

PRESS 450 P/N

D3433




Fig. 18

Diagrams relating to nozzles:

BERGONZO type B5 - 50° with 25 bar delivery pressure.

- 50° recommended atomisation angles
- For narrow combustion chambers use nozzles at 35°.

5.11 Fuel oil supply



Explosion danger due to fuel leaks in the presence of a flammable source.

Precautions: avoid knocking, attrition, sparks and heat.

Make sure the fuel shut-off valve is closed before performing any operation on the burner.



ATTENTION

The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.



ATTENTION

Before starting the burner make sure that the return pipe line is not clogged.

Any obstruction would cause the pump seals to break.

Oil pipes must be completely airtight.

- To facilitate the fuel flow, all pipes must be suitably dimensioned, insulated and heated (electrically or through vapour or hot water).
- To limit the formation of gas or vapour, the fuel pressure in the degassing unit 10)(Fig. 19) must be adjusted according to the supply temperature as per the table above.
- The transfer pump must have a flow rate that is at least twice the burner pump one.
- For several burners supplied by the same loop, the pump must ensure a supply of approx. 30% more than the sum of flow rates of the single burners.
- **For start-up:** with burner disabled through gate valves 5) make fuel flow in the supply loop. Once standard circulation is reached, open the gate valves and regularly supply the burner.




Fig. 19

Key

- 1 - Tank (heated for thick oil)
- 2 - Filter (oil resistance > 7°E / 50°C)
- 3 - Transfer pump
- 4 - Control pressure gauge
- 5 - Gate valves for burner disabling (coupled)
- 6 - Burner (with thick oil kit code **3000721**)
- 7 - Pressure regulator (calibrated according to Tab. I)
- 8 - Filter (oil resistance > 7°E / 50°C)
- 9 - Burner pump
- 10 - Degassing unit

HEAVY OIL TEMPERATURE	PRESSURE
°C	bar
up to 80	1
90	1.5
100	2
110	2.5
120	3

Tab. I

Variation for secondary power supply

The degassing unit for tick oil must be equipped with heater code **3010050**.




Fig. 20

5.11.1 Hydraulic connections



CAUTION

- Make sure that the hoses to the pump supply and return line are installed correctly.

Install the hoses where they cannot be stepped on or come into contact with hot surfaces of the boiler.



ATTENTION

During the installation, hoses must not be stressed with twisting.

Periodically clean the tank filter.

Make sure that the nozzle has no filter.

5.11.2 Hydraulic circuit diagram

D2009




Fig. 21

- Burner stand-by conditions
- **P** oil pressure switch: it can be adjusted from 2 to 15 bar, in case of excessive back pressure on the fuel return line, it locks the burner (recommended calibration at 5 bar).

5.12 Pump

5.12.1 Technical data

Pump		E7NC1069-5P	TA2C4010-5	TA3C4010-5	TA4C4010-7
Burner		PRESS 140 P/N	PRESS 200 P/N	PRESS 300 P/N	PRESS 450 P/N
Min. delivery rate at 30 bar pressure (140)					
Min. delivery rate at 40 bar pressure (200-300-450)	kg/h	235	350	540	730
Delivery pressure range	bar	14-30	7-40	7-40	7-40
Max. suction depression	cm Hg	30	30	30	30
Viscosity range	cSt	2.8-800	4-800	4-800	4-75
Maximum heavy oil temperature	°C	120	140	140	140
Max. suction and return pressure	bar	3.5	5	5	5
Pressure calibration in the factory	bar	30	25	25	25

Tab. J

5.12.2 Priming pump



Before starting the burner, make sure that the tank return line is not clogged.

Obstructions in the line could cause the sealing organ located on the pump shaft to break.

- In order for self-priming to take place, the cap 4) on the pump (Fig. 22) must be loosened to bleed off the air contained in the suction line.
- Start the burner by closing the remote controls. As soon as the burner starts, check the direction of rotation of the fan blade.
- The pump can be considered to be primed when the light oil starts coming out of the cap 4).
- Close the burner and tighten the cap 4).

The time required for this operation depends upon the diameter and length of the suction tubing.

If the pump fails to prime at first start-up and the burner locks out, wait approx. 15 seconds, reset the burner, and then repeat the start-up operation. And so on.

After 5 or 6 starting operations allow 2 or 3 minutes for the transformer to cool.


Do not light the flame sensor in order to prevent the burner lockout; the burner locks out in any case about ten seconds after its start.



The above-mentioned operation is possible because the pump is already full of fuel when it leaves the factory.

If the pump has been drained, fill it with fuel through the opening on the vacuummeter 3)(Fig. 22) prior to starting; otherwise, the pump will seize.

Whenever the length of the suction piping exceeds 20-30 meters, the supply line must be filled using a separate pump.



20172792

Fig. 22

- 1 Suction line
- 2 Return line
- 3 Vacuummeter connection
- 4 Pressure gauge connection
- 5 Pressure adjustment

5.13 Electrical connections

Notes on safety for the electrical wiring



DANGER

- The electrical wiring must be carried out with the electrical supply disconnected.
- Electrical wiring must be made in accordance with the regulations currently in force in the country of destination and by qualified personnel. Refer to the wiring diagrams.
- The manufacturer declines all responsibility for modifications or connections different from those shown in the wiring diagrams.
- Check that the electrical supply of the burner corresponds to that shown on the identification label and in this manual.
- The burner has been type-approved for intermittent use. This means they should compulsorily be stopped at least once every 24 hours to enable the flame control to perform checks of its own start-up efficiency. Normally, burner stopping is guaranteed by the boiler's thermostat/pressure switch.
- If this is not the case, a time switch should be fitted in series to TL to stop the burner at least once every 24 hours. Refer to the wiring diagrams.
- The electrical safety of the device is obtained only when it is correctly connected to an efficient earthing system, made according to current standards. It is necessary to check this fundamental safety requirement. In the event of doubt, have the electrical system checked by qualified personnel. Do not use the gas tubes as an earthing system for electrical devices.
- The electrical system must be suitable for the maximum power absorption of the device, as indicated on the label and in the manual, checking in particular that the section of the cables is suitable for that level of power absorption.
- For the main power supply of the device from the electricity mains:
 - do not use adapters, multiple sockets or extensions;
 - make provisions for an omnipolar switch with a gap between the contacts of at least 3 mm (over-voltage category III), as required by current safety regulations.
- Do not touch the device with wet or damp body parts and/or in bare feet.
- Do not pull the electric cables.

Before carrying out any maintenance, cleaning or checking operations:



DANGER

Disconnect the electrical supply from the burner by means of the system main switch.



DANGER

Close the fuel shut-off valve.



DANGER

Avoid condensate, ice and water leaks from forming.

If the cover is still present, remove it and proceed with the electrical wiring according to the wiring diagrams.

Use flexible cables according to EN 60 335-1 standard.

5.14 Calibration of the thermal relay

The thermal relay (Fig. 23) serves to avoid damage to the motor due to an excessive absorption increase or if a phase is missing. For calibration 2), refer to the table indicated in the electrical layout (electrical wiring by the installer).

To reset, in case of an intervention of the thermal relay, press button "RESET" 1). In case of 230V power supply, change the motor connection from star to delta and replace the thermal relay with the one supplied with the burner.

The button "STOP" 3) opens the NC contact (95-96) and stops the motor.

Insert a screwdriver in the window "TEST/TRIP" 4) and move it in the arrow direction (to the right) to carry out the thermal relay test.




Fig. 23



The automatic reset can be dangerous. This operation is not foreseen in the burner operation.

5.15 Motor rotation

As soon as the burner starts, place yourself in front of the cooling fan of the fan motor and check that it turns anticlockwise (Fig. 24).

If this is not the case:

- put the switch of the burner to "0" (off) and wait until the flame control carries out the switching off phase.



Disconnect the electrical supply from the burner by means of the system main switch.

- Invert the phases on the three-phase motor power supply.




Fig. 24

6 Start-up, calibration and operation of the burner

6.1 Notes on safety for the first start-up



The first start-up of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



Check the correct working of the adjustment, command and safety devices.

6.2 Adjustments prior to ignition

The optimum calibration of the burner requires an analysis of the flue gases at the boiler outlet and interventions on the following points.

6.2.2 Pump pressure

The pump leaves the factory set at 25 bar. It is activated by loosening the vacuumeter connection plug. See information on page 23.

6.2.1 Nozzle

See information on page 18.

6.3 Maximum fuel flow rate adjustment

It is carried out by choosing the right nozzle in Tab. K:

Model	Nozzle BERGONZO B5	Output Maximum flow rate kg/h	Fuel pressure at pressure gauge delivery bar	Fuel maximum pressure at pressure gauge return bar
140	150	150	25	24.5
	125	125	25	24.8
	100	100	25	24
	90	90	25	21
	80	80	25	22.5
200	200	200	25	24
	175	175	25	24.5
	150	150	25	24.5
	125	125	25	24.8
	100	100	25	24
300	300	300	25	24
	275	275	25	23.5
	250	250	25	25
	225	225	25	24
	200	200	25	24
	175	175	25	24.5
	150	150	25	24.5
450	450	450	25	22.5
	400	400	25	23.5
	350	350	25	23.5
	325	325	25	24
	300	300	25	24
	275	275	25	23.5
	250	250	25	25
	225	225	25	24

Tab. K

NOTE:

25 bar for fluid oil - up to 30 bar for thick oil (viscosity $\geq 20^{\circ}\text{E}$ at 50°C).

If you want a maximum flow rate somewhere between the two values shown in the table, select a nozzle with a higher flow rate.

Flow rate can be decreased at a later time by acting on the pressure variator, as specified in page 27.



To prevent clogging, remove the filter from the nozzle.

6.4 Pressure variator adjustment

The pressure variation on the return line (pressure gauge, 3) Fig. 25 on page 27) changes the flow rate of the fuel coming out of the nozzle.

6.4.1 Pressure variator

To calibrate the eccentric 8), proceed as follow:

remove the cover 9), loosen the screws 7), turn the screw 4) until the desired eccentricity is obtained. By turning screw 4) to the right (+) the eccentricity increases, thereby increasing the difference between the maximum and minimum capacity of the nozzle. By turning screw 4) to the left (-) the eccentricity decreases, thereby decreasing the difference between the maximum and minimum capacity of the nozzle.

- For a correct calibration, the eccentric 8) must operate on the entire range of travel of the servomotor ($20^\circ \div 130^\circ$): a pressure variation must correspond to each servomotor variation.
- Never drive the variator piston fully home: the stop ring 5) determines the maximum stroke.
- At the end of the adjustment, manually check that between 20° and 130° there is no sticking and that the maximum and minimum pressures correspond to the one selected according the diagram of page 19.

To control the outlet delivery of the nozzle, proceed as follows:

- open the burner following the instructions of page 17, connect a pipe to the nozzle, simulate the ignition and proceed with the weighing at the maximum and minimum pressures.

If at the maximum delivery of the nozzle (maximum pressure on the return line) pressure oscillations can be seen on the pressure gauge 3), slightly reduce the pressure until they disappear (Fig. 25).




Fig. 25

Key (Fig. 25)

- 1 Pressure switch connection
- 2 Delivery pressure gauge
- 3 Return pressure gauge
- 4 Eccentric adjustment screw
- 5 Piston stop ring
- 6 Piston calibration nut and lock nut
- 7 Eccentric locking screws
- 8 Variable eccentric
- 9 Cover

6.5 Combustion head adjustment

The adjustment of the combustion head is obtained in function of the maximum output indicated in the diagrams.

Example with PRESS 140 P/N burner:

The burner must be combined with a 1,100,000 kcal/h boiler.
 Considering a 90% efficiency, it is required to develop 1,450 kW, namely to burn approximately 125 kg/h.
 Diagram in Fig. 15 on page 19 shows that with an average delivery pressure of 25 bar, you obtain for 125 kg/h:
 – nozzle type W2 - 130 - 50°
 – maximum pressure on return line of 19.2 bar.

Diagram Fig. 27 shows that the combustion head must be adjusted to notch **8.5**.

Burner	140	200	300	450
Notch	8.5	8	7	5.5

The adjustment is performed by turning the screw **A** until the notch, shown in the diagram, matches the surface of bush **B**.




Fig. 26




Fig. 27




Fig. 28




Fig. 29




Fig. 30

6.6 Air damper setting

The setting of the air damper is carried out by acting on the variable profile cam 1)(Fig. 31). This operation must be performed after regulating the pressure variator and the combustion head. With burner on, disconnect the servomotor from the power supply and release it manually by pressing the release button placed on the lower side.

Maximum output adjustment

Set the servomotor to 130°, lock it and change the profile 4) by gradually acting on the screws 2)(Fig. 31).

Minimum output adjustment

Unlock the servomotor again, set it manually to 20°, lock it and adjust the profile 4)(Fig. 31) by gradually acting on the screws 2).

Intermediate output adjustments

They are carried out in the same manner.

At the end of the operation, check all calibrations, restore the electrical connections of the servomotor and lock the adjustment screws 2) by means of the transversal screws 3).

6.6.1 Variation of the air damper tie-rod length

Lengthening the tie-rod is recommended when the air damper moves within a reduced angle (air damper approx. halfway its stroke at the maximum output). In this way, a too curved cam profile 4)(Fig. 31) can be avoided.

With the burner off, proceed as follows:

- disengage the articulated coupling 2)(Fig. 32) from the lever 1);
- loosen the extension 3) from the tie-rod 4) by some turns;
- reconnect the articulated coupling to the lever and lift the profile 4) until setting the index of the air damper to 0 with servomotor at 0°.





Fig. 31

- 1 - Cam
- 2 - Adjustment screws
- 3 - Locking screws
- 4 - Adjustable profile



D2004

Fig. 32

6.7 Atomising temperature setting

6.7.1 Minimum - maximum temperature - setting thermostat

The electronic setting thermostat, by means of a PT100 probe immersed in the fuel oil delivery manifold, adjusts the atomising temperature. (For a correct atomisation, see the temperature/viscosity diagram Fig. 34).

Example:

a fuel oil 7 °E at 50 °C must be pre-heated to about 110 °C.

NOTE:

The temperature set on the thermostat corresponds to the fluid temperature, check in any case the correspondence using the thermometer after a few minutes of operation. The LED on indicates that heating elements are correctly enabled.

The minimum temperature thermostat, besides stopping the burner in the case that the fuel temperature drops below a critical value, in order to ensure a good combustion, enables the burner start-up phase. (It is factory set at about 80 °C and can be adjusted by removing the pre-heater cover and the relevant plate).

The maximum temperature thermostat disables heating elements when, due to a fault of the setting thermostat, a significant increase is detected in the pre-heater temperature; any alarm (high temperature) is provided on the burner terminal strip. (It is factory set at 180°C).

Replacing minimum and maximum temperature thermostats

Reposition the probes of the new thermostats after having loosened the fastening screws of the plate pack, making sure that the probe is in contact with the pipes and the heating element as shown in the figure on the side. Use the same precautions for the replacement of heating elements in contact with thermostat probes. In case of malfunction, check the continuity of the heating elements in contact with temperature probes using an ohmmeter (value of approximately 35 Ohm).

Replacing PT100 probe in the delivery manifold

Insert nut and bicone connection (supplied as standard) in the new heating element and insert it into the manifold connection by approximately 40 mm, then tighten strongly. The external part can be folded as required (without damaging the heating element).




Fig. 33




Fig. 34




Fig. 35




Fig. 36

6.8 Servomotor adjustment

The servomotor adjusts simultaneously, through driving gears, the output and pressure of the air and the delivery of the fuel in use. It performs a 135° rotation in 45s. After the adjustment made in the factory to its 6 cams to allow an initial ignition.

Check that they are as shown below.

In the event of a modification, follow what is described below for each cam:




Fig. 37

Cam I (RED): **135°** (The same for all models).
Limits rotation toward maximum position.



Do not make any adjustments.

ATTENTION

Cam II (BLUE): **0°** (The same for all models).
Limits rotation toward minimum position. With the burner off, the air damper is completely closed: 0°



It is recommended that no adjustments are made.

ATTENTION

Cam III: Not used.
Cam IV: Not used.

Cam V (BLACK): **20°** (The same for all models).
Adjusts the ignition position and the minimum output.

Cam VI (GREEN): **130°** (The same for all models).
Adjusts the position of the maximum output.

6.9 Pressure switch adjustment

6.9.1 Oil pressure switch

It triggers the lockout condition of the burner in case of too much counter-pressure on the fuel return line.

Recommended calibration (recommended values with return line resistance in tank of ≤ 0.5 bar): **3.0 ÷ 3.5 bar**.

In case of flame control lockout (in position "P") calibrate the pressure switch again with incremental values of 0.5 bar.


6.9.2 Air pressure switch

Adjust the air pressure switch after performing all other burner adjustments with the air pressure switch set to the start of the scale (Fig. 39).

With the burner operating in 1st stage, increase adjustment pressure by slowly turning the relevant knob clockwise until the burner locks out.

Then turn the knob anticlockwise by about 20% of the set point and repeat burner start-up to ensure it is correct.

If the burner locks out again, turn the knob slightly anticlockwise.



20211345

Fig. 38




ATTENTION

As a rule, the air pressure switch must limit the CO in the fumes to less than 1% (10,000 ppm).

To check this, insert a combustion analyser into the chimney, slowly close the fan suction inlet (for example with cardboard) and check that the burner locks out, before the CO in the fumes exceeds 1%.

The incorporated air pressure switch can work in a 'differential' mode if connected with two pipes. If a strong depression in the combustion chamber during the pre-purging phase does not allow the air pressure switch to switch, this can be obtained by applying a second tube between the air pressure switch and the suction inlet of the fan. In this way, the pressure switch will work in differential mode.



D3854

Fig. 39



ATTENTION

The use of the air pressure switch with differential operation is allowed only in industrial applications and where rules enable the air pressure switch to control only fan operation without any reference to CO limit.




ATTENTION

Connecting the air pressure switch in differential mode, the burner will no longer be certified according to the EN 267 standard.

6.10 Operation sequence of the burner

6.10.1 Burner start-up program



* Adjustable from the timer

Fig. 40

6.11 Final checks

- **Block the flame sensor and turn off the remote controls:** the burner must start and then stop in lockout after approximately 5 s after start-up.
- **Free the flame sensor and turn off the remote controls:** the burner must stop in lockout.
- **Block the flame sensor when the burner is operating:** the flame must turn off and the burner stop in lockout within 3 s.
- **Turn on the remote control TL followed by TS while the burner is operating:** the burner must stop.



Make sure that the mechanical locking systems on the adjustment devices are fully tightened.

7 Maintenance

7.1 Notes on safety for the maintenance

The periodic maintenance is essential for the good operation, safety, yield and duration of the burner.

It allows you to reduce consumption and polluting emissions and to keep the product in a reliable state over time.



The maintenance interventions and the calibration of the burner must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

Before carrying out any maintenance, cleaning or checking operations:



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.



Wait for the components in contact with heat sources to cool down completely.

7.2 Maintenance programme

7.2.1 Maintenance frequency



The gas combustion system should be checked at least once a year by a representative of the manufacturer or another specialised technician.

7.2.2 Checking and cleaning



The operator must use the required equipment during maintenance.

Combustion

Carry out an analysis of the combustion flue gases. Significant differences with respect to the previous measurements indicate the points where more care should be exercised during maintenance.

If the combustion values measured before starting maintenance do not comply with applicable Standards or do not indicate efficient combustion, consult the table below or contact our Technical Support Service to implement the necessary adjustments.

EN 267	Air excess		CO
	Max. output $\lambda \leq 1.2$	Min. output $\lambda \leq 1.3$	
Theoretical max CO ₂ 0 % O ₂	CO ₂ % Calibration		mg/kWh
	$\lambda = 1.2$	$\lambda = 1.3$	
15.2	12.6	11.5	≤ 100

Tab. L

Burner

Make sure that the screws are well secured.

Combustion head

Check to make sure that all the parts of the combustion head are in good condition, positioned correctly, free of all impurities, and that no deformation has been caused by operation at high temperatures.

Nozzle

It is advisable to replace nozzles once a year during periodical maintenance.

Do not clean the nozzle openings.

Flexible hoses

Check to make sure that the hoses are still in good condition.

Fuel tank

Approximately every 5 years, or whenever necessary, suck any water or other impurities present on the bottom of the tank using a separate pump.

Pump

The delivery pressure must be stable at 20 bar.

The depression must be less than 0.45 bar.

Unusual noise must not be evident during pump operation.

If the pressure is unstable, or the pump runs noisily, the flexible hose must be detached from the line filter and the fuel must be sucked from a tank located near the burner.

This measure permits the cause of the anomaly to be traced to either the suction piping or the pump.

If the pump is found to be responsible, check to make sure that the filter is not dirty. The vacuumeter is installed upstream from the filter and consequently will not indicate whether the filter is clogged or not.

Contrarily, if the problem lies in the suction line, check to make sure that the filter is clean and that air is not entering the piping.

Actions on the nozzle holder

After any disassembly of the nozzle holder, it is necessary to correctly calibrate the shaft that controls the nozzle rod. With a nozzle fitted, screw the fork 1)(Fig. 41) by hand until any gap is eliminated, without tensioning the shaft 3); now unscrew the fork by a turn and lock it with the nut 2).

NOTE:

For "BERGONZO" nozzles unscrew the fork by 2 turns.




Fig. 41

Electrical current to flame sensor (Fig. 42)

Clean the glass cover from any dust that may have accumulated. To remove the sensor pull it outwards with force; it is inserted only by pressure.

Min. value for a good work: 70 µA.

If the value is lower, it could be due to:

- exhausted sensor;
- low voltage (lower than 187 V);
- bad regulation of the burner;

In order to measure the current, use a microammeter of 100 µA d.c., connected in series to the sensor, as in the scheme, with a capacitor of 100 µF - 1V d.c. at the same level of the instrument.




Fig. 42

7.2.3 Safety components

The safety components should be replaced at the end of their life cycle indicated in the following table.

The specified life cycles do not refer to the warranty terms indicated in the delivery or payment conditions.

Safety component	Life cycle
Flame control	10 years or 250.000 operation cycles
Flame sensor	10 years or 250.000 operation cycles
Gas valves (solenoid)	10 years or 250.000 operation cycles
Pressure switches	10 years or 250.000 operation cycles
Pressure adjuster	15 years
Servomotor (electronic cam)	10 years or 250.000 operation cycles
Oil valve (solenoid)	10 years or 250.000 operation cycles
Oil regulator	10 years or 250.000 operation cycles
Pipes/ oil fittings (metallic)	10 years
Fan impeller	10 years or 500.000 start-ups

Tab. M

7.3 Opening the burner



Disconnect the electrical supply from the burner by means of the system main switch.



Wait for the components in contact with heat sources to cool down completely.



Close the fuel shut-off valve.

To open the burner, proceed as indicated in paragraph "Securing the burner to the boiler" on page 17.

7.4 Closing the burner

Refit following the steps described but in reverse order; refit all burner components as they were originally assembled.




After carrying out maintenance, cleaning or checking operations, reassemble the cover and all the safety and protection devices of the burner.

8 Faults - Possible causes - Solutions

The flame control is equipped with a lockout indicator (Fig. 43) that turns during the start-up programme, and is visible from the small lockout window.

When the burner does not start or stops, due to a failure, the symbol that appears on the indicator indicates the type of interruption. The positions of the lockout indicator are shown in Fig. 44.



Lockout indicator

- a-b Start-up sequence
- b(b') Idle stages (without contact confirmation)
- b(b')-a Post-purging programme

Fig. 43




Fig. 44

Fuse replacement

The fuse 2)(Fig. 45) is in the rear part of the flame control. A spare fuse 1) is also available: it can be extracted after breaking the panel tab A) that houses it. In the event that fuse 2) has been tripped, replace it as shown in Fig. 45.

Find a list of faults, causes and possible solutions for a set of failures that may occur and result in irregular burner operation or no functioning at all.

If a burner malfunction is detected, first of all:

- check that the electrical wiring is adequately connected;
- check whether fuel is delivered;
- check that every adjustment parameter is adequately set.




Fig. 45



ATTENTION

In the event the burner stops, in order to prevent any damage to the installation, do not unblock the burner more than twice in a row. If the burner locks out for a third time, contact the customer service.



DANGER

In the event there are further lockouts or faults with the burner, the maintenance interventions must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

8.1 Light oil operation

Symbol	Problem	Probable cause	Suggested remedy	
◀	The burner does not start	Limiter or safety control device open	Adjust or replace	
		Flame control lockout	Release	
		Fan motor lockout	Release the thermal relay	
		No electrical power supply	Close all switches - check connections	
		No light oil	Check the light oil supply circuit	
		Flame control fuse interrupted	Replace	
		Pump is jammed	Replace	
		Faulty motor remote control switch	Replace	
		Defective flame control	Replace	
		Faulty electrical motor	Replace	
		Defective safety solenoid valve	Replace	
		The burner does not come on and the lockout appears	Flame simulation	Replace the flame control
			Flame sensor short circuit	Replace flame sensor
			Two-phase electrical supply, thermal relay steps in	Reset the thermal relay at return of the three phases
▲	The burner starts but stops at maximum air damper setting	The servomotor contact does not intervene	Adjust cam or replace servomotor	
P	The burner starts and then goes into lockout	Air pressure switch poorly adjusted	Adjust it	
		Pressure switch pressure point pipe blocked	Clean	
■	The burner starts and then goes into lockout	Failure to the flame detection circuit	Replace flame control	
▼	The burner remains in pre-purging phase	The servomotor contact III does not intervene	Adjust cam or replace servomotor	
1	Once the pre-purging and the safety time has elapsed the burner goes into lockout without the flame appearing	No fuel in the tank, or water on the bottom	Refill with fuel, or remove the water	
		Bad head and damper adjustments	Adjust	
		High voltage cable defective or grounded	Replace	
		High voltage cable deformed by high temperature	Replace and protect	
		Bad electrical wiring on valves or transformer	Check	
		Pump unprimed	Prime it	
		Pump suction line connected to return line	Correct connection	
		Soiled filters (nozzle line)	Clean	
		Valves up-line from pump closed	Open them	
		Opposite motor rotation	Change electrical wiring to the motor	
		Light oil solenoid valves do not open	Check connections and solenoids	
		Pilot burner does not work	Check	
		Defective flame control	Replace	
		Ignition electrode incorrectly adjusted	Adjust it	
		Electrode grounded due to broken insulation	Replace	
		Motor/pump coupling broken	Replace	
		Faulty ignition transformer	Replace	
		The flame ignites regularly but the burner goes into lock out at the end of the safety time	Faulty flame sensor or defective flame control	Replace flame sensor or flame control
			Dirty flame sensor	Clean
		Smoke in flame (dark Bacharach)	Little air	Adjust the fan head and damper
Incorrect pump pressure			Adjust	
Nozzle filter clogged			Clean or replace	
Boiler room air vents insufficient			Increase	
Dirty or worn nozzle			Replace	
Flame disk soiled, loose or deformed			Clean it, tighten it or replace it	
	Smoke in flame (yellow Bacharach)	Too much air	Adjust head and air dampers	

Symbol	Problem	Probable cause	Suggested remedy
	Ignition with pulses or flame failure, delayed ignition	Poorly adjusted head	Adjust
		Incorrectly adjusted fan air damper: too much air	Adjust
		Nozzle not fit for burner or boiler	See nozzle table
		Defective nozzle	Replace
		Unsuitable pump pressure	Adjust
		Ignition electrode not adjusted correctly or soiled	Adjust it
		Output during ignition phase is too high	Reduce
	The burner does not pass to the 2nd stage	Remote control device TR fails to close	Adjust or replace
		Defective flame control	Replace
	Uneven fuel supply	Understand whether the cause lies in the pump or the fuel supply system	Supply fuel to the burner from a tank positioned near the burner itself
	Pump rusty on the inside	Water in the tank	Remove the water with a pump
	Noisy pump, unstable pressure	Air has entered the suction line	Block the couplings
		Depression value too high (higher than 35 cm Hg):	
		Excessive difference of level between burner and tank	Power the burner from a loop circuit
		Piping diameter too small	Increase
		Dirty suction line filters	Clean
		Suction line valves closed	Open them
		The paraffin solidifies due to the low temperature	Put additive in the light oil
	Pump unprimes after prolonged pause	Return pipe not immersed in fuel	Bring it to the same height as the suction line
		Air in the suction line	Block the couplings
	Pump leaks light oil	Loss of sealing organ	Replace the pump
	Dirty combustion head	Dirty nozzle or nozzle filter	Replace
		Unsuitable nozzle delivery or angle	See recommended nozzles
		Loose nozzle	Block it
		Environmental impurities on flame stability disc	Clean
		Incorrect head adjustment, or little air	Adjust it, opening the damper
		Blast tube length not suitable for the boiler	Contact the boiler manufacturer
I	Burner goes into lockout during operation	Flame sensor faulty or dirty	Replace it or clean it
		Air pressure switch faulty	Replace

Tab. N

A Appendix - Accessories**Soundproofing box kit**

Burner	Type	dB(A)	Code
PRESS 140 P/N PRESS 200 P/N	C4/5	10	3010404
PRESS 300 P/N PRESS 450 P/N	C7	10	3010376

Kit for modulating operation

The parts to be ordered are two:

- output regulator to be installed to the burner;
- probe to be installed to heat generator.

PARAMETER TO BE CONTROLLED		PROBE		OUTPUT REGULATOR	
Adjustment field		Type	Code	Type	Code
Temperature	- 100...+ 500 °C	PT 100	3010110	RWF50.2 RWF55.5	20100018 20101965
Pressure	0...2.5 bar	Output probe 4...20 mA	3010213		
	0...16 bar		3010214		
	0...25 bar		3090873		

Self-cleaning filter kit

Burner		Code
All models	Diameter 1" 1/2 (60° E at 50°C)	3010022

Burner support kit

Burner	Code
PRESS 300-450 P/N	3000731

Degasser kit

Burner	Code
PRESS 140 P/N PRESS 200 P/N	3000748
PRESS 300 P/N PRESS 450 P/N	3010012

Heavy oil kit

Burner	Code
All models	3000721

Cartridge filter kit

Burner	Code
All models	3005209

Potentiometer kit

Burner	Code
All models	20096322

Spacer kit

Burner	Code
PRESS 140 P/N	3000722
PRESS 200 P/N	3000722
PRESS 300 P/N	3000723
PRESS 450 P/N	3000751

Heavy oil pre-circulation kit

Burner	Code
PRESS 140-200 P/N	3000749
PRESS 300-450 P/N	3000750

Thermal relay kit


Burner	Code
PRESS 300 P/N	20163347


**ATTENTION**

The installer is responsible for the addition of any safety device not foreseen in this manual.


B Appendix - Electrical panel layout


1	Index of layouts
2	Reference indication
3	Functional layout Star/delta start-up
4	Functional layout
5	Functional layout LFL
6	Functional layout LFL
7	Functional layout LFL
8	Electrical wiring that is the responsibility of the installer
9	Electrical wiring that is the responsibility of the installer
10	Functional layout RWF50


2 Reference indication




Per collegamenti elettrici vedere pag. 8
 For electrical wiring to see sheet 8











P 300 - STAR/DELTA START-UP

BU = BLU / BLUE / BLEU / BLAU	YE = GIALLO / YELLOW / JAUNE / GELB	WH = BIANCO / WHITE / BLANC / WEISS	GY = GRIGIO / GREY / GRIS / GRAU	TO = TURCHESE / TURQUOISE / TURKOISE / TURKISBLAU
BK = NERO / BLACK / NOIR / SCHWARZ	GN = VERDE / GREEN / VERT / GRÜN	OG = ARANCIO / ORANGE / ORANGE / ORANGE	PK = ROSA / PINK / ROSE / ROSA	SR = ARGENTO / SILVER / ARGENT / SILBER
BN = MARRONE / BROWN / MARRON / BRAUN	RD = ROSSO / RED / ROUGE / ROT	VT = VIOLETTA / VIOLET / VIOLET / VIOLETT	GD = ORO / GOLD / OR / GOLD	GNTE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN
SCHEMA FUNZIONALE		OPERATIONAL LAYOUT		SCHEMA FONCTIONNEL
				Sheet : 4

Per collegamenti elettrici vedere pag. 8
For electrical wiring to see sheet 8







STAR/DELTA START-UP


BU = BLU / BLUE / BLEU / BLAU	YE = GIALLO / YELLOW / JAUNE / GELB	WH = BIANCO / WHITE / BLANC / WEISS	GY = GRIGIO / GREY / GRIS / GRAU	TO= TURCHESE / TURQUOISE / TURKOISE / TURKISBLAU
BK = NERO / BLACK / NOIR / SCHWARZ	GN = VERDE / GREEN / VERT / GRÜN	OG= ARANCIO / ORANGE / ORANGE / ORANGE	PK= ROSA / PINK / ROSE / ROSA	SR= ARGENTO / SILVER / ARGENT / SILBER
BN = MARRONE / BROWN / MARRON / BRAUN	RD = ROSSO / RED / ROUGE / ROT	VT= VIOLETTO / VIOLET / VIOLET / VIOLETT	GO= ORO / GOLD / OR / GOLD	GNVE= GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN

SCHEMA FUNZIONALE LFL1335 OPERATIONAL LAYOUT LFL1335 FUNKTIONSSCHEMA LFL1335 SCHEMA FONCTIONNEL LFL1335

Sheet : 5







Sheet : 7


SCHEMA FONCTIONNEL LFL1.335

FUNKTIONSSCHEMA LFL1.335

OPERATIONAL LAYOUT LFL1.335

SCHEMA FUNZIONALE LFL1.335

- BU = BLU / BLUE / BLEU / BLAU
- BK = NERO / BLACK / NOIR / SCHWARZ
- BN = MARRONE / BROWN / MARRON / BRAUN
- YE = GIALLO / YELLOW / JAUNE / GELB
- GN = VERDE / GREEN / VERT / GRÜN
- RD = ROSSO / RED / ROUGE / ROT
- WH = BIANCO / WHITE / BLANC / WEISS
- OG = ARANCIO / ORANGE / ORANGE / ORANGE
- VF = VIOLETT / VIOLET / VIOLET / VIOLETT
- GY = GRIGIO / GREY / GRIS / GRAU
- PK = ROSA / PINK / ROSE / ROSA
- GD = ORO / GOLD / OR / GOLD
- WH = BIANCO / WHITE / BLANC / WEISS
- OG = ARANCIO / ORANGE / ORANGE / ORANGE
- VF = VIOLETT / VIOLET / VIOLET / VIOLETT
- GY = GRIGIO / GREY / GRIS / GRAU
- PK = ROSA / PINK / ROSE / ROSA
- GD = ORO / GOLD / OR / GOLD
- TO = TURCHESE / TURQUOISE / TURQUOISE / TURKISBLAU
- SR = ARGENTO / SILVER / ARGENT / SILBER
- GNV = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN



⚠

NEL CASO DI INTERRUPTORE MAGNETOTERMICO SCEGLIERE IL TIPO C
WITH A MAGNETO-THERMAL SWITCH CHOOSE TYPE C
IM FALLE EINES MAGNETOTHERMISCHEN SCHALTERS TYP C WÄHLEN
EN CAS D' INTERRUPTEUR MAGNÉTOHERMIQUE CHOISIR LE TYPE C

	P 140 P/N	P 140 P/N	P 140 P/N
FU	400V	230V	
S	8A aM 12A gG	12A aM 20A gG	
MV	1.5 mm ²	2.5 mm ²	
F1	3 kW 6.6	3 kW MAX	

FAN MOTOR

	P 140 P/N	P 140 P/N
FU1	400V	230V
S1	25A aM 40A gG	40A aM 50A gG
	6 mm ²	10 mm ²

PRE-HEATER TANK

P 140 - DIRECT START-UP

TO= TURKISE / TURQUOISE / TURQUOISE / TURKISBLAU
SR= ARGENTO / SILVER / ARGENT / SILBER
GN= GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN
WH = BIANCO / WHITE / BLANC / WEISS
OG= ARANCIO / ORANGE / ORANGE / ORANGE
VT= VIOLETT / VIOLET / VIOLET / VIOLETT
YE = GIALLO / YELLOW / JAUNE / GELB
GN = NERO / BLACK / NOIR / SCHWARZ
RD = ROSSO / RED / ROUGE / ROT
BU = BLU / BLUE / BLEU / BLAU
BK = NERO / BLACK / NOIR / SCHWARZ
BN = MARRONE / BROWN / BRUN

GY= GRIGIO / GREY / GRIS / GRAU
PK= ROSA / PINK / ROSE / ROSA
GD= ORO / GOLD / OR / GOLD

max 0,5A 230V AC

INDICATORS/ANCILLARIES

ELECTRICAL POWER


TRIGGERING/SAFETY DEVICES


POWER REGULATION WITH 3-POSITION CONTACT


ELECTRICAL POWER PRE-HEATER TANK

COLLEGAMENTI ELETTRICI A CURA DELL' INSTALLATORE ELECTRICAL CONNECTIONS SET BY INSTALLER


IN CASO DI APPLICAZIONE DEL KIT REGOLATORE DI POTENZA RWF50.2
IN CASE OF RWF50.2 OUTPUT POWER REGULATOR APPLICATION
EN CAS D'APPLICATION DU REGULATEUR DE PUISSANCE RWF50.2
BEI ANWENDUNG DES LEISTUNGSREGLEERS RWF50.2







P 300 - DIRECT START-UP



Sheet : 10

8

7

6

5

4

3

2

1

SCHEMA FUNZIONALE RWF50...

BETRIEBSSCHEMA RWF50...

OPERATIONAL LAYOUT

RWF50...

SCHEMA FUNZIONALE RWF50...

BETRIEBSSCHEMA RWF50...

OPERATIONAL LAYOUT

RWF50...

SCHEMA FUNZIONALE RWF50...

BU = BLU / BLUE / BLEU / BLAU
 BK = NERO / BLACK / NOIR / SCHWARZ
 BN = MARRONE / BROWN / MARRON / BRAUN
 YE = GIALLO / YELLOW / JAUNE / GELB
 GN = VERDE / GREEN / VERT / GRÜN
 RD = ROSSO / RED / ROUGE / ROT
 WH = BIANCO / WHITE / BLANC / WEISS
 OG = ARANCIO / ORANGE / ORANGE / ORANGE
 VT = VIOLETTA / VIOLET / VIOLET / VIOLETT
 GY = GRIGIO / GREY / GRIS / GRAU
 PK = ROSA / PINK / ROSE / ROSA
 GD = ORO / GOLD / OR / GOLD
 TO = TURCHESE / TURQUOISE / TURQUOISE / TURKISBLAU
 SR = ARGENTO / SILVER / ARGENT / SILBER
 GNYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN

WIRING DIAGRAM KEY

A1	Flame control
B	Filter to protect against radio disturbance
B1	RWF50 output power regulator
BA	Current input DC 4...20mA
BA1	Current input DC 4...20mA for remote setpoint change
BP	Pressure probe
BP1	Pressure probe
BR	Remote setpoint potentiometer
BT1	Thermocouple probe
BT2	Probe Pt100, 2 wires
BT3	Probe Pt100, 3 wires
BT4	Probe Pt100, 3 wires
BTEXT	External probe for climatic compensation of the set- point
BV	Voltage input DC 0...10V
BV1	Voltage input DC 0...10V for remote setpoint change
C	Suppressor
CN	Servomotor connector
F1	Three-phase line fuses, fan motor thermal relay
F2	Single-phase line fuses
F3	Fan motor thermal relay
FU	Three-phase line fuses
FU1	Three-phase line fuses
K1	Relay
K2	Relay
KT	Timer relay
KL1	Line contactor
KM	Fan motor contactor
KR	Pre-heater contactor
KS1	Star contactor
KT1	Triangle contactor
KST1	Timer
MV	Fan motor
IN	Burner manual stop switch
H	Lockout signalling
H1	Lockout signalling
Q1	Three-phase disconnecting switch
Q3	Three-phase disconnecting switch
Q2	Single-phase disconnecting switch
Q4	Three-phase disconnecting switch
VF	Working valve
PO	Oil pressure switch
TA	Ignition transformer
TE	Electronic thermostat
TM	Maximum temperature thermostat
Tm	Minimum temperature thermostat
TL	Limit thermostat/pressure switch
TS	Safety thermostat/pressure switch
TR	Adjustment thermostat/pressure switch
UV	Flame sensor
XPE	Flame control earth
XRWF	RWF50 terminal board
S	Pre-heater
SA	High oil temperature alarm
SM	Servomotor
VS1	Safety valve 1
VS2	Safety valve 2
X1	Burner terminal strip
XA	Starter terminal strip
XBT4	3-wire probe Pt100 connector
XTB	Burner earth

RIELLO

RIELLO S.p.A.
I-37045 Legnago (VR)
Tel.: +39.0442.630111
[http:// www.riello.it](http://www.riello.it)
[http:// www.riello.com](http://www.riello.com)