

GB **Dual fuel light oil/gas burners**

Progressive two-stage or modulating operation



CODE	MODEL	TYPE
20206345	RLS 1000/M MX	1311 T
20212536	RLS 1200/M MX	1312 T



Translation of the original instructions

1	Information and general warnings.....	3
1.1	Information about the instruction manual	3
1.2	Guarantee and responsibility.....	4
2	Safety and prevention.....	5
2.1	Introduction.....	5
2.2	Personnel training	5
3	Technical description of the burner	6
3.1	Burner designation	6
3.2	Models available.....	6
3.3	Burner categories - Countries of destination	6
3.4	Technical data	7
3.5	Electrical data.....	7
3.6	Maximum dimensions.....	8
3.7	Firing rates	9
3.8	Test boiler.....	9
3.9	Burner description	10
3.10	Electrical panel description.....	11
3.11	Burner equipment.....	11
3.12	Flame control (LFL.....)	12
3.13	Servomotor SQM40	13
4	Installation	14
4.1	Notes on safety for the installation	14
4.2	Handling	14
4.3	Preliminary checks	14
4.4	Operating position	15
4.5	Removing the shutter lockout screws.....	15
4.6	Preparing the boiler	15
4.7	Securing the burner to the boiler	16
4.8	Access to head internal part.....	16
4.9	Electrode position.....	16
4.10	Nozzle installation	17
4.11	Combustion head adjustment.....	18
4.12	Light oil supply.....	19
4.13	Pump	21
4.14	Gas supply	22
4.15	Activation of the burner lance.....	25
4.16	Electrical connections.....	26
4.17	Calibration of the thermal relay	27
4.18	Motor rotation	27
5	Start-up, calibration and operation of the burner	28
5.1	Notes on safety for the first start-up	28
5.2	Adjustments prior to ignition (light oil)	28
5.3	Burner ignition (light oil).....	28
5.4	Adjustments prior to ignition (gas).....	29
5.5	Burner start-up (gas)	29
5.6	Burner ignition	29
5.7	Change of fuel	29
5.8	Servomotor adjustment	30
5.9	Combustion air adjustment.....	31

5.10	Burner adjustment and output modulation	32
5.11	Air / fuel adjustment	32
5.12	Pressure switch adjustment	34
5.13	Operation sequence of the burner	35
5.14	Final checks (with burner operating)	36
6	Maintenance	37
6.1	Notes on safety for the maintenance	37
6.2	Maintenance programme	37
6.3	Opening the burner	40
6.4	Closing the burner	40
7	Faults - Possible causes - Solutions	41
7.1	Light oil operation	42
7.2	Gas operation	44
A	Appendix - Accessories	46
B	Appendix - Electrical panel layout	47

1 Information and general warnings

1.1 Information about the instruction manual

1.1.1 Introduction

The instruction manual supplied with the burner:

- is an integral and essential part of the product and must not be separated from it; it must therefore be kept carefully for any necessary consultation and must accompany the burner even if it is transferred to another owner or user, or to another system. If the manual is lost or damaged, another copy must be requested from the Technical Assistance Centre of the area;
- is designed for use by qualified personnel;
- offers important indications and instructions relating to the installation safety, start-up, use and maintenance of the burner.

Symbols used in the manual

In some parts of the manual you will see triangular DANGER signs. Pay great attention to these, as they indicate a situation of potential danger.

1.1.2 General dangers

The **dangers** can be of **3 levels**, as indicated below.



Maximum danger level!
This symbol indicates operations which, if not carried out correctly, cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause damage to the machine and/or injury to people.

1.1.3 Other symbols



DANGER: LIVE COMPONENTS
This symbol indicates operations which, if not carried out correctly, lead to electric shocks with lethal consequences.



DANGER: FLAMMABLE MATERIAL
This symbol indicates the presence of flammable materials.



DANGER: BURNING
This symbol indicates the risks of burns due to high temperatures.



DANGER: CRUSHING OF LIMBS
This symbol indicates the presence of moving parts: danger of crushing of limbs.



WARNING: MOVING PARTS

This symbol indicates that you must keep limbs away from moving mechanical parts; danger of crushing.



DANGER: EXPLOSION

This symbol signals places where an explosive atmosphere may be present. An explosive atmosphere is defined as a mixture - under atmospheric conditions - of air and flammable substances in the form of gases, vapours, mist or dust in which, after ignition has occurred, combustion spreads to the entire unburned mixture.



PERSONAL PROTECTION EQUIPMENT

These symbols indicate the equipment that must be worn and kept by the operator for protection against threats against safety and/or health while at work.



OBLIGATION TO ASSEMBLE THE COVER AND ALL THE SAFETY AND PROTECTION DEVICES

This symbol signals the obligation to reassemble the cover and all the safety and protection devices of the burner after any maintenance, cleaning or checking operations.



ENVIRONMENTAL PROTECTION

This symbol gives indications for the use of the machine with respect for the environment.



IMPORTANT INFORMATION

This symbol indicates important information that you must bear in mind.

- This symbol indicates a list.

Abbreviations used

Ch.	Chapter
Fig.	Figure
Page	Page
Sec.	Section
Tab.	Table

1.1.4 Delivery of the system and the instruction manual

When the system is delivered, it is important that:

- the instruction manual is delivered to the user by the system manufacturer, with the recommendation to keep it in the room where the heat generator is to be installed.
- The instruction manual shows:
 - the serial number of the burner;

.....

- the address and telephone number of the nearest Assistance Centre;

.....
.....
.....

- The system supplier must carefully inform the user about:
 - the use of the system;
 - any further tests that may be required before activating the system;
 - maintenance, and the need to have the system checked at least once a year by a representative of the manufacturer or another specialised technician.To ensure a periodic check, the manufacturer recommends the drawing up of a Maintenance Contract.

1.2 Guarantee and responsibility

The manufacturer guarantees its new products from the date of installation, in accordance with the regulations in force and/or the sales contract. At the moment of the first start-up, check that the burner is integral and complete.



WARNING

Failure to observe the information given in this manual, operating negligence, incorrect installation and carrying out of non authorised modifications will result in the annulment by the manufacturer of the guarantee that it supplies with the burner.

In particular, the rights to the guarantee and the responsibility will no longer be valid, in the event of damage to things or injury to people, if such damage/injury was due to any of the following causes:

- incorrect installation, start-up, use and maintenance of the burner;
- improper, incorrect or unreasonable use of the burner;
- intervention of unqualified personnel;
- carrying out of unauthorised modifications on the equipment;
- use of the burner with safety devices that are faulty, incorrectly applied and/or not working;
- installation of untested supplementary components on the burner;
- powering of the burner with unsuitable fuels;
- faults in the fuel supply system;
- continuation of use of the burner when a fault has occurred;
- repairs and/or overhauls incorrectly carried out;
- modification of the combustion chamber with inserts that prevent the regular development of the structurally established flame;
- insufficient and inappropriate surveillance and care of those burner components most likely to be subject to wear and tear;
- use of non-original components, including spare parts, kits, accessories and optional;
- force majeure.

The manufacturer furthermore declines any and every responsibility for the failure to observe the contents of this manual.

2 Safety and prevention

2.1 Introduction

The burners have been designed and built in compliance with current regulations and directives, applying the known technical safety rules and envisaging all the potential danger situations.

It is necessary, however, to bear in mind that the imprudent and clumsy use of the equipment may lead to situations of death risk for the user or third parties, as well as the damaging of the burner or other items. Inattention, thoughtlessness and excessive confidence often cause accidents; the same applies to tiredness and sleepiness.

It is a good idea to remember the following:

- The burner must only be used as expressly described. Any other use should be considered improper and therefore dangerous.

Specifically:

it can be applied to boilers operating with water, steam, diathermic oil, and to other uses expressly named by the manufacturer;

the type and pressure of the fuel, the voltage and frequency of the electrical power supply, the minimum and maximum deliveries for which the burner has been regulated, the pressurisation of the combustion chamber, the dimensions of the combustion chamber and the ambient temperature must all be within the values indicated in the instruction manual.

- Modification of the burner to alter its performance and destinations is not allowed.
- The burner must be used in exemplary technical safety conditions. Any disturbances that could compromise safety must be quickly eliminated.
- Opening or tampering with the burner components is not allowed, apart from the parts requiring maintenance.
- Only those parts envisaged by the manufacturer can be replaced.



The manufacturer guarantees safety and proper operation only if all burner components are intact and correctly positioned.

2.2 Personnel training

The user is the person, body or company that has acquired the machine and intends to use it for the specific purpose. He is responsible for the machine and for the training of the people working around it.

The user:

- undertakes to entrust the machine exclusively to suitably trained and qualified personnel;
- undertakes to inform his personnel in a suitable way about the application and observance of the safety instructions. With that aim, he undertakes to ensure that everyone knows the use and safety instructions for his own duties;
- Personnel must observe all the danger and caution indications shown on the machine.
- Personnel must not carry out, on their own initiative, operations or interventions that are not within their province.
- Personnel must inform their superiors of every problem or dangerous situation that may arise.
- The assembly of parts of other makes, or any modifications, can alter the characteristics of the machine and hence compromise operating safety. The manufacturer therefore declines any and every responsibility for any damage that may be caused by the use of non-original parts.


In addition:



- must take all the measures necessary to prevent unauthorised people gaining access to the machine;
- the user must inform the manufacturer if faults or malfunctioning of the accident prevention systems are noticed, along with any presumed danger situation;
- personnel must always use the personal protective equipment envisaged by legislation and follow the indications given in this manual.

3 Technical description of the burner

3.1 Burner designation



3.2 Models available

Designation	Voltage	Start-up	Code
RLS 1000/M MX TC	3N/400/50	Star/Triangle	20206345
RLS 1200/M MX TC	3N/400/50	Star/Triangle	20212536

Tab. A

3.3 Burner categories - Countries of destination

Country of destination	Gas category
AT - BG - CH - CZ - DK - EE - ES - FI - GB - GR - HU - IE - IS - IT - LT - LV - NO - PT - RO - SE - SI - SK - TR	I ₂ H
DE	I ₂ ELL
NL	I ₂ EK
FR	I ₂ Er
BE	I ₂ E(R)
LU - PL	I ₂ E

Tab. B

3.4 Technical data

Model			RLS 1000/M MX	RLS 1200/M MX
Type			1311 T	1312 T
Output ⁽¹⁾	min - max	kW	1200/3750 ÷ 10600	1500/5500 ÷ 11500
Delivery ⁽¹⁾		kg/h	100/315 ÷ 867	171/462 ÷ 942
Fuels			– Light oil, max. viscosity at 20 °C: 6 mm ² /s (1.5 °E - 6 cSt) – Natural gas: G20 (methane) - G25	
Operation			– Intermittent (min. 1 stop in 24 hours) – Progressive two-stage or modulating by kit (see accessories)	
Pump	Output at 30 bar	kg/h	1400	1826
	Pressure range	bar	9/40	9/40
	Fuel temperature	°C max	140	140
Nozzles			number 1	
Standard applications			Boilers: water, steam, diathermic oil	
Ambient temperature			°C 0 - 50	
Combustion air temperature			°C max 60	
Noise levels ⁽²⁾	Sound pressure	dB(A)	85.4	84.4
	Sound power		96.4	95.4
Weight			500	540
CE			No. CE-0476DQ3601	

Tab. C

- (1) Reference conditions: Ambient temperature 20°C - Gas temperature 15°C - Barometric pressure 1013 mbar - Altitude 0 m a.s.l.
 (2) Sound pressure measured in manufacturer's combustion laboratory, with burner operating on test boiler and at maximum output. The sound power is measured using the "Free Field" method, required by EN 15036 standard, and according to an "Accuracy: Category 3" measurement, as described in EN ISO 3746.

3.5 Electrical data

Model			RLS 1000/M MX	RLS 1200/M MX
Electrical power supply			3N ~ 400V 50 Hz	
Electrical power consumption	Light oil	kW max	27.4	32.9
	Gas		25	28
Protection level			IP 55	

Tab. D

3.6 Maximum dimensions

The dimensions of the burner are given in Fig. 1.

Bear in mind that inspection of the combustion head requires the burner to be opened and the rear part turned on the hinge.

The maximum dimensions of the open burner are indicated by the L and R positions.

The I position is reference for the refractory thickness of the boiler door.




Fig. 1

mm	A	B	C	D	E	F	G	H	I	L	R
RLS 1000/M MX	1637	674	200	413	885	DN80	1206	1338	484	1425	1350
RLS 1200/M MX	1637	658	200	456	885	DN80	1250	1338	465	1425	1350

Tab. E

3.7 Firing rates

The **MAXIMUM OUTPUT** is chosen from within the continuous diagram area (Fig. 2).

The **MINIMUM OUTPUT** must not be lower than the minimum limit of the diagram:

RLS 1000/M MX = 3750 kW

RLS 1200/M MX = 5500 kW



The firing rate value (Fig. 2) has been obtained considering an ambient temperature of 20 °C, an atmospheric pressure of 1013 mbar (approx. 0 m a.s.l.), and with the combustion head adjusted as shown on page 18.




Fig. 2

3.8 Test boiler

The burner/boiler combination does not pose any problems if the boiler is EC approved and its combustion chamber dimensions are similar to those indicated in the diagram (Fig. 3).

If the burner must be combined with a boiler that has not been EC approved and/or its combustion chamber dimensions are clearly smaller than those indicated in the diagram, consult the manufacturer.

The firing rates were obtained in special test boilers, according to EN 676 standard.

In Fig. 3 you can see the diameter and length of the test combustion chamber.

Example:

Output 7000 kW - diameter 120 cm - length 6 m

MODULATING RATIO

The modulating ratio, obtained in test boilers, according to standard (EN 676 for gas, EN 267 for light oil), is of 4:1 for light oil and 7:1 for gas.





Fig. 3

3.9 Burner description



20062788

Fig. 4

- | | |
|---|--|
| 1 Lifting rings | 23 Pump |
| 2 Impeller | 24 Pump motor |
| 3 Fan motor | 25 Maximum oil pressure switch |
| 4 Air damper servomotor | 26 Minimum oil pressure switch |
| 5 Combustion head gas pressure test point | 27 Nozzle return pressure gauge |
| 6 Combustion head | 28 Screws to lock the shutter during transportation (replace them with the M12x25 screws supplied as standard) |
| 7 Ignition pilot | 29 Oil modulator |
| 8 Flame stability disc | 30 Pressure gauge connection |
| 9 Electrical panel casing | 31 Pilot gas train |
| 10 Hinge for opening the burner | 32 3-way valve for the mechanical activation of the burner lance |
| 11 Fan air inlet | |
| 12 Pipe coupling | |
| 13 Gasket for boiler fixing | |
| 14 Gas train flange | |
| 15 Shutter | |
| 16 Combustion head movement lever | |
| 17 Air damper movement levers | |
| 18 Air pressure switch (differential type) | |
| 19 Combustion head air pressure test point | |
| 20 Maximum gas pressure switch with pressure test point | |
| 21 UV cell | |
| 22 Pressure test point for air pressure switch “+” | |



The burner can be opened to the right or to the left without links to the fuel supply side.



The gas can only enter from the left side of the burner as shown in Fig. 4.

3.10 Electrical panel description




Fig. 5

- | | |
|---|---|
| 1 Main terminal supply board | 19 Oil/Gas selection relay |
| 2 Dry contact relay output | 20 Flame sensor plug/sensor socket |
| 3 Ignition transformer | 21 Light signalling of mains live state |
| 4 Stop push-button | 22 Heat request lighting signal |
| 5 OFF-automatic-manual selector | 23 Light signalling of main fuel valve open |
| 6 Power increase - power reduction selector | 24 Terminal board for RWF50 kit |
| 7 Fan/pump motor, motor thermal relay indicator light | |
| 8 Burner lockout warning lamp and reset switch | |
| 9 Flame control | |
| 10 Timer | |
| 11 Air pressure switch | |
| 12 Fan motor contactor and thermal relay, star-triangle starter | |
| 13 Supply cables, external connections and kits | |
| 14 Fuel selector and enable signal to remote fuel selector | |
| 15 Auxiliary circuits fuse | |
| 16 Plug/socket servomotor | |
| 17 Valve/pump motor plug/socket, Pgm (deriv. unit) | |
| 18 Pump motor contactor and thermal relay | |

NOTE

Two types of burner lockout may occur:

- **Flame control lockout:** if the button (red LED) of flame control 9(Fig. 5) and signal button 8) light up, the burner is locked out. Release by pressing button 8).
- **Motor lockout:** release by pressing the button on thermal relay.


3.11 Burner equipment

Gasket for gas train flange	No. 1
Gas flange fixing screws, M 16 x 70.	No. 8
Thermal flange gasket	No. 1
M 12 x 25 screws	No. 2
M 20 x 70 screws to secure the burner flange to the boiler.	No. 4
Light gas flexible hoses	No. 2
Fitting 1" - 3/4" (RLS 1000/M MX)	No. 1
Fitting 1" - 1" 1/2 (RLS 1200/M MX).	No. 1
Fitting 1" - 1/2"	No. 1
Rotating elbow 1" 1/2	No. 1
Instruction.	No. 1
Spare parts list	No. 1



It is recommended to tighten the screws of the gas flange with a tightening torque of:

- DN80: **40 Nm ±10%**
- DN100: **50 Nm ±10%**
- DN125: **60 Nm ±10%**



Tighten the nuts gradually (first to 30%, then to 60% up to 100%) according to the cross pattern shown in the figure.

S10230

3.12 Flame control (LFL...)

Important notes



WARNING

To avoid accidents, material or environmental damage, observe the following instructions!

The flame control LFL1... is a safety device! Avoid opening or modifying it, or forcing its operation. Riello S.p.A. cannot assume any responsibility for damage resulting from unauthorised interventions!

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Before modifying the wiring in the LFL1... flame control connection area, fully disconnect the system from the power supply (omnipolar separation).
- Protection against electrocution from the flame control and all connected electric components is obtained with the correct assembly.
- Before any intervention (assembly and installation operations, assistance, etc.), ensure the wiring is in order and that the parameters are correctly set, then make the safety checks.
- Falls and collisions can negatively affect the safety functions. In this case, the flame control must not be operated, even if it displays no evident damage.
- **Do not press the reset button or the remote reset button of the flame control for more than 10 seconds because this will damage the internal relay.**

For safety and reliability, comply with the following instructions:

- Avoid conditions that can favour the development of condensate and humidity. Otherwise, before switching on again, make sure that the entire flame control is perfectly dry!
- Static charges must be avoided since they can damage the flame control's electronic components when touched.

Use

The LFL1... flame control is a control and supervision system of medium and large capacity forced draft burners for intermittent operation (at least one controlled shutdown every 24 hours).

Installation notes

- Check the electrical wiring inside the boiler complies with the national and local safety regulations.
- Do not confuse the powered conductors with the neutral ones.
- Ensure that spliced wires cannot get into contact with neighbouring terminals. Use adequate ferrules.
- Arrange the H.V. ignition cables separately, as far as possible from the flame control and the other cables.
- When wiring the unit, make sure that AC 230 V mains voltage cables are run strictly separate from extra low-voltage cables to avoid risks of electrical shock hazard.




Fig. 6

Electrical wiring of the flame detector

It is important for signal transmission to be almost totally free of any disturbances or loss:

- Always separate the detector cables from the other cables:
 - The capacitive reactance of the line reduces the size of the flame signal.
 - Use a separate cable.
- Respect the allowed cable lengths.
- The ionisation probe is not protected against the risk of electrocution. When connected to the electricity supply, the ionisation probe must be protected against any accidental contact.
- Position the ignition electrode and the ionisation probe so that the ignition spark cannot form an arc on the probe (risk of electric overcharge).

Technical data

Mains voltage	AC 230 V -15 % / +10 %
Mains frequency	50 / 60 Hz ±6 %
Fuse (Internal)	T6.3H250V
Primary fuse (external)	max. 10 A
Weight	approx. 1 kg
Power absorption	approx. AC 3.5 VA
Protection level	IP40
Safety class	II
Input current at terminal 1	max. 5 A continuous (peaks of 20 A / 20 ms)
Load on the control terminals	max. 4 A continuous (peaks of 20 A / 20 ms)
Environmental conditions	
Operation	DIN EN 60721-3-1
Climatic conditions	Class 1K3
Mechanical conditions	Class 1M2
Temperature range	-20...+60°C
Humidity	< 95% RH

Tab. F

3.13 Servomotor SQM40 ...

Important notes



To avoid accidents, material or environmental damage, observe the following instructions!
 Avoid opening, modifying or forcing the servomotor.

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Falls and collisions can negatively affect the safety functions. In this case, the servomotor must not be operated, even if it displays no evident damage.
- Fully disconnect the burner from the mains when working near terminals and servomotor connections.
- Condensation and exposure to water are not allowed.
- For safety reasons, the servomotor must be checked after long periods of non-use.



S8907

Fig. 7

Technical data

Mains voltage	230 V -15% +10%
Mains frequency	50 / 60 Hz
Power absorption	10 VA
Motor	Synchronous
Drive angle	Varying between 0° and 135°
Protection level	Max. IP 66, with appropriate cable entry
Cable entry	2 x M20
Cable connection	terminal board for 0.5mm ² (min.) and 2.5mm ² (max.)
Rotation direction	Anticlockwise
Rated torque (max.)	10 Nm
Holding torque	5 Nm
Operation time	30 s. at 90°
Weight	approx. 2 kg
Environmental conditions:	
Operation	-20...+60° C
Transport and storage	-20...+60° C

Tab. G

4.4 Operating position



- The burner is designed to operate only in positions **1**, **2**, **3** and **4** (Fig. 9).
- Installation **1** is preferable, as it is the only one that allows the maintenance operations as described in this manual.
- Installations **2**, **3** and **4** allow operation but make maintenance and inspection of the combustion head more difficult.



- Any other position could compromise the correct operation of the appliance.
- The installation **5** is prohibited for safety reasons.




Fig. 9

4.5 Removing the shutter lockout screws

Remove the screws 1)-2) and nuts before fitting the burner onto the boiler (Fig. 10).
Replace them with the screws 3) M12x25 supplied as standard.




Fig. 10

4.6 Preparing the boiler

4.6.1 Boring the boiler plate

Pierce the closing plate of the combustion chamber, as in Fig. 11.
The position of the threaded holes can be marked using the thermal insulation screen supplied with the burner.




Fig. 11

mm	A	B	C
RLS 1000/M MX	460	608	M 20
RLS 1200/M MX	500	608	M 20

Tab. H

4.6.2 Blast tube length

The length of the blast tube must be selected according to the indications provided by the manufacturer of the boiler, and in any case it must be greater than the thickness of the boiler door complete with its fettling.

For boilers with front flue passes 1)(Fig. 12) or flame inversion chamber, a protection in refractory material 5) must be inserted between the boiler fettling 2) and the blast tube 4).

This protection must not compromise the extraction of the blast tube.

4.7 Securing the burner to the boiler



Prepare a suitable lifting system using rings 3)(Fig. 12).

- Fit the heat insulation supplied onto the blast tube 4).
- Fit the entire burner onto the boiler hole prepared previously, as in Fig. 11, and fasten with the screws supplied.



WARNING

The seal between burner and boiler must be airtight.




Fig. 12

4.8 Access to head internal part

In order to reach inside the combustion head (Fig. 13) proceed as follows:

- disconnect the electrical connections of the servomotor pump motor derivation unit;
- disconnect the levers related to the cam and the movement of the head 12);
- unscrew the 4 fixing screws 1) and open the burner on the hinge;
- disconnect the cable 14) from the electrode 2);
- disconnect the light oil pipes unscrewing the two pipe fittings 3).



Be careful as some drops of fuel may leak out during this phase.

- Release the ignition pilot fitting 13);
- remove the gas pressure screw/test point 6) of the head;
- unscrew the locking screw of the oil lance 9) and extract the oil lance from the combustion head 10);
- pull out the inner part of the head 5).




Fig. 13

4.9 Electrode position



WARNING

Position the electrode on ignition pilot according to the dimensions shown in Fig. 14.




Fig. 14

4.10 Nozzle installation

The burner complies with the emission requirements of the EN 267 standard. In order to guarantee that emissions do not vary, recommended and/or alternative nozzles specified by Riello in the Instruction and warning booklet should be used.



WARNING

It is advisable to replace the nozzle once a year during periodical maintenance.



CAUTION

The use of nozzles other than those specified by Riello S.p.A. and inadequate regular maintenance may result into emission limits non-conforming to the values set forth by the regulations in force, and in extremely serious cases, into potential hazards to people and objects.

The manufacturing Company shall not be liable for any such damage arising from non-observance of the requirements contained in this manual.

Fit the nozzle with a 24 mm (for RLS 1000/M MX) and 41 mm (for RLS 1200/M MX) box wrench, passing from the centre opening of the flame stability disc (Fig. 15).

Fit the nozzles with the fuel interception rod on the nozzle holder. To calibrate the delivery range of operation of the nozzle, adjust the fuel pressure on the nozzle return line, according to Tab. I.



WARNING

- Do not use any sealing products such as: gaskets, tape or sealants.
- Be careful to avoid damaging the nozzle sealing seat.
- The nozzle must be screwed into place tightly but not to the maximum torque value provided by the wrench.




Fig. 15

4.10.1 Recommended nozzle

Model	Nozzle
RLS 1000/M MX	– Bergonzo type B5 60°
	– Fluidics type W2 60°
RLS 1200/M MX	– Bergonzo type C3 - C5 60°

Complete range of nozzles:

- Bergonzo type B5 60°:
350 - 375 - 400 - 425 - 450 - 475 - 500 - 525 - 550 - 575 - 600 - 650 - 700 - 750 - 800 - 850 - 900.
- Bergonzo type C3 - C5 60°:
700 - 800 - 900 - 1000 - 1100.
- Fluidics type W2 60°:
375 - 400 - 450 - 500 - 550 - 600 - 650 - 700 - 750.

Nozzle	kg/h	Delivery pressure (bar)	Return pressure (bar)	kg/h	kW
Bergonzo B5 60°	350	18	8	100	1200
		20	17.5	315	3750
	600	20	6	140	1675
		22	16	563	6700
	750	20	6.5	180	2150
		22	19	722	8600
900	16	4	168	2000	
	20	15	867	10300	
Bergonzo C3 - C5 60°	700	18	3	172	2043
		20	16	462	5500
	700	18	3	172	2043
		20	19	635	7550
	900	17	5	237	2815
		18	17.5	791	9400
1100	16	6	273	3242	
	18	16.5	961	11425	

Tab. I

4.11 Combustion head adjustment

The air damper servomotor 4)(Fig. 4), beyond varying the air output according to the output demand, through a leverage varies the combustion head adjustment.

This system allows an optimum adjustment also at minimum firing rate.

Similarly to servomotor rotation, it is possible to vary the opening of the combustion head moving the tie-rod on the holes (5-6-7-8-10)(Fig. 16).

The selection of the hole to be used is determined based on the maximum output requested, as illustrated in Tab. J.

In the factory, the hole is adjusted for the maximum stroke (hole 10, Fig. 16).




Fig. 16

	Leverage hole	Output (kW)	
		From	To
RLS 1000/M	5	1200	3750
	5	3750	6700
	8	6700	8600
	8	8600	10600
RLS 1200/M	5	1500	5500
	5	5500	7500
	6	7500	9600
	10	9600	11500

Tab. J



The gas pipes leave the factory calibrated at notch 1.

The adjustment shown in Fig. 17 allows the gas pipes to be positioned in the best way for the application on which the burner is installed (e.g. boilers with flame inversion chamber).




Fig. 17

4.12 Light oil supply



Explosion danger due to fuel leaks in the presence of a flammable source.

Precautions: avoid knocking, attrition, sparks and heat.

Make sure the fuel shut-off valve is closed before performing any operation on the burner.



WARNING

The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.

4.12.1 Double-pipe circuit

The burner is equipped with a self-priming pump which is capable of feeding itself within the limits listed in Tab. K.

Tank higher than burner A (Fig. 18)

The distance "P" must not exceed 10 meters in order to avoid subjecting the pumps seal to excessive strain; the distance "V" must not exceed 4 meters in order to permit pump self-priming even when the tank is almost completely empty.

Tank lower than burner B (Fig. 18)

The pump depression value must not exceed 0.45 bar (35 cm Hg). Because at higher levels gas is released from the fuel; the pump becomes noisy and its lifetime is shortened.

It is good practice to ensure that the return and suction lines enter the burner from the same height; the suction line is more difficult to disconnect.

4.12.2 Loop circuit

The loop circuit is composed of a duct starting from the tank and going back to it, in which an auxiliary pump makes the pressurised fuel flow. A branch from the loop supplies the burner.

This circuit is extremely useful whenever the burner pump does not succeed in self-priming because the tank distance and/or height difference are higher than the values listed in Tab. K.

+/- H [m]	RLS 1000/M MX				RLS 1200/M MX			
	Ø [mm]							
	20	22	24	27	22	24	27	36
4.0	26	45	73	138	19	33	65	300
3.0	22	39	63	120	16	28	55	260
2.0	18	33	53	102	13	23	45	220
1.0	15	26	44	84	10	18	38	185
0.5	13	23	39	75	9	16	33	165
0	11	20	34	66	7	13	30	145
-4.0	-	-	-	-	-	-	-	-
-3.0	-	-	-	12	-	-	-	30
-2.0	-	7	14	30	-	-	11	70
-1.0	7	14	24	48	-	9	20	108
-0.5	9	17	29	57	5	11	25	125
0	11	20	34	66	7	13	29	145

Tab. K




Fig. 18

Key (Fig. 18)

H = Pump/Foot valve height difference

Ø = Inside pipe diameter

1 = Burner

2 = Pump

3 = Filter

4 = Manual on/off valve

5 = Suction line

6 = Foot valve

7 = Quick closing manual valve with remote control (Italy only)

8 = On/off solenoid valve (Italy only). See electrical layout. Connections to be carried out by the installer (SV).

9 = Return line

4.12.3 Hydraulic connections




- Make sure that the hoses to the pump supply and return line are installed correctly.



Follow the instructions below:

- Tighten the flexible hoses with the supplied gaskets.
- During the installation, hoses must not be stressed with twisting.
- Position hoses so that they cannot be stepped on or get into contact with hot parts of the boiler and so that they allow burner opening.
- Finally, connect the other end of the flexible hoses to the suction and return line ducts.

4.12.4 Hydraulic circuit diagram



Key (Fig. 19)

- 1 Pump suction line
- 2 Pump return line and nozzle return line
- 3 Pump pressure regulator
- 4 Delivery safety valve
- 5 Delivery safety valve
- 6 Nozzle delivery line
- 7 Nozzle without interception rod
- 8 Nozzle return line
- 9 Pressure variator on nozzle return line
- 10 Pressure variator servomotor
- 11 Pressure switch on nozzle return line
- 12 Safety valve on nozzle return line
- 13 Safety valve on nozzle return line
- 14 Pressure switch on pump delivery line
- M Pressure gauges
- V Vacuum connection

OPERATION

Pre-purging phase: valves 4), 5), 12) and 13) closed.

Ignition and operation phase: valves 4), 4), 12) and 13) open.

Stop: all valves closed.

4.12.5 Pressure variator

Calibration pressure on return line

With a servomotor position of 20°, the nut and the corresponding lock nut 6)(Fig. 20), are fixed in contact with the eccentric 3). During the rotation towards 130° of the servomotor, the eccentric will push the modulator shaft, taking the pressure, read on the pressure gauge 2)(Fig. 20), to the desired value.

To calibrate the eccentric, loosen screws 7), and turn screw 4) until the desired eccentricity is obtained.

- By turning screw 4) to the right (+) the eccentricity increases, thereby increasing the difference between the maximum and minimum capacity of the nozzle.
- By turning screw 4) to the left (-) the eccentricity decreases, thereby decreasing the difference between the maximum and minimum capacity of the nozzle.

Calibration pressure on delivery line

To adjust the delivery pressure, operate on the pump as described on page 21.

Example:

if you use a 750 kg/h nozzle and you want to obtain an output of 6650 kW, the pressure read on the pressure gauge 3)(Fig. 20) (max. pressure on return circuit) must be approx. 19 bar. Relevant delivery pressure read on the pressure gauge 2), must be 22 bar (see table on page 17).




Fig. 20

Fig. 19

Key (Fig. 20)

- 1 Maximum oil pressure switch
- 2 Return pressure gauge
- 3 Variable eccentric
- 4 Eccentric adjustment screw
- 5 Piston stop ring
- 6 Piston calibration nut and lock nut
- 7 Eccentric locking screws
- 8 Adjustment screw/calibration for maximum oil pressure switch



For a correct calibration, the eccentric 3) must operate on the entire range of travel of the servomotor (20° ÷ 130°): a pressure variation must correspond to each servomotor variation.



Never drive the variator piston fully home: the stop ring 5) determines the maximum stroke.



Screw 8)(Fig. 20) does not need adjusting as it has been calibrated in the factory

To control the outlet delivery of the nozzle, proceed as follows:

- open the burner following the instructions on page 16,
- connect a pipe to the nozzle, simulate the ignition and proceed with the weighing at the maximum and minimum pressures.

If at the maximum delivery of the nozzle (maximum pressure on the return line) pressure oscillations can be seen on the pressure gauge 2), slightly reduce the pressure until they disappear.

NOTE:

The burner is factory calibrated with maximum pressure on the return line of approximately 19.5 bar and delivery pressure of approximately 22 bar.

4.13 Pump

4.13.1 Technical data

Pump	RLS 1000/M MX VBHRG	RLS 1200/M MX VBHGRP
Min. delivery rate at 40 bar pressure	1160 kg/h	1660 kg/h
Delivery pressure range	9 - 40 bar	9 - 40 bar
Max. suction depression	0.6 bar	0.6 bar
Viscosity range	6 - 800 cSt	6 - 800 cSt
Max. light oil temperature	140 °C	140 °C
Max. suction and return pressure	5 bar	5 bar
Pressure calibration in the factory	22 bar	22 bar

Tab. L




Fig. 21

Key (Fig. 21)

- | | |
|-------------------------|-----------------------|
| 1 Suction line | G 3/4" (RLS 1000/M) |
| | G 1" 1/2 (RLS 1200/M) |
| 2 Return line | G 1" |
| 3 Vacuumeter connection | G 1/4" |
| 4 Gauge connection | G 1/4" |
| 5 Pressure adjuster | |

4.13.2 Priming pump



Before starting the burner, make sure that the tank return line is not clogged.

Obstructions in the line could cause the sealing organ located on the pump shaft to break.

- In order for the pump (Fig. 21) to be able to self-prime, the screw 4) must be loosened to purge the air in the suction line.
- Start the burner by closing the remote controls. As soon as the burner starts, check the direction of rotation of the fan blade.
- The pump can be considered to be primed when the light oil starts coming out of the screw 4).
- Close the burner and undo the screws 4).

The time required for this operation depends upon the diameter and length of the suction tubing.

If the pump fails to prime at first start-up and the burner locks out, wait approx. 15 seconds, reset the burner, and then repeat the start-up operation. And so on.

After 5 or 6 starting operations allow 2 or 3 minutes for the transformer to cool.

Do not light the UV cell in order to prevent the burner lockout; the burner locks out in any case about ten second after its start.



The a.m. operation is possible because the pump is already full of fuel when it leaves the factory.

If the pump has been drained, fill it with fuel through the opening on the vacuumeter 4)(Fig. 21) prior to starting; otherwise, the pump will seize.

Whenever the length of the suction piping exceeds 20-30 meters, the supply line must be filled using a separate pump.

4.14 Gas supply



Explosion danger due to fuel leaks in the presence of a flammable source.

Precautions: avoid knocking, attrition, sparks and heat.

Make sure the fuel shut-off valve is closed before performing any operation on the burner.



The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.

4.14.1 Gas feeding line (Example) - Please refer to the gas train documentation for more information




Fig. 22

Key (Fig. 22)

- 1 Manually operated shut-off valve
- 2 Pressure gauge
- 3 Filter
- 4 Governor
- 5a Low pressure protection device
- 5b Maximum gas pressure switch
- 6 1st safety shut-off device
- 7 2nd safety shut-off device
- 8 Ignition device
- 15 Valve leak detection control system
- L Gas train (supplied separately)
- L1 Responsibility of the installer
- L2 Burner
- M1 Pressure test point
- M2 Pressure test point
- M3 Pressure test point

4.14.2 Gas train

Type-approved in accordance with EN 676 and supplied separately from the burner.

4.14.3 Gas train installation



Disconnect the power supply using the system main switch.



Check that there are no gas leaks.



Pay attention when handling the train: danger of crushing of limbs.



Make sure that the gas train is properly installed by checking for any fuel leaks.



The operator must use the required equipment during installation.

The gas train is prearranged to be connected to the burner by the flange 1)(Fig. 23).




Fig. 23

4.14.4 Gas pressure

Tab. M indicates the pressure drops of the combustion head and gas butterfly valve depending on the burner operating output.

	kW	1 Δp (mbar)		2 Δp (mbar)	
		G 20	G 25	G 20	G 25
RLS 1000/M MX	3750	9.2	13.7	1.0	1.4
	4000	10.8	16.0	1.1	1.6
	4500	13.9	20.7	1.4	2.1
	5000	17.0	25.4	1.7	2.5
	5500	20.2	30.1	2.1	3.1
	6000	23.3	34.8	2.4	3.7
	6500	26.4	39.4	2.9	4.3
	7000	30.4	45.3	3.3	5.0
	7500	34.8	51.9	3.8	5.7
	8000	39.2	58.5	4.4	6.5
	8500	43.6	65.1	4.9	7.3
9000	49.2	73.3	5.5	8.2	
9500	55.0	82.0	6.1	9.2	
10000	60.8	90.7	6.8	10.1	
10600	67.8	101.1	7.6	11.4	
RLS 1200/M MX	5500	23.1	34.5	2.1	3.1
	6000	27.9	41.6	2.4	3.7
	6500	32.6	48.7	2.9	4.3
	7000	37.4	55.7	3.3	5.0
	7500	42.1	62.8	3.8	5.7
	8000	48.3	72.1	4.4	6.5
	8500	54.5	81.3	4.9	7.3
	9000	60.7	90.6	5.5	8.2
	9500	67.0	99.8	6.1	9.2
	10000	74.3	110.8	6.8	10.2
	10500	81.9	122.2	7.5	11.2
11000	89.6	133.6	8.2	12.3	
11500	97.2	145.0	9.0	13.4	

Tab. M



Data of head thermal power and gas pressure refer to operation with gas butterfly valve fully open (90°).

The values shown in Tab. M refer to:

- Natural gas G 20 NCV 9.45 kWh/Sm³ (8.2 Mcal/Sm³)
- Natural gas G 25 NCV 8.13 kWh/Sm³ (7.0 Mcal/Sm³)

Column 1

Combustion head pressure drop.

Gas pressure measured at test point 1)(Fig. 24), with:

- combustion chamber at 0 mbar;
- burner working at maximum modulating output;
- combustion head adjusted as in page 18.

Column 2

Pressure drop at gas butterfly valve 2)(Fig. 24) with maximum opening: 90°.

To calculate the approximate output at which the burner operates:

- subtract the combustion chamber pressure from the gas pressure measured at test point 1)(Fig. 24).
- Find in Tab. M on page 23 related to the burner concerned, the pressure value closest to the result of the subtraction.
- Read the corresponding output on the left.

Example RLS 1000/M MX with natural gas G20:

Operation at maximum modulating output

Gas pressure at test point 1)(Fig. 24)	=	44.2 mbar
Pressure in combustion chamber	=	5 mbar
44.2 - 5	=	39.2 mbar

A pressure of 39.2 mbar, column 1, corresponds in the table Tab. M to an output of 8000 kW.

This value serves as a rough guide; the effective output must be measured at the gas meter.

To calculate the required gas pressure at test point 1)(Fig. 24), set the maximum modulating output required from the burner operation:

- find the nearest output value in Tab. M on page 23 for the burner in question.
- Read, on the right (column 1), the pressure at the test point 1)(Fig. 24).
- Add this value to the estimated pressure in combustion chamber.

Example RLS 1000/M MX with natural gas G20:

Operation at maximum modulating output

Gas pressure at an output of 8000 kW	=	39.2 mbar
Pressure in combustion chamber	=	5 mbar
39.2 + 5	=	44.2 mbar

pressure required at test point 1)(Fig. 24).

4.14.5 Pilot - gas train connection

The burner is equipped with a dedicated gas train fixed to the sleeve.

- Connect it to the main gas train, downstream of the filter or pressure adjuster (according to the configuration).

Oil burners (with LPG pilot) can be directly connected to the LPG cylinder.



Supply pressure 68 ± 500 mbar.

4.14.6 Ignition pilot

For proper operation, adjust gas pressure (measured at pressure test point 1)(Fig. 25) as follows:

Model	Gas	mbar	Sm ³ /h
RLS 1000/M MX	G20	1.5	12.3
	G31	1.4	3.2
RLS 1200/M MX	G20	40	14.3
	G31	30	7.1

Tab. N



Check the stability of the pilot flame before igniting the main burner.

In case of ignition problems, check:

- the correct positioning of the ignition electrode;
- the gas pressure, according to the specifications.




Fig. 24





Fig. 25

4.15 Activation of the burner lance

The burner is equipped with a spray lance for light oil.
 Fig. 26 shows the 3-way valve used for the mechanical activation of the burner lance and the point at which the compressed air input A) must be connected.

It must operate at 6 ÷ 7 bar.





Fig. 26

4.16 Electrical connections

Notes on safety for the electrical wiring



- The electrical wiring must be carried out with the electrical supply disconnected.
- Electrical wiring must be made in accordance with the regulations currently in force in the country of destination and by qualified personnel. Refer to the wiring diagrams.
- The manufacturer declines all responsibility for modifications or connections different from those shown in the wiring diagrams.
- Check that the electrical supply of the burner corresponds to that shown on the identification label and in this manual.
- The burner has been type-approved for intermittent use. This means they should compulsorily be stopped at least once every 24 hours to enable the flame control to perform checks of its own start-up efficiency. Normally, burner stopping is guaranteed by the boiler's thermostat/pressure switch.
- If this is not the case, a time switch should be fitted in series to TL to stop the burner at least once every 24 hours. Refer to the wiring diagrams.
- The electrical safety of the device is obtained only when it is correctly connected to an efficient earthing system, made according to current standards. It is necessary to check this fundamental safety requirement. In the event of doubt, have the electrical system checked by qualified personnel. Do not use the gas tubes as an earthing system for electrical devices.
- The electrical system must be suitable for the maximum power absorption of the device, as indicated on the label and in the manual, checking in particular that the section of the cables is suitable for that level of power absorption.
- For the main power supply of the device from the electricity mains:
 - do not use adapters, multiple sockets or extensions;
 - make provisions for an omnipolar switch with a gap between the contacts of at least 3 mm (over-voltage category III), as required by current safety regulations.
- Do not touch the device with wet or damp body parts and/or in bare feet.
- Do not pull the electric cables.

Before carrying out any maintenance, cleaning or checking operations:



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.




Avoid condensate, ice and water leaks from forming.

If the cover is still present, remove it and proceed with the electrical wiring according to the wiring diagrams.

Use flexible cables according to EN 60 335-1 standard.

4.16.1 Supply cables and external connections passage

All the cables to be connected to the burner should be passed through cable grommets, as shown in Fig. 27.



20062902

Fig. 27

Key (Fig. 27)

- 1 Electrical power supply
- 2 Minimum gas pressure switch
- 3 Pressure switch for VPS gas valve leak detection
- 4 Gas train
- 5 Enabling signals / Safety devices
- 6 Available
- 7 Available



After carrying out maintenance, cleaning or checking operations, reassemble the cover and all the safety and protection devices of the burner.

4.17 Calibration of the thermal relay

The thermal relay (Fig. 28) serves to avoid damage to the motor due to an excessive absorption increase or if a phase is missing. For calibration 2), refer to the table indicated in the electrical layout (electrical wiring by the installer).

To reset, in case of thermal relay activation, press the "RESET" button 1).

The button "STOP" 3) opens the NC contact (95-96) and stops the motor.

Insert a screwdriver in the window "TEST/TRIP" 4) and move it in the arrow direction (to the right) to carry out the thermal relay test.



The automatic reset can be dangerous. This operation is not foreseen in the burner operation.




Fig. 28

4.18 Motor rotation

As soon as the burner starts, place yourself in front of the cooling fan of the fan motor and check that it turns anticlockwise (Fig. 29).

If this is not the case:

- put the switch of the burner to "0" (off) and wait until the flame control carries out the switching off phase.



Disconnect the electrical supply from the burner by means of the system main switch.

- Invert the phases on the three-phase motor power supply.




Fig. 29

5 Start-up, calibration and operation of the burner

5.1 Notes on safety for the first start-up



The first start-up of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



Check the correct working of the adjustment, command and safety devices.



Before starting up the burner, refer to section "Safety test - with no gas supply" on page 37.

5.2 Adjustments prior to ignition (light oil)



It is recommended to adjust first the light oil burner and then the gas burner.
Carry out the fuel change with burner off.

The optimum calibration of the burner requires an analysis of the flue gases at the boiler outlet and interventions on the following points.

5.2.1 Nozzle

See information on page 17.

5.2.2 Combustion head

The adjustment of the combustion head already carried out on page 18 need not to be altered unless the 2nd stage output of the burner is changed.

5.2.3 Pump pressure

In order to change pump pressure, act on screw 5)(Fig. 21 on page 21). See information on page 17.

5.2.4 Fan damper

Refer to the adjustment of the servomotor on page 30.

5.3 Burner ignition (light oil)

Position the selector 1)(Fig. 30) on "AUTO".

Position the selector 2) on "OIL" to select light oil fuel.


When the limit thermostat (TL) is closed, the "CALL FOR HEAT" 3) signal must be switched on.

At first ignition, there is a momentary drop in fuel pressure due to the filling of the nozzle piping. This lowering of the fuel pressure

can cause the burner to lockout and can sometimes give rise to pulsations.

If the burner locks out again, refer to chapter "Faults - Possible causes - Solutions" on page 41.

Once the following adjustments have been made, the ignition of the burner must generate a noise similar to the noise generated during operation.



S8411

Fig. 30

5.4 Adjustments prior to ignition (gas)

In addition, the following adjustments must also be made:

- Slowly open the manual valves situated upstream of the gas train.
- Adjust the minimum gas pressure switch (Fig. 38 on page 34) to the start of the scale.
- Adjust the maximum gas pressure switch (Fig. 37 on page 34) to the end of the scale.
- Adjust the air pressure switch (Fig. 36 on page 34) to the start of the scale.
- Purge the air from the gas line.
We recommend using a plastic tube routed outside the building and to purge air until gas is smelt.
- Fit a U-type pressure gauge or a differential pressure gauge (Fig. 31), with socket (+) on the gas pressure of the pipe coupling and (-) in the combustion chamber.
Used to approximately calculate the MAX burner output.
- Connect two lamps or testers to the two gas line solenoid valves to check the exact moment in which voltage is supplied.
This operation is not required if each of the two solenoid valves is equipped with a pilot light that signals voltage passing through.



Before starting up the burner, it is good practice to adjust the gas train so that ignition takes place in conditions of maximum safety, i.e. with gas delivery at the minimum.




Fig. 31

5.5 Burner start-up (gas)

Close the remote controls and set the switch 1)(Fig. 30) to “**AUTO**”.

Position the selector 2) on “**GAS**” to select gas as fuel.

Check that the lamps or testers connected to the solenoid valves, or the pilot lights on the solenoid valves, indicate that no voltage is present. If they indicate the presence of voltage, stop the burner immediately and check the electric connections.

When the limit thermostat (TL) is closed, the heat request indication “**CALL FOR HEAT**” 3)(Fig. 30) must be displayed and the burner starts the starting cycle.

5.6 Burner ignition

If the motor starts but the flame does not appear and the flame control goes into lockout, reset and wait for a new ignition attempt.

If ignition does not occur, it is possible that gas is not reaching the combustion head within the safety time period of 3 seconds. Therefore, it is necessary to increase gas ignition delivery.

The arrival of gas to the sleeve is indicated by the U-type pressure gauge (Fig. 31).

If the burner locks out again, refer to chapter "Faults - Possible causes - Solutions" on page 41.



In the event the burner stops, in order to prevent any damage to the installation, do not unblock the burner more than twice in a row. If the burner locks out for a third time, contact the customer service.



In the event there are further lockouts or faults with the burner, the maintenance interventions must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

Once ignition has taken place, proceed with burner global calibration operations.

5.7 Change of fuel

There are two change of fuel options:

- 1 with selector 2)(Fig. 30);
- 2 with a remote selector connected to the main terminal board. Positioning the selector 2)(Fig. 30) to “**EXT**” activates the remote selection of the fuel.

5.8 Servomotor adjustment

The servomotor adjusts simultaneously, through driving gears, the output and pressure of the air and the delivery of the fuel in use. It performs a 130° rotation in 45s. After the adjustment made in the factory to its 6 cams to allow an initial ignition.

Check that they are as shown below.

In the event of a modification, follow what is described below for each cam:

Cam I (RED): **135°** (The same for all models). Limits rotation toward maximum position. Do not modify.



WARNING

Do not make any adjustments.

Cam II (BLUE): **0°** (The same for all models). Limits rotation toward minimum position. With the burner off, the air damper is completely closed: 0°.



WARNING

It is recommended that no adjustments are made.

Cam III (ORANGE): **20°** Adjusts the ignition position and the minimum output.

Cam IV (YELLOW): **130°** Adjusts the ignition position and the maximum output.

Cam V (BLACK): Not used.

Cam VI (GREEN): Not used.




Fig. 32

5.9 Combustion air adjustment

The fuel/combustion synchronization is made by means of a servomotor connected to two variable profile cams, which act on the outlet air damper 1)(Fig. 33) and gas damper 2) and on the combustion head by appropriate levers.

It is advisable, to reduce the loss and for a wide calibration field, to adjust the servomotor to the maximum of the output used, the nearest possible to the maximum opening (130°).

On the gas butterfly valve, fuel step according to the burner output required, with servomotor completely open, is carried out by the pressure stabiliser placed on the train.




Fig. 33

The values indicated in Tab. O and Tab. P can be a reference for a good combustion calibration.

EN 676		Air excess		CO
		Max. output $\lambda \leq 1.2$	Max. output $\lambda \leq 1.3$	
GAS	Theoretical max. CO ₂ 0 % O ₂	CO ₂ % Calibration		mg/kWh
		$\lambda = 1.2$	$\lambda = 1.3$	
G 20	11.7	9.7	9	≤ 100
G 25	11.5	9.5	8.8	≤ 100
G 30	14.0	11.6	10.7	≤ 100
G 31	13.7	11.4	10.5	≤ 100

Tab. O

EN 267		Air excess		CO
		Max. output $\lambda \leq 1.2$	Min. output $\lambda \leq 1.3$	
Theoretical max CO ₂ 0 % O ₂		CO ₂ % Calibration		mg/kWh
		$\lambda = 1.2$	$\lambda = 1.3$	
15.2		12.6	11.5	≤ 100

Tab. P

5.10 Burner adjustment and output modulation

5.10.1 Maximum output

The servomotor (Fig. 32 on page 30) must be adjusted to the maximum opening so that the air dampers are completely open.

5.10.2 Minimum output

MIN output must be selected within the firing rate range indicated on page 9.

Turn the selector 4)(Fig. 30 on page 28) "output reduction", and keep "-" pressed until the servomotor has closed the air damper and the gas butterfly valve at 35° (adjustment made in the factory).

Air adjustment

The starting profile of cam 1)(Fig. 34) must be progressively adjusted by turning the screws 2)(Fig. 34).



If possible, do not turn the first screw, since this is used to set the air damper to its fully closed position.

5.10.3 Intermediate outputs

After adjusting the maximum and minimum output of the burner, carry out air and gas adjustment on several intermediate positions of the servomotor.

The passage from one position to the next one is obtained by pressing the selector 4)(Fig. 30 on page 28) on the symbol "+" or "-".

For better adjustment repeatability, take care to stop the rotation of the cam unit when the upper bearing that slides on the profile 4)(Fig. 34) is aligned with one of the adjustment screws 2).

Screw or unscrew the pre-set screw 2) to increase or decrease the air output so as to adjust it to the corresponding gas output.



After output adjustment (maximum, minimum and intermediate), it is important to lock all the air adjustment screws 2) by the locking screws 3) so as to avoid possible movements from the position of air - gas calibration.




Fig. 34

Key (Fig. 34)

- 1 Cam
- 2 Adjustment screws
- 3 Locking screws
- 4 Adjustable profile

5.11 Air / fuel adjustment

The following adjustments must be performed during the calibration of the air/fuel ratio:

- A Oil pump outlet pressure:**
turn screw 5)(Fig. 21 on page 21), on the pump.
- B Air cam:**
turn the adjustment screws 2)(Fig. 34) after having loosened screws 3).
- C Gas cam:**
turn the adjustment screws 2)(Fig. 34) after having loosened screws 3).
- D Oil cam:**
modify the eccentricity by turning the screw 7)(Fig. 35) after having loosened the screws 6).
By tightening the screw 7) the eccentricity increases, thereby increasing the difference between the maximum and minimum return pressure of the nozzle.




Fig. 35

Key (Fig. 35)

- 1 Maximum oil pressure switch
- 2 Return pressure gauge
- 3 Variable eccentric
- 4 Eccentric adjustment screw
- 5 Piston stop ring
- 6 Piston calibration nut and lock nut
- 7 Eccentric locking screws
- 8 Adjustment screw/calibration for maximum oil pressure switch

5.11.1 Burner calibration procedure

- Install the nozzle suitable to achieve the maximum desired output.
- Verify that the eccentricity of the oil cam is such to make a travel of about 8 mm on the shaft of oil modulator.
Normally, with a shaft stroke of 8 mm, the pressure variation needed for the modulation of the minimum to maximum output is obtained.
To verify this, manually rotate the cam after having released the servomotor with the lever 7)(Fig. 32 on page 30), so that the travel of the shaft is not exaggerated or insufficient.
Remember to block the servomotor after the verification.
- Switch on the burner with the selector on the control panel in manual "MAN" 1) position (Fig. 30 on page 28).
At this point, after the pre-purging phase, the servomotor stops at about 45°.
- Adjust the outlet pressure of the pump as shown in point **A (oil pump outlet pressure)** to obtain an outlet pressure to the nozzle of 24 - 25 bar.
- Adjust the minimum return pressure to approx. 6 bar.
To do so, the length of the shaft 5)(Fig. 35 on page 32) must be varied by means of nut 6).
- Calibrate the air delivery by adjusting the variable profile cam with the screws 2)(Fig. 34 on page 32).
- Having performed this first adjustment, increase the output supplied via the automatic return selector on the control panel. Pause after a 15° rotation of the servomotor and perform another adjustment by means of the variable profile cam of the air.
It is recommended to perform a calibration that will prevent the formation of a smoky flame and arrive as soon as possible to the maximum output (maximum stroke of the servomotor 130°); on the eccentric screw 5)(Fig. 35 on page 32), calibrate the pressure on the return line to obtain the output desired and requested by the nozzle, and then go back to calibrate the intermediate points.
- Then recheck the values of the combustion parameters at the various modulation outputs and if necessary make the necessary adjustments.
- Turn off the burner and wait for the complete shut-down of the fan motor.
- Now move the selector 2)(Fig. 30 on page 28) to "GAS", perform a new ignition and check the correct gas operation at the desired output.
If this is not so, calibrate the gas cam as in point **C (Gas Cam)** mentioned above.
- With the optimal adjustment achieved, remember to lock the adjustment screws of the cam profiles by means of screws 3)(Fig. 34 on page 32).



WARNING

When calibrating the cams, never go beyond the travel limits of the servomotor 0° - 130° to avoid any sticking.

Carrying out a manual travel 0 - 130° of the cams, check that there are no mechanical stops before the micro-switches 1-2 of the servomotor are activated.

5.12 Pressure switch adjustment

5.12.1 Air pressure switch - check CO

Adjust the air pressure switch after performing all other burner adjustments with the air pressure switch set to the start of the scale (Fig. 36).

With the burner operating at MIN output, increase adjustment pressure by slowly turning the relevant knob clockwise until the burner locks out.

Then turn the knob anticlockwise by about 20% of the set point and repeat burner start-up to ensure it is correct.

If the burner locks out again, turn the knob slightly anticlockwise.



WARNING

In conformity with the standard, the air pressure switch must prevent the air pressure falling below 80% of the adjusted value and the CO in the flue gases exceeding 1% (10,000 ppm).

To check this, insert a combustion analyser in the flue, slowly reduce the burner air setting (for example with a piece of cardboard) and verify that the burner locks out before the CO value in the flue gases exceeds 1%.

The air pressure switch is installed in the "absolute" position, i.e. it is connected only to the pressure test point "+" 22)(Fig. 4).



WARNING

Connecting the air pressure switch in differential mode, the burner will no longer be certified according to the EN 676 standard.

5.12.2 Maximum gas pressure switch

Adjust the maximum gas pressure switch (Fig. 37) after making all other burner adjustments with the maximum gas pressure switch set to the end of the scale.

To calibrate the maximum gas pressure switch, open the tap and then connect a pressure gauge to its pressure test point.

The maximum gas pressure switch must be regulated to a value no higher than 30% of the measurement read on the gauge when the burner is working at maximum output.

After making the adjustment, remove the pressure gauge and close the tap.

5.12.3 Minimum gas pressure switch

The purpose of the minimum gas pressure switch is to prevent the burner from operating in an unsuitable way due to too low gas pressure.

Adjust the minimum gas pressure switch (Fig. 38) after having adjusted the burner, the gas valves and the gas train stabiliser. With the burner operating at maximum output:

- install a pressure gauge downstream of the gas train stabiliser (for example at the gas pressure test point on the burner combustion head);
- choke slowly the manual gas cock until the pressure gauge detects a decrease in the pressure read of about 0.1 kPa (1 mbar). In this phase, verify the CO value which must always be less than 100 mg/kWh (93 ppm).
- Increase the adjustment of the gas pressure switch until it intervenes, causing the burner shutdown;
- remove the pressure gauge and close the cock of the gas pressure test point used for the measurement;
- open completely the manual gas cock.




Fig. 36




Fig. 37




Fig. 38



WARNING

1 kPa = 10 mbar

5.13 Operation sequence of the burner

5.13.1 Burner start-up

- 0s TL thermostat/pressure switch closure.
Fan motor start-up.
- 6s Servomotor start-up: rotate to the right by 130°, i.e. until the contact intervenes on the cam 1).
If it's operating with oil or cam 4) if it's operating with gas.
- 48s The air damper is positioned to MAX output.
Pre-purging stage with MAX output air delivery.
- 80s The servomotor rotates towards the left until the angle set on the cam 3).
If it's operating with oil or cam 5) if it's operating with gas.
- 109s The air damper and the gas butterfly valve adopt the MIN output position.
- 113s Ignition electrode strikes a spark.
- 116s The pilot valves VP1 and VP2 open.
The flame is ignited at a low output level, point A (Fig. 39).
- 119s The spark goes out.
- 130s The safety valve VS opens, along with the adjustment valve VR (quick opening).
The output is then progressively increased, with the valve opening slowly up to MIN output, point B (Fig. 39).
- 143s The start-up cycle ends.




Fig. 39

5.13.2 Steady state operation

Burner without RWF50 output regulator

Once the start-up cycle is completed, the servomotor command moves on to the TR thermostat/pressure switch that controls the pressure or the temperature in the boiler, point C (Fig. 39). (The flame control continues to check the presence of the flame and the correct position of the air and gas maximum pressure switches).

- If the temperature or the pressure is low so the thermostat/pressure switch TR is closed, the burner progressively increases the output up to the MAX value (section C-D).
- Then if the temperature or pressure increases until the TR opens, the burner progressively decreases its output to the MIN value (section E-F). And so on.
- The burner locks out when the heat request is less than the heat supplied by the burner at MIN output, (section G-H). The TL thermostat/pressure switch opens, and the servomotor returns to angle 0° limited by the contact of cam 2).
The air damper closes completely to reduce heat losses to a minimum.

For every change of output, the servomotor will automatically change the gas flow rate (butterfly valve), the airflow (fan damper) and the air pressure (2 shutters in the combustion head).

Burner with RWF50 output regulator

See the manual supplied with the regulator.




Fig. 40





5.13.3 Burner flame goes out during operation

If the flame should accidentally go out during operation, the burner will lock out within 1s.

5.13.4 Ignition failure

If the burner does not ignite (Fig. 40), it locks out within 3 s after the gas valve opens, 119 s after the TL closes.

5.14 Final checks (with burner operating)

<ul style="list-style-type: none"> ➤ Open the thermostat/pressure switch TL ➤ Open the thermostat/pressure switch TS 		The burner must stop
<ul style="list-style-type: none"> ➤ Turn the knob of the gas maximum pressure switch to the minimum end of scale position ➤ Turn the air pressure switch knob to the maximum end of scale position 		The burner must stop in lockout
<ul style="list-style-type: none"> ➤ Turn off the burner and cut off the power ➤ Disconnect the minimum gas pressure switch connector 		The burner must not start
<ul style="list-style-type: none"> ➤ Disconnect flame sensor electrical connections 		The burner must stop in lockout due to ignition failure

Tab. Q



WARNING

Make sure that the mechanical locking systems on the adjustment devices are fully tightened.

6 Maintenance

6.1 Notes on safety for the maintenance

The periodic maintenance is essential for the good operation, safety, yield and duration of the burner.

It allows you to reduce consumption and polluting emissions and to keep the product in a reliable state over time.



The maintenance interventions and the calibration of the burner must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

Before carrying out any maintenance, cleaning or checking operations:



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.



Wait for the components in contact with heat sources to cool down completely.

6.2 Maintenance programme

6.2.1 Maintenance frequency



The gas combustion system should be checked at least once a year by a representative of the manufacturer or another specialised technician.

6.2.2 Safety test - with no gas supply

To perform commissioning in safety conditions, it is very important to check correct wiring between gas valves and burner.

For this purpose, after checking that connections comply with the burner wiring diagrams, it is necessary to carry out a start-up cycle with gas cock closed (dry test).

- 1 The manual gas valve must be closed using the locking/unlocking device ("Lock-out / tag out" procedure).
- 2 Ensure that burner limit electrical contacts are closed
- 3 Ensure that minimum gas pressure switch contact is closed
- 4 Try to start the burner

The start-up cycle must occur according to the following steps:

- Fan motor start-up for pre-purging
- Gas valve leak detection control, if applicable
- Pre-purging completion
- Achievement of the ignition point
- Power supply of the ignition transformer
- Supply of gas valves

As gas is closed, the burner cannot ignite and its flame control will switch to stop or safety lockout condition.

The actual supply of gas valves can be checked by inserting a tester; some valves are equipped with lights (or closing/opening position indicators) that activate as soon as they are powered.



IF POWER SUPPLY OF GAS VALVES OCCURS IN UNEXPECTED MOMENTS, DO NOT OPEN THE MANUAL VALVE, DISCONNECT POWER SUPPLY, CHECK WIRINGS, CORRECT THE ERRORS AND CARRY OUT THE WHOLE TEST AGAIN.

6.2.3 Checking and cleaning



The operator must use the required equipment during maintenance.

Combustion

Carry out an analysis of the combustion flue gases.

Significant differences with respect to the previous measurements indicate the points where most care should be exercised during maintenance.

Combustion head

Open the burner and make sure that all components of the combustion head are in good condition, not deformed by the high temperatures, free of impurities from the surroundings and correctly positioned.

Burner

Check that there is no excess wear or loosen screws, especially on cams 3)(Fig. 34).

Clean the outside of the burner.

Clean and grease the adjustable profile of the cams.

Fan

Check to make sure that no dust has accumulated inside the fan or on its impellers, as this condition will cause a reduction in the air flow rate and provoke polluting combustion.

Boiler

Clean the boiler as indicated in its accompanying instructions in order to maintain all the original combustion characteristics intact, especially: the flue gas temperature and combustion chamber pressure.

Electrical current to flame sensor (Fig. 41)

Clean the glass cover from any dust that may have accumulated. To remove the sensor pull it outwards with force; it is inserted only by pressure.

Min. value for a good work: 70 μ A.

If the value is lower, it could be due to:

- exhausted sensor;
- low voltage (lower than 187 V);
- bad regulation of the burner.

In order to measure the current, use a microammeter of 100 μ A d.c., connected in series to the sensor, as in the scheme, with a capacitor of 100 μ F - 1V d.c. at the same level of the instrument.




Fig. 41

6.2.4 Safety components

The safety components should be replaced at the end of their life cycle indicated in the following table.



WARNING

The specified life cycles do not refer to the warranty terms indicated in the delivery or payment conditions.

Safety component	Life cycle
Flame control	10 years or 250.000 operation cycles
Flame sensor	10 years or 250.000 operation cycles
Gas valves (solenoid)	10 years or 250.000 operation cycles
Pressure switches	10 years or 250.000 operation cycles
Pressure adjuster	15 years
Servomotor (electronic cam)(if any)	10 years or 250.000 operation cycles
Oil valve (solenoid)(if any)	10 years or 250.000 operation cycles
Oil regulator (if present)	10 years or 250.000 operation cycles
Oil pipes/ couplings (metallic) (if present)	10 years
Fan impeller	10 years or 500.000 start-ups

Tab. R

LIGHT OIL OPERATION

Pump

The delivery pressure must comply with the table on page 17.

The depression must be less than 0.45 bar.

Unusual noise must not be evident during pump operation.

If the pressure is unstable, or the pump runs noisily, the flexible hose must be detached from the line filter and the fuel must be sucked from a tank located near the burner. This measure permits the cause of the anomaly to be traced to either the suction piping or the pump. If the problem lies in the suction line, check the filter is clean and that air is not entering the piping.

Filters (Fig. 42)

Check the filtering baskets on line 1) and at nozzle 2) present in the system. Clean or replace if necessary. If rust or other impurities are observed inside the pump, use a separate pump to lift any water and other impurities that may have deposited on the bottom of the tank.




Fig. 42

Nozzles

It is advisable to replace nozzles once a year during periodical maintenance.

Do not clean the nozzle openings.

Flexible hoses

Check to make sure that the hoses are still in good condition.

Fuel tank

Approximately every 5 years, suck any water on the bottom of the tank using a separate pump.

Combustion

If the combustion values measured before starting maintenance do not comply with applicable Standards or do not indicate efficient combustion, consult the table below or contact our Technical Support Service to implement the necessary adjustments.

EN 267	Air excess		CO
	Max. output $\lambda \leq 1.2$	Min. output $\lambda \leq 1.3$	
Theoretical max CO ₂ 0 % O ₂	CO ₂ % Calibration		mg/kWh
	$\lambda = 1.2$	$\lambda = 1.3$	
15.2	12.6	11.5	≤ 100

Tab. S

GAS OPERATION

Gas leaks

Make sure that there are no gas leaks on the pipe between the gas meter and the burner.

Gas filter

Change the gas filter when it is dirty.

Combustion

If the combustion values measured before starting maintenance do not comply with applicable Standards or do not indicate efficient combustion, consult the table below or contact our Technical Support Service to implement the necessary adjustments.

EN 676	Theoretical max CO ₂ 0 % O ₂	Air excess		CO
		Max. output $\lambda \leq 1.2$	Max. output $\lambda \leq 1.3$	
GAS	CO ₂ % Calibration	CO ₂ % Calibration		mg/kWh
		$\lambda = 1.2$	$\lambda = 1.3$	
G 20	11.7	9.7	9	≤ 100
G 25	11.5	9.5	8.8	≤ 100
G 30	14.0	11.6	10.7	≤ 100
G 31	13.7	11.4	10.5	≤ 100

Tab. T

6.3 Opening the burner



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.



Wait for the components in contact with heat sources to cool down completely.

- Remove the tie-rods 1) and 4)(Fig. 43) of the head movement and damper opening lever, loosening nut 2);
- disconnect the socket 3) of the servomotor;
- Disconnect the socket 7) of the derivation unit;
- remove the screws 5).

At this point, it is possible to open the burner on the hinge.




Fig. 43

6.4 Closing the burner

Refit following the steps described but in reverse order; refit all burner components as they were originally assembled.



After carrying out maintenance, cleaning or checking operations, reassemble the cover and all the safety and protection devices of the burner.

7 Faults - Possible causes - Solutions

The LFL1... flame control is equipped with a lockout indicator (Fig. 44) that turns during the start-up programme, and is visible from the small lockout window.

When the burner does not start or stops, due to a failure, the symbol that appears on the indicator indicates the type of interruption.

The positions of the lockout indicator are shown in Fig. 45.



Lockout indicator

- a-b Start-up sequence
- b(b') Idle stages (without contact confirmation)
- b(b')-a Post-purging programme

Fig. 44




Fig. 45

Fuse replacement

The fuse 2)(Fig. 46) is in the rear part of the flame control. A spare fuse 1) is also available: it can be extracted after breaking the panel tab A) that houses it.

Find a list of faults, causes and possible solutions for a set of failures that may occur and result in irregular burner operation or no functioning at all.

If a burner malfunction is detected, first of all:

- check that the electrical wiring is adequately connected;
- check whether fuel is delivered;
- check that every adjustment parameter is adequately set.




Fig. 46



WARNING

In the event the burner stops, in order to prevent any damage to the installation, do not unblock the burner more than twice in a row. If the burner locks out for a third time, contact the customer service.



DANGER

In the event there are further lockouts or faults with the burner, the maintenance interventions must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

7.1 Light oil operation

Symbol	Problem	Probable cause	Suggested remedy
◀	The burner does not start	Limiter or safety control device open	Adjust or replace
		Flame control lockout	Release
		Fan motor lockout	Release the thermal relay
		No electrical power supply	Close all switches - check connections
		No light oil	Check the light oil supply circuit
		Flame control fuse interrupted	Replace
		Pump is jammed	Replace
		Faulty motor remote control switch	Replace
		Defective flame control	Replace
		Faulty electrical motor	Replace
		Defective safety solenoid valve	Replace
		The burner does not come on and the lockout appears	Flame simulation
Flame sensor short circuit	Replace flame sensor		
Two-phase electrical supply, thermal relay steps in	Reset the thermal relay at return of the three phases		
▲	The burner starts but stops at maximum air damper setting	The servomotor contact does not intervene	Adjust cam or replace servomotor
P	The burner starts and then goes into lockout	Air pressure switch poorly adjusted	Adjust it
		Pressure switch pressure point pipe blocked	Clean
■	The burner starts and then goes into lockout	Failure to the flame detection circuit	Replace flame control
▼	The burner remains in pre-purging phase	The servomotor contact III does not intervene	Adjust cam or replace servomotor
1	Once the pre-purging and the safety time has elapsed the burner goes into lockout without the flame appearing	No fuel in the tank, or water on the bottom	Refill with fuel, or remove the water
		Bad head and damper adjustments	Adjust
		High voltage cable defective or grounded	Replace
		High voltage cable deformed by high temperature	Replace and protect
		Bad electrical wiring on valves or transformer	Check
		Pump unprimed	Prime it
		Pump suction line connected to return line	Correct connection
		Soiled filters (nozzle line)	Clean
		Valves up-line from pump closed	Open them
		Opposite motor rotation	Change electrical wiring to the motor
		Light oil solenoid valves do not open	Check connections and solenoids
		Pilot burner does not work	Check
		Defective flame control	Replace
		Ignition electrode incorrectly adjusted	Adjust it
		Electrode grounded due to broken insulation	Replace
		Motor/pump coupling broken	Replace
		Faulty ignition transformer	Replace
		The flame ignites regularly but the burner goes into lock out at the end of the safety time	Faulty flame sensor or defective flame control
	Dirty flame sensor		Clean
		Smoke in flame (dark Bacharach)	Little air
Incorrect pump pressure			Adjust
Nozzle filter clogged			Clean or replace
Boiler room air vents insufficient			Increase
Dirty or worn nozzle			Replace
	Smoke in flame (yellow Bacharach)	Flame disk soiled, loose or deformed	Clean it, tighten it or replace it
		Too much air	Adjust head and air dampers

Symbol	Problem	Probable cause	Suggested remedy
	Ignition with pulses or flame failure, delayed ignition	Poorly adjusted head	Adjust
		Incorrectly adjusted fan air damper: too much air	Adjust
		Nozzle not fit for burner or boiler	See nozzle table
		Defective nozzle	Replace
		Unsuitable pump pressure	Adjust
		Ignition electrode not adjusted correctly or soiled	Adjust it
		Output during ignition phase is too high	Reduce
	The burner does not pass to the 2nd stage	Remote control device TR fails to close	Adjust or replace
		Defective flame control	Replace
	Uneven fuel supply	Understand whether the cause lies in the pump or the fuel supply system	Supply fuel to the burner from a tank positioned near the burner itself
	Pump rusty on the inside	Water in the tank	Remove the water with a pump
	Noisy pump, unstable pressure	Air has entered the suction line	Block the couplings
		Depression value too high (higher than 35 cm Hg):	
		Excessive difference of level between burner and tank	Power the burner from a loop circuit
		Piping diameter too small	Increase
		Dirty suction line filters	Clean
		Suction line valves closed	Open them
		The paraffin solidifies due to the low temperature	Put additive in the light oil
	Pump unprimes after prolonged pause	Return pipe not immersed in fuel	Bring it to the same height as the suction line
		Air in the suction line	Block the couplings
	Pump leaks light oil	Loss of sealing organ	Replace the pump
	Dirty combustion head	Dirty nozzle or nozzle filter	Replace
		Unsuitable nozzle delivery or angle	See recommended nozzles
		Loose nozzle	Block it
		Environmental impurities on flame stability disc	Clean
		Incorrect head adjustment, or little air	Adjust it, opening the damper
		Blast tube length not suitable for the boiler	Contact the boiler manufacturer
I	Burner goes into lockout during operation	Flame sensor faulty or dirty	Replace it or clean it
		Air pressure switch faulty	Replace

Tab. U

7.2 Gas operation

Symbol	Problem	Probable cause	Suggested remedy
◀	The burner does not start	No electrical power supply	Close all switches and check connections
		A limit or safety thermostat/pressure switch open	Adjust or replace
		Flame control lockout	Release the flame control
		Flame control fuse interrupted	Replace it
		Incorrect electrical wiring	Check
		Defective flame control	Replace
		No gas supply	Open the manual valves between meter and train
		Mains gas pressure insufficient	Contact your GAS COMPANY
		Minimum gas pressure switch fails to close	Adjust or replace
		Air pressure switch in operating position	Adjust or replace
		The servomotor contact does not intervene (closure cam 0°)	Adjust the closure cam 0° or replace the servomotor
	The burner does not come on and the lockout appears	Flame simulation	Replace the flame control
		Faulty motor remote control switch	Replace
		Defective electrical motor	Replace
▲	The burner starts but stops at maximum air damper setting	Motor lockout	Release the thermal relay
		The servomotor contact does not intervene (maximum cam opening)	Cam adjustment (maximum opening) or replace the servomotor
P	The burner starts and then goes into lockout	Air pressure switch does not switch owing to lack of air pressure:	
		Air pressure switch poorly adjusted	Adjust or replace
		Pressure switch pressure point pipe clogged	Clean
		Poorly adjusted head	Adjust
		Dirty fan	Clean
■	The burner turns on and then remains in lockout mode	High depression in the furnace	Contact our Technical Department
		Failure to the flame detection circuit	Replace the flame control
▼	The burner remains in pre-purging phase	The servomotor contact does not intervene (minimum cam)	Cam adjustment (minimum) or replace the servomotor

Symbol	Problem	Probable cause	Suggested remedy
1	Once the pre-purging and the safety time has elapsed the burner goes into lockout without the flame appearing	The GAS solenoid valve lets too little gas through	Increase
		The GAS solenoid valve does not open	Replace the coil or the rectifier panel
		Gas pressure too low	Increase pressure at governor
		Ignition electrode incorrectly adjusted	Adjust it
		Electrode grounded due to broken insulation	Replace
		High voltage cable defective or grounded	Replace
		High voltage cable deformed by high temperature	Replace and protect
		Faulty ignition transformer	Replace
		Incorrect valve or ignition transformer connections	Redo them
		Defective flame control	Replace
		A closed valve upstream the gas train	Open
		Air in pipework	Bleed air
		Lockout with flame appearing	The GAS solenoid valve lets too little gas through
	Dirty flame sensor		Check, replace flame sensor
Faulty connection	Check, replace flame sensor		
Insufficient detection current (min.70 µA)	Measure current, replace flame sensor		
Flame sensor exhausted, faulty	Replace		
Maximum gas pressure switch intervention	Adjust or replace		
Defective flame control	Replace		
	The burner continues to repeat the start-up cycle without lockout	The gas pressure in the gas mains lies very close to the value to which the gas pressure switch has been set. The sudden drop in pressure after valve opening causes temporary opening of the pressure switch itself, the valve immediately closes and the burner stops. Pressure increases again, the pressure switch closes again and the ignition cycle is repeated. And so on.	Reduce the intervention pressure of the minimum gas pressure switch. Replace the gas filter cartridge
	Lockout without symbol indication	Flame simulation	Replace the flame control
	Burner goes into lockout during operation	Faulty flame sensor	Replace worn parts
		Air pressure switch faulty	Replace
◀	Lockout when the burner stops	Permanent flame in the combustion head or flame simulation	Eliminate permanency of flame or replace the flame control
	Ignition with pulsations	Poorly adjusted head	Adjust
		Ignition electrode incorrectly adjusted	Adjust it
		Incorrectly adjusted fan air damper: too much air	Adjust
		Output during ignition phase is too high	Reduce

Tab. V

A Appendix - Accessories

Output regulator kit for modulating operation

With modulating operation, the burner continuously adjusts its output to the heat request, thereby ensuring a great stability of the controlled parameter: temperature or pressure.

The parts to be ordered are two:

- output regulator to be installed to the burner;
- probe to be installed to heat generator.

Parameter to be controlled		Probe		Output regulator	
	Adjustment field	Type	Code	Type	Code
Temperature	- 100...+ 500°C	PT 100	3010110	RWF50 RWF55	20101190
Pressure	0...2.5 bar 0...16 bar	Output probe 4...20 mA	3010213 3010214		20101191

Output regulator kit with signal 4-20 mA, 0-10V

The parts to be ordered are two:

- the analogue signal converter;
- the potentiometer

Burner	Potentiometer		Analogue Signal Converter	
	Type	Code	Type	Code
RLS 1000/M MX RLS 1200/M MX	ASZ...	3013532	E5202	3010390

Continuous purging kit

Burner	Code
RLS 1000/M MX RLS 1200/M MX	3010094

Soundproofing box kit


Burner	Code
RLS 1000/M MX RLS 1200/M MX	3010401


Gas trains in compliance with EN 676


Please refer to manual.


B Appendix - Electrical panel layout

1	Index of layouts	
2	Indication of references	
3	Single line power layout	RLS 1000/M MX RLS 1200/M MX
4	Functional layout star/triangle starter	
5	Functional layout	
6	Functional layout	
7	Functional layout	
8	Functional layout	
9	Electrical wiring kit RWF50 internal	
10	Electrical wiring to be carried out by the installer	RLS 1000/M MX RLS 1200/M MX
11	Electrical wiring that is the responsibility of the installer	
12	Functional layout RWF50	
13	Electrical wiring kit RWF50 external	

2 Indication of references








TO= TURCHESE / TURQUOISE / TURKOISE / TURKISBLAU
 SR= ARGENTO / SILVER / ARGENT / SILBER
 GNYE= GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRUN

GY= GRIGIO / GREY / GRIS / GRAU
 PK= ROSA / PINK / ROSE / ROSA
 GO= ORO / GOLD / OR / GOLD

WH= BIANCO / WHITE / BLANC / WEISS
 OG= ARANCIO / ORANGE / ORANGE / ORANGE
 VT= VIOLETTO / VIOLET / VIOLET / VIOLETT

YE= GIALLO / YELLOW / JAUNE / GELB
 GN= VERDE / GREEN / VERT / GRÜN
 RD= ROSSO / RED / ROUGE / ROT

BU= BLU / BLUE / BLEU / BLAU
 BK= NERO / BLACK / NOIR / SCHWARZ
 BN= MARRONE / BROWN / MARRON / BRAUN




Sheet : 8

SCHEMA FONCTIONNEL LFL 1...


BETRIEBSSCHEMA LFL 1...


LFL 1... OPERATIONAL LAYOUT

SCHEMA FUNZIONALE LFL 1...



Per il collegamento fare riferimento a pagina 13
 For the connection refer to the sheet 13
 Se référer aux page 13
 Für Elektroanschluß siehe Seite 13






RLS 1200/M MX

BU = BLU / BLUE / BLEU / BLAU
 BK = NERO / BLACK / NOIR / SCHWARZ
 BN = MARRONE / BROWN / MARRON / BRAUN
 YE = GIALLO / YELLOW / JAUNE / GELB
 GN = VERDE / GREEN / VERT / GRÜN
 RD = ROSSO / RED / ROUGE / ROT
 WH = BIANCO / WHITE / BLANC / WEISS
 OG= ARANCIO / ORANGE / ORANGE / ORANGE
 VF= VIOLETTA / VIOLET / VIOLET / VIOLETT
 GY= GRIGIO / GREY / GRIS / GRAU
 PK= ROSA / PINK / ROSE / ROSA
 GD= ORO / GOLD / OR / GOLD
 IO= TURCHESE / TURQUOISE / TURQUOISE / TURKISBLAU
 SR= ARGENTO / SILVER / ARGENT / SILBER
 GNY= GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN

ELECTRICAL CONNECTIONS SET BY INSTALLER ELETTRONANSCHLÜSSE VOM INSTALLATEUR EFFECTUÉ PAR L'INSTALLATEUR

Sheet : 10



Wiring layout key

A1	Flame control	X4	Light oil unit terminal board
B1	Internal RWF output power regulator	XAUX	Auxiliary terminal board
B2	External RWF output power regulator	XGD	Derivation unit connector
BA	Probe with output under current	XPGM	Maximum gas pressure switch connector
BA1	Output device in current to modify remote setpoint	XPO	Oil pressure switch connector
BP	Pressure probe	XPO1	Oil return pressure switch connector
BP1	Pressure probe	XRWF	Terminal board for RWF50 output power regulator
BR	Remote setpoint potentiometer	XS	Flame sensor connector
BT1	Thermocouple probe	XSM	Servomotor connector
BT2	Probe Pt100, 2 wires	XVP1	Pilot valve 1 connector
BT3	Probe Pt100, 3 wires	XVP2	Pilot valve 2 connector
BT4	Probe Pt100, 3 wires	XVU	Nozzle valve connector
BTEXT	External probe for climatic compensation of the setpoint	Y	Gas adjustment valve + gas safety valve
BV	Probe with output under voltage	YVPS	Gas valve leak detection device
BV1	Device with output under voltage for change of remote setpoint		
FU	Three-phase line fuses		
F1	Fan motor thermal relay		
F2	Pump motor thermal relay		
F3	Auxiliary fuse		
H1	Burner ON warning lamp		
H2	Fan motor and pump motor lockout warning lamp		
H3	Heat request lighting signal		
H4	Burner working lighting signal		
KL1	Star/triangle starter line contactor and direct start-up		
KMP	Pump motor contactor		
KT1	Star/triangle starter triangle contactor		
KS1	Start/triangle starter star contactor		
KST1	Star/triangle starter timer		
K1	Burner ON dry contact output relay		
K3	Burner lockout dry contact output relay		
K4	Output relay for light oil operation clean contacts		
K5	Output relay for gas operation clean contacts		
KG	Gas operation relay		
KO	Light oil operation relay		
MP	Pump motor		
MV	Fan motor		
PA	Air pressure switch		
PE	Burner earth		
PGM	Maximum gas pressure switch		
PGMin	Minimum gas pressure switch		
PO	Oil pressure switch		
PO1	Maximum oil pressure switch on return line		
RS	Remote burner reset button		
S1	Emergency stop button		
S2	Off / automatic / manual selector		
S4	Output increase / decrease selector		
S5	Fuel selector and enable signal to remote fuel selector		
SH3	Burner reset button and lockout signal		
SM	Servomotor		
SV	External safety valve		
TA	Ignition transformer		
TL	Limit thermostat/pressure switch		
TR	Adjustment thermostat/pressure switch		
TS	Safety thermostat/pressure switch		
UV	Flame sensor		
VF	Light oil operation valve		
VP1	Pilot valve 1		
VP2	Pilot valve 2		
VR	Light oil return valve		
VR1	Light oil return valve		
VS	Safety light oil valve		
VU	Nozzle valve		
X1	Main supply terminal board		
X2	Terminal board for kit RWF		

RIELLO

RIELLO S.p.A.
I-37045 Legnago (VR)
Tel.: +39.0442.630111
[http:// www.riello.it](http://www.riello.it)
[http:// www.riello.com](http://www.riello.com)