

# Multi-Function Burner Display

Burner control V3.60

Code	Model
20107665	MFBD 4.3" TOUCHSCREEN KIT - LMV3
20167984	MFBD 4.3" TOUCHSCREEN KIT - LMV5
20179829	MFBD 7" TOUCHSCREEN KIT - LMV5

**Multi-Function Burner Display**

<b>1</b>	<b>Information And General Warnings</b>	<b>3</b>
1.1	General Warnings . . . . .	3
1.2	General Information . . . . .	3
1.3	Other Relevant Documents . . . . .	3
<b>2</b>	<b>System And Hardware Configuration</b>	<b>4</b>
2.1	Introduction . . . . .	4
2.2	Burner Touchscreen Kits Bom . . . . .	4
2.2.1	4.3" Touch Screen Kit (Lmv3) - 20107665 . . . . .	4
2.2.2	4.3" Touch Screen Kit (Lmv5) - 20167984 . . . . .	4
2.2.3	7" Touch Screen Kit (Lmv5) - 201798294 . . . . .	5
2.2.4	Header Supply Sensor (Piccolo Setup) . . . . .	5
2.2.5	Optional Parts . . . . .	5
2.3	Factory Integrated Components . . . . .	6
2.4	Standard Features . . . . .	6
2.5	Communication . . . . .	7
2.5.1	Touch Screen Communication For Burner Control . . . . .	7
2.5.2	External Communication . . . . .	7
2.5.3	Changing the COM2 address (MFBM modbus settings) . . . . .	7
2.6	System Overview . . . . .	9
2.6.1	Solo & Piccolo System Overview . . . . .	9
2.6.1	Solo - Lmv3/5 Burner 1 . . . . .	9
2.6.2	Piccolo Burner 1- Burner 2 . . . . .	9
2.6.3	Massimo System Overview . . . . .	10
2.6.3	Massimo System: Burner Examples . . . . .	10
2.6.3	Massimo Panel . . . . .	10
2.7	Navigation . . . . .	11
2.7.1	Solo Wiring: Lmv3x, 4.3" Touchscreen . . . . .	12
2.7.2	Solo Wiring: Lmv5x, 4.3"/ 7" Touchscreen . . . . .	12
2.7.3	Piccolo Wiring: Lmv3x, 4.3" Touchscreen . . . . .	13
2.7.4	Piccolo Wiring: Lmv5x, 4.3"/7" Touchscreen . . . . .	13
2.7.5	Massimo Wiring: Lmv5x, 4.3" Touchscreen . . . . .	14
2.7.6	Massimo Wiring: Lmv5x, 7" Touchscreen . . . . .	14
<b>3</b>	<b>User Interface</b>	<b>15</b>
3.1	Burner View . . . . .	15
3.2	Control . . . . .	15
3.3	Burner Mode . . . . .	16
3.4	System Configuration (Main Menu) . . . . .	16
3.5	Media/ Units Selection . . . . .	17
3.6	Inputs Info And Configuration . . . . .	17
3.7	Remote Setpoint Source & Remote Modulation Source . . . . .	18
3.8	Hot Standby Configuration . . . . .	18
3.8.1	Cold Start Configuration . . . . .	19
3.8.2	Function mode . . . . .	19
3.9	Pump/Valve Configuration . . . . .	20
3.10	Night Setback . . . . .	20
3.11	Ethernet Configuration . . . . .	21
3.12	Comms Config . . . . .	22
3.13	General Setup Guide . . . . .	22
3.14	System Setup Examples . . . . .	23
3.14	2 Stage Control Setup . . . . .	23
3.16	Alarms & Warnings Page . . . . .	24
3.17	Burner . . . . .	25
3.18	Automatic Fuel Change Over . . . . .	26
3.19	Show/Hide Display Items . . . . .	26

**Multi-Function Burner Display**

<b>4</b>	<b>QuickStart Guide- Setting Up Control Mode</b>	<b>27</b>
4.1	QuickStart Guide- Setting Up Solo Mode .....	27
4.2	QuickStart Guide- Setting Up Piccolo Mode .....	27
	Step 1: Selecting Piccolo Mode .....	27
	Step 2: Selecting Boiler Number .....	28
	Step 3: Piccolo Configurations .....	28
	Step 4: Piccolo Configurations (Lead/Lag) .....	29
4.3	QuickStart Guide- Setting Up Massimo Mode .....	30
	Step 1: Selecting Massimo Mode .....	30
	Step 2: Selecting Boiler Number .....	30
	Step 3: Finishing Setup Of The Massimo .....	30
<b>5</b>	<b>Remote Monitoring - Vnc Viewer</b>	<b>31</b>
5.1	Hardwire .....	31
5.2	Setting Up Vnc Viewer Application .....	31
<b>6</b>	<b>Multi-Function Display Version Update</b>	<b>32</b>
6.1	Unpacking The Software .....	32
6.2	Burner Hmi Update .....	32
<b>7</b>	<b>Points List</b>	<b>33</b>
7.1	MFBD Points List: Modbus .....	33

**1 Information and general warnings**

**1.1 General warnings**



Disconnect all power supplies before attempting installation



Installation must only be conducted by qualified and skilled personnel in compliance with these instructions and all local and national codes



Ensure adequate work space before attempting installation



All accessory kits must be inspected for contents and integrity. If any components appear damaged DO NOT attempt installation; contact your supplier



After all operations are completed in compliance with these instructions; remount the cover and reconnect all safety devices before operating



Failure to follow these instructions could result in unsafe operation.

**1.2 General information**

Please note, this manual is only for burner display control. See Massimo Boiler Control manual for panel control system.

The multi-function display for LMV3x/5x is a common component for 3 systems: Solo, Piccolo and Massimo.

The **Solo** is a system that provides easy access to operators and BMS systems and burner functions. The burner is equipped with high definition 4.3" color HMI screen, delivering a modern and clean overview of the system in a snapshot.

The **Piccolo** is a 2 boiler lead/lag system that only needs the burners to be equipped with the multi-function displays and includes many functions already present in **Solo**.

The **Massimo** is a full boiler room control system and any burner equipped with a multi-function display can communicate with it and participate on the up to 8 boilers lead/lag system.

Please note that in manual contains the following legend to help navigate what functionality is compatible with the 4 modes of control:

- Solo ● Massimo ●
- Piccolo ● Remote Modulation ●

The Mult-Function Burner Display Control is not a safety control. It does not interfere with any safety limitation set on the burner and boiler.

This manual may be updated without notice of change.

**1.3 Other relevant documents**

- "Massimo System v3.60" manual (Main control panel for Massimo).
- "Riello Gateway N54 Manual"
- "Riello Gateway N34 & N35 Manual"

## 2 System and hardware configuration


### 2.1 Introduction

The Multi-Function Burner Display is included in kits defined in section 2.2 that can be selected as 4.3" or 7" displays with LMV3 and LMV5 controls.

### 2.2 Burner touch screen kits BOM


#### 2.2.1 4.3" touch screen kit (LMV3) - 20107665

4.3" kit (20107665) Components list		
#	Description	Part Number
1	DB9 to wire	20143749
2	4.3" touch screen	20180445
3	Wire (beldon,white, red , green, black)	
4	Display bracket,	20115121
5	Display bracket	20110020
6	120AC/24 VDC power supply	20138550
7	Din rail	C5311121
8	OCI412.10	C5360140
9	Light and Light button	
10	M6 Threaded rivet	20143688




#### 2.2.2 4.3" touch screen kit (LMV5) - 20167984

4.3" kit (20167984) Components list		
#	Description	Part Number
1	DB9 to wire	20143749
2	4.3" touch screen	20180445
3	Wire (beldon,white, red , green, black)	
4	Display bracket,	20115121
5	Display bracket	20110020
6	120AC/24 VDC power supply	20138550
7	Din rail	C5311121
8	OCI412.10	C5360140
9	Light and Light button	
10	M6 Threaded rivet	20143688
11	RJ45 - RJ12 cable	20146748
12	PLC: CO-11ARE-D	20138547



**2.2.3 7" touch screen kit (LMV5) - 20179829**

7" kit (20179829) Components list		
#	Description	Part Number
1	DB9 to wire	20143749
2	7" touch screen	20164159
3	Wire (beldon,white, red , green, black)	
4	120AC/24 VDC power supply	20138550
5	Din rail	C5311121
6	OCI412.10	C5360140
7	Light and Light button	
8	M6 Threaded rivet	20143688
9	RJ45 - RJ12 cable	20146748
10	PLC: CO-11ARE-D	20138547




7" kit mounting case kit		
#	Description	Part Number
1	Mounting Case and components - Only to be used on larger power burners. Please contact local area representative for more details.	20076792

**2.2.4 Header Supply Sensor (Piccolo Setup)**

Header Supply Sensor (Piccolo System)		
#	Description	Part Number
1	Pt1000. (This PT1000 is a dual element sensor that is connected on both burners in a Piccolo setup) See Input 3 at the touchscreen for more information).	20152275

**2.2.5 Optional parts**

Optional parts		
#	Description	Part Number
9a	Gateway (5 protocol) - 1 per 8 burners	20214203
9b	Gateway (Lonworks)- 1 per 8 burners	20141214



**2.3 Factory integrated components**

---

Burner integration kit installed and tested.

- ▶ 4.3" HMI (LMV3/LMV5)
- ▶ 7.0" HMI (LMV5)

Protocol gateway (optional)

**2.4 Standard features**

---

In order to handle a wide variety of systems, the touch-screen is configurable. Please note that most of these features will not appear in certain modes. The following options are available:

System output type:

- ▶ Steam
- ▶ Hot water

Monitoring of burner/boiler & system:

- ▶ PV, status, firing rate, communication

Setpoint selection:

- ▶ Local (selectable/night/weekend setpoint)
- ▶ BMS (network/hardwire via analog signal 4-20ma or 0-10Vdc) - note this is not available for Solo or Piccolo LMV5

Night/weekend setback

- ▶ Individual days selection
- ▶ Individual time and setpoint selection

Hot Standby

- ▶ Selectable temperature/pressure target
- ▶ Choice of first lag boiler or all lag boilers

Cold start

- ▶ Individual start and stop of setpoint selection
- ▶ Maximum time selection

Pumps/Valve setup

- ▶ Boiler circulator pump off delay
- ▶ Boiler isolation valve close delay

Modbus RTU connection for BMS connection to software points.

Modbus TCP connection for BMS in Solo mode

Remote viewing

Piccolo

- ▶ Start and stop for lag boiler
- ▶ Start and stop delay for lag boiler
- ▶ Boiler automatic setpoint correction function
- ▶ Lead boiler rotation interval

Massimo: Touchscreens configurable to work in conjunction with Massimo Panel

**2.5 Communication**

**2.5.1 Touch screen communication for burner control**

The burner touchscreen utilizes Modbus/TCP for communications to 1 other burner (Piccolo option) or to Massimo panel (Massimo option).

For an LMV5, the AZL module communicates using Modbus RTU over RS232.

The burner touchscreen utilizes Modbus RTU, RS485 for communications to the burner controls including LMV3, temperature controller.

For remote connection to Massimo, see Massimo manual.

**2.5.2 External communication**

BMS communication is available via Modbus RTU for Solo and Piccolo and Modbus TCP from Solo.


Points list is protocol dependant, consult section 6.

An optional gateway can be included in the burner with other protocols (BACnet IP or BACnet/MSTP, Modbus TCP, Ethernet/IP, Metasys N2, Lonworks).


**2.5.3 Changing the COM2 address (MFB D modbus settings)**

To change the COM2 address on MFB D, follow the below instructions:

1. Hold your finger anywhere in the touchscreen where there are no buttons for 2-3 seconds, until a bar on the left side of the touchscreen appears. See below:




2. Click the gear symbol and a window will pop up as "go to system menu?" then select "yes"
3. In the system menu, select "System Setting"



### 2.5 Communication

#### 2.5.3 Changing the COM2 address (MFBD modbus settings)


4. Scroll at the bottom tabs using the arrows until you find "COM port", select the tab and click the blue arrow pointing down to access more information on COM2 port.



5. To change the address, it is located in COM2 tab as "HMI Station No.:"


If you are using MFBD with Piccolo or Solo system, change the address for all touchscreens. (adress 1 to 8)

For the first boot when connecting the gateway, make sure to change all the settings on the HMI Station No: 1 (COM2 address 1 "Burner 1") to load all settings.



## 2.5.3 Changing the COM2 address (MFBF modbus settings)


6. You are now done. To go back to the main menu touchscreen page, click the home button located in the top right side and select the icon in the reference picture below:



## 2.6 System overview

### 2.6.1 & 2.6.2 Solo & Piccolo system overview


Solo - LMV3/5 (2.6.1)



For LMV5:

► PLC is added to interface between LMV5 and touch-screen

Piccolo (2.6.2)




For LMV5:

► PLC is added to interface between LMV5 and touch-screen

### 2.6.3 Massimo system overview

#### Massimo System: Burner Examples



### Massimo Panel

SYSTEM SP 083.0 °F

080.2 °F 081.6 °F 078.6 °F

16:23 07/18/2022

Boiler ID	Status	Supply Temp (°F)	Power (%)
N1 BOILER 4	Normal Operation	082 °F	100.0 %
N2 BOILER 5	Normal Operation	082 °F	100.0 %
N3 BOILER 0	Lockout	000 °F	000.0 %
N4 BOILER 0	Lockout	000 °F	000.0 %

SEQ: 5 0 0 4 0 0 0 0


N4 not ready N3 not ready

Alarms > Trending > Settings >

Access level 1

1. VMC


2.7 Navigation



Please note, some of the above menu options will not be available in certain modes as they may not apply. See section 3 for more details.


### 2.7 Navigation

#### 2.7.1 Solo wiring: LMV3x, 4.3" touchscreen




Please note: Use the wiring diagrams as reference only.

#### 2.7.2 Solo wiring: LMV5x, 4.3"/ 7" touchscreen



Please note: Use the wiring diagrams as reference only.

## 2.7.3 Piccolo wiring: LMV3x, 4.3" touchscreen



LMV PARAMETERS FOR MODBUS


- PARAMETER 141 = 1
- PARAMETER 142 = 120
- PARAMETER 145 = 1 (ADDRESS)
- PARAMETER 146 = 1 (19200 BAUD)
- PARAMETER 147 = 0

RWF55 PARAMETERS

- BDRT = 2 (19200 BAUD RATE)
- ADR = 2 (ADDRESS)


Please note: Use the wiring diagrams as reference only.

## 2.7.4 Piccolo wiring: LMV5x, 4.3"/7" touchscreen




Please note: Use the wiring diagrams as reference only.

## 2.7.5 Massimo wiring: LMV3x, 4.3"/7" touchscreen



## 2.7.6 Massimo wiring: LMV5x, 4.3"/7" touchscreen



OPERATION  
 OptgModeSelect  
 Type of Gateway = "Modbus"

Params & Display  
 AZL  
 Modbus  
 Address = 1  
 Baudrate = 19200  
 Parity = No

Params & Display  
 Load Controller  
 Configuration  
 LC\_Optgmode = IntLC

### 3 User interface

The MFBD has features common to different modes. To keep it simple please use the following legend, as it applies to relevant functionality:

#### 3.1 Burner view ● ● ●

The following will be displayed depending on the mode selected:

**Solo** - Custom IP option for connection to Modbus TCP

**Piccolo** - Boiler1/2

**Massimo** - Boiler 1/2/3/4/5/6/7/8

The burner screen gives an overall picture of what is happening with the burner.

Summary:

- ▶ Viewable mode selection: ("Manual On", "Manual Off", "Remote Modulation", "Solo", "Piccolo", "Massimo")
- ▶ Date/time
- ▶ Steam/ hot water

- ▶ Return temperature (if required - Solo or Massimo)
- ▶ Alarm indication
- ▶ Process value
- ▶ Setpoint
- ▶ Firing Rate (Power)
- ▶ Boiler number (Only in Piccolo and Massimo)
- ▶ Communication failure

#### 3.2 Control ● ● ●

- ▶ Selectable setpoint source (local/remote)

Remote setpoints include:

- ▶ Bus
- ▶ 0 - 10 VDC, 4-20ma


LMV3/LMV5 flamesafeguard selection

Control mode selection: ("Manual On", "Manual Off", "Remote Modulation", "Solo", "Piccolo", "Massimo") (Ref. 3.3)

Burner information (Ref. 3.17)

System Configuration (Ref. 3.4)

### 3.3 Burner Mode ● ● ●



**Standalone (Solo):** The burner will use local or remote setpoint to modulate and maintain the process value (PV), without any external intervention. When the selected media is steam and hot standby is active, sending a setpoint of 0 PSI will shut down the burner, however the boiler will be kept warm within the limits of the hot standby routine.

**Remote Modulation:** The burner will run at the specified load received from the BMS system. Load requests from the BMS with value below 20% will shut down the burner.


**Manual ON:** Starts the burner and runs at the specified manual load for an undetermined period of time. The temperature or pressure limit control will still shut down the system.

**Lead/Lag Piccolo mode:** Enables communication and control for the 2 boilers Lead/Lag system.


**Lead/Lag Massimo mode:** Enables communication and control for the 2+ boilers Lead/Lag system.

**Manual OFF:** Stops the burner for an undetermined period of time regardless any existing call for heat.

### 3.4 System Configuration (main menu)






3.5 Media/ Units selection   




Specific Parameters	Default Value	Range
Type of Media - Choose between Steam or Hot Water.	Steam	Steam - Water
Unit display - Select proper temperature unit to be displayed.	°F	°F - °C

3.6 Inputs info and configuration   


When using Burner with LMV3 and RWF55 Help screens are available to assist the technician properly set up the RWF55 to work with the touchscreen.

### 3.7 Remote Setpoint Source & Remote Modulation Source




A remote setpoint can be sent to the burner via 0-20ma/4-20ma/0-10vd hardwired or bus signal.

For Piccolo, signal only needs to be sent to one burner.



A remote modulation signal can be sent to the burner via 0-20ma/4-20ma/0-10vd hardwired or bus signal.

### 3.8 Hot Standby Configuration



Boiler "Hot Standby" will be activated if the water temperature drops below the "Minimum" value. The burner will start and enter "Hot Standby" even if there is no call for heat.


Hot water systems use boiler PV for reference. No extra belly sensor needed.

Steam systems use an extra sensor installed in the boiler belly or boiler pressure depending on "Function mode".

► Do NOT set "Maximum" value over 80% of the "steam temperature" at the system setpoint or the setpoint for the hot water supply.

Specific Parameters	Default Value	Range
<b>Hot Standby -</b> Enable/Disable the hot stand-by routine.	Disabled	Enabled Disabled
<b>Maximum -</b> Target temperature/pressure for the hot standby.	Dependent on system setpoint and media	1 - 400 °F/°C 1 - 400 PSI
<b>Minimum -</b> Trigger value for initiation of hot standby.	Dependent on system setpoint and media	2 - 400 °F/°C 2 - 400 PSI

### 3.8.1 Cold Start Configuration



Specific Parameters	Default Value	Range
<b>Cold start</b> - Enable/Disable the cold start routine.	Disabled	Enabled Disabled
<b>Release</b> - Target temperature/pressure for the cold start.	Dependent on system setpoint and media	1 - 400 °F/°C 1 - 400 PSI
<b>Trigger</b> - Trigger value for initiation of cold start.	Dependent on system setpoint and media	1 - 400 °F/°C 1 - 400 PSI
<b>Max. Time</b> - Max. wait time for load increase.	2 minutes	1 - 10 minutes


Boiler "Cold Start" function will be activated when the water temperature drops below "Trigger". The burner will start and enter "Cold Start" when there is a call for heat.

Hot water systems use boiler PV for reference. No extra belly sensor needed.

Steam systems use an extra sensor installed in the boiler belly or boiler pressure depending on "Function mode".

► Do NOT set "Maximum" value over 80% of the "steam temperature" at the system setpoint or the setpoint for the hot water supply.

### 3.8.2 Function Mode




#### Function mode for Hot Standby and Cold start:

To be used in steam systems when it is not possible (ex. can't install belly sensor) or preferable to use Pressure instead of Temperature as the reference for the functions.


Using temperature on the belly sensor it is still the best choice of control.

Specific Parameters	Default Value	Range
<b>Function mode</b> - Selection of the source reference for control.	Temperature	Temperature Pressure

### 3.9 Pump/Valve Configuration ● ●



### 3.10 Night Setback ● ●



Night setback can be set for any range of time any day of the week. Night setback setpoint will take priority over local or remote setpoint.

3.11 Ethernet Configuration   

Ethernet configuration



Screen IP address  
192 168 100 101

Netmask  
255 255 255 0

Gateway  
0 0 0 0

Here you can change the settings for ethernet communication with this screen.


This address will be used for e-remote access or BMS communication.

(Power cycle required)

Massimo N# config

Done

1 VNC



Set as first in the sequence N1

Set as second in the sequence N2

Set as third in the sequence N3

Set as fourth in the sequence N4

Set as fifth in the sequence N5

Set as sixth in the sequence N6

Set as seventh in the sequence N7

Set as eighth in the sequence N8


Massimo N1

Name your boiler:  
BOILER 4

Done

1 VNC

- Massimo mode: Select "Massimo N# config", sets the actual position of how the boiler will be displayed in the Massimo Touchscreen to match the order of how the boilers are installed in the mechanical room. Also in the bottom right side select the button to give the desired name (number) to this boiler.
- Power cycle after selection.



Screen IP address  
192 168 100 101

Netmask  
255 255 255 0

Gateway  
0 0 0 0

For Massimo or Piccolo Lead/Lag communication use the buttons on the lower left corner for IP assignment.

Custom IP for special applications can be entered on the left side controls.

(Power cycle required)

Piccolo BOILER 1

Piccolo IP config

Done

1 VNC



Set as BOILER 1

Set as BOILER 2


CUSTOM IP

Piccolo BOILER 1

Done

1 VNC

- Piccolo mode: Select "Piccolo IP config", in the next page select the desired boiler number. Power cycle after selection.



Screen IP address  
192 168 100 101

Netmask  
255 255 255 0

Gateway  
0 0 0 0

Here you can change the settings for ethernet communication with this screen.

This address will be used for e-remote access or BMS communication.


(Power cycle required)

Done

1 VNC

- Solo mode: you can set the IP address of the screen for connection through Modbus TCP.

## 3.12 Comms Config ● ●



If a **Riello gateway is connected to the Riello burner**, it is configured in "BMS communication". The S3 dip switch has to be in the off position.


To connect the touchscreen to a gateway, please refer to Riello Gateway N54 Manual or Riello Gateway N34 & N35 Manual. Scan the QR code to view the gateway manual on section 2.2.

Available gateway protocols:

- ▶ BACnet MS/TP
- ▶ BACnet/IP
- ▶ Modbus TCP (gateway only needed for Piccolo)
- ▶ Ethernet/IP
- ▶ Metasys N2
- ▶ Lonworks



## 3.13 General setup Guide ● ● ●






The "General setup Guide" offers assistance to the user in setting up the touchscreen.

- ▶ Burner mode
- ▶ Ethernet Config
- ▶ Media / Units selection
- ▶ Flame safeguard selected

- ▶ RWF communications
- ▶ Input 1 config
- ▶ Input 2 config
- ▶ Input 3 config
- ▶ 2 stage control setup
- ▶ System setup examples

### 3.14 System setup examples ● ● ●



The "Setup system examples" gives an overview view of the control flow for the MFBD.

Examples are included as a guide to setting up RWF55.

### 3.15 2 Stages Control Setup ● ●



**2 stages setup**

Choose the type of control used on the burner. (Fuel 0 / Fuel 1)

**50**

Requested output of this burner **0200** /10

Second stage on this burner will be active when the requested output is over the "switch load setting".

The Start/stop delay buttons on this page allow different delays for lead/lag when the burners are operating in two stage mode.

**4**      **5**

This page displays all the settings for 2 stage setup with Piccolo & Massimo System. When the burner fuel selection is in oil, and in 2 stage mode, the "type of control" selection should be in "modulating/2 stages".


The user adjustable "2nd stage switch load %" will allow the burner to engage into 2nd stage when the requested firing rate of the burner is greater than "2nd stage switch load %".

When burner is operating in second stage, the burner will revert back to its first stage when the firing rate of the burner is less than "2nd stage switch load %".

The "start/stop delay" buttons allow different delays for lead/lag when burners are operating in two stage mode.

It is recommended that burners with 2 stage operation can not be used as a lead boiler.

### 3.16 Alarms & Warnings page ● ● ●




Error screens gives the user plenty of information about each error occurring at the burner, including what the burner failure is, when it occurred and also a translation of what the error means.

The user is able to "Translate" any displayed "ERROR CODE" + "DIAG. CODE"

The last 20 burner alarms are stored.

3.17 Burner ● ● ●




This page displays details of the burner such as:

- ▶ Run hours
- ▶ Number of Starts
- ▶ Air Servomotor
- ▶ Fuel Servomotor
- ▶ Boiler safety
- ▶ Air switch
- ▶ High limit alarm
- ▶ Water level alarm
- ▶ Call for heat indicator
- ▶ Low fuel pressure
- ▶ Error code
- ▶ Diagnostic code
- ▶ Error phase
- ▶ Fan running light
- ▶ Fuel open light
- ▶ Alarm & Warnings page Button


### 3.18 Automatic Fuel Change Over

The automatic fuel changeover function is an optional function for both LMV3X and LMV5X. (LMV3X requires additional hardware). The parameters are programmable to suit your application needs.



Specific Parameters	Default Value	Range
<b>Automatic fuel changeover</b> - Enable/Disable the function.	OFF	OFF - ON
<b>NG/OIL delay</b> - Delay to change to NG when running NG/Digester setup.	45 sec	5 - 600 sec or 5 - 600 min
<b>NG/OIL delay</b> - Delay to change to OIL when running NG/OIL setup.	15 sec	5 - 600 sec or 5 - 600 min
<b>DG/NG delay</b> - Delay to change back to digester on a NG/Digester setup.	180 min	5 - 600 sec or 5 - 600 min
<b>DG/NG delay</b> - Delay to change back to NG on a NG/OIL setup.	30 min	5 - 600 sec or 5 - 600 min
<b>DG/OIL pump delay</b> - Delay to shutdown a digester booster or oil ring pump to avoid low pressure alarms during changeover.	45 sec	1 - 60 sec or 1 - 60 min

### 3.19 Show/Hide Display Items



Show/Hide display items:  
The button function on this page hides the temperature in Return/Belly readings.  
Show Pump/Valve Status is only available in LMV5x.




## QuickStart Guide - Setting up control mode

4

### QuickStart Guide - Setting up control mode

#### 4.1 QuickStart Guide - Setting up Solo mode


For Solo mode functionality. See below for setting up touch screen in Solo mode.



Set for LMV3x or LMV5x

Select "Standalone (Solo)"  
After selection, click done and power cycle the touchscreen.




After completion your main screen will display "Standalone Mode selected"



#### 4.2 QuickStart Guide - Setting up Piccolo mode

See below for lead/lag functionality.  
See below for setting up touchscreen in Piccolo mode.


##### Step 1: Selecting Piccolo mode




Set for LMV3x or LMV5x

Select "Lead/ Lag Piccolo (2 boilers)"


After completion your main screen will display "Piccolo Lead/Lag selected"




### Step 2: Selecting boiler number for Piccolo mode



Select "Piccolo IP config".




After selecting boiler number, power cycle the touchscreen. THIS IS VERY IMPORTANT!



After power cycle is done, on the main screen you will see "Piccolo B(x)" displayed.

### Step 3: Piccolo configurations



This page displays lead/lag information and the actual configurations.

See Page 26

## QuickStart Guide- Setting up control mode

### Step 4: Piccolo configurations (Lead/Lag)

**Lead/Lag Configuration**

"Start Lag" is the point where the Lag boiler will be started to supplement the load.

"Stop Lag" is the point where the Lag boiler will be stopped when the Lead is able to provide full system load.

Percentage referent to the Lead boiler load.

Start Lag %: **60**

Stop Lag %: **30**

Done Next >>

Specific Parameters	Default Value	Range
<b>Start Lag</b> - Point where the lag boiler will be started.	60 %	50 to 99 %
<b>Stop Lag</b> - Point where the lag boiler will be stopped.	30 %	20 to 40 %

**Lead/Lag Configuration**

"Start Delay" is the delay for starting the Lag boiler after the function "Start Lag" is triggered.

"Stop Delay" is the delay for stopping the Lag boiler after the function "Stop Lag" is triggered.

Units are minutes.

Start Delay: **2**

Stop Delay: **2**

<< Back Done Next >>

Specific Parameters	Default Value	Range
<b>Start Delay</b> - Delay for starting the lag boiler.	2 minute(s)	1 to 10 minute(s)
<b>Stop Delay</b> - Delay for stopping the lag boiler.	2 minute(s)	1 to 10 minute(s)

**Lead/Lag Configuration - Boiler SP correction**

Enter Maximum and Minimum values that the system will set the BOILER SP when performing a correction.

Over SP hysteresis: **1**

Below SP: **5**

Boiler SP correction interval in minutes: **5**

Maximum Boiler SP: **0**

Minimum Boiler SP: **0**

HEADER PV <-> SP deviation that triggers correction (PV units)

<< Back Done Next >>

Specific Parameters	Default Value	Range
<b>Max. Boiler SP</b> - Max. value that system will set Boiler SP.	Dependent on system setpoint and media	1 to 10 minute(s)
<b>Min. Boiler SP</b> - Min. value that system will set Boiler SP.	Dependent on system setpoint and media	1 to 10 minute(s)
<b>Over SP</b> - Deviation that triggers correction.	1 unit(s)	1 to 2 unit(s)
<b>Below SP</b> - Deviation that triggers correction.	5 unit(s)	1 to 9 unit(s)
<b>Boiler SP interval</b> - Boiler correction interval in minutes.	5 minute(s)	3 to 9 minute(s)

This screen is for setting up the setpoint shift on the Piccolo system.

"Minimum" and "Maximum" BOILER operation SETPOINT shift per "Boiler SP correction interval in minutes" Hysteresis set the minimum and maximum limits that the setpoint can be shifted to.

**Lead/Lag Configuration**

Rotation Time in hours: **0**

Set how many hours will take for the system to rotate the lead boiler. 0 never rotates

This boiler is the "Server" (the one that will make the rules). BMS hardwired setpoint should be connected on this burner.

Deviation from Header SP: **0**

Safety value: **150**

Any undetected failure on the Lead boiler will turn this one into lead if the HEADER PV drops below the safety value

<< Back Done Next >>

Specific Parameters	Default Value	Range
<b>Rotation time</b> - Schedule lead rotation.	24 hour(s)	0 to 168 hour(s)
<b>Header SP Deviation</b> - Safety trigger value for undetected failure.	Dependent on system setpoint and media	0 to 250 unit(s)

Rotation time can only be set on boiler 1

## 4.3 QuickStart Guide- Setting up Massimo

See below for lead/lag functionality.  
See below for setting up touchscreen in Massimo mode.

### Step 1: Selecting Massimo mode

Boiler SP: 150 PSI  
Steam System  
Belly Temp: 088 °F  
Return Temp: 000 °F  
RIELLO MFB0 v3.50b 09:22 08/05/2022 Alarm & Warnings page Burner Info Control 1 VNC

Normal Operation  
Power: 024 %  
Boiler PV: 081 PSI  
Standalone Mode selected

SP source selection  
Local Setpoint Input 150  
Remote Setpoint Display 080  
Change Burner Mode  
Standalone (Solo) Mode selected  
System Configuration  
LMV 3x selected Burner Info Main 1 VNC

Set for LMV3x or LMV5x

Standalone (Solo) Remote Modulation  
Manual ON Lead / Lag Piccolo (2 boilers)  
Manual OFF Lead / Lag Massimo (2+ boilers)  
Standalone (Solo) Mode selected Done

Select "Lead/lag Massimo (2+ boilers)"

### Step 2: Selecting boiler number

SP source selection  
Local Setpoint Input 150  
Remote Setpoint Display 080  
Change Burner Mode  
Lead / Lag Massimo mode selected (2+ boilers)  
System Configuration  
LMV 3x selected Burner Info Main 1 VNC

Media / Units selection Hot Standby configuration  
Inputs Info and configuration  
Alarm & Warnings page Show/Hide display items Control Main 1 VNC

Ethernet configuration  
General setup Guide  
Cold Start configuration  
System setup examples

Screen IP address  
192 168 100 101  
Netmask 255 255 255 0  
Gateway 0 0 0 0  
Here you can change the settings for ethernet communication with this screen.  
This address will be used for e-remote access or BMS communication.  
(Power cycle required)  
Select N1 Massimo N# config Done 1 VNC

Select "Massimo N# config".

Set as first in the sequence N1  
Set as second in the sequence N2  
Set as third in the sequence N3  
Set as fourth in the sequence N4  
Set as fifth in the sequence N5  
Set as sixth in the sequence N6  
Set as seventh in the sequence N7  
Set as eighth in the sequence N8  
Massimo N1  
Name your boiler:  
BOILER 4  
Done 1 VNC

Boiler SP: 150 PSI  
Steam System  
Belly Temp: 088 °F  
Return Temp: 000 °F  
RIELLO MFB0 v3.50b 11:36 08/05/2022 Alarm & Warnings page Burner Info Control 1 VNC

Massimo N1  
Boiler 4  
Normal Operation  
Power: 100 %  
Boiler PV: 081 PSI  
Massimo Lead/Lag selected

After selecting the position of the boiler in the sequence of operation and naming the boiler, power cycle the touchscreen. (THIS IS IMPORTANT)

After the power cycle, on the main screen you will see "Massimo N(x) and Boiler (x)" displayed.

### Step 3: Finishing setup of the Massimo

Please refer to "Massimo System v3.50" manual for completion of system lead/lag setup.


5

Remote monitoring - VNC Viewer

Remote monitoring of the Massimo touchscreen is possible from VNC Viewer application.

5.1 Hardware

Connect a Cat 5 or Cat 6 ethernet cable between remote desktop and Ethernet LAN2 as shown below.



5.2 Setting up VNC Viewer application

Connect to the Riello touchscreen through a third party VNC software by entering the IP of the touchscreen.

The IP of the burner touchscreens is set up and accessed through the burner touchscreen in "Ethernet Configuration" parameter.

The IP of the Massimo panel touchscreen is 192.168.100.111.

Recommended software for the VNC is "VNC CONNECT by RealVNC" (VNC Viewer) See link below for download:

<https://www.realvnc.com/en/connect/download/viewer/>



### 6


### Multi-function display version update

#### Introduction

The multi-function display is designed and programmed inhouse. Continuous improvements are being made to the system. For latest version please send a request to Riello for newest version (if available).

#### 6.1 Unpacking the software


1- Unzip "vX.XX\_loader" into a separate folder you desire



These are the contents of the folder after you have unzipped them.

2- Prepare one USB drive, formatted using FAT32 file system

3- For the burner screen update (Solo, Piccolo, Massimo), open the folder "burner hmi" indicated as selection B



This is the content of the folder "burner hmi" after you open it.


4- Copy then this "HMI\_AutoUP" folder to the root directory of and empty USB drive.

#### 6.2 Burner HMI update

1- Power OFF the burner screen

2- Insert USB stick with "HMI\_AutoUP" from selection B (see section 6.1)


3- Power up the screen and wait for full boot up and the screen will ask you:  
"Start automatic update?"



5 – Answer yes and Wait for FULL boot up. The screen will ask again to begin update, say no.

6 – Power OFF the screen and unplug the USB disk.

7 – Power the screen back ON and you're done... :)



**7** Points list  
**7.1** MFBD points list: Modbus

Point Name	Modbus Address (4xxxx)	Modbus TPC Data Type	Unit	Range
Burner Phase	001 (U16)	Holding Reg.	No-units	0-255
Fuel Servo	002 (U16)	Holding Reg.	Degrees-angular	(-)-3-93°
Air servo	005 (U16)	Holding Reg.	Degrees-angular	(-)-3-93°
VFD	009 (U16)	Holding Reg.	Percent	0-100 %
Current fuel	010 (U16)	Holding Reg.	No-units	0= Gas 1= Oil
Current output	011 (U16)	Holding Reg.	Percent	0-100 %
Flame signal	014 (U16)	Holding Reg.	Percent	0-100 %
Error code	026 (U16)	Holding Reg.	No-units	0-255
Diagnostic code	027 (U16)	Holding Reg.	No-units	0-255
Error phase	029 (U16)	Holding Reg.	No-units	0-255
<b>Inputs</b>	036 (U16)	Holding Reg.	-	-
Calls for heat	Bit 0	-	No-units	0 - off, 1 - on
Boiler safety loop	Bit 8	-	No-units	0 -open, 1-closed
Gas low & high pressure	Bit 10	-	No-units	0 -open, 1-closed
Air pressure	Bit 13	-	No-units	0 - off, 1 - on
<b>Outputs</b>	038 (U16)	Holding Reg.	-	-
Alarm	Bit 0	-	No-units	0-Normal, 1- Alarm
Ignition transformer	Bit 4	-	No-units	0 - off, 1 - on
Burner fan	Bit 6	-	No-units	0 - off, 1 - on
Fuel valve	Bit 13	-	No-units	0 - off, 1- on
Hours run gas	057,058 (S32)	Holding Reg.	Hours	0 - 999999 h
Hours run oil	059,060 (S32)	Holding Reg.	Hours	0 - 999999 h
Starts gas	071,072 (S32)	Holding Reg.	No-units	0 - 999999 h
Starts oil	073,074 (S32)	Holding Reg.	No-units	0 - 999999 h
Total Starts	077,078 (S32)	Holding Reg.	No-units	0 - 999999 h
Boiler PV	085 (U16)	Holding Reg.	No Unit	**
<b>Boiler Inputs</b>	086 (U16)	Holding Reg.	-	-
Boiler high limit	Bit 0	-	No-units	0 - normal, 1 - alarm
Boiler LWCO	Bit 1	-	No-units	0 - normal, 1 - alarm
Header Process Value	088 (U16)	Holding Reg.	No-units	**
Outside Temp. Sensor (MFBD+)	089 (U16)	Holding Reg.	No-units	**
BMS Modulation (W)	99 (U16)	Holding Reg.	No units	0-100
BMS setpoint (W)	100 (U16)	Holding Reg.	No units	**

\*\* For gateway points list for all other available protocols see "Riello Gateway N34 & N35 Manual" or "Riello Gateway N54 Manual".

\*\* Means - Unit range depends on the unit selected on the burner control (F,C & PSI). All units are scaled and within acceptable range of the variable.

(W) - Means Writable Points.



35 Pond Park Road  
Hingham, Massachusetts  
USA 02043

RIELLO BURNERS NORTH AMERICA  
1(800)4-RIELLO

1(800)474-3556

[www.riello.ca](http://www.riello.ca)

2165 Meadowpine Blvd.  
Mississauga, Ontario  
Canada L5N 6H6