

Light oil burners

Low - High Operation



CODE	MODEL	TYPE
C9514200 (3475070)	RL 70	660T70
C9514201 (3475075)	RL 70	660T70
C9515200 (3475270)	RL 100	661T70
C9515201 (3475275)	RL 100	661T70
C9516200 (3475470)	RL 130	662T70
C9516201 (3475475)	RL 130	662T70

CONTENTS

TECHNICAL DATA	page 3
Burner models designations.	4
Accessories	4
Burner description	5
Packaging - Weight	5
Max. dimensions	5
Standard equipment.	5
Firing rate	6
Minimum furnace dimensions.	6
INSTALLATION	7
Boiler plate	7
Blast tube length	7
Securing the burner to the boiler	7
Choice of nozzles for low and high fire.	7
Nozzle assembly	8
Combustion head setting	8
Fuel supply	9
Hydraulic connections	9
Pump	10
Burner calibration	11
Final checks.	12
Maintenance	12
Burner operation	13
Procedure to refer burner operating condition in high altitude plants.	14
Flame signal measurements	15
Burner faults	16
Motor connection at 208-230 or 460V	17
Calibration of the thermal relay	18
Factory wiring diagram.	19
Burner start up report.	21
Spare parts list.	22

N.B.

Figures mentioned in the text are identified as follows:

- 1)(A) = part 1 of figure A, same page as text;
- 1)(A)p.4 = part 1 of figure A, page number 4.

WARNING

Do not store flammable or hazardous materials in the vicinity of fuel burning appliances.

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death. Refer to this manual for instructional or additional information. Consult a certified installer, service representative or the gas supplier for further assistance.

Burner shall be installed in accordance with manufacturers requirements as outlined in this manual, local codes and authorities having jurisdiction.

TECHNICAL DATA

MODEL			RL 70	RL 100	RL 130
Output ⁽¹⁾ Delivery ⁽¹⁾	High fire	MBtu/hr ⁽³⁾	1792 - 3136	2688 - 4480	3584 - 5824
		GPH	12.8 - 22.4	19.2 - 32	25.6 - 41.6
	Low fire	MBtu/hr ⁽³⁾	966 - 1792	1344 - 2688	1834 - 3584
		GPH	6.9 - 12.8	9.6 - 19.2	13.1 - 25.6
Fuel			# 2 Fuel oil		
Operation			Low - high		
Nozzles		number	2		
Standard applications			Hot water, steam, thermal oil		
Ambient temperature		°F	32 - 104 (0 - 40 °C)		
Combustion air temperature		°F max	140 (60 °C)		
Pump	delivery (174 Psi) pressure range	GPH	54		
		PSI	145 - 290		
Noise levels ⁽²⁾		dBA	68.0	70.0	70.0

(1) Reference conditions: Ambient temperature 68° F (20° C) - Barometric pressure 394" WC - Altitude 329 ft.

(2) Sound pressure measured in manufacturers combustion laboratory, with burner operating on test boiler and at maximum rated output.

(3) Equivalent Btu values based on 1 USGPH = 140,000 Btu/hr.

Fan motor IE1

Three phase burner

Model		RL 70	RL 100	RL 130
Control circuit power supply	V/Ph/Hz	120/1/60		
Main electrical supply (+/- 10%)	V/Ph/Hz	208-230/3/60		
Fan and pump motor	rpm	3400	3400	3400
	W - HP	1100 - 1.5	2200 - 3	2200 - 3
	V	208-230	208-230	208-230
	A	4.7	8.5	8.5
Ignition transformer	V1 - V2	120 V - 2 X 5 kV		
	I1 - I2	2.7 A - 30 mA		
Electrical power consumption	W max	1550	2750	2750
Electrical control circuit coms.	W	750		
Total electrical consumption	W	2300	3500	3500
Electrical protection		NEMA 1		

Model		RL 70	RL 100	RL 130
Control circuit power supply	V/Ph/Hz	120/1/60		
Main electrical supply (+/- 10%)	V/Ph/Hz	460/3/60		
Fan and pump motor	rpm	3400	3400	3400
	W - HP	1100 - 1.5	2200 - 3	2200 - 3
	V	460	460	460
	A	2.7	4.9	4.9
Ignition transformer	V1 - V2	120 V - 2 X 5 kV		
	I1 - I2	2.7 A - 30 mA		
Electrical power consumption	W max	1750	3150	3150
Electrical control circuit coms.	W	750		
Total electrical consumption	W	2500	3900	3900
Electrical protection		NEMA 1		

Model		RL 70	RL 100	RL 130
Control circuit power supply	V/Ph/Hz	120/1/60		
Main electrical supply (+/- 10%)	V/Ph/Hz	575/3/60		
Fan and pump motor	rpm	3360	3400	3400
	W - HP	1100 - 1.5	2200 - 3	2200 - 3
	V	575	575	575
	A	2	3.7	3.7
Ignition transformer	V1 - V2	120 V - 2 X 5 kV		
	I1 - I2	2.7 A - 30 mA		
Electrical power consumption	W max	1550	2900	2900
Electrical control circuit coms.	W	750		
Total electrical consumption	W	2300	3650	3650
Electrical protection		NEMA 1		

Three phase burner

Model		RL 70	RL 100	RL 130
Control circuit power supply	V/Ph/Hz	120/1/60		
Main electrical supply (+/- 10%)	V/Ph/Hz	208-230/3/60		
Fan and pump motor	rpm	3475	3500	3500
	W - HP	1100 - 1.5	2200 - 3	2200 - 3
	V	208-230	208-230	208-230
	A	4	7.8	7.8
Ignition transformer	V1 - V2	120 V - 2 X 5 kV		
	I1 - I2	2.7 A - 30 mA		
Electrical power consumption	W max	1350	2600	2600
Electrical control circuit coms.	W	750		
Total electrical consumption	W	2100	3350	3350
Electrical protection		NEMA 1		

Model		RL 70	RL 100	RL 130
Control circuit power supply	V/Ph/Hz	120/1/60		
Main electrical supply (+/- 10%)	V/Ph/Hz	460/3/60		
Fan and pump motor	rpm	3475	3500	3500
	W - HP	1100 - 1.5	2200 - 3	2200 - 3
	V	460	460	460
	A	2	3.9	3.9
Ignition transformer	V1 - V2	120 V - 2 X 5 kV		
	I1 - I2	2.7 A - 30 mA		
Electrical power consumption	W max	1350	2600	2600
Electrical control circuit coms.	W	750		
Total electrical consumption	W	2100	3350	3350
Electrical protection		NEMA 1		

Model		RL 70	RL 100	RL 130
Control circuit power supply	V/Ph/Hz	120/1/60		
Main electrical supply (+/- 10%)	V/Ph/Hz	575/3/60		
Fan and pump motor	rpm	3475	3500	3500
	W - HP	1100 - 1.5	2200 - 3	2200 - 3
	V	575	575	575
	A	1.6	3.1	3.1
Ignition transformer	V1 - V2	120 V - 2 X 5 kV		
	I1 - I2	2.7 A - 30 mA		
Electrical power consumption	W max	1350	2600	2600
Electrical control circuit coms.	W	750		
Total electrical consumption	W	2100	3350	3350
Electrical protection		NEMA 1		

Burner models designations:

Model	Code	Voltage	Flame safeguard
RL 70	C9514200 (3475070)	208-230/460/3/60	Burner mounted
	C9514201 (3475075)	575/3/60	Burner mounted
RL 100	C9515200 (3475270)	208-230/460/3/60	Burner mounted
	C9515201 (3475275)	575/3/60	Burner mounted
RL 130	C9516200 (3475470)	208-230/460/3/60	Burner mounted
	C9516201 (3475475)	575/3/60	Burner mounted

ACCESSORIES (optional):

• Kit for lengthening the combustion head

L = Standard length

L1 = Length obtainable with the kit



COD. **3010253** L = 9²⁷/₃₂" L1 = 15⁵/₃₂" • RL 70

COD. **3010254** L = 9²⁷/₃₂" L1 = 15⁵/₃₂" • RL 100

COD. **3010255** L = 9²⁷/₃₂" L1 = 15⁵/₃₂" • RL 130


Important:

The installer is responsible for the supply and installation of any safety device(s) not indicated in this manual.




(A)

inch	A ₍₁₎	B	C	lbs
RL70	37 ²⁵ / ₃₂ " - 45 ⁹ / ₃₂ "	23 ⁵ / ₈ "	25 ¹¹ / ₁₆ "	132
RL100	37 ²⁵ / ₃₂ " - 45 ⁹ / ₃₂ "	23 ⁵ / ₈ "	25 ¹¹ / ₁₆ "	139
RL130	37 ²⁵ / ₃₂ " - 45 ⁹ / ₃₂ "	23 ⁵ / ₈ "	25 ¹¹ / ₁₆ "	146



(B)



(C)

RL	A	B	C	D	E	F ₍₁₎	G	H	I ₍₁₎
70	22 ²⁷ / ₃₂ "	11 ²¹ / ₃₂ "	11 ³ / ₁₆ "	21 ²⁷ / ₃₂ "	26 ²⁵ / ₃₂ "	9 ²⁷ / ₃₂ " - 15 ⁵ / ₃₂ "	7 ¹ / ₁₆ "	16 ¹⁵ / ₁₆ "	37 ⁷ / ₁₆ " - 42 ³ / ₄ "
100	23 ¹⁹ / ₃₂ "	12 ⁹ / ₃₂ "	11 ⁵ / ₁₆ "	21 ²⁷ / ₃₂ "	26 ²⁵ / ₃₂ "	9 ²⁷ / ₃₂ " - 15 ⁵ / ₃₂ "	7 ¹ / ₁₆ "	16 ¹⁵ / ₁₆ "	37 ⁷ / ₁₆ " - 42 ³ / ₄ "
130	24 ⁵ / ₈ "	13 ⁵ / ₁₆ "	11 ⁵ / ₁₆ "	21 ²⁷ / ₃₂ "	26 ²⁵ / ₃₂ "	9 ²⁷ / ₃₂ " - 15 ⁵ / ₃₂ "	7 ⁷ / ₁₆ "	16 ¹⁵ / ₁₆ "	37 ⁷ / ₁₆ " - 42 ³ / ₄ "

(1) Blast tube: short - long (obtainable with the kit)

BURNER DESCRIPTION (A)

- 1 Ignition electrodes
- 2 Combustion head
- 3 Screw for combustion head adjustment
- 4 Screw for fixing fan to flange
- 5 Slide bars for opening the burner and inspecting the combustion head
- 6 Safety solenoid valve
- 7 Pump
- 8 Air inlet to fan
- 9 Air damper
- 10 Hydraulic cylinder for regulation of the air damper at low and high positions. When the burner is not operating the air damper is fully closed in order to reduce heat loss from the boiler.
- 11 Fan pressure test point
- 12 Boiler mounting flange
- 13 Flame stability disk
- 14 Electrical motor
- 15 Extensions for slide bars 5)
- 16 Ignition transformer
- 17 Motor contactor and thermal cut-out with reset button
- 18 Low and high fire valve assembly
- 19 Terminal strip
- 20 Two switches:
 - one "burner off - on"
 - one low - high operation"
- 21 Knockouts for wiring carried out by the installer
- 22 Flame safeguard with lock-out pilot light and lock-out reset button
- 23 Flame inspection window
- 24 Pump pressure adjustment
- 25 Photocell (cad cell)
- 26 Air pressure switch

Two types of burner failure may occur:

• FLAME SAFEGUARD LOCK-OUT:

if the Flame relay 22)(A) pushbutton lights up, it indicates that the burner is in lock-out.

To reset, press the pushbutton.

• MOTOR TRIP:

release by pressing the pushbutton on thermal relay.

PACKAGING-WEIGHT (B)

Approximate measurements

- The burner is shipped on a skid. Outer dimensions of packaging are indicated in (B)
- The weight of the burner complete with packaging is indicated in table (B).

MAX. DIMENSIONS (C)

Approximate measurements

The maximum dimensions of the burners are given in (C).


Inspection of the combustion head requires the burner to be opened and the rear part withdrawn on the slide bars.

The maximum dimension of the burner when open is given in measurement I.


STANDARD EQUIPMENT

- 2 - Flexible hoses
- 1 - Head gasket
- 4 - Screws to secure the burner flange to the boiler: 1/2 W x 13/8"
- 1 - Instruction booklet
- 1 - Spare parts list
- 1 - Adaptor G1/8" - 1 3/8" NPT


RL 70



RL 100



RL 130



FIRING RATE (A)

The RL 70 - 100 - 130 Model burners can work in two ways: Low and High fire.

LOW FIRE DELIVERY must be selected within area A of the adjacent diagrams.

HIGH FIRE DELIVERY must be selected within area B (and C for model RL 130). This area provides the maximum delivery of the burner in relation to the pressure in the combustion chamber.

The firing rate may be found by plotting a vertical line from the desired delivery and a horizontal line from the pressure in the combustion chamber. The intersection of these two lines is the firing rate which must lie within area B. In order to also utilize area C (RL 130) it is necessary to perform the calibration of the combustion head as explained on page 7.

Important:

the FIRING RATE area values have been obtained considering an ambient temperature of 68° F (20 °C), and an atmospheric pressure of 394" WC (approx. 329 ft above sea level) and with the combustion head adjusted as shown on page 8.

Note:

The FIRING RATE areas given in figure (A) have been reduced by 10% with respect to the maximum range that can be reached.

Consult Procedure on page 14 to refer burner operating condition in high altitude plants.

MINIMUM FURNACE DIMENSIONS (B)

The firing rates were set in relation to certified test boilers.


Figure (B) indicates the diameter and length of the test combustion chamber.

Example

Output 2579 MBTU/hr:
diameter 24 inch - length 6.6 ft.

(A)


D2325




(B)

D2919


inch	A	B	C
RL 70	7 ⁹ / ₃₂ "	10 ²⁷ / ₃₂ " - 12 ¹³ / ₁₆ "	1/2 W
RL 100	7 ⁹ / ₃₂ "	10 ²⁷ / ₃₂ " - 12 ¹³ / ₁₆ "	1/2 W
RL 130	7 ⁹ / ₃₂ "	10 ²⁷ / ₃₂ " - 12 ¹³ / ₁₆ "	1/2 W



(A)



(B)



(C)

Nozzle size	145 PSI	GPH	203 PSI	MBtu/hr
		174 PSI		174 PSI
5.0	6.15	6.79	7.40	951
5.5	6.76	7.46	8.13	1044
6.0	7.40	8.17	8.87	1144
6.5	8.00	8.84	9.60	1238
7.0	8.61	9.51	10.34	1331
7.5	9.22	10.18	11.08	1425
8.0	9.86	10.85	11.81	1519
8.3	10.21	11.27	12.26	1578
8.5	10.47	11.56	12.55	1618
9.0	11.08	12.23	13.29	1712
9.5	11.69	12.90	14.06	1806
10.0	12.30	13.58	14.76	1901
10.5	12.94	14.28	15.50	1999
11.0	13.54	14.95	16.23	2093
12.0	14.76	16.30	17.71	2282
12.3	15.15	16.71	18.16	2339
13.0	16.01	17.64	19.18	2470
13.8	17.00	18.73	20.27	2622
14.0	17.23	19.02	20.65	2663
15.0	18.48	20.37	22.16	2852
15.3	18.83	20.78	22.57	2909
16.0	19.69	21.74	23.63	3044
17.0	20.94	23.09	25.10	3233
17.5	21.55	23.76	25.84	3326
18.0	22.16	24.46	26.58	3424
19.0	23.38	25.81	28.05	3613
19.5	24.01	26.48	28.79	3707
20.0	24.62	27.15	29.52	3801
21.5	26.48	29.20	31.73	4088
22.0	27.09	29.86	32.47	4180

(D)

INSTALLATION

BOILER PLATE (A)

Drill the combustion chamber mounting plate as shown in (A). The position of the threaded holes can be marked using the burner gasket supplied with the burner.

BLAST TUBE LENGTH (B)

The length of the blast tube must be selected according to the indications provided by the manufacturer of the boiler, and it must be greater than the thickness of the boiler door complete with its insulation. The range of lengths available, L (inch), is as follows:

Blast tube 9):	RL 70	RL 100	RL 130
• short	9 ²⁷ / ₃₂	9 ²⁷ / ₃₂	9 ²⁷ / ₃₂
• long (with the kit)	15 ⁵ / ₃₂	15 ⁵ / ₃₂	15 ⁵ / ₃₂

For boilers with front flue passes 12) or flame inversion chambers, protective insulation material 10) must be inserted between the boiler's refractory 11) and the blast tube 9).

This protective insulation must not compromise the extraction of the blast tube.

For boilers having a water-cooled front, the insulation 10)-11)(B) is not required unless it is required by the boiler manufacturer.

SECURING THE BURNER TO THE BOILER (B)

Disassemble the blast tube 9) from the burner 6) by proceeding as follows:

- Loosen the four screws 3) and remove the cover 1).
- Remove the screws 2) from the two slide bars 5).
- Remove the two screws 4) fixing the burner 6) to the flange 5).
- Withdraw the blast tube 9) complete with flange 7) and slide bars 5).

COMBUSTION HEAD CALIBRATION

At this point check, for model RL 130, whether the maximum delivery of the burner in high fire operation is contained in area B or in area C of the firing rate. See page 5.

If it is in area B then no operation is required.

If, on the other hand, it is in area C:

- Unscrew the screws 1)(C) and disassemble the blast tube 5).
- Unscrew the screws 3) and remove the shutter 4).
- Tighten the screws 3) on the rod 2).
- Now refit the blast tube 5) and the screws 1).

Once this operation has been carried out (if required), secure flange 7)(B) to the boiler plate inserting the supplied gasket 8). Use the 4 screws provided after having protected the thread with an antiseize product (high-temperature grease, compounds, graphite). The burner-boiler seal must be airtight.

CHOICE OF NOZZLES FOR LOW AND HIGH FIRE




Both nozzles must be chosen from among those listed in Table (D).

The first nozzle determines the delivery of the burner at low fire.



The second nozzle works in combination with the low fire nozzle to determine the delivery of the burner at high fire.

The total deliveries of low and high fire must be contained within the value range indicated on page 3.

Use nozzles with a 60° spray angle at the recommended pressure of 174 PSI.



SETTING THE COMBUSTION HEAD



The two nozzles usually have equal deliveries, but the low fire nozzle may have the following specifications if required:

- a delivery less than 50% of the total delivery whenever the back-pressure peak must be reduced at the moment of firing: the burner allows good combustion values also with a ratio 40 - 100 % between low and high fire;
- a delivery higher than 50% of the total delivery whenever the combustion during low fire must be improved.

Example with the RL 70 Model:

Boiler output = 2130 MBTU/hr - efficiency 80 %

Output required by the burner =

2130 : 0.8 = 2662 MBTU/hr;

2662 : 2 = 1331 MBTU/hr per nozzle;

therefore, two equal, 60°, 174 PSI nozzles are required:

1° = 7.0 GPH - 2° = 7.0 GPH,

or the following two different nozzles:

1° = 6.0 GPH - 2° = 8.0 GPH,

or:

1° = 8.0 GPH - 2° = 6.0 GPH.

NOZZLE ASSEMBLY

At this stage of installation the burner is still disassembled from the blast tube; it is now possible to install the two nozzles, after having removed the plastic plugs 2)(A), fitting the wrench through the central hole in the flame stability disk.

Do not use any sealing products such as gaskets, sealing compound, or tape. Be careful to avoid damaging the nozzle sealing seat. The nozzles must be screwed into place tightly but carefully.

The nozzle for low fire operation is the one lying beneath the firing electrodes Fig. (B).

Make sure that the electrodes are positioned as shown in Figure (B).

Finally remount the burner 3)(C) to the slide bars 2) and slide it up to the flange 5), keeping it slightly raised to prevent the flame stability disk from pressing against the blast tube.

Tighten the screws 1) on the slide bars 2) and screws 4) fixing the burner to the flange.

If it proves necessary to change a nozzle with the burner already fitted to the boiler, proceed as outlined below:

- Retract the burner on its slide bars as shown in fig. (B)p.6.
- Remove the nuts 1)(D) and the disk 2).
- Use wrench 3)(D) to change the nozzles.

COMBUSTION HEAD SETTING

The setting of the combustion head depends exclusively on the delivery of the burner at high fire - in other words, the combined delivery of the two nozzles selected on page 7. Turn screw 4)(E) until the notch shown in diagram (F) is level with the front surface of flange 5)(E).


Example:

The RL 70 Model with two 6.00 GPH nozzles and 174 PSI pump pressure.

Find the delivery of the two 6.00 GPH nozzles in table (D), page 7:

8.17 + 8.17 = 16.34 GPH.


Diagram (F) indicates that for a delivery of 16.34 GPH the RL 70 Model requires the combustion head to be set to approx. three notches, as shown in Figure (E).



+ H - H ft	L ft		
	RLS 70 - 100 - 130 Ø inch		
	3/8"	1/2"	5/8"
+ 13	100	210	320
+ 10	88	180	320
+ 6.6	75	155	320
+ 3.3	68	140	320
+ 1.6	52	110	270
0	45	98	240
- 1.6	39	85	200
- 3.3	26	55	140
- 6.6	19	42	104
- 10	--	13	36

(A)

HYDRAULIC CONNECTIONS



(B)

HYDRAULIC SYSTEM

FUEL SUPPLY

Double-pipe circuit (A)

The burner is equipped with a self-priming pump which is capable of feeding itself within the limits listed in the table at the left.

The tank higher than the burner A

The distance "P" must not exceed 32 ft in order to avoid subjecting the pump's seal to excessive strain; the distance "V" must not exceed 13 ft in order to permit pump self-priming even when the tank is almost completely empty.

The tank lower than the burner B

Pump suction values higher than 13 "Hg must not be exceeded because at higher levels gas is released from the fuel, the pump starts making noise and its working life-span decreases.

It is good practice to ensure that the return and suction lines enter the burner from the same height; in this way it will be less probable that the suction line fails to prime or stops priming.

The loop circuit

A loop circuit consists of a loop of piping exiting and returning to the tank with an auxiliary pump that circulates the fuel under pressure. A branch connection from the loop goes to feed the burner. This circuit is extremely useful whenever the burner pump does not succeed in self-priming because the tank distance and/or height difference are higher than the values listed in the table.

Key (A)

H = Pump/Foot valve height difference

L = Piping length

Ø = Inside pipe diameter

1 = Burner

2 = Pump

3 = Filter

4 = Manual on/off valve

5 = Suction line

6 = Foot valve

7 = Return line

HYDRAULIC CONNECTIONS (B)

The pumps are equipped with a by-pass that connects return line and suction line.

The pumps are installed on the burner with the by-pass closed by screw 6)(A)p.13.

It is therefore necessary to connect both hoses to the pump.

The pump seal will be damaged immediately if it is run with the return line closed and the bi-pass screw inserted.


Remove the plugs from the suction and return connections of the pump.

Insert the hose connectors with the supplied seals into the connections and screw them down.

Take care that the hoses are not stretched or twisted during installation.

Install the hoses where they cannot be stepped on or come into contact with hot surfaces of the boiler.

Now connect the other end of the hoses to the supplied nipples, using two wrenches, one to hold the nipple steady while using the other one to turn the rotary union on the hose.



PUMP		AJ4
A	GPH	54
B	PSI	145 - 290
C	"Hg	13
D	cSt	2,8 - 75
E	°F - °C	140 - 60
F	PSI	29
G	PSI	174
H	inch	0,006

PUMP (A)

- 1 - Suction 1/4" NPT
- 2 - Return 1/4" NPT
- 3 - Pressure gauge attachment G 1/8
- 4 - Vacuum gauge attachment G 1/8
- 5 - Pressure adjustment screw
- 6 - Screw for by-pass

- A - Min. delivery rate at 174 PSI pressure
- B - Delivery pressure range
- C - Max. suction pressure
- D - Viscosity range
- E - Light oil max. temperature
- F - Max. suction and return pressure
- G - Pressure calibration in the factory
- H - Filter mesh width

PUMP PRIMING

- Before starting the burner, make sure that the tank return line is not clogged. Obstructions in the line could cause the seal located on the pump shaft to break. (The pump leaves the factory with the by-pass closed).
- In order for self-priming to take place, one of the screws 3)(A) of the pump must be loosened in order to bleed off the air contained in the suction line.
- Start the burner by closing the control circuit and with switch 1)(C)p.11 in the "ON" position. The pump must rotate in the direction of the arrow marked on the cover.
- The pump can be considered to be primed when the light oil starts coming out of the screw 3). Stop the burner: switch 1)(C)p.11 set to "OFF" and tighten the screw 3).

The time required for this operation depends upon the diameter and length of the suction tubing.

If the pump fails to prime at the first starting of the burner and the burner locks out, wait approx. 15 seconds, reset the burner, and then repeat the starting operation as often as required.

After 5 or 6 starting operations allow 2 or 3 minutes for the transformer to cool.

Do not illuminate the photocell or the burner will lock out; the burner should lock out anyway about 10 seconds after it starts.

Important:

The priming operation is possible because the pump is already full of fuel when it leaves the factory.

If the pump has been drained, fill it with fuel through the opening on the vacuum gauge prior to starting; otherwise, the pump will seize.

Whenever the length of the suction piping exceeds 66-99 ft, the supply line must be filled using a separate pump.

(A)

BURNER CALIBRATION

FIRING

Set switch 1)(C) to "ON".

During the first firing, during the switch over from low to the high fire, there is a momentary lowering of the fuel pressure caused by the filling of the high fire nozzle tubing.

This lowering of the fuel pressure can cause the burner to lock-out and can sometimes give rise to pulsations.

Once the following adjustments have been made, the firing of the burner must generate a noise similar to the noise generated during operation.

OPERATION

The optimum calibration of the burner requires an analysis of the flue gases at the boiler outlet and adjustments at the following points:

• Low and high fire nozzles

See the information listed on page 7.

• Combustion head

The adjustment of the combustion head already carried out need not be altered unless the high fire delivery of the burner is changed.

• Pump pressure

174 PSI: this is the pressure calibrated in the factory which is usually sufficient for most purposes.

Sometimes, this pressure must be adjusted to:

145 PSI in order to reduce fuel delivery.

This adjustment is possible only if the ambient temperature remains above 0°C.

Never calibrate to pressures below 145 PSI, at which pressures the cylinders may have difficulty in opening;

203 PSI order to increase fuel delivery or to ensure firings even at temperatures of less than 0°C.

In order to adjust pump pressure, use the relevant screw 5)(A)p.11.

• Low fire air damper

Keep the burner operating at low fire by setting the switch 2)(C) to the low position.

Opening of the air damper 6)(B) must be adjusted in proportion to the selected nozzle: the index 1)(A) must be aligned with the notch 2)(A) specified in table (D).

This adjustment is achieved by turning the hex element 2)(B):

- in rh direction (- sign) the opening is reduced

- in lh direction (+ sign) the opening increases.

Example RL 70 - Low fire nozzle 6.00 GPH:

2.3 (A) notch aligned with index 1)(A).

When the adjustment is done lock the hex element 2)(B) with the ring nut 1).

• High fire air damper



Set switch 2)(C) to the high position and adjust the air damper 6)(B) by turning the hex element 4)(B), after having loosened the ring nut 3)(B).

Air pressure at attachment 1)(E) must be approximately the same as the pressure specified in table (E) plus the combustion chamber pressure measured at attachment 2).

Refer to the example in the adjacent figure.

NOTE:

in order to facilitate adjustment of hex elements 2) and 4)(B), use a 1/8" Allen key 5)(B).



Low fire

RL 70		RL 100		RL 130	
Nozzle size GPH	N°	Nozzle size GPH	N°	Nozzle size GPH	N°
5	2	7	2	10	2
6	2.3	8	2.1	11	2.1
7	2.6	9	2.2	12	2.2
8	2.7	10	2.4	13	2.3
9	2.8	11	2.6	14	2.5
		12	2.7	15	2.6
		13	2.8	16	2.7
		14	2.9	17	2.8
				18	2.9
				19	3


(D)

High fire


RL 70		RL 100		RL 130	
Nozzle size GPH	"WC	Nozzle size GPH	"WC	Nozzle size GPH	"WC
13	3.3	19	2.8	26	2.7
16	3.4	22	3.0	29	2.8
19	3.5	26	3.3	32	3.0
22	3.6	29	3.7	35	3.2
		32	4.3	38	3.5
				42	4.3
					3.3 (1)

"WC = Air pressure in 1) with zero pressure in 2)


(1) Without shutter 4)(C)p.6




(E)




(A)




(B)



(C)



(D)



(E)

FINAL CHECKS

- Obscure the photocell and switch on the control device: the burner should start and then lock-out about 5 s after opening of the low fire nozzle operation valve.
- Illuminate the photocell and switch on the control circuit: the burner should go into lock-out.
- Obscure the photocell while the burner is in high fire operation, the following must occur in sequence: flame extinguished within 1 s, pre-purging for about 20 s, sparking for about 5 s, burner goes into lock-out.
- Switch off control device TL followed by control device TS while the burner is operating: the burner should stop.

MAINTENANCE

Combustion

An analysis of the flue gases is required at the boiler outlet. Significant differences with respect to the previous measurements indicate the points where more care should be exercised during maintenance.

Pump

The pump delivery pressure must be stable at 174 PSI. The suction must be less than 6.5 PSI.

Unusual noise must not be evident during pump operation.

If the pressure is found to be unstable or if the pump runs noisily, the flexible hose must be detached from the line filter and the fuel must be sucked from a tank located near the burner. This measure permits the cause of the anomaly to be traced to either the suction line or the pump.

If the problem lies in the suction line, check to make sure that the filter is clean and that air is not entering the piping.

Filters (A)

Check the following filter boxes:

- on line 1) at pump 2) • at nozzle 3), and clean or replace as required.

If rust or other impurities are observed inside the pump, use a separate pump to suck out any water and other impurities that may have deposited on the bottom of the tank.

Fan

Check to make sure that no dust has accumulated inside the fan or on its blades, as this condition will cause a reduction in the air flow rate and produce incomplete combustion.

Combustion head

Check to make sure that all the parts of the combustion head are in good condition, positioned correctly, free of all impurities, and that no deformation has been caused by operation at high temperatures.

Nozzles

Do not clean the nozzle orifices.

Replace the nozzles every 2-3 years or whenever necessary. Combustion must be checked after the nozzles have been changed.

Photocell (cad cell) (B)

Clean the glass cover from any dust that may have accumulated. Photocell 1) can be removed by pulling it outward forcefully.

Flame inspection window (C)

Clean the glass.

Flexible hoses

Check to make sure that the flexible hoses are still in good condition.

Boiler

Clean the boiler as indicated in its accompanying instructions in order to maintain all the original combustion characteristics intact, especially the flue gas temperature and combustion chamber pressure. Lastly, check the condition of the flue gas stack.


TO OPEN THE BURNER (D)

- Switch off the electrical power.
- Loosen screws 1) and withdraw the cover 2).
- Unscrew screws 3).
- Fit the two extensions 4) supplied with the burner onto the slide bars 5) (model with long blast tube, obtainable with the kit).
- Pull part A backward keeping it slightly raised to avoid damaging the disk 6) on blast tube 7).

FUEL PUMP AND/OR COUPLINGS REPLACEMENT (E)

As per fig. (E), dimension X should set as follows:

- RL70 - 1 1/2"
- RL100 - 1 7/16"
- RL130 - 1 7/16"



(A)

D2331

BURNER OPERATION

BURNER STARTING (A)

Operating control closes.

The motor starts and the ignition transformer is connected.

The pump (3) sucks the fuel from the tank through the piping (1) and the filter (2) and pumps it under pressure to delivery.

The piston (4) rises and the fuel returns to the tank through the piping (5) - (7).

The screw (6) closes the by-pass heading towards suction and the solenoid valves (8) - (11) - (16), de-energized, close the passage to the nozzles.

The hydraulic cylinder (15), piston A, opens the air damper: pre-purging begins with the low fire air delivery.

At the opening of the solenoid valves (8) and (16) open and the fuel passes through the piping (9) and filter (10) and is then sprayed out through the nozzle, igniting when it comes into contact with the spark. This is the low fire flame.

If the high fire control device is closed or has been replaced by with a jumper wire, the high fire solenoid valve (11) is opened and the fuel enters the valve (12) and raises the piston which opens two passages: one to piping (13), filter (14), and the high fire nozzle, and the other to the cylinder (15), piston B, that opens the fan air damper at high fire.

FIRING FAILURE

If the burner does not fire, it goes into lock-out within 5 s of the opening of the low fire solenoid valve.

The flame relay pilot light will light up.

LOCKOUT DURING OPERATION

If the flame goes out during operation, the burner shuts down automatically within 1 second and automatically attempts to start again by repeating the starting cycle.

PROCEDURE TO REFER BURNER OPERATING CONDITION IN HIGH ALTITUDE PLANTS

- Find the **corrected burner capacity** for the plant's altitude in chart 1 and the **corrected pressure** in chart 2.
- Check in the firing rate graph of the burner (page 6), if the working point defined by the values above is within the range limits.
If not, higher burner size is needed.

Note

Charts are based only on altitude variation
(reference temperature = 68°F , 20°C)

To get the combined correction in case of different
air temperature, a compensation of **1000 ft each
20°F (305 m each 11°C)** is applicable.

Example

Rated capacity = 3000 MBtu/hr - Rated air pressure = 1.5" w.c.

Real altitude = 5000 ft - Real temperature = 108°F

$\Delta = 108^\circ\text{F} - 68^\circ\text{F}$ (reference temp.) = 40°F (equivalent 2000 ft variation)

Proceeding as described above and considering a "virtual altitude" of (5000 + 2000) ft:

- the corrected capacity is 3847 MBtu/hr;

- the corrected burner air pressure is 1.92.



Burner RL 100 is OK

1

CORRECTED BURNER CAPACITY ACCORDING TO ALTITUDE

	Altitude										
Rated Capacity	m. a.s.l.	0	100	305	610	915	1220	1525	1830	2135	2440
	ft a.s.l	0	328	1000	2000	3000	4000	5000	6000	7000	8000
500		494	500	512	530	551	571	593	616	641	669
1000		987	1000	1023	1061	1101	1142	1186	1232	1282	1337
1500		1481	1500	1535	1591	1652	1713	1778	1848	1924	2006
2000		1974	2000	2046	2121	2202	2284	2371	2464	2565	2675
2500		2468	2500	2558	2652	2753	2855	2964	3079	3206	3343
3000		2962	3000	3069	3182	3303	3425	3557	3695	3847	4012
3500		3455	3500	3581	3712	3854	3996	4149	4311	4488	4680
4000		3949	4000	4092	4243	4404	4567	4742	4927	5130	5349
4500		4442	4500	4604	4773	4955	5138	5335	5543	5771	6018
5000		4936	5000	5116	5303	5505	5709	5928	6159	6412	6686
5500		5429	5500	5627	5834	6056	6280	6520	6775	7053	7355
6000		5923	6000	6139	6364	6606	6851	7113	7391	7694	8024
6500		6417	6500	6650	6894	7157	7422	7706	8006	8335	8692
7000		6910	7000	7162	7425	7708	7993	8299	8622	8977	9361
7500		7404	7500	7673	7955	8258	8564	8892	9238	9618	10029
8000		7897	8000	8185	8485	8809	9135	9484	9854	10259	10698
8500		8391	8500	8697	9016	9359	9705	10077	10470	10900	11367
9000		8885	9000	9208	9546	9910	10276	10670	11086	11541	12035
9500		9378	9500	9720	10076	10460	10847	11263	11702	12183	12704
10000		9872	10000	10231	10607	11011	11418	11855	12318	12824	13373
Average barometric Pressure (20°C)	mbar	1013	1000	977,4	942,8	908,2	875,8	843,5	811,85	779,8	747,8
Average barometric Pressure (68°F)	"w.c.	399	394	385	371	358	345	332	320	307	294


2

CORRECTED BURNER AIR PRESSURE ACCORDING TO ALTITUDE

	Altitude										
Rated Pressure	m. a.s.l.	0	100	305	610	915	1220	1525	1830	2135	2440
	ft a.s.l	0	328	1000	2000	3000	4000	5000	6000	7000	8000
0,50		0,49	0,50	0,51	0,53	0,55	0,57	0,59	0,62	0,64	0,67
1,00		0,99	1,00	1,02	1,06	1,10	1,14	1,19	1,23	1,28	1,34
1,50		1,48	1,50	1,53	1,59	1,65	1,71	1,78	1,85	1,92	2,01
2,00		1,97	2,00	2,05	2,12	2,20	2,28	2,37	2,46	2,56	2,67
2,50		2,47	2,50	2,56	2,65	2,75	2,85	2,96	3,08	3,21	3,34
3,00		2,96	3,00	3,07	3,18	3,30	3,43	3,56	3,70	3,85	4,01
3,50		3,46	3,50	3,58	3,71	3,85	4,00	4,15	4,31	4,49	4,68
4,00		3,95	4,00	4,09	4,24	4,40	4,57	4,74	4,93	5,13	5,35
4,50		4,44	4,50	4,60	4,77	4,95	5,14	5,33	5,54	5,77	6,02
5,00		4,94	5,00	5,12	5,30	5,51	5,71	5,93	6,16	6,41	6,69
5,50		5,43	5,50	5,63	5,83	6,06	6,28	6,52	6,77	7,05	7,35
6,00		5,92	6,00	6,14	6,36	6,61	6,85	7,11	7,39	7,69	8,02
6,50		6,42	6,50	6,65	6,89	7,16	7,42	7,71	8,01	8,34	8,69
7,00		6,91	7,00	7,16	7,42	7,71	7,99	8,30	8,62	8,98	9,36
7,50		7,40	7,50	7,67	7,96	8,26	8,56	8,89	9,24	9,62	10,03
8,00		7,90	8,00	8,18	8,49	8,81	9,13	9,48	9,85	10,26	10,70
8,50		8,39	8,50	8,70	9,02	9,36	9,71	10,08	10,47	10,90	11,37
9,00		8,88	9,00	9,21	9,55	9,91	10,28	10,67	11,09	11,54	12,04
9,50		9,38	9,50	9,72	10,08	10,46	10,85	11,26	11,70	12,18	12,70
10,00		9,87	10,00	10,23	10,61	11,01	11,42	11,86	12,32	12,82	13,37
Average barometric Pressure (20°C)	mbar	1013	1000	977,4	942,8	908,2	875,8	843,5	811,85	779,8	747,8
Average barometric Pressure (68°F)	"w.c.	399	394	385	371	358	345	332	320	307	294

Reference conditions (Charts 1-2): Ambient temperature 68 °F (20 °C) - Barometric pressure 394" WC (1000 mbar) - Altitude 328 ft a.s.l. (100 m a.s.l.).


LAL2... Sub-base



(A)

D3206

Siemens LAL control



D2870

(B)

FLAME SIGNAL MEASUREMENT (A)

Min value for a good signal: 8 μ A.

If the value is lower, it can be due to:

- Worn photocell;
- Low current;
- Bad set up of the burner.

In order to measure the current, use a microammeter of 100 μ A c.c., connected to the scanner, as in the diagram.

Min. detector current required at AC 230 V	8 μ A
Max. detector current required without flame	0.8 μ A
Max. detector current that can occur	35 μ A
Instrument's + pole	to term. 22
Length of detector line	
In the same cable as the control lines	not perm.
Separate cable in the cable duct	20 m
Three-wire cable	---
Two-wire cable for the detector line (bl, sw); separate single-wire cable for the line (br)	---
Shielded cable (e.g. RG62, shielding insulated)	200 m
Shielding	to term. 23

SEQUENCE OF OPERATION (B)

See fig. (B).

Switching times are given in seconds, in the burner startup sequence.

LAL 2.25

t1	18	t5	optional
t2	4	t6	optional
t3	2	t7	12
t4	12	t8	4

Legend for the times

- t1 Pre-purge time with air damper open.
- t2 Safety time.
- t3 Pre-ignition time, short ("Z" connected to terminal "16").
- t4 Interval between voltage at terminals "18" and "20"
- t5 Air damper running time to OPEN position.
- t6 Air damper running time to low-flame position (MIN).
- t7 Permissible after-burn time.
- t8 Interval to the OPEN command for the air damper.

BURNER FAULTS

SYMBOL (1)	FAULT	PROBABLE CAUSE	SUGGESTED REMEDY
◀	The burner does not start	1 - A limit or safety control device is open 2 - Control box lock-out 3 - Oil pressure switch tripped 4 - Motor protection tripped 5 - No electrical power supply 6 - Flame safeguard fuse blown 7 - Contact II of servomotor does not operate, flame safeguard terminals 11 - 8 8 - Pump is jammed 9 - Defective motor command control device 10 - Defective Flame safeguard 11 - Defective electrical motor	Adjust or replace Reset control box Adjust pressure switch or eliminate pressure Reset thermal cut-out Close all switches - Check connections Replace Adjust cam II or replace servomotor Replace Replace Replace Replace
	The burner does not start and a function lock-out occurs	12 - Flame simulation 13 - Photocell short-circuit 14 - Missing phase thermal cut-out trips	Replace control box Replace photocell Reset thermal cut-out when third phase is re-connected
▲	The burner starts but stops at maximum air damper setting	15 - Contact I of servomotor does not operate, flame safeguard terminals 9-8	Adjust cam I or replace servomotor
■	The burner starts and then goes into lock-out	16 - Fault in flame detection circuit	Replace flame safeguard
▼	The burner remains in pre-purging phase	17 - Contact III of servomotor does not operate, flame safeguard terminals 10-8	Adjust cam III or replace servomotor
1	After pre-purge and the safety time, the burner goes to lock-out and the flame does not appear	18 - No fuel in tank; water on tank bottom 19 - Inappropriate head and air damper adjustments 20 - Light oil solenoid valves fail to open 21 - Nozzle clogged, dirty, or deformed 22 - Dirty or poorly adjusted firing electrodes 23 - Grounded electrode due to broken insulation 24 - High voltage cable defective or grounded 25 - High voltage cable deformed by high temperature 26 - Ignition transformer defective 27 - Poor electrical connections of valves or transformer 28 - Defective flame safeguard 29 - Pump unprimed 30 - Pump/motor coupling broken 31 - Pump suction line connected to return line 32 - Valves up-line from pump closed 33 - Filters dirty: line - pump - nozzle 34 - Incorrect motor rotation direction	Top up fuel level or suck up water Adjust Check connections; replace coil Replace Adjust or clean Replace Replace Replace and protect Replace Check Replace Prime pump and see "Pump unprimed" Replace Correct connection Open Clean Change motor electrical connections
	The flame ignites normally but the burner locks out when the safety time has elapsed	35 - Defective photocell or flame safeguard 36 - Dirty photocell	Replace photocell or flame safeguard Clean
2	Firing with pulsations or flame detachment, (lift off) delayed firing	37 - Poorly adjusted head 38 - Poorly adjusted or dirty firing electrodes 39 - Poorly adjusted fan air gate: too much air 40 - Nozzle unsuited for burner or boiler 41 - Defective nozzle 42 - Inappropriate pump pressure	Adjust Adjust Adjust See Nozzle Table Replace Adjust
	The burner does not pass to 2nd stage	43 - Control device TR does not close 44 - Defective control box	Adjust or replace Replace
	Uneven fuel supply	45 - Check if cause is in pump or fuel supply system	Feed burner from tank located near burner
	Internally rusted pump	46 - Water in tank	Remove water from tank bottom with separate pump
	Noisy pump, unstable pressure	47 - Air has entered the suction line - Depression value too high (higher than 35 cm Hg): 48 - Tank/burner height difference too great 49 - Piping diameter too small 50 - Suction filters clogged 51 - Suction valves closed 52 - Paraffin solidified due to low temperature	Tighten connectors Feed burner with loop circuit Increase Clean Open Add additive to light oil
	Pump loses prime after prolonged pause	53 - Return pipe not immersed in fuel 54 - Air enters suction piping	Bring to same height as suction pipe Tighten connectors
	Pump leaks light oil	55 - Leakage from sealing organ	Replace pump
	Smoke in flame - dark Bacharach	56 - Not enough air 57 - Nozzle worn or dirty 58 - Nozzle filter clogged 59 - Erroneous pump pressure 60 - Flame stability disk dirty, loose, or deformed 61 - Boiler room air vents insufficient 62 - Too much air	Adjust head and fan damper Replace Clean or replace Adjust Clean, tighten in place, or replace Increase Adjust head and fan damper
	- yellow Bacharach		
	Dirty combustion head	63 - Nozzle or filter dirty 64 - Unsuitable nozzle delivery or angle 65 - Loose nozzle 66 - Impurities on flame stability disk 67 - Wrong head adjustment or not enough air 68 - Blast tube length unsuited to boiler	Replace See recommended nozzles Tighten Clean Adjust, open air damper Contact boiler manufacturer
I	During operation, the burner stops in lock out	69 - Dirty or defective photocell	Clean or replace

(1) When the burner does not fire or stops following a fault, the symbol which appears on control box after lockout indicates type of problem.


(2) The fuse is located in the rear part of the control box. A spare fuse is also available located under a break off tang.

Motor connection at 208-230 or 460V


WARNING:

the motors, manufactured for 208-230/460 **IE2/Epact** voltage, have a different connection than **IE1** motors, no more star/delta but star/double star. Please, pay attention to the indications in case of modification of voltage, maintenance, or substitution.

IE1




IE2/Epact



Motor connection at 575V

WARNING:




the motors, manufactured for 575V **IE2/Epact** voltage, have the same control box base of the IE1 motors. Please pay attention to the indications in case of maintenance or substitution.



Reversible direction

WARNING:

If it is necessary to reverse the direction then reverse the two main supply phases. For example: L1 with L2, there is not difference between **IE1** and **IE2/Epact**.




Calibration of the thermal relay

The thermal relay is used to avoid damage to the motor owing to a strong increase in absorption or the lack of a phase.

For the calibration, refer to the table below.

To reset, in the case of an intervention of the thermal relay, press the button 1) of (A).



IE 1

		RL 70			RL 100			RL 130		
		208 - 230 V	460 V	575 V	208 - 230 V	460 V	575 V	208 - 230 V	460 V	575 V
F (A) Fuse	Non time Delay	15 A	8 A	6 A	25 A	15 A	10 A	25 A	15 A	10 A
	Time Delay	8 A	5 A	4 A	15 A	9 A	6 A	15 A	9 A	6 A
S (AWG)		14	14	14	14	14	14	14	14	14

IE 2/Epact

		RL 70			RL 100			RL 130		
		208 - 230 V	460 V	575 V	208 - 230 V	460 V	575 V	208 - 230 V	460 V	575 V
F (A) Fuse	Non time Delay	15 A	6 A	5 A	25 A	10 A	10 A	25 A	10 A	10 A
	Time Delay	7 A	4 A	3 A	15 A	7 A	5 A	15 A	7 A	5 A
S (AWG)		14	14	14	14	14	14	14	14	14

Thermal overload calibration

IE 1


		RL 70			RL 100			RL 130		
		208 - 230 V	460 V	575 V	208 - 230 V	460 V	575 V	208 - 230 V	460 V	575 V
Thermal overload Set to Max:		5.4 A	3.1 A	2.3 A	9.8 A	5.6 A	4.3 A	9.8 A	5.6 A	4.3 A

IE 2/Epact

		RL 70			RL 100			RL 130		
		208 - 230 V	460 V	575 V	208 - 230 V	460 V	575 V	208 - 230 V	460 V	575 V
Thermal overload Set to Max:		4.6 A	2.3 A	1.8 A	9 A	4.5 A	3.6 A	9 A	4.5 A	3.6 A


Factory Wiring Diagram

RL70 - 130 three phase with burner mounted Siemens LAL control



Continuous fan operation

Change the wire connection from terminal 7 to terminal 1, remove the jumper between terminals 12-13 and the wire from terminal 13 of control box.



LAYOUT (A)

Burners RL 70 - 100 - 130

The flame safeguard is on burner mounted


Key to Layout (A)

CMV	- Motor contactor
DA	- Control box
FR	- Photocell
I1	- Switch: burner off - on
I2	- Switch: low - high fire operation
MV	- Fan motor
MB	- Burner terminal strip

P	- Air pressure switch
TA	- Ignition transformer
TB	- Burner ground (earth) connection
V1	- Low fire solenoid valve
V2	- High fire solenoid valve
VS	- Safety solenoid valve
RT	- Thermal relay

Field Wiring Diagram

RL 70 - 130 three phase burner with burner mounted LAL flame safeguard



(A)

D11616

FIELD WIRING CONNECTIONS

As set by installer

Use flexible cables according to local regulation.

LAYOUT (A)

RL 70 - 100 - 130 Burners three-phase 208-230/460/575 V power supply .

Key to wiring layout (A)

- MB - Burner terminal strip
- PS - Remote lock-out reset
- H1 - Remote lock-out signal
- H2 - Low fire signal
- H3 - High fire signal
- H4 - Power on signal
- H5 - Limit satisfied
- IN - Manual burner stop switch
- OC - Operating control.
- OC2 - High-low control.
- HL - High limit.

Important:

the burner is factory set for high operation and must be connected to the OC2 control to control fuel oil valve V2. If on-off operation is required, install a jumper lead between terminals T6 and T8 of burner terminal strip.

NOTE

- The setting of the thermal overload must be according to the table at page 18.
- The RL 70-100-130 burners leave the factory preset for:
 - **208-230 V** power supply: only in this case, if 460 V power supply is required, change the fan motor connection from delta to star for IE1 and double star to star for IE2/EPACT according to the indications of page 17 and change the setting of the thermal overload according to the table at page 18;
 - or **575 V** power supply; depending on the burner model (see page 4).
- The RL 70 - 100 - 130 burners have been type-approved for intermittent operation. This means they should compulsorily be stopped at least once every 24 hours to enable the control box to perform checks of its own efficiency at start-up. Burner halts are normally provided for automatically by the boiler load control system.

BURNER START UP REPORT

Model number: _____	Serial number: _____
Project name: _____	Start-up date: _____
Installing contractor: _____	Phone number: _____


GAS OPERATION					
Gas Supply Pressure: _____		CO ₂ : Low Fire _____		High Fire _____	
Main Power Supply: _____		O ₂ : Low Fire _____		High Fire _____	
Control Power Supply: _____		CO: Low Fire _____		High Fire _____	
Burner Firing Rate: _____		NO _x : Low Fire _____		High Fire _____	
Manifold Pressure: _____		Net Stack Temp - Low Fire: _____		High Fire: _____	
Pilot Flame Signal: _____		Comb. Efficiency - Low Fire: _____		High Fire: _____	
Low Fire Flame Signal: _____		Overfire Draft: _____			
High Fire Flame Signal: _____					

OIL OPERATION					
Oil supply pressure: _____		CO ₂ : Low Fire _____		High Fire _____	
Oil suction pressure: _____		O ₂ : Low Fire _____		High Fire _____	
Control Power Supply: _____		CO: Low Fire _____		High Fire _____	
Burner Firing Rate: _____		NO _x : Low Fire _____		High Fire _____	
Low Fire Flame Signal: _____		Net Stack Temp - Low Fire: _____		High Fire: _____	
High Fire Flame Signal: _____		Comb. Efficiency - Low Fire: _____		High Fire: _____	
Low Fire Nozzle Size: _____		Overfire Draft: _____			
High Fire Nozzle Size: _____		Smoke number: _____			

CONTROL SETTINGS			
Operating Setpoint: _____	Low Oil Pressure: _____		
High Limit Setpoint: _____	High Oil Pressure: _____		
Low Gas Pressure: _____	Flame Safeguard Model Number: _____		
High Gas Pressure: _____	Modulating Signal Type: _____		

NOTES

SPARE PARTS LIST



N.	COD.	C9514200 (3475070)	C9514201 (3475075)	C9515200 (3475270)	C9515201 (3475275)	C9516200 (3475470)	C9516201 (3475475)	DESCRIPTION	DESCRIZIONE	BURNER SERIAL NUMBER MATRICOLA BRUCIATORE
1	3003948	•	•	•	•	•	•	AIR DAMPER ASSEMBLY	GRUPPO SERRANDA	
2	3003949	•	•	•	•	•	•	GRID	PROTEZIONE	
3	C5360001 3012950	•	•	•	•	•	•	CONTROL BOX BASE	ZOCCOLO	
4	C5830009 3012933	•	•	•	•	•	•	CONTROL BOX LAL 2.25	APPARECCHIATURA LAL 2.25	
5	3013127	•	•	•	•	•	•	BASE PLATE	MENSOLA	
6	3003951	•	•	•	•	•	•	AIR INTAKE	BOCCA D'ASPIRAZIONE	
7	3003952	•	•	•	•	•	•	SOUND DAMPING	FONOASSORBENTE	
8	3003763	•	•	•	•	•	•	INSPECTION WINDOW	VISORE	
9	3013056	•	•					DRIVE COUPLING	GRUPPO GIUNZIONE	
9	3003954			•	•	•	•	DRIVE COUPLING	GRUPPO GIUNZIONE	
10	3012939	•	•					FAN	GIRANTE	
10	3012403			•	•			FAN	GIRANTE	
10	3012940					•	•	FAN	GIRANTE	
11	3012938	•	•	•	•	•	•	TRANSFORMER	TRASFORMATORE	
12	3013037	•	•	•	•	•	•	CONNECTOR	RACCORDO	
13	3012948	•	•	•	•	•	•	AIR PRESSURE SWITCH	PRESSOSTATO ARIA	
14	3003957	•	•	•	•	•	•	SUPPORT	SUPPORTO	
15	3012622	•	•	•	•	•	•	DRIVE DISC	DISCO ELASTICO	
16	3012935	•						OVERLOAD+CONTACTOR 208-230/460V	RELE' TERMICO+CONTATTORE 208-230/460V	
16	3012936			•				OVERLOAD+CONTACTOR 208-230/460V	RELE' TERMICO+CONTATTORE 208-230/460V	
16	3012937					•		OVERLOAD+CONTACTOR 208-230/460V	RELE' TERMICO+CONTATTORE 208-230/460V	
16	3012991		•					OVERLOAD+CONTACTOR 575V	RELE' TERMICO+CONTATTORE 575V	
16	3013124				•			OVERLOAD+CONTACTOR 575V	RELE' TERMICO+CONTATTORE 575V	
16	3013125					•		OVERLOAD+CONTACTOR 575V	RELE' TERMICO+CONTATTORE 575V	
17	3003770	•	•	•	•	•	•	SWITCH	INTERRUTTORE	
18	3007627	•	•	•	•	•	•	MEMBRAN	MEMBRANA	
19	3012934	•	•	•	•	•	•	COVER	COFANO	
20	3003825	•	•	•	•	•	•	HYDRAULIC JACK	MARTINETTO	
21	3003824	•	•	•	•	•	•	GRADUATE SECTOR	QUADRANTE	
22	3012941	•						MOTOR 208-230/460V	MOTORE 208-230/460V	
22	3012943			•		•		MOTOR 208-230/460V	MOTORE 208-230/460V	
22	3013059		•					MOTOR 575V	MOTORE 575V	

N.	COD.	C9514200 (3475070)	C9514201 (3475075)	C9515200 (3475270)	C9515201 (3475275)	C9516200 (3475470)	C9516201 (3475475)	DESCRIPTION	DESCRIZIONE	BURNER SERIAL NUMBER MATRICOLA BRUCIATORE
22	3013060				•			MOTOR 575V	MOTORE 575V	
22	3013061				•			MOTOR 575V	MOTORE 575V	
23	3003969	•	•	•	•	•	•	HALF-SHELL	GUSCIO	
24	3003481	•	•	•	•	•	•	SCREW	VITE	
25	3003970	•	•	•	•	•	•	BAR	PERNO	
26	3012006	•	•	•	•	•	•	TUBE	TUBO	
27	3006784	•	•	•	•	•	•	CONNECTOR	RACCORDO	
28	3003971	•	•	•	•	•	•	SUPPORT	SUPPORTO	
29	3003814	•	•	•	•	•	•	NOZZLE HOLDER	PORTASPRUZZO	
30	3012959	•	•	•	•	•	•	H.T. LEAD	COLLEGAMENTO	
31	3003796	•	•	•	•	•	•	ELECTROD	ELETTRODO	
32	3003495	•	•	•	•	•	•	U BOLT	CAVALLOTTO	
33	3003974	•	•	•	•	•	•	CONTROL DEVICE	GRUPPO REGOLAZIONE	
34	3003975	•	•	•	•			FRONT PIECE	FRONTONE	
34	3003976					•	•	FRONT PIECE	FRONTONE	
35	3003977	•	•					SQUARE	SQUADRETTA	
35	3003979			•	•			SQUARE	SQUADRETTA	
35	3003981					•	•	SQUARE	SQUADRETTA	
36	3003983	•	•	•	•			SHUTTER	OTTURATORE	
36	3003984					•	•	SHUTTER	OTTURATORE	
37	3003985	•	•					END CONE	IMBUTO FIAMMA	
37	3003987			•	•			END CONE	IMBUTO FIAMMA	
37	3003989					•	•	END CONE	IMBUTO FIAMMA	
39	3003893	•	•	•	•	•	•	CONNECTOR	RACCORDO	
40	3003992	•	•					DIFFUSER DISC	ELICA	
40	3003993			•	•	•	•	DIFFUSER DISC	ELICA	
41	3003815	•	•	•	•	•	•	SUPPORT	SUPPORTO	
42	3003994	•	•	•	•	•	•	TUBE	TUBO	
43	3003995	•	•	•	•	•	•	TUBE	TUBO	
44	3006767	•	•	•	•	•	•	COIL	BOBINA	
45	3003996	•	•	•	•	•	•	PLUG	TAPPO	
46	C5360027	3006216	•	•	•	•	•	P.E. CELL	FOTORESISTENZA	

N.	COD.	C9514200 (3475070)	C9514201 (3475075)	C9515200 (3475270)	C9515201 (3475275)	C9516200 (3475470)	C9516201 (3475475)	DESCRIPTION	DESCRIZIONE	BURNER SERIAL NUMBER MATRICOLA BRUCIATORE
47	3003997	•	•	•	•	•	•	VALVE ASSEMBLY	GRUPPO VALVOLE	
48	3013525	•	•	•	•	•	•	CONNECTOR	RACCORDO	
49	3006722	•	•	•	•	•	•	CONNECTOR	RACCORDO	
50	3013523	•	•	•	•	•	•	PUMP	POMPA	
51	3007979	•	•	•	•	•	•	SEAL	GUARNIZIONE	
52	3007077	•	•	•	•	•	•	SEAL	GUARNIZIONE	
53	3006719	•	•	•	•	•	•	CONNECTOR	RACCORDO	
54	3005733	•	•	•	•	•	•	NEEDLE VALVE	VALVOLA	
55	3003823	•	•	•	•	•	•	PISTON SEAL	ANELLO	
56	3003820	•	•	•	•	•	•	PISTON SEAL	ANELLO	
57	3012000	•	•	•	•	•	•	TUBE	TUBO	
58	3012001	•	•	•	•	•	•	TUBE	TUBO	
59	3012952	•	•	•	•	•	•	SOLENOID VALVE	VALVOLA	
60	3012953	•	•	•	•	•	•	SOCKET	PRESA	
61	3012003	•	•	•	•	•	•	BAR	PERNO	
62	3009087	•	•	•	•	•	•	CONNECTOR	RACCORDO	
63	3003936	•	•	•	•	•	•	FILTER+SEAL	FILTRO+GUARNIZIONE	
64	3013015	•	•	•	•	•	•	LEAD	COLLEGAMENTO	
65	3013016	•	•	•	•	•	•	COIL	BOBINA	

RIELLO

RIELLO S.p.A.
I-37045 Legnago (VR)
Tel.: +39.0442.630111
[http:// www.riello.it](http://www.riello.it)
[http:// www.rielloburners.com](http://www.rielloburners.com)

RIELLO

35 Pond Park Road
Hingham, Massachusetts,
U.S.A. 02043

RIELLO BURNERS NORTH AMERICA

1-800-4-RIELLO

1-800-474-3556

<http://www.riello-burners.com>

2165 Meadowpine Blvd
Mississauga, Ontario
Canada L5N 6H6