

# RTC-80 1000-5500

USA INSTALLATION, OPERATION AND SERVICE MANUAL

# RIELLO

#### Dear heating engineer,

Congratulations for purchasing a **RIELLO** boiler. This appliance ensures maximum performance throughout an extended operating life, with high reliability, efficiency, quality and safety. This manual provides information that is essential to the installa-

This manual provides information that is essential to the installation of the appliance. Used in conjunction with your own knowledge and expertise, it will enable you to install the appliance quickly, easily, and correctly.

Please accept our thanks, and congratulations on your choice of product.

Riello S.p.A.

#### RANGE

MODEL	CODE
RTC 1000-80	20165080
RTC 1300-80	20166926
RTC 1700-80	20166937
RTC 2300-80	20166942
RTC 3000-80	20166947
RTC 3800-80	20166962
RTC 4700-80	20166970
RTC 5500-80	20166987

#### CONFORMITY



1 G	ENERAL
1.1	General safety information
1.2	General safety instructions
1.3	Description of the appliance
1.4	Identification
1.5	System layout
1.6	Technical specifications
1.6.1	Ratings (natural gas firing)8
1.6.2	Ratings (oil firing)
1.6.3	Specifications
1.7	Intended use
1.8	Certification and test mark
1.9	Regulations and guidelines 10
1.9.1	
1.9.2	Compliance with standards and regulations 10
1.9.3	Additional regulations for installations in the
1 10	
1.10	Burnors 11
1.11	Performended humans and human plate accessories kit12
	Recommended burners and burner plate accessories kitiz
2 IN	STALLATION
2 IN 2.1	STALLATION
<b>2 IN</b> 2.1 2.2	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15
2 IN 2.1 2.2 2.3	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16
<b>2</b> IN 2.1 2.2 2.3 2.4	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17         Installation clearances       17
2 IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17         Installation clearances       17         Minimum clearance to combustibles       18
2 IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17         Installation clearances       17         Minimum clearance to combustibles       18         Water connections       19
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17         Installation clearances       17         Minimum clearance to combustibles       18         Water connections       19         Sensor manifold installation       21
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6 2.7	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17         Installation clearances       17         Minimum clearance to combustibles       18         Water connections       19         Sensor manifold installation       21         Sensor manifold connections       22
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6 2.7 2.8	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17         Installation clearances       17         Minimum clearance to combustibles       18         Water connections       19         Sensor manifold installation       21         Sensor manifold connections       22         Positioning of sensor sockets       23
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6 2.7 2.8 2.8.1 2.8.1	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17         Installation clearances       17         Minimum clearance to combustibles       18         Water connections       19         Sensor manifold installation       21         Sensor manifold connections       22         Positioning of sensor sockets       23         Water-side pressure drop       25
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6 2.7 2.8 2.8.1 2.8.2 2.8.2	STALLATION14Unpacking the product14Overall dimensions and weights15Moving and removing the packaging16Installation premises17Installation clearances17Minimum clearance to combustibles18Water connections19Sensor manifold installation21Sensor manifold connections22Positioning of sensor sockets23Water-side pressure drop25Flow limits26
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6 2.7 2.8 2.8.1 2.8.2 2.8.3	STALLATION14Unpacking the product14Overall dimensions and weights15Moving and removing the packaging16Installation premises17Installation clearances17Minimum clearance to combustibles18Water connections19Sensor manifold installation21Sensor manifold connections22Positioning of sensor sockets23Water-side pressure drop25Flow limits26Water quality requirements26
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6 2.7 2.8 2.8.1 2.8.2 2.8.3 2.8.4 2.8.4	STALLATION14Unpacking the product14Overall dimensions and weights15Moving and removing the packaging16Installation premises17Installation clearances17Minimum clearance to combustibles18Water connections19Sensor manifold installation21Sensor manifold connections22Positioning of sensor sockets23Water-side pressure drop25Flow limits26Water quality requirements26Vew control heating system26
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6 2.7 2.8 2.8.1 2.8.2 2.8.3 2.8.4 2.8.5	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17         Installation clearances       17         Minimum clearance to combustibles       18         Water connections       19         Sensor manifold installation       21         Sensor manifold connections       22         Positioning of sensor sockets       23         Water-side pressure drop       25         Flow limits       26         Water quality requirements       26         New central heating systems       26         New central heating systems       26
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6 2.7 2.8 2.8.1 2.8.2 2.8.3 2.8.4 2.8.5 2.8.6 2.8.5 2.8.6	STALLATION       14         Unpacking the product       14         Overall dimensions and weights       15         Moving and removing the packaging       16         Installation premises       17         Installation clearances       17         Minimum clearance to combustibles       18         Water connections       19         Sensor manifold installation       21         Sensor manifold connections       22         Positioning of sensor sockets       23         Water-side pressure drop       25         Flow limits       26         Water quality requirements       26         New central heating systems       26         Reconditioning of ar and gas from contral heating systems       27         Flimination of air and gas from contral heating systems       27
<b>2</b> IN 2.1 2.2 2.3 2.4 2.4.1 2.4.2 2.5 2.6 2.7 2.8 2.8.1 2.8.2 2.8.3 2.8.4 2.8.5 2.8.6 2.8.7	STALLATION14Unpacking the product14Overall dimensions and weights15Moving and removing the packaging16Installation premises17Installation clearances17Minimum clearance to combustibles18Water connections19Sensor manifold installation21Sensor manifold connections22Positioning of sensor sockets23Water-side pressure drop25Flow limits26Water quality requirements26New central heating systems26Reconditioning old heating systems27Elimination of air and gas from central heating system27

2.10Draining the condensate	36 36 37 38 38 39 39
2.12.5 Condensate removal	9 10 10 12 12 13
3 COMMISSIONING43.1 Preparing for initial startup43.2 Third party control units43.3 Hydraulic connection to the heating system43.4 Making the electrical connection43.5 Fitting temperature sensors43.6 Flushing the heating system43.7 Filling the heating system43.8 Preparing the heating system for operation43.9 Commissioning the control unit and burner43.10 Commissioning report4	444444555566
4SHUTDOWN44.1Shutting down the heating system.44.2Shutting down the heating system in an emergency.4	<b>17</b> 47
5INSPECTION AND MAINTENANCE45.1Why is regular maintenance important?45.2Maintenance45.3Cleaning the boiler45.4External cleaning55.5Checking and correcting the water pressure55.5.1Inspection and maintenance reports55.6Troubleshooting56ENVIRONMENTAL PROTECTION/DISPOSAL5	<b>18</b> 18 19 50 51 52 53

The following symbols are used in this manual:
<b>CAUTION! =</b> Identifies actions that require caution and adequate preparation.
<b>E STOP! =</b> Identifies actions that you MUST NOT do.

This manual, Code 20158857 - Rev. 3 (06/2020) comprises 56 pages.

#### GENERAL 1

#### General safety information 1.1

 $oldsymbol{A}$  Check that the product is complete, undamaged and as or– dered as soon as you receive it. Report any discrepancies or damage to the **RIELLO** dealer who sold it.

A The boiler must be installed by a qualified heating engineer.

UPON COMPLETION OF THE INSTALLATION THE INSTALLER MUST INSTRUCT THE OWNER AND OPERATOR ON THE FUNCTIONALITY AND THE PROPER OPERATION OF THE BOILER AND THE HEATING SYSTEM.

#### THIS MANUAL SHOULD BE HANDED TO THE OWNER AND **OPERATOR OF THE APPLIANCE.**

#### THE INSTALLER MUST REVIEW ALL SAFETY INSTRUCTIONS WITH THE OWNER AND OPERATOR.

The installation instructions included in this Manual are intended solely for use by a qualified installer, service agency or gas supplier. If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury, or death.

- Have installation and service performed by a trained and certified installer or service company, or the gas supply company.
- RIELLO recommends signing a service and maintenance contract with a trained and certified installer or service company that covers annual servicing and condition-based maintenance. Proper maintenance is a fundamental requirement for safe and efficient operation and long service life.
- The boiler must be serviced annually including the burner, ignition system, the entire venting system, and the combustion air supply. All parts that show any signs of damage or corrosion must be replaced.
- The owner and operator is responsible for the operational safety and regulatory compliance of the heating system.
- Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or death. Refer to this manual and consult a trained and certified installer or service company, or the gas supply company before installation, service or maintenance.

A This product must only be used for the purpose for which it is designed and made, as specified by **RIELLO**. **RIELLO** declines all responsibility, contractual or other, for damage to property or injury to persons or animals caused by improper installation, adjustment, maintenance or use.

A The room where the boiler is installed must be properly ventilated to ensure a sufficient supply of air for correct combustion.

🚹 If you notice any water leaks, disconnect the boiler from the main electrical supply and shut off the water supply.

 $oldsymbol{A}$  Periodically check that pressure in the central heating circuit, when cold, is approximately 20 psi (1.4 bar) and below the maximum limit specified for the boiler.

A If the boiler is not going to be used for an extended period of time, perform the operations described later in this manual.

A This instruction manual is an integral part of the boiler. It must be kept safe and must ALWAYS accompany the boiler, even if it is sold to another owner or transferred to another user or to another installation. If you damage or lose this manual, order a replacement immediately from your local RIELLO Technical Assistance Center.

#### **1.2** General safety instructions

#### If you hear gas leaking

- Leave the building immediately.
- Prevent others from entering the building.
- From outside of the building, notify the police and fire department.
- From outside of the building, call the gas supplier and qualified installer or service agency.

#### If you smell gas

- Turn off the gas shut-off valve.
- Open windows and doors
- Do not touch any electrical switch, telephone, or use electrical outlets.
- Extinguish all open flames.
- \_ Do not smoke!
- Do not use lighters!
- Warn all occupants of the building that they need to leave the building.
- Do not ring doorbells!
- From outside of the building, notify the police and fire department.
- From outside of the building, call the gas supplier and qualified installer or service agency.

#### If you smell flue gas

- Switch off the appliance.
- \_ Open windows and doors.
- \_ Inform a gualified installer, service agency or the gas supplier.

#### DANGER: Risk of fatal injury from failing to consider your own safety!

 Never risk your own life. Your own safety must always take the highest priority.

# **M** NOTE: Risk of appliance damage from improper operation!

- Only use the boiler for its intended purpose.
- Only operate the boiler if it has been installed and maintained per the instructions provided in the Installation, Operation & Service Manual.
- Do not attempt to operate the appliance if any part of it is not in working order or is damaged.
- WARNING: Use only original spare parts! The use of parts not supplied by the manufacturer may cause damage to the boiler, substantial property damage, severe personal injury or death. Also, boiler damage caused by the use of unauthorized parts is not covered by the warranty.

#### DANGER: Risk of fire when soldering and brazing!

Take appropriate protective measures when soldering and brazing around combustible and flammable material.

# A NOTICE!

- The installation must comply with all applicable national, state/provincial, and local codes, rules, and regulations.
- The operator is responsible for the operational safety and regulatory compliance of the heating system.
- In the Commonwealth of Massachusetts, the appliance must be installed by a licensed plumber or gas fitter.

#### A DANGER: Risk of personal injury or death from flue gas poisoning!

- Do not install a thermostatic flue gas damper downstream of the draft hood.
- Do not tamper with, remove, or attempt to repair a blocked vent switch.
- When replacing the blocked vent switch, install the new part in the original location.
- A blocked vent switch tripping more than once indicates a problem with the venting system or chimney which must be repaired immediately.
- Ensure none of the vent pipes and chimneys are damaged or blocked.
- Connect only one appliance to each venting system or chimney.
- The venting system must not feed into or route through another air extraction duct.
- The venting system must be inspected annually. All parts that show any signs of damage or corrosion must be replaced.
- Never close off or reduce the size of the combustion air openings.
- The boiler must not be operated until any obstructions have been removed.

# A DANGER: Risk of personal injury or death from explosion!

- Work on gas components may only be carried out by a trained and certified installer or service company.
- Appliance installation, the connection of gas and vent piping, initial commissioning, electrical connections and service and maintenance must only be carried out by a trained and certified installer or service company.

# A DANGER: Risk of personal injury or death from fire!

- Do not use flammable or combustible material in the boiler room.
- It is recommended not to store any items within 16 inches (415mm) of the appliance.

# A CAUTION: Appliance damage from contaminated combustion air!

- Keep the combustion air free of corrosive substances, e.g. halogenated hydrocarbons from painting operations or beauty salons.
- Keep combustion air free from dust and lint, e.g. from laundry or agricultural operations.
- If clean room air is not available, fresh outdoor combustion air must be provided.

# A DANGER: Risk of personal injury or death from electric shock!

- Before removing the front panel, disconnect the heating system from the electrical power supply by shutting off the emergency shutoff switch or the heating system circuit breaker.
- It is not enough to switch off the control panel. Power to the panel must be disconnected! Ensure that the power is not restored unintentionally by following proper lock out/ tag out procedures.
- Only qualified electricians are permitted to carry out electrical work.

# DANGER: Safety devices!

- Never shut off safety valves!
- Hot water may escape from the safety valve at any time when the appliance is running.

# DANGER: Risk of personal injury or death after a flood!

- Do not attempt to operate an appliance if any part of it has been under water.
- An appliance that was subject to flooding must be replaced.

# A NOTICE!

- Upon completion of the installation, these instructions should be handed to the owner and operator of the appliance.
- The installer must instruct the owner and operator on the functionality of the components and the proper operation of the boiler and the heating system.
- The boiler must be serviced annually including the burner, ignition system and pilot, the entire venting system, and the combustion air supply. All parts that show any signs of damage or corrosion must be replaced.

#### **1.3** Description of the appliance

**RTC-80** stainless steel boilers are triple-pass, condensing boilers for installation in a boiler room. While they are designed for central heating purposes, they can also be used in conjunction with a suitable plate exchanger and storage tank to produce domestic hot water.

All parts that come into contact with the combustion gases are made from high grade stainless steel (316Ti/316L) to ensure maximum resistance to the corrosive action of acidic condensation.

The boiler has been designed with the combustion chamber at the top and the multi-pipe tube bundle (smooth pipes) at the bottom to optimize heat transfer and energy efficiency and to maximize the condensing effect.

The boiler has a high total water content allowing effective temperature stratification between its top and bottom sections. This allows outgoing water to reach the set temperature quickly while maintaining the condensing effect and maximizing the water heating dwell time around the tube bundle.

**RTC-80** boilers feature a low back-pressure combustion chamber for smoother burner operation, and low backpressure waterway for reduced pump electrical consumption.

- High temperature resistant stainless steel turbulators are utilized inside the tube bundle for maximum combustion efficiency.
- The boiler body is thoroughly insulated with a layer of high density glass wool.
- The external panelling is enamel painted and internally insulated with an additional layer of high density glass wool.
- The boiler's front door and the flue gas chamber can be easily and completely opened to facilitate the inspection, maintenance and cleaning of internal parts and to speed up servicing in general.
- The hinged front door can open in either direction and can be opened without removing the burner. The door is factory fitted with hinges on the left, but these can be field-reversed if necessary to suit individual installations.

#### 1.4 Identification

The products are identified by:



#### Data plate

This lists the technical specifications and performance of the product. This is supplied inside the document bag and MUST BE APPLIED to the boiler by the installer on completion of installation. If you damage or lose this label, order a replacement immediately from your local **RIELO** boiler representative.

NOTE: If these plates or any other means clearly identifying the product are defaced, removed or lost, proper installation and servicing may be rendered difficult.

#### 1.5 System layout



## **1.6** Technical specifications

# 1.6.1 Ratings (natural gas firing)

		Description	RTC-80							
		Description	1000	1300	1700	2300	3000	3800	4700	5500
Minimum Input <sup>(1)</sup>		MBH (KVV)	100 (29.3)	130 (38.1)	170 (49.8)	230 (67.4)	300 (87.9)	380 (111.4)	470 (137.7)	550 (161.2)
Maximum Input		MBH (kVV)	1000 (293.1)	1300 (381.0)	1700 (498.2)	2300 (674.1)	3000 (879.2)	3800 (1113.7)	4700 (1377.4)	5500 (1611.9)
Output <sup>(2)</sup>	Condition 1 <sup>(3)</sup>	MBH (KVV)	884 (259.1)	1151 (337.3)	1505 (441.1)	2036 (596.7)	2655 (778.1)	3363 (985.6)	4160 (1219.2)	4868 (1426.7)
	Condition 2 <sup>(4)</sup>	MBH (kW)	963 (282.2)	1252 (366.9)	1638 (480.0)	2215 (649.2)	2889 (846.7)	3660 (1072.6)	4526 (1326.4)	5297 (1552.4)
Efficience (	Condition 1 <sup>(3)</sup>		88.4%	88.5%	88.5%	88.5%	88.5%	88.5%	88.5%	88.5%
Efficiency	Condition 2 <sup>(4)</sup>		96.3%	96.3%	96.3%	96.3%	96.3%	96.3%	96.3%	96.3%
AHRI Combustion and Thermal Efficiency			94.0%	94.0%	94.0%	94.0%	94.0%	94.0%	94.0%	94.0%

<sup>(1)</sup> Values based on natural gas firing. Based on standard burner with optional high-turndown kit. <sup>(2)</sup> Maximum output dependent upon application <sup>(3)</sup> Condition 1 based on return temperature 140°F and ΔT 36°F <sup>(4)</sup> Condition 2 based on return temperature 80°F and ΔT 36°F

# 1.6.2 Ratings (oil firing)

		Description	RTC-80							
		Description	1000	1300	1700	2300	3000	3800	4700	5500
Minimum Input <sup>(1)</sup>		MBH (kW)	330 (96.7)	420 (123.1)	540 (158.2)	720 (211.0)	970 (284.2)	1210 (354.5)	1510 (442.4)	1750 (512.8)
Maximum Input		MBH (kW)	974 (285.4)	1270 (372.1)	1625 (476.1)	2167 (634.9)	2893 (847.6)	3619 (1060.4)	4516 (1323.2)	5242 (1535.9)
Output <sup>(2)</sup>	Condition 1 <sup>(3)</sup>	MBH (kW)	902 (264.3)	1177 (344.9)	1506 (441.3)	2009 (588.6)	2682 (785.8)	3355 (983.0)	4186 (1226.5)	4859 (1423.7)
Efficiency	Condition 1 <sup>(3)</sup>		92.6%	92.7%	92.7%	92.7%	92.7%	92.7%	92.7%	92.7%

<sup>(1)</sup> Values based on oil firing

<sup>(2)</sup> Maximum output dependent upon application <sup>(3)</sup> Condition 1 based on return temperature 140°F and  $\Delta$ T 36°F

# 1.6.3 Specifications

Description	RTC-80									
Description	1000	1300	1700	2300	3000	3800	4700	5500		
Boiler category	ASME Section IV									
Maximum allowable working pressure	80 psi	80 psi	80 psi	80 psi	80 psi	80 psi	80 psi	80 psi		
Maximum allowable working temperature	210°F	210°F	210°F	210°F	210°F	210°F	210°F	210°F		
Water Connections Inlet/Outlet (Flanged)	2-1/2"	3"	4"	4"	5"	5"	6"	6"		
High Temp. Return Water Connections	2"	2-1/2"	3"	3"	3"	3"	4"	4"		
Minimum Water Flow (GPM) (*)	12	15	20	30	40	50	60	70		
Maximum Water Flow (GPM) (*)	130	160	200	290	370	480	580	690		
Water Volume (Gal) (*)	130.7	146.6	196.2	203.4	348.7	368.5	482.1	501.9		
Water Pressure Drop	0.67 psi at 95 GPM (*)	0.49 psi at 124 GPM (*)	0.44 psi at 162 GPM (*)	1.86 psi at 219 GPM (*)	1.76 psi at 285 GPM (*)	1.36 psi at 361 GPM (*)	1.45 psi at 447 GPM (*)	2.18 psi at 523 GPM (*)		
Maximum turndown (Nat.Gas)	10:1	10:1	10:1	10:1	10:1	10:1	10:1	10:1		
Vent Connections	10"	10"	12''	12''	14''	14"	16"	18"		
Vent Materials	AISI 316L AL29-4C (29% Cr - 4% Mo)									
Type of Fuel (**)			Natural (	Gas, Propar	ne, #2 Fuel	0il (***)				
NOx Emissions <30ppm Capability on Nat. Gas				ye	S					
Temperature Control Range				80°F to	195°F					
Ambient Temperature Range				32°F to	140°F					
Standard Listings & Approvals				ASME, ET	l, ahri					
Water capacity (Gal) (*)	130.7	146.6	196.2	203.4	348.7	368.5	482.1	501.9		
Weight (dry) lbs. (without paneling)	1676	1786	2679	2965	4167	4777	5908	6834		
Shipping Weight Ibs. (without paneling)	1720	1841	2756	3097	4334	4956	6085	7028		
Weight of paneling lbs.	132	154	198	264	308	352	473	506		
Weight (wet) lbs. (with paneling)	2899	3164	4515	4927	7385	8206	10406	11530		

(\*) (\*\*) (\*\*\*)

Units shown are in US Gallons. Other fuels may be used. For alternate fuels not listed, please contact factory. Using #2 Fuel Oil, the boiler return temperature must not be lower than 140 °F (non-condensing operation).

#### 1.7 Intended use

This boiler must only be used for the purpose specified by the manufacturer and for which it is designed.

The **RTC-80** can be operated with gas, oil, and combination burners. For a list of the approved burners, see specific paragraph in this manual.

A variety of alternate fuels such as biodiesel, jet fuel, etc may also be utilized (contact **RIELO** engineering for applicability).

The boiler can be operated with an aquastat and other control systems.

The manufacturer declines all responsibility, contractual or other, for damage to property or injury to persons or animals caused by improper installation, adjustment, maintenance or use.

#### **1.8** Certification and test mark

This appliance has been tested and certified and meets all applicable standards for the US markets:

- UL 296 Standard for oil burners
- UL 726 Standard for oil-fired boiler assemblies
- UL 795 Standard for commercial industrial gas heating equipment.

And for Canadian market:

- UL 726 Issued: 1995/11/30 Ed: 7 Rev: 2013/10/09 Oil-Fired Boiler Assemblies
- UL 795 Issued: 2011/04/06 Ed: 7 Rev: 2013/11/27 Commercial-Industrial Gas Heating Equipment
- Industrial And Commercial Gas-Fired Package Boilers (R2016) [CGA 3.1:1977 +A1:13;U14]
- Oil-Burning Equipment: General Requirements (R2013) [CSA B140.0:2003 Ed.3]
- Oil-Burning Equipment: Steam And Hot-Water Boilers (R2014) [CSA B140.7:2005 Ed.2

#### **1.9** Regulations and guidelines

#### 1.9.1 National regulation

The heating system must comply with the requirements of the relevant regulatory authorities or otherwise of the National Fuel Gas Code, ANSI Z 223.1.

If specified by the relevant regulatory authorities, the heating system must comply with the regulations of the Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1. Carbon monoxide detectors must be installed as specified by the local regulations. The boiler must be serviced annually.

#### 1.9.2 Compliance with standards and regulations

Installation of the boiler must comply with all applicable codes and regulations imposed by the national, federal or local authorities and bodies. If no specific requirements are defined, in the USA, the boiler must comply with the latest edition of the National Fuel Gas Code ANSI Z223.1/NFPA 54.

Where required by local regulations, the system must comply with the American Society of Mechanical Engineers Safety Code for Controls and Safety Devices for Automatically Fired Boilers (ASME CSD-1).

WARNING: Risk of fatal injury from explosion of flammable gases.

- Installation, connection of the fuel supply and flue pipe, commissioning, connection of the electrical power supply, servicing and repair may only be carried out by an authorized heating engineer.
- Any work on gas piping components may only be carried out by an authorized gas installer.

The local regulations regarding minimum pressure detectors, maximum relief valves and low water safety cutouts must be observed. Installation and operation must comply with the device manufacturer's technical documentation.

We recommend fitting an 80 mesh dirt filter externally to the boiler return to prevent contamination of the boiler by the water source.

#### Leak test

A leak test must be carried out on the hydronic heating system. The testing pressure is based on the normal operating pressure of the heating system and should be 1.3 times that pressure, and in any case no less than 14 psi (1 bar).

#### Safety limits

Safety limits	Value
Maximum operating temperature:	210 °F
Permissible operating pressure:	80 psi
Maximum cycle time for safety temperature limiter:	40 s
Maximum cycle time for temperature control:	40 s

# **1.9.3** Additional regulations for installations in the Commonwealth of Massachusetts

a) For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:

**INSTALLATION OF CARBON MONOXIDE DETECTORS:** At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gasfitter shall observe that a hard wired carbon monoxide detector with an alarm and battery backup is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gasfitter shall observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors.

- In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.
- In the event that the requirements of this subdivision cannot be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.

**APPROVED CARBON MONOXIDE DETECTORS:** Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.

**SIGNAGE:** A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment.

The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS".

**INSPECTION:** The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspections, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CRM 5.08(2)(a) 1 through 4.

**b) EXEMPTIONS:** The following equipment is exempt from 248 CRM 5.08(2)(a) 1 through 4:

- The equipment listed in Section 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the board;
- Product Approved side wall horizontally vented gas fueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.

c) MANUFACTURERS REQUIREMENTS – GAS EQUIPMENT VENTING SYS-TEM REQUIRED: When the manufacturer of Product Approved side wall horizontally mounted gas equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for the installation of the equipment and venting shall include:

- Detailed instructions for the installation of the venting system or the venting system components;
- A complete parts list for the venting system design or venting system.

d) MANUFACTURERS REQUIREMENTS – GAS EQUIPMENT VENTING SYS-TEM NOT PROVIDED: When the manufacturer of Product Approved side wall horizontally vented gas fueled equipment does not provide the parts for the venting of flue gases, but identifies "special venting systems", the following requirements shall be satisfied by the manufacturer:

- The referenced "special venting systems" shall be included with the appliance or equipment installation instructions;
- The "special venting systems" shall be Product Approved by the Board and the instructions for that system shall include a parts list and detailed installation instructions.

**e)** A copy of all instructions for all Product Approved side wall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions and/or venting design instructions shall remain with the appliance or equipment at the completion of the installation.

# 1.10 Suitable fuels

#### **Permissible fuels**

- Natural gas from the public gas supply in accordance with national regulations with a total sulphur content < 15ppm.
- LP in accordance with national regulations with a content of elementary sulphur < 1.5 ppm and volatile sulphur < 50 ppm.
- Ultra Low Sulphur Diesel in accordance with national regulations with a content of elementary sulphur < 15 ppm (for use as back-up fuel in condensing operation).</li>
- Heating oil type 2 when boiler return temperature is not lower than 140 °F; non-condensing operation. See the warranty statement for additional details.
- A variety of alternate fuels such as biodiesel, jet fuel A, etc may also be utilized. Contact **RIELIO** for applicability.

**A** Do not use gasoline, crankcase drainings, or any oil containing gasoline.

- The boiler must only be operated with the specified fuels.
- Only burners that are suitable for the specified fuels may be used.
- Observe the manufacturer's burner selection list and the burner manufacturer's instructions.

# 1.11 Burners

Follow the burner manufacturer's instructions when fitting the burner. A pre-drilled burner plate is included with the boiler.

An adapter plate may be required if a non-standard burner is used (see table).

As standard, the burner plate gasket must be trimmed in order to fit the burner blast tube.

The installer must cut the hole 3/8" larger than the blast tube diameter.

The combustion chamber door must be opened to allow the burner to be mounted.

If the burner head is too long to open/close the combustion chamber door, the burner will have to be removed prior to the opening/closing of the door.

For reduction of burner capacity according to altitude make reference to the burner manual.

After the burner is installed, fill the gap between the burner tube and the refractory material in the door with the ceramic insulation supplied loose with the boiler.

		RTC 1000- 80	RTC 1300- 80	RTC 1700- 80	RTC 2300- 80
Fireside	inch W.C.	1.284	1.846	2.007	2.208
pressure drop	mbar	3.2	4.6	5.0	5.5

		RTC 3000- 80	RTC 3800- 80	RTC 4700- 80	RTC 5500- 80
Fireside	inch W.C.	2.288	2.529	2.729	2.970
pressure drop	mbar	5.7	6.3	6.8	7.4

At maximum output with water temps supply/return of 176/140  $^{\circ}$ F (80/60  $^{\circ}$ C), CO2=9.7% and O2=3.6%.

#### 1.11.1 Recommended burners and burner plate accessories kit

BURNERS RTC-80 MODEL 1000 1300 1700 2300 3000 3800 4700 5500 GAS RS28/M х **RS28/E** х RS38/M ٠ Х• RS38/E х• • RS45/M LN х• х• х RS45/E LN X • х• х RS50/M х RS50/E х RS68/M LN • 20176959 х• RS68/E LN • 20067545 x • RS70/M • 20067545 х• RS 70/E • 20067545 x • 20067545 RS 100/M x • х RS 100/E x • 20067546 x 20067546 RS 120/M LN X • х **RS 120/E LN** X • х RS 130/M х RS 130/E • 20067546 x 20067546 RS 160/M LN x • 20067546 x • 20067546 X • RS 160/E LN x • 20067546 x • 20067546 x • RS 190/M • 20067546 X • RS 190/E • 20067546 X • **COMBINATION OIL/GAS** RLS 28 х RLS28/E х **RLS 38** • х RLS38/E х • **RLS 50** х ٠ **RLS 50/E** • х **RLS 70** • 20067545 х • • 20067545 **RLS 68/E** • 20067545 **RLS 100** X • х RLS 130 • х RLS 160/E x • 20067546 X • **RLS 190** • 20067546 х• RLS 190/E • 20067546 X •

The following table shows the ordering codes for the burner mounting plate kits.

(x) (●) (\*) 0 feet altitude

6000 feet altitude Sliding

Burners are approved to UL Standard UL 295 and CSA Standard CGA 3.4 Riello file number MP 3252

BURNERS				RTC	-80			
MODEL	1000	1300	1700	2300	3000	3800	4700	5500
PREMIX @ 0	feet altitude							
RX 400	x 20067543 (*)							
RX 500		• 20067543 (*)	x 20067544 (30/20 ppm)					
RX 700			x 20169559 (9 ppm)	x 20169559 (30/20 ppm)				
RX 850				x 20169559 (9 ppm)	x 20169560 (30 ppm)			
RX1000					x 20169560 (20/9 ppm)	x 20169560 (30/20 ppm)		
RX1500							x 20124397 (30/20/9 ppm)	x 20124397 (30 ppm)
RX1800								x 20124397 (20/9 ppm)
PREMIX @ 60	000 feet altitud	9						
RX 400	x 20067543 (*)							
RX 500		• 20067543 (*)	x 20067544 (30/20 ppm)					
RX 700			• 20169559 (20/9 ppm)	• 20169559 (30 ppm)				
RX 850				• 20169559 (20/9 ppm)	• 20169560 (30 ppm)			
RX1000					• 20169560 (20/9 ppm)	• 20169560 (30/20 ppm)		
RX1500							• 20124397 (30/20/9 ppm)	• 20124397 (30 ppm)
RX1800								• 20124397 (20/9 ppm)

(x) 0 feet altitude
 (•) 6000 feet altitude
 (\*) Sliding
 Burners are approved to UL Standard UL 295 and CSA Standard CGA 3.4 Riello file number MP 3252

#### INSTALLATION 2

#### 2.1 Unpacking the product

RTC-80 boilers are delivered in two separate packs. The first contains:

- the boiler body inside a protective bag (A);
- flue cleaning brush (B);
- ceramic insulation (C) (within combustion chamber);
- fiberglass braid (20x15) (D) (within combustion chamber);
  documentation envelope (E) containing:
  - instruction manual Copy of H-2 Form data label and warning label (to be applied to the casing upon completion of the installation) water treatment instructions



The second contains:

- the boiler casing complete with installation accessories, protected by cardboard packing and a wooden crate.





NOTE: The instruction manual is an integral part of the appliance; therefore, it should be read and stored carefully.

**NOTE:** Keep the documentation envelope in a safe place. Any replacement documents must be ordered from Riello S.p.A. who reserve the right to charge for the cost of the replacement.

# **2.2** Overall dimensions and weights



Description	llait	RTC-80								
Description	Unit	1000	1300	1700	2300	3000	3800	4700	5500	
A: Base width	inch (mm)	29 1/2 (750)	29 1/2 (750)	31 1/8 (790)	31 1/8 (790)	38 9/16 (980)	38 9/16 (980)	42 1/8 (1070)	44 1/2 (1130)	
B: Overall width	inch (mm)	32 5/16 (820)	32 5/16 (820)	35 1/16 (890)	35 1/16 (890)	42 1/2 (1080)	42 1/2 (1080)	46 1/16 (1170)	48 1/4 (1225)	
C: Length base to front	inch (mm)	4 15/16 (125)	4 15/16 (125)	5 1/8 (130)	5 1/8 (130)	5 1/2 (140)	5 1/2 (140)	6 1/8 (155)	5 7/8 (150)	
D: Height of burner plate	inch (mm)	40 9/16 (1030)	40 9/16 (1030)	48 5/8 (1235)	48 5/8 (1235)	54 3/4 (1390)	54 3/4 (1390)	58 7/8 (1495)	62 5/8 (1590)	
E: Length base to rear	inch (mm)	1 9/16 (40)	1 9/16 (40)	1 3/8 (35)	1 3/8 (35)	2 3/4 (70)	2 3/4 (70)	3 1/8 (80)	3 15/16 (100)	
F: Flue connection depth	inch (mm)	2 3/8 (60)	2 3/8 (60)	3 1/8 (80)	3 1/8 (80)	3 9/16 (90)	3 9/16 (90)	3 1/8 (80)	3 1/8 (80)	
H – Height of water fittings	inch (mm)	57 1/16 (1450)	57 1/16 (1450)	66 3/4 (1695)	66 3/4 (1695)	75 (1905)	75 (1905)	80 5/16 (2040)	85 13/16 (2180)	
H1 – Boiler height	inch (mm)	56 9/16 (1435)	56 9/16 (1435)	66 1/8 (1680)	66 1/8 (1680)	74 7/16 (1890)	74 7/16 (1890)	79 3/4 (2025)	85 1/4 (2165)	
L – Length	inch (mm)	65 3/16 (1655)	73 1/16 (1855)	80 1/8 (2035)	88 (2235)	103 1/8 (2620)	113 (2870)	120 11/16 (3065)	121 1/4 (3080)	
L1 – Base length	inch (mm)	58 11/16 (1490)	66 9/16 (1690)	73 7/16 (1865)	81 1/2 (2070)	94 7/8 (2410)	104 3/4 (2660)	111 7/16 (2830)	111 7/16 (2830)	
Weight of boiler	lbs (kg)	1676 (760)	1786 (810)	2679 (1215)	2965 (1345)	4167 (1890)	4777 (2167)	5908 (2680)	6834 (3100)	
Weight of paneling	lbs (kg)	132 (60)	154 (70)	198 (90)	264 (120)	308 (140)	352 (160)	473 (215)	506 (230)	

# **2.3** Moving and removing the packaging

A Wear suitable personal protection equipment when moving the boiler and removing the packing. Only use lifting equipment that is suitable for the weight involved.

The product can be moved in two ways:

- using a hoist of suitable lifting capacity;
  using a fork lift of suitable lifting capacity.

Two lifting points (A) are provided at the top of the boiler body for use with a hoist.

A Move the boiler to its place of installation, using equipment of suitable lifting capacity.



CAUTION: Do not dispose of packaging material into the environment, or leave it within the reach of children, since it can become a potential hazard. Dispose of packaging material in compliance with the applicable legislation.



- for lifting using a rigging crane, use only the lifting provisions supplied.
- when lifting the boiler using chains, make sure that at least two chains are load-bearing. Lift up very carefully.
- maintain less than a 45 degree angle with the vertical when lifting the boiler with chains or cables.
- \_ the rigging crane must be operated by trained personnel.

WARNING: Risk of injury from carrying heavy loads and inadequately securing loads for transport.

- Use suitable means of transportation, e.g. several pallet trucks, a forklift truck, crane or heavy duty rollers
- secure the load against falling.

# 2.4 Installation premises

RTC-80 boilers must be installed in a dedicated boiler room that conforms to applicable laws and standards. The boiler room must have adequately sized vents that also conform to applicable laws and standards.

Ambient temperature must be between 32°F and 140°F (0°C and 60°C).

All boiler models must be installed at a height of at least 4" from the floor to permit the necessary pipes and valves to be connected to the boiler drain and condensate drain.

If possible, the boiler should be installed on a raised base to prevent the burner fan from drawing in dust and to facilitate draining of condensate to a neutralization system. The boiler base must be flat and levelled.

The boiler condensate drain must be located above the height of the top of the system's condensate neutralizer.

The gas supply pipe should be installed in such a way that the boiler's paneling can be removed and the front door opened without having to remove the burner.



A WARNING: Check that the electric protection level of the appliance is suitable for features of the room where it is installed.

A WARNING: Make sure that combustion air is not contaminated by substances containing chlorine or fluorine (elements found in sprays, paints, detergents etc.).

These boilers must be installed indoors. They are not designed for outside use.

WARNING: Do not obstruct or restrict the air vents in the room where the boiler is installed. A free air supply is essential for correct combustion.

# 2.4.1 Installation clearances

#### **Single Boiler configuration**

This figure shows suggested installation clearances. If necessary, the boilers may be mounted side by side with reduced clearance between. Top clearance may also be reduced depending on the mounting positions of accessories such as temperature sensors and relief valve.



DTC 00	Minimum	Unit	
RIC-80	Α	В	Unit
1000	32	25	inch
1300	32	28	inch
1700	40	28	inch
2300	40	28	inch
3000	48	28	inch
3800	48	36	inch
4700	48	36	inch
5500	48	40	inch

#### **Two-Boilers configuration**



# Three-Boilers configuration



# Four-Boilers configuration



RTC-80	A Minimum distances	Unit
1000	32	inch
1300	32	inch
1700	40	inch
2300	40	inch
3000	48	inch
3800	48	inch
4700	48	inch
5500	48	inch

**WARNING**: Make sure that the door is properly oriented.

2.4.2 Minimum clearance to combustibles



#### 2.5 Water connections

The following table gives the dimensions and positions of the water fittings on **RTC-80** boilers. Before installing the boiler, flush out all the pipes of the central heating circuit to remove any machining residues, oils, scale, dirt and debris.





Description	Unit				RTC	-80			
Description	Unit	1000	1300	1700	2300	3000	3800	4700	5500
1 – Heating supply	NPS	2-1/2'' #150	3" #150	4" #150	4" #150	5" #150	5" #150	6" #150	6" #150
2 – Heating return 1 (Low Temperature)	NPS	2-1/2'' #150	3" #150	4" #150	4" #150	5" #150	5" #150	6" #150	6" #150
3 – Heating return 2 (High Temperature)	NPS	2" #150	2-1/2" #150	3" #150	3" #150	3" #150	3" #150	4" #150	4" #150
4 – Safety device fitting	inch – NPS	11/4	11/4	11/2	1 1/2	3" #150	3" #150	3" #150	3" #150
5 – Boiler drain fitting	Ø inch	1	1	1	1	1 1/4	1 1/4	11/4	11/4
6 – Condensate drain fitting	Ø inch	1	1	11/4	1 1/4	1 1/4	1 1/4	1 1/4	11/4
7 – Flue gas exhaust fitting	Ø mm	250	250	300	300	350	350	400	450
8 – Instrument bulb/ probe sockets	n° x Ø ''	3 x 1/2	3 x 1/2	3 x 1/2					
A – Distance from boiler front to supply outlet	inch (mm)	12 1/16 (306)	12 5/8 (321)	12 1/4 (311)	12 1/4 (311)	16 1/8 (410)	16 1/8 (410)	17 5/16 (440)	17 3/8 (442)
<ul> <li>B – Distance from</li> <li>heating flow outlet to</li> <li>return 1</li> </ul>	inch (mm)	41 3/8 (1050)	48 5/8 (1235)	55 5/16 (1405)	63 3/16 (1605)	70 7/8 (1800)	80 11/16 (2050)	86 5/8 (2200)	101 5/8 (2582)
C – Distance between heating returns 1 & 2	inch (mm)	11 13/16 (300)	9 7/8 (250)	10 1/8 (255)	11 13/16 (300)	13 13/16 (350)	13 13/16 (350)	13 13/16 (350)	28 13/16 (732)
<ul> <li>D – Distance between</li> <li>heating return 2 and</li> <li>safety device fitting</li> </ul>	inch (mm)	11 13/16 (300)	17 3/4 (450)	23 5/8 (600)	27 9/16 (700)	29 1/2 (750)	33 1/2 (850)	33 1/2 (850)	33 1/2 (850)
E – Distance between heating flow outlet and safety device fitting	inch (mm)	17 3/4 (450)	21 1/16 (535)	21 11/16 (550)	23 13/16 (605)	27 9/16 (700)	33 1/2 (850)	39 3/8 (1000)	39 3/8 (1000)
F – Distance between heating return 1 and flue gas outlet	inch (mm)	9 1/2 (242)	9 1/2 (242)	10 5/8 (270)	10 5/8 (270)	12 13/16 (325)	12 13/16 (325)	13 3/4 (350)	22 1/4 (565)
G – Height of conden- sate drain	inch (mm)	6 1/8 (155)	6 1/8 (155)	8 1/2 (215)	8 1/2 (215)	7 11/16 (195)	7 11/16 (195)	8 7/16 (215)	9 1/4 (235)
H – Height of boiler flanges	inch (mm)	57 1/16 (1450)	57 1/16 (1450)	66 3/4 (1695)	66 3/4 (1695)	75 (1905)	75 (1905)	80 5/16 (2040)	85 13/16 (2180)
I – Height of flue gas outlet	inch (mm)	21 1/16 (535)	21 1/16 (535)	25 (635)	25 (635)	26 3/4 (680)	26 3/4 (680)	28 3/8 (720)	31 11/16 (805)
L – Height of boiler drain fitting	inch (mm)	2 13/32 (61)	2 13/32 (61)	3 1/4 (82)	3 1/4 (82)	3 3/8 (86)	3 3/8 (86)	3 1/2 (90)	3 3/8 (85)
M – Boiler centerline	inch (mm)	14 3/4 (375)	14 3/4 (375)	15 9/16 (395)	15 9/16 (395)	19 5/16 (490)	19 5/16 (490)	21 1/16 (535)	22 1/4 (565)
0 – Distance from Boiler drain fitting	inch (mm)	5 3/8 (137)	5 3/8 (137)	4 15/16 (125)	4 15/16 (125)	6 7/8 (175)	6 7/8 (175)	7 1/8 (181)	7 (178)
P – Height of heating re- turn 1 (Low Temperature)	inch (mm)	_	_	-	-	-	_	-	53 7/8 (1370)

Flange as per ASME B16.5

# **2.6** Sensor manifold installation



	1000	1300	1700	2300	3000	3800	4700	5500	
Sensor manifold type	2-1/2" #150	3" #150	4" ‡	<b>‡</b> 150	5" ‡	<b>‡</b> 150	6" ‡	<b>‡</b> 150	Ø NPS

# 2.7 Sensor manifold connections



Sensor manifold type	2-1/2'' #150	3″ #150	4''#150	5″ #150	6''#150
А	3 <b>-</b> 17/64''	3 <b>-</b> 17/64''	3-5/32''	3-5/32"	3-5/32"
	83 mm	83 mm	80 mm	80 mm	80 mm
В	3 <b>-</b> 15/16"	3 <b>-</b> 15/16''	3 <b>-</b> 47/64''	3 <b>-</b> 47/64"	3 <b>-</b> 47/64"
	100 mm	100 mm	95 mm	95 mm	95 mm
С	4–29/64''	4−1/4''	4-21/64''	4-21/64''	4-21/64''
	113 mm	108 mm	110 mm	110 mm	110 mm
D	3 <b>-</b> 15/16"	3 <b>-</b> 15/16''	3 <b>-</b> 15/16''	3 <b>-</b> 15/16''	3–15/16''
	100 mm	100 mm	100 mm	100 mm	100 mm
E	5 <b>-</b> 5/8"	5-5/8"	5-33/64"	5-33/64"	5-33/64"
	143 mm	143 mm	140 mm	140 mm	140 mm
F	3 <b>-</b> 15/16"	3 <b>-</b> 15/16"	4–1/8''	4−1/8"	4–1/8''
	100 mm	100 mm	105 mm	105 mm	105 mm
G	12-51/64"	12-51/64"	12-51/64"	12-51/64"	12-51/64"
	325 mm	325 mm	325 mm	325 mm	325 mm

#### 2.8 Positioning of sensor sockets



- (\*) On the models **RTC 3000-80** to **RTC 5500-80** the safety fitting is flanged.
- 1 Outlet operating temperature thermowell (G 1/2") for n.2÷3 instrument bulb. Internal diameter probe sockets 7 mm. Thermowell length L170 mm
- 2 Over-temperature protection thermowell (G 1/2") for n.1 instrument bulb. Internal diameter probe sockets 15 mm. Thermowell length L170 mm
- 3 Inlet operating temperature thermowell (G 1/2") for n.2÷3 instrument bulb. Internal diameter probe sockets 7 mm. Thermowell length L100 mm

Poilor	RTC-80													
Boller	1000		1300		1700		2300		3000		3800		4700	
Sensor manifold type Ø NPS	2-1/2'	' #150	3″ ‡	<b>‡</b> 150	4" ‡	<b>‡</b> 150	4" ‡	<b>‡</b> 150	5″ ‡	<b>‡</b> 150	5″ ‡	<b>‡</b> 150	6" ‡	<b>‡</b> 150
Thermowell length (*)	min.	max.	min.	max.	min.	max.	min.	max.	min.	max.	min.	max.	min.	max.
4 – LWCO (3/4'' NPT)														
5 – Gauge (3/4" NPT)	2-31/64"	3-15/16"	2-31/64" 3	3 <b>-</b> 15/16" 100 mm	2 <b>-</b> 31/64" 63 mm	3-15/16"	2-31/64" 3-15/16 63 mm 100 mn	3-15/16"	2-31/64" 4-59/ 63 mm 125 m	4-59/64"	" 2-31/64" 4-59/64" 63 mm 125 mm	4-59/64"	2-31/64" 4-5 63 mm 125	4-59/64"
6 - Manual reset high limit (3/4" NPT)	63 mm	100 mm	63 mm			100 mm		100 mm		125 mm		125 mm		125 mm
7 – Outlet temperature sensor (1/2" NPT)														

(\*) The sensor sockets are not supplied.

The LWCO must be installed in a position higher than all other regulation and safety devices (over-temperature protection, operating temperature sensor and temperature gauge).



(\*) On the models **RTC 3000–80** to **RTC 5500–80** the safety fitting is flanged.

- 1 Outlet operating temperature thermowell (G 1/2") for n.2÷3 instrument bulb. Internal diameter probe sockets 7 mm. Thermowell length L170 mm
- 2 Over-temperature protection thermowell (G 1/2") for n.1 instrument bulb. Internal diameter probe sockets 15 mm. Thermowell length L170 mm
- 3 Inlet operating temperature thermowell (G 1/2") for n.2÷3 instrument bulb. Internal diameter probe sockets 7 mm. Thermowell length L100 mm

Poiler	RTC-8	0				
Boller	5500					
Sensor manifold type Ø NPS	6" #150					
Thermowell length (*)	min.	max.				
4 - LWCO (3/4" NPT)						
5 – Gauge (3/4" NPT)	2-31/64"	4-59/64"				
6 - Manual reset high limit (3/4" NPT)	63 mm	125 mm				
7 – Outlet temperature sensor (1/2" NPT)						



The sensor sockets are not supplied.

The LWCO must be installed in a position higher than all other regulation and safety devices (over-temperature protection, operating temperature sensor and temperature gauge).

# 2.8.1 Water-side pressure drop

	∆ <b>T=</b> 2	∆ <b>T=20°F</b>		∆ <b>T=30°F</b>		۱0°F	∆ <b>T=60°F</b>	
Model	Flow rate	Pressure drop	Flow rate	Pressure drop	Flow rate	Pressure drop	Flow rate	Pressure drop
	(GPM) (*)	(psi)	(GPM) (*)	(psi)	(GPM) (*)	(psi)	(GPM) (*)	(psi)
RTC 1000-80	95	0.67	63	0.30	48	0.19	32	0.08
RTC 1300-80	124	0.49	82	0.22	62	0.13	41	0.06
RTC 1700-80	162	0.44	108	0.20	81	0.12	54	0.05
RTC 2300-80	219	1.86	146	0.83	109	0.42	73	0.19
RTC 3000-80	285	1.76	190	0.78	143	0.44	95	0.20
RTC 3800-80	361	1.36	241	0.60	181	0.38	120	0.17
RTC 4700-80	447	1.45	298	0.64	223	0.41	149	0.18
RTC 5500-80	523	2.18	348	0.97	261	0.52	174	0.23

At 95% efficiency and full firing rate

	Δ <b>T=</b> 2	20°F	Δ <b>T=</b> 3	30°F	∆ <b>T=</b> 4	+0°F	∆ <b>T=60°F</b>	
Model	Flow rate	Pressure drop	Flow rate	Pressure drop	Flow rate	Pressure drop	Flow rate	Pressure drop
	(GPM) (*)	(psi)	(GPM) (*)	(psi)	(GPM) (*)	(psi)	(GPM) (*)	(psi)
RTC 1000-80	92	0.63	61	0.28	46	0.18	31	0.08
RTC 1300-80	120	0.46	80	0.20	60	0.12	40	0.05
RTC 1700-80	156	0.41	104	0.18	78	0.11	52	0.05
RTC 2300-80	212	1.74	141	0.78	106	0.39	71	0.18
RTC 3000-80	276	1.65	184	0.73	138	0.41	92	0.18
RTC 3800-80	350	1.28	233	0.57	175	0.36	117	0.16
RTC 4700-80	432	1.36	288	0.60	216	0.38	144	0.17
RTC 5500-80	506	2.04	337	0.91	253	0.49	169	0.22

At 92% efficiency and full firing rate

	∆ <b>T=20°F</b>		∆ <b>T=</b> 3	∆ <b>T=30°F</b>		۰0°F	∆ <b>T=60°F</b>		
Model	Flow rate	Pressure drop	Flow rate	Pressure drop	Flow rate	Pressure drop	Flow rate	Pressure drop	
	(GPM) (*)	(psi)	(GPM) (*)	(psi)	(GPM) (*)	(psi)	(GPM) (*)	(psi)	
RTC 1000-80	87	0.56	58	0.25	44	0.16	29	0.07	
RTC 1300-80	113	0.41	75	0.18	57	0.11	38	0.05	
RTC 1700-80	148	0.37	99	0.16	74	0.10	49	0.04	
RTC 2300-80	200	1.56	133	0.69	100	0.35	67	0.16	
RTC 3000-80	261	1.48	174	0.66	131	0.37	87	0.16	
RTC 3800-80	331	1.14	220	0.51	165	0.32	110	0.14	
RTC 4700-80	409	1.22	273	0.54	204	0.34	136	0.15	
RTC 5500-80	479	1.83	319	0.81	239	0.44	160	0.19	

At 87% efficiency and full firing rate

(\*) Units shown are in US Gallons.

#### 2.8.2 Flow limits

**RTC-80** boilers do not require a minimum flow rate in order to maintain warranty. The boiler has been designed to operate with a temperature difference between the supply and return of up to 100 °F. Flow should be initiated with the start of the burner to minimize temperature fluctuations and control deviations. The field installed manual reset high limit (as required by CSD-1) must be fitted to the instrument tapping of the heating supply, set to 210°F and electrically connected into the Control unit or the burner enable/disable circuit directly.

**RTC-80** boilers can operate with zero flow, and do not require a minimum flow rate.

A minimum flow is recommended only to provide heat transfer, and the maximum flow to prevent erosion.

Madal	Flow	Flow Limits					
Model	Maximum	Minimum					
RTC 1000-80	130	12	GPM (*)				
RTC 1300-80	160	15	GPM (*)				
RTC 1700-80	200	20	GPM (*)				
RTC 2300-80	290	30	GPM (*)				
RTC 3000-80	370	40	GPM (*)				
RTC 3800-80	480	50	GPM (*)				
RTC 4700-80	580	60	GPM (*)				
RTC 5500-80	690	70	GPM (*)				

(\*) Units shown are in US Gallons.

#### 2.8.3 Water quality requirements

The manufacturer recommends the use of water as heat transfer fluid for the central heating system. A chemical treatment system must be provided for this water.

The heat transfer fluid (water) for the central heating circuit must conform to the quality parameters given in the following table:

Chemical and physical requirements of heating system water									
		Initial filling water	Regular service water (*)						
ph		6-8	7.5-9.5						
Hardness	⁰fH / ppm	< 5° / 50	< 5° / 50						
Electrical con- ductivity	µs/cm		< 100						
Chlorides	mg/l / ppm		< 10 / 10						
Sulphides	mg/l / ppm		< 10 / 10						
Nitrides	mg/l / ppm		< 10 / 10						
Iron	mg/l / ppm		< 0.5 / 0.5						

(\*) values for water in system after 8 weeks of functioning

# A NOTICE:

If it proves impossible to treat the heating system water supply properly because the water charging system is automatic and uncontrolled, if there are no barriers installed to prevent water oxygenation and if the heating system includes an open expansion vessel, then the boiler itself must be separated from the heating system by means of a heat exchanger.

If the hardness of the water exceeds the value specified in the table, it is mandatory to install a water softening system.

# A NOTICE:

- Chemical products used for water treatment must be compatible with applicable water pollution laws.
- Provided they are properly applied, these laws guarantee the safe functioning of the heating system.

#### 2.8.4 Central heating system

#### Possible causes for corrosion and limescale

Typical problems encountered in central heating systems include:

- the breakage of heated surfaces through overheating caused by the thermal insulation of limescale deposits on the water side
- oxygen corrosion
- deposit corrosion
- stray current corrosion
- diffused and localized acid corrosion.

The technical details provided in this section refer specifically to domestic and industrial hot water heating systems with working temperatures up to 210°F (99°C).

#### 2.8.5 New central heating systems

#### Mistakes to avoid and precautions.

To eliminate contact between system water and the air, the following is required:

- ensure that the expansion vessel is a closed vessel, and of the correct size and pre-charge pressure (the pressure should be checked periodically)
- ensure that the system is always kept at a pressure higher than atmospheric pressure at all points (including the pump suction side) and at all operating conditions (precisely because the seals, gaskets and joints in a water circuit are designed to resist pressure from within, but not to resist a vacuum within)
- ensure that no part of the system is made from materials that are permeable to gases (e.g. plastic pipes with no oxygen barrier used in floor heating systems).

# A NOTICE:

The original system filling water and any topping up water must always be filtered (using synthetic or metal mesh filters with a filtration rating of no less than 50 microns) to prevent sludge from forming and triggering deposit induced corrosion.

# A NOTICE:

We recommend fitting an 80 mesh dirt filter externally to the boiler return to prevent contamination of the boiler by the water source.

# A NOTICE:

- Loss of water from the system, and the consequential need to add water, can be caused not only by leaks from the circuit, but also from the incorrect sizing of the expansion vessel or precharge pressure. (If normal thermal expansion causes pressure in the system to increase beyond the setting of the safety valve, that safety valve will open continuously.)
- The expansion vessel size should be corrected to prevent unnecessary safety valve blow-off.

The heating system should not need any further topping up once it is filled and bled of all air.

Any top-ups need to be monitored (by a meter), treated and recorded in the heating system's technical log. The presence of a water softener in conjunction with an automatic filling system is not sufficient to ensure proper performance.

If more than one boiler is installed in a large system, all boilers must be switched on at the same time to ensure that any possible limescale formation is uniformly distributed.

#### **2.8.6** Reconditioning old heating systems

#### Frequent mistakes and necessary precautions.

If a boiler must be replaced, do not refill the entire central heating circuit if the quality of water in it conforms to requirements. If the quality of water fails to conform to requirements, either recondition the old water or separate the water circuits (water in the boiler circuit must conform to requirements).

#### Conclusions

Never forget that proper water conditioning and proper heating system design not only guarantee safety and security but also ensures significant savings in maintenance costs and overall thermal efficiency.

# **2.8.7** Elimination of air and gas from central heating system

When designing new heating systems, it is necessary to eliminate the air and other gases that form in the system.

Recently added fill or top-up water loses much of its volume in the first few days because it releases gases. With new systems you should therefore initially check the heating water pressure on a daily basis, and then at gradually longer intervals. Air and gas in the water system not only causes the corrosion problems listed above, but also reduces thermal efficiency, causing pump failure and noise and vibration throughout the heating system. Air bubbles and gas inevitably form in heating circuits during normal functioning, especially if the precautions listed above are not fully respected.

In particular:

- as temperature increases, oxygen becomes less watersoluble and bubbles begin to form;
- C02 (carbon dioxide) is generated as the carbonates of calcium and magnesium precipitate out;
- the chemical oxidation of the metals in the system also generates hydrogen.

These gases must be eliminated as they are formed. The system needs to be designed and installed so that all gases can be vented quickly, easily, and effectively.

# 2.8.8 Use of antifreeze

Do not use automotive silicate-based antifreeze in the heating system.

In areas where freezing may occur, an antifreeze may be added to the system water as protection. Please adhere to the specifications provided by the antifreeze manufacturer.

- Use the anti-freeze manufacturer's data to determine the anti-freeze ratio for the desired freeze protection temperature.
- Do not exceed 50% antifreeze mix ratio and do not use antifreeze other than specifically made for hot water heating systems.
- the chemical oxidation of the metals in the system also generates hydrogen.

#### **2.9** Typical water system schematics

The following P&ID represent the typical arrangements for the most common types of installation and they are only a suggestion for the installer that is resposible for all equipment and details required by local laws.

The DHW and central heating circuits must incorporate expansion vessels of adequate capacity as well as suitably rated safety valves. The condensate drain must be connected to a suitable collection and drain system.

**Single Boiler Piping Schematic Type A** 

The selection and the installation of the components of the system is the responsibility of the installer, who must operate in accordance with good practice and current Legislation.

A If needed, water supplies and recovery circuits must be conditioned by suitable treatment systems. Refer to the values listed in the table in the paragraph Water quality requirements.

**CAUTION:** It is prohibited to operate the circulators without water.



#### Single Boiler Piping Schematic Type B



#### **Single Boiler Combination Heating & Domestic Water Plant**



- 1 Boiler
- Burner 2 3 4
- Isolation valves
- Central heating system pump
- 5 Non-return valves
- 6 Automatic vent valve 7 Boiler safety valve
- 8 Boiler drain valve
- Y strainer 9
- 10 Pressure reducer
- 11 Expansion tank
- 12 Water softener filter
- Siphon 13
- Condensate outlet 14
- 15 Drain
- 16 Isolation valve

- 17 Non-return valve
- 18 Air separator
- Domestic water storage tank 19
- Storage tank drain valve 20
- DHW circuit expansion tank 21
- 22 Storage tank safety valve
- 23 3-way valve
- Central heating system manifold 24
- 25 Pressure gauge
- (\*) (\*\*) LT= Low Temperature/HT= High Temperature On the RTC 1000-80 to RTC 4700-80 the low temperature heating return is located on the top of the boiler. See "Single Boiler Piping Schematic Type A".

**Multiple Boiler Piping Schematic with Sequencing Panel** 



Multiple Boiler Piping with Primary and Secondary Piping



#### Multiple-Boiler Piping with Motorized Sequencing Valves



#### **Two-Boiler Combination Heating & Domestic Water Plant**



- 12 Water softener filter
- 13 Siphon
- Condensate outlet 14
- 15 Drain 16
  - Isolation valve

- .\_. (\*) (\*\*) LT= Low Temperature/HT= High Temperature On the **RTC 1000-80** to **RTC 4700-80** the low temperature heating return is located on the top of the boiler. See "Single Boiler Piping Schematic Type A".

#### **Multi-Boiler Combination**



#### 2.10 Draining the condensate

RTC-80 condensing boilers produce a flow of condensate that varies according to operating conditions.

The maximum hourly production of condensate for each model is given in the table in the paragraph Neutralizing the condensate.

The condensate drain system must be suitably dimensioned to cope with the flow produced. Also, pipe and hose diameter must not be less than 1" for RTC-80 1000 ÷ 1300 and 1-1/4" for RTC-80 1700 ÷ 5500 at any point. This diameter corresponds to that of the boiler's condensate drain fitting (7).

Collection and connection to the drain system must conform to applicable national and local codes.

To prevent combustion fumes from leaking into the air of the boiler room, the condensate drain pipe must incorporate a siphon creating a minimum head equivalent to the furnace pressure plus 1" W.C..

The connecting pipes between the boiler, siphon and waste water drain pit must be laid at a minimum down slope of 3° and must be installed in such a way as to prevent any build-up of condensate.



#### 2.11 Neutralizing the condensate

Installation of a condensate neutralization kit is always recommended. The following table states the rate of condensate flow produced by the boiler.

Model	Condensate Production		Condensate Production	
RTC 1000-80	8.42	GPH	31.9	l/h
RTC 1300-80	10.80	GPH	40.9	l/h
RTC 1700-80	13.78	GPH	52.2	l/h
RTC 2300-80	19.49	GPH	73.8	l/h
RTC 3000-80	23.24	GPH	88.0	l/h
RTC 3800-80	29.42	GPH	111.14	l/h
RTC 4700-80	35.05	GPH	132.7	l/h
RTC 5500-80	42.13	GPH	159.5	l/h

At full load with Tin=86°F and Tout=122°F

All connecting hoses must be kept as straight and as short as possible. Any curves or sharp bends can lead to the hoses becoming clogged and can therefore prevent proper condensate discharge.



Refer to the manual supplied with the kit for installation and connection instructions.

**NOTICE**: The boiler room's condensate drain pit must be located at a lower level than the fitting on the neutralization unit.

If it ever proves necessary to neutralize the condensate that forms in the flue gas stack, connect the condensate drain fittings of the boiler and flue gas stack together using a 'T' union and connect the leg of the 'T' to the inlet of the neutralization unit.

#### 2.12 Combustion gas exhaust

The flue pipe (1) and the connection to the stack (2) must conform to applicable national and local laws and standards. Flue pipe must be rigid, impermeable to fumes, able to withstand mechanical strain, heat, and the action of combustion gases and the condensate formed by them.

The stack must be fitted with a condensate trap and drain and the flue gas exhaust pipe must be installed at a slope of at least 3° towards the boiler. All condensate should be treated through a neutralization media before being eliminated to the floor drain (3).





Description	Symbol	Unit		RTC	-80	
Description		Unit	1000	1300	1700	2300
Height of flue gas outlet	А	inch (mm)	21 1 (53	/16 85)	2 (63	5 35)
Diameter of flue gas fitting	Øi	inch (mm)	9 27 (25	7/32 50)	11 13 (30	3/16 00)
Description	Complexed the the			RTC	-80	
Description	Symbol Unit	3000	3800	4700	5500	
Height of flue gas outlet	А	inch (mm)	26 3/4 (680)		28 3/8 (720)	31 11/16 (805)
Diameter of flue gas fitting	Øi	inch (mm)	13 25/32 (350)		15 3/4 (400)	17 23/32 (450)

The boiler takes in combustion air from the boiler room. Room vents must therefore be compliant with the relevant technical standards.

Do not obstruct or restrict the air vents in the room where the boiler is installed. Adequate ventilation is essential for correct combustion and functioning.

# 2.12.1 Venting requirements

**M** WARNING: Risk of system damage or personal injury!

- The vent system could fail, causing flue gas leakage, resulting in severe personal injury or death.
- Use only an approved vent starter coupling and approved vent pipe from **RIELLO**
- Do not mix components from different systems.

**NOTICE:** How to design the flue gas outlet

 Connect an oil-fired unit to a vent having sufficient draft at all times to ensure safe and proper operation of the unit.

The RTC Boiler is a category II or IV appliance and the exhaust vent materials must be UL listed for use with a category IV appliance: operating temperatures of up to 240 °F, positive pressure, condensing flue gas. Currently, UL Listed vents of AL29–4C or 316L stainless steel must be used with the RTC Boiler. Proper clearances to combustibles must be maintained per UL and vent manufacturer instructions.

The specifying engineer should dictate flue venting as appropriate to the installation.

The vent system should be designed to facilitate smooth travel for both the intake and exhaust. Avoid the use of bullhead tees and back-to-back 90 degree elbows. The exhaust system must never be installed in a downward fashion. Be sure to follow all instructions provided by the vent manufacturer.

Keep the supply of combustion air free of corrosive substances (e.g. halogenated hydrocarbons that contain chlorine or fluorine compounds). This will help prevent corrosion. Never use or store chlorinated cleaning agents or halogenated hydrocarbons (as contained in spray cans, solvents or cleaning agents, paints and adhesives, for example) in the boiler room.

UL, NFPA 54 & 211, ANSI Z223.1 and CSA B149.1 guidelines are often the basis for state and local codes. Follow the guidelines of these recognized agencies unless codes applicable to the installation site are most stringent. The venting and combustion air systems must meet all applicable code requirements. Where code differs from the instructions provided with the equipment, code will take precedence.

Constant pressure at the flue gas outlet is not required. Size the flue system to limit pressure variations. The maximum allowable breech pressure for design of the flue system is positive 0.2" W.C. for proper combustion and light off.

A draft control system may be required to ensure proper draft when two or more boilers are connected to a common stack. Consult the flue material manufacturer for design calculations and recommendations.

# 2.12.2 Code required vent terminations

#### Horizontal Terminations:

- Vent terminations should be at least 4 feet below, 1 foot above or 4 feet horizontally from any window, door or gravity air inlet of a building.
- The termination shall be at least 6 feet away from any other building opening, gas utility meter, service regulator or the like.
- The termination shall be at least 6 feet away from the combustion air intake of any other appliance.
- The bottom of the vent terminal should be at least 12 inches above both finished grade and any snow accumulation point.
- Vent should not terminate over public walkways or over an area where condensate or vapor could create a nuisance or be detrimental to the operation of regulators, meters and other equipment.
- Discharges should not be in wind-blocked areas, corners, or directly adjacent to vegetation.

#### **Vertical Terminations:**

- Roof penetrations should follow all appliance codes and the vent manufacturer's instructions. The vent should never be installed at less than the required clearances to combustible materials per UL, NFPA and local codes. "Double-wall or thimble" assemblies are required when penetrating combustible walls and roofs.
- Vertical discharges should extend at least 2 feet above the roof through properly flashed penetrations and at least 2 feet above anything within a 10 foot horizontal diameter. Discharges that extend more than 2 feet above the roof must be laterally supported.
- If the vent systems is to be connected to an existing stack, the stack must be UL Listed for Category II or IV appliances (capable of 240 °F, positive pressure and condensing flue gas operation).
- Masonry stacks must be lined and the vent penetration must terminate flush with and be sealed to this liner. Vents may enter the stack through the bottom or side.
- RTC Boiler vent systems must not be interconnected to any other venting system; The RTC Boiler is designed to maintain its own vent system.
- The exhaust vent must be pitched up toward the termination a minimum of 1/4 inch per foot of length. Condensate must flow back to the boiler flue collector freely, without accumulating in the vent.

# 2.12.3 Combustion air from outside the building

#### Two permanent openings method

If outside combustion air is required, the room shall have two permanent louvered openings to the outdoors. Each opening must have a minimum free area of 1 square inch for each 4.000 Btu/hr of total input rating of all fuel burning equipment in the space. When the air is supplied to the room via ducts, two ducts must be used. Vertical ducts and openings must have a minimum free area of 1 square inch for each 4.000 Btu/hr of the total input rating of all fuel burning equipment in the space. Horizontal ducts and openings must have a minimum free area of 1 square inch for each 2.000 Btu/hr of the total input rating of all fuel burning equipment in the space.

#### One permanent opening method

If outside combustion air is required, the room shall have one permanent louvered opening to the outdoors. The opening must communicate directly with the outdoors or through a duct in either a vertical or horizontal arrangement. The opening must have a minimum free area of 1 square inch for each 3.000 Btu/hr of total input rating of all fuel burning equipment in the space.

The free area of the opening must take into account restrictions from louvers and screens. The louver manufacturer should be consulted for the percentage of free area available. When free area is not known, metal louvers typically have 60–70% of free area, wooden louvers have between 20–25% of free area. Louvers should be in a fixed position or interlocked with equipment so that they open automatically during equipment operation. The combustion air damper opening shall be located as follows: top louver shall begin within 12" of the ceiling and the bottom louver within 12" of the floor as prescribed in NFPA 54.

#### Direct intake method

If outside combustion air is required, air may be drawn from the outdoors via a duct connected directly to the burner intake. The duct shall be constructed of galvanized steel or a material having equivalent strength and rigidity. Refer to the burner manufacturer's recommendations and installation instructions for additional guidelines and application requirements.

#### 2.12.4 Combustion air from an adjacent room

Where combustion air is to be used from within the building, air must be provided into the equipment room through two permanent openings into the interior building. Each opening must have a minimum free area of 1 square inch for each 1.000 Btu/hr of the total input rating of all fuel burning equipment in the space. The louvers shall be located as follows: top louver shall start within 12" of the ceiling and the bottom louver within 12" of the floor as prescribed in NFPA 54.

#### 2.12.5 Condensate removal

The exhaust vent pipe must be pitched at least 1/4" per foot of length back to the boiler. This will allow condensate to drain back to the unit to be disposed. Low spots in the venting where condensate may collect should be avoided. A plastic hose or PVC drain pipe may be used to discharge condensate to the neutralization system. Care should be taken to avoid kinks and from raising the drain line above the trap assembly.

#### 2.13 Door hinges

The boilers are pre-fitted with three hinges so that the direction of opening of the door can be rapidly reversed.

Once you have checked that the default direction of opening is as required, or have reversed the direction of opening as instructed in the 'Changing the direction of door opening' section, remove the spare hinge assembly 'B' (screw, bushing and washer) opposite the pivot side of the door.

Two different door hinge systems have been used to meet different design requirements

#### System A

(on the smaller sizes) – comes with a bracket and two hinge fixing nuts.

#### System B

(on the larger sizes) – comes with a hinge fixing plate, a nut and an internal compression spring.



#### 2.14 Changing the direction of door opening

The boiler door hinges are fitted on the right of the door at the factory. If you need to reverse the direction of opening, remove the boiler's side panel and proceed as follows:

#### System A – Smaller sizes







or fixing brackets (3) Insert a spar slot and hold

Insert a spanner through the top side slot and hold the bushing (4) steady. Unscrew the top screw (5), then remove the bushing (4) and washer (6).

Check that the main door fixing bolts (1) are tight and then remove the safety bolts (2).

And lift off the door fixing brackets (3)

Reverse the above steps to fit the door on the opposite side.

#### System B - Larger sizes



Open the door and use a hacksaw or file to remove the cutouts (top and bottom) on the opposite side of the head.





Hermetically close the door again by tightening the bolts (2) until the door compresses the braided seal. Remove the plug (1) taking care not to lose the compressed spring inserted in the threaded tube.



Remove the bolt (3) and the nuts (4).

Remove the nuts (4) that secure the hinge plate (5) to the door and remove the plate.

Remount the hinge plate on the opposite side, ensuring that the cylinder projecting above the nut (6) enters into its slot. If necessary tighten the nut (6) to raise it. Lastly, tighten the bolt (3). Also need to reattach nuts (4) on the new side.

#### 2.15 Removing the hinge assembly "B"

#### System A

- First ensure that the side safety bolt (2) is tight and then remove the main fixing bolt (1)



- With the door open, remove the hinge assembly 'B' (bushing, bolt, and washer) opposite the pivot side of the door.



#### 2.16 Earth connection

A terminal is provided on the front boiler head to connect the boiler body to an efficient earth system.

Proceed as follows:

- Unscrew the nut and washer (1) from the earth terminal
  Attach the earth cable's eye connector (2) to the terminal. (Make sure that the cable is of adequate size and complies with legislation in the country of installation)
- Fit the nut and washer (1) to the earth terminal and tighten the nut
- Connect the other end of the cable to the system's earth \_ ground.



Another hole (\*) in the left side of the boiler head can also be used to ground the appliance. If you wish to use this hole for the earth connection, remove the terminal fittings from the right of the head and move them to the left grounding point.

# 2.17 Fitting the casing panels

Proceed as follows to fit the boiler casing panels: Attach the front side panels ((2) and (3)) and rear side panels ((4) and (5)) over the boiler frame (1) and to the top side beams.

On models **RTC 1700–80**, **RTC 2300–80**, **RTC 3000–80**, **RTC 3800–80**, **RTC 4700–80**, **RTC 5500–80** also fit side panels (6) and (7).

- Secure the side panels in place using the top cross beams
   (8) and the screws provided
- Fit the top rear panel (9), the bottom rear bracket (10) and then the bottom rear panels (11) and (12).
- Fit the front top panel (13)

- Fit the top panels (14), (15), (16) and (17)
- Smaller models have only two top panels, one over the right and one over the left of the boiler
- Finally, fit the front trim panels (18) and (19).



#### **3** COMMISSIONING

#### 3.1 Preparing for initial startup

**NOTICE:** Risk of boiler damage through contaminated combustion air.

- Never operate the boiler in very dusty conditions, e.g. if building work is taking place in the installation room.
- Ensure adequate ventilation.
- Never use or store chlorinated cleaning agents or halogenated hydrocarbons (as contained in spray cans, solvents or cleaning agents, paints and adhesives, for example) in the boiler room.
- A burner contaminated during building work must be cleaned before commissioning.
- All cover plates, enclosures, clean out ports, and guards must be in place at all times, except during maintenance and servicing.
- Never burn garbage or paper in the unit, and never leave combustible materials around it.

#### 3.2 Third party control units

#### Control panels are not supplied.

**A** NOTICE: System damage due to incorrect sensor position!

- Safety cut-out and thermostat sensors of third party control units must be fitted in the instrument tapping of the outlet of the boiler.
  - The third party control unit (building management system or PLC controllers) must ensure a maximum internal boiler water temperature that is sufficiently different from the high limit safety cut-out. It must also be ensured that the digital burner controller rather than the boiler water temperature regulator switch the burner on and off.
  - The control unit must ensure that the burner is switched to low fire before being shut down.
  - Select control equipment that allows a gentle start-up with a time delay when the system is cold.
  - After the burner demand, an automatic timer (for example) should limit the burner to low fire for a period of approx.
     180 seconds. This restricted heat demand will prevent uncontrolled starting and stopping of the burner.
  - It must be possible to show the number of burner starts on the control unit used.

# 3.3 Hydraulic connection to the heating system

- If the system temperatures are different, use both return connectors high temperature and low temperature. For an optimum energy yield, we recommend supplying a flow rate of > 10 % of the total nominal flow rate via the low temperature flange, with a return temperature below the dew point. If there are no varying return temperatures, only the low temperature flange needs to be connected.
- Size the pumps correctly. High flow rates and oversized pumps can result in the accumulation of sludge or deposits on the heat exchanger surfaces.
- Before connecting the boiler, flush sludge and dirt out of the heating system.
- Ensure that no oxygen enters the heating water during operation.
- Only operate the boiler in sealed unvented systems.

# 3.4 Making the electrical connection

- Â
- **DANGER:** Danger to life through electric shock!
  - Before opening the boiler, isolate the heating system across all live phases and secure against unintentional reconnection.
  - Carefully route the cables/leads and capillary tubes.
  - Ensure that capillaries are never kinked.
  - Only carry out electrical work if you are a competent person. If you are not suitably qualified, arrange for a qualified electrician to make the electrical connections.
  - Observe local installation regulations.
  - Create all electrical connections in accordance with National Electrical Code or the applicable and local regulations.

# A NOTICE:

- The phase-neutral polarity must be respected.
- A ground (earth) connection is obligatory.

Wiring diagrams related to the burner installation may be found in the burner installation manual.

#### 3.5 Fitting temperature sensors

**NOTICE:** System damage through damaged capillaries or incorrectly fitted temperature sensor.

- Ensure that the capillaries are neither kinked nor flattened when uncoiling and routing them.
- Always push the temperature sensor completely into the bottom of the sensor well.
- Insert the temperature sensor set as far as it will go into the test point (to the bottom). Mark the sensor to determine if it is correctly installed.
- Secure the temperature sensor set in the test point with a sensor retainer.
- Never kink excess lengths of capillaries.
- Route the sensor lead through the cable conduit to the control unit.
- Connect the sensor lead to the control unit.
- Complete the commissioning report.

# 3.6 Flushing the heating system

If the heating system contains several heating circuits, these must be flushed one after the other.

To prevent contamination in the boiler, flush the heating system prior to commissioning.

- Flush the system prior to connection to the boiler. Isolate the heating supply and return at the boiler.
- Connect the heating supply to a water connection.
- Connect hose to the heating return of the heating system.
- Route hose from the heating return to a drain.
- Open connected consumers (e.g. radiators).
- Flush the heating system with fresh water until clear water emerges from the heating return.
- Drain the heating system.

#### 3.7 Filling the heating system

 CAUTION: Health risk through contaminated drinking water.
 Observe all country-specific regulations and standards regarding the prevention of drinking water contamination.

**A** NOTICE: System damage through temperature stresses.

- Only fill the heating system when cold (the water supply temperature must not exceed 104 °F (40 °C).
- During operation, only fill the heating system via the fill valve in the heating system pipework (return).

Open the automatic air vent valve only briefly for venting.

The fill and top-up water quality must comply with the water requirements in this manual.

The pH value of the heating water increases after the heating system has been filled. After 3 - 6 months (initial service) check whether the pH value of the heating water has settled down.

- Adjust the pre-charge pressure of the expansion vessel to the required pressure (only for sealed unvented systems).
- Open the shut-off valves on the heating water side.
- Fill the heating system slowly and observe the pressure gauge whilst doing so.
- Vent the heating system via the radiator air vent valves.
- If the water pressure drops as a result of venting the system:
  - Top up the system with water.
  - Carry out a leak test in accordance with locally applicable regulations.
  - After the tightness test, reinstate all components that were taken out of operation.
  - Ensure that all pressure, control and safety equipment is functioning correctly.

Once the boiler has been tested for tightness and no leaks have been found:

- Set the correct operating pressure. The working pressure in the heating system should be over 14 PSI but below the maximum limit specified for the boiler.
- Close the automatic air vent valve.

# 3.8 Preparing the heating system for operation

Observe the following points during commissioning:

- Before commissioning, vent the heating system via the ventilation facilities provided for this purpose.
- Check that the inspection opening on the flue gas collector is closed.
- Check that the combustion chamber door is securely closed.
- Check that the safety equipment (e.g. safety valve, minimum and maximum pressure limiters, high limit safety cut-out) is functioning correctly.
- Check that the required operating pressure has been achieved.
- Check the flange connections and other connections for tightness.
- Check the control unit connections and temperature sensor positions.
- Fill the condensate siphon.

#### **3.9** Commissioning the control unit and burner

By commissioning the control unit you automatically commission the burner as well. The burner can then be started by the control unit. For further information, see the installation instructions of the relevant control unit or burner.

- Use the control unit to commission the boiler.
- Set the control unit parameters.
- Complete the commissioning report in the technical documentation of the burner.

# 3.10 Commissioning report

- The boiler can be operated with a gas or dual fuel burner.
  Carefully complete the commissioning report for the relevant approved burner.
  Sign all completed commissioning work and enter the date.

COMMISSIONING STEPS	COMMENTS (SIGNATURE)
Flush the heating system.	
Fill the heating system with water.	
Vent the heating system.	
Carry out tightness test.	
Switch on the control unit. –Boiler–specific parameters set and recorded.	
Ensure the function of all safety equipment.	
Check the fuel line for tightness.	
Start the burner.	
Complete the burner test report regarding the individual output stages.	
Conduct a tightness test on the hot gas side. After a short time in operation, tighten the screws in the com- bustion chamber door to prevent leakage around the door as a result of the packing cord settling.	
Check the flange connections and fittings after the boiler has been heated up and retighten.	
Check flue path for tightness.	
Check the flue gas temperature.	
Carry out a function test on all safety equipment and record this.	
Instruct the system user and hand over technical documenta- tion.	
Enter the fuel used in the table (See ''General'' operating instructions)	
Confirm commissioning by a competent person. Company stamp/signature/date	

#### 4 SHUTDOWN

A CAUTION: Risk of system damage through frost.

When there is a frost, the heating system can freeze up if it is not operational, e.g. because of a fault shutdown.

- When there is a risk of frost, protect your heating system against freezing up.
- If your heating system has been shut down for several days due to a fault shutdown and there is a risk of frost, drain the heating water at the drain & fill valve. Also leave the air vent valve at the highest point in the system open.

# **NOTICE:** Risk of system damage through frost.

The heating system can freeze up as a result of a power failure or if the power has been switched off.

- Check the "Control unit settings" to ensure the system remains operational (especially when there is a risk of frost).

# A NOTICE:

 Always keep the oil supply valve shut off if the burner is shut down for an extended period of time.

#### **4.1** Shutting down the heating system

Shut down your heating system via the control unit. Switching off the control unit also switches off the burner automatically.

- Set the On/Off switch of the control unit to Off.
- Isolate the fuel supply to the burner.

# **4.2** Shutting down the heating system in an emergency

Only in emergencies, switch OFF the heating system via the boiler room breaker or the heating system emergency stop switch.

- In dangerous situations, immediately close the main fuel shut-off valve and the power supply of the heating system via the boiler room main breaker or the heating system emergency stop switch.
- Isolate the fuel supply to the burner.
- Never put your life at risk. Your own safety is paramount.

#### **5** INSPECTION AND MAINTENANCE

#### 5.1 Why is regular maintenance important?

Heating systems require regular maintenance and service for the following reasons:

- to maintain a high level of efficiency and to operate the system economically (low fuel consumption),
- to achieve a high level of operational reliability
- to maintain the cleanest possible combustion

The operator is required to have the entire heating system at least once a year maintained, serviced and cleaned. We recommend that an annual inspection and as-required ser-

vice contract is signed.

The servicing work carried out should be recorded.

Burner servicing should be carried out in accordance with the instructions of the burner manufacturer.

#### 5.2 Maintenance

Regular maintenance is a legal requirement. It is also essential for the safety, efficiency and durability of the boiler. Proper maintenance keeps consumption and emissions down, and ensures that the boiler continues to operate reliably over time. Have your boiler serviced either by **RIELO**'s Technical Assistance Ser-

Have your boiler serviced either by **RIELO**'s Technical Assistance Service or by a qualified heating engineer. Analyze the combustion exhaust gases before commencing any maintenance. The results of the flue gas analysis can give a clear idea of what servicing or repairs are needed.

- Turn the system's main power switch OFF
- Close all the gas cocks.



**DANGER:** Risk to life from electric shock!

- Before opening a unit: disconnect electrical power and lockout to prevent accidental reactivation.
- DANGER: Risk to life from explosion of flammable gases!
   Work on gas components must only be carried out by qualified and authorized gas fitters.

# A NOTICE:

- All cover plates, enclosures, and guards must be in place at all times, except during maintenance and servicing.

Analyze the combustion flue gas before commencing any main-tenance.

The results of flue gas analysis can give a clear idea of what servicing or repairs are needed.

#### **OPENING THE DOOR**

#### System A

Make sure that the safety bolts (1) on the side of the boiler are tight.



#### System A – B

To open the door, simply remove the main fixing bolts (2) under the caps (3) holding the door in place.



#### ADJUSTING THE DOOR

Make quite sure that the door presses uniformly all around the double seal to prevent dangerous fumes escaping into the air from the pressurized furnace. Proceed as follows to adjust the door seals:

#### System A

- Fit the door and tighten the main fixing bolts (2) until the seals start to compress
- Loosen the safety bolts (1) then fully screw in the main door fixing bolts (2)
- Make sure that the door is properly adjusted after every maintenance operation.



#### System B

 Put the door in its correct position and tighten the main locking screws (4) until the packing starts to be compressed.



Make sure that the door is properly adjusted after every maintenance operation.

#### 5.3 Cleaning the boiler

Clean the boiler and remove any carbon deposits from the surfaces of the heat exchanger at least once a year. This not only extends the boiler's working life, but also keeps it efficient in terms of heat output and fuel consumption.

Proceed as follows to clean the boiler:

- Open the front door (1) and remove turbolators (2)
  Use a flue brush (3) or other suitable tool to clean inside the combustion chamber and the flue gas pipes



The first time opening the door, remove the spare hinge assembly (B) (bushing, bolt, and washer) opposite the pivot side of the door.

Remove the deposits accumulated in the flue box through the opening of the inspection door (4).

If more thorough cleaning is required, remove the outer panels, unscrew the eight fixing bolts (5) and pull firmly on the flue gas box (6) to remove it from the boiler.

Check at regular intervals that the condensate drain (7) is not blocked.



If necessary, replace the seal (8).



On completion of cleaning, follow the above steps in the reverse order to refit all removed parts.

Use a tightening force of 8 Nm/6 ft-lbs on the retaining nuts.



## **5.4** External cleaning

Clean the outside of the boiler casing with a soft cloth dampened with soapy water.

To remove stubborn marks, use a cloth dampened in a 50% mix of water and denatured alcohol or a suitable cleaning product. Dry the boiler after cleaning it.



🕒 Do not use abrasive products, petrol or triethylene.

#### **5.5** Checking and correcting the water pressure

The heating system must contain sufficient water to safeguard its correct function.

 If the water pressure in the heating system is too low, top up with water.

#### When should you check the water pressure in the heating system?

The fill and top-up water quality must comply with the water requirements in this manual.

Air pockets may form in the heating system from gases released by the fill and/or top-up water.

- Vent the heating system (e.g. bleeding the radiators).
- If required, top up with water

Recently added fill or top-up water loses much of its volume in the first few days because it releases gases. With new systems you should therefore initially check the heating water pressure on a daily basis, and thereafter at gradually longer intervals.

Once the volume of the heating system has stabilized, check the heating water pressure monthly.

A distinction is generally made between open vented and sealed unvented systems. In practice, open vented systems are hardly installed nowadays. We will therefore be using a sealed unvented heating system to demonstrate how you can check the water pressure. All settings will have already been made by the installation engineer when the system was first commissioned.

#### Sealed unvented systems

NOTICE: System damage through frequent topping up. Subject to the water quality, your heating system can be damaged through corrosion or scaling.

- Ensure that the heating system is vented correctly.
- Check the heating system for leaks and the expansion vessel for functionality.
- Observe the requirements regarding water quality.
- If water loss occurs frequently, locate the cause and rectify the problem without delay.

# NOTICE: System damage through temperature stresses.

- Only fill the heating system when cold (the system flow temperature must not exceed 104 °F (40 °C)).
- During operation, only fill the heating system via the fill valve in the heating system pipework (return).

For sealed unvented systems, the pressure gauge needle should be near the mid point of the gauge. The red needle of the pressure gauge must be set to the pressure required for the heating system.

- Check the heating system water pressure.
- Top up with water via the filling valve in the heating system pipework.
- Vent the heating system.
- Check the water pressure once more.

#### **5.5.1** Inspection and maintenance reports

The inspection and maintenance reports provide an overview of the required inspection and service steps that should be carried out annually.

Warranty:

- Annual inspection and service are part of the warranty terms.

Complete these reports after inspections and service. The report can also be used as copying template:

- Sign and date the completed inspection work.

INSPECTION WORK	REFERENCES	NOTES
Check the general condition of the heating system (visual inspection).		
Check the heating system function.		
Check the components in contact with fuel and water throughout the system for the following: -Tightness -Visible signs of corrosion -Signs of aging		
Check the combustion chamber and heating sur- face for contamination and clean them. For this, shut down the heating system.	See spec. chapter of this manual	
Check gaskets/packing cords on combustion cham- ber door and replace if required.		
Check and clean the burner: -Visual inspection and remove any contamination. -Check all safety equipment (safety shutdown). -Function check -Flue gas analysis with test report for each output stage.	See technical burner documentation.	
Check the flue for function and safety.	See flue manufacturer documentation.	
Check the hydraulic seal of the condensate siphon and replace if required.		
Check the water pressure and pre-charge pressure of the expansion vessel.	See spec. chapter of this manual	
Confirm the control unit settings are suitable and adjust if required.	See technical control unit	
Test all safety equipment (safety shutdown) and record findings. For example: -High limit safety cut-out -Minimum limiter pressure -Maximum limiter pressure (if installed) -Other safety equipment.		
Conduct a water analysis and record the results in the operator's log: -pH value -Residual hardness -Oxygen binder -Phosphate -Electrical conductivity -Appearance -Check water records (e.g. amount of make-up water) in the operator's log.		
Check the neutralization system.		
Final check of the inspection work, take measure- ments and record values and test results.		

# 5.6 Troubleshooting

PROBLEM	CAUSE TROUBLESHOOTING	TROUBLESHOOTING	
The boiler does not reach its set tempera- ture.	Heat exchanger dirty.	– Clean the flue gas pipes.	
	Heat exchanger and burner mismatched.	<ul> <li>Check specifications and settings.</li> </ul>	
	Insufficient burner gas flow.	– Check and adjust the burner.	
	Countreal the average text in we have	<ul> <li>Check the functioning of the aquastat.</li> </ul>	
	control thermostat problem.	<ul> <li>Check the temperature setting.</li> </ul>	
The boiler keeps shutting down, and the control panel warning light comes on.		<ul> <li>Check the functioning of the aquastat.</li> </ul>	
	Control thermestat problem	<ul> <li>Check the temperature setting.</li> </ul>	
	control thermostat problem.	– Check the electrical wiring.	
		– Check the sensor bulbs.	
	No water supply.	– Check the circuit pressure.	
	Air in the circuit.	– Check the vent valve.	
The boiler has reached the set tempera- ture but the radiators are still cold.	Air in the circuit.	– Bleed the circuit.	
	Pump malfunctioning.	– Check/release the pump.	
	Problem with minimum temperature aquastat (if present).	<ul> <li>Check the temperature setting.</li> </ul>	
		– Check that the boiler body is clean.	
There is a smell of exhaust fumes.	Fumes are escaping into the air.	– Check that the flue pipes are clean.	
		<ul> <li>Check that the boiler, flue pipes and flue gas exhaust stack are all properly sealed.</li> </ul>	
		- Check the circuit pressure.	
	Excessive pressure in the circuit.	<ul> <li>Check the functioning of the pressure reducer.</li> </ul>	
The safety valve keeps opening.		<ul> <li>Check the settings of the pressure reduc- er.</li> </ul>	
	Problem with heating system expansion vessel.	<ul> <li>Check the efficiency of the expansion vessel.</li> </ul>	
There are traces of condensate on the rear head.	Flue gas box seals.	<ul> <li>Check the seals between the rear head and the flue gas box.</li> </ul>	

#### 6 ENVIRONMENTAL PROTECTION/DISPOSAL

Environmental protection is one of the fundamental company policies of the Riello. We regard quality of performance, economy and environmental protection as equal objectives.

Environmental protection laws and regulations are strictly adhered to.

To protect the environment, we use the best possible technology and materials taking into account economic points of view.

#### Packaging

For the packaging, we participate in the country–specific recycling systems, which guarantee optimal recycling. All packaging materials used are environmentally–friendly and recyclable.

#### **Old appliances**

Old appliances contain resources that should be recycled. The components are easy to separate and the plastics are marked. This allows the various components to be sorted for appropriate recycling or disposal.



RIELLO S.p.A. Via Ing. Pilade Riello, 7 37045 – Legnago (VR) – Italy www.rielloboilers.com

North America: 35 Pond Park Road Hingham, Massachusetts U.S.A. 02043

2165 Meadowpine Blvd. Mississauga, ON L5N6H6 CANADA

www.rielloboilers.com

The manufacturer strives to continuously improve all products: appearance, dimensions, technical specifications, standard equipment and accessories are subject to change without notice.