

GB Dual fuel light oil/ gas burners

Two stage progressive or modulating operation



CODE	MODEL	TYPE
20163249	GI/EMME 1400	680T1
20163312	GI/EMME 2000	681T1
20163313	GI/EMME 2000	681T1
20163264	GI/EMME 2000	681T1
20160903	GI/EMME 3000	682T1
20162382	GI/EMME 3000	682T1
20162388	GI/EMME 3000	682T1
20162385	GI/EMME 3000	682T1
20162391	GI/EMME 3000	682T1
20160912	GI/EMME 4500	683T1



Translation of the original instructions

1	Information and general warnings.....	3
1.1	Information about the instruction manual	3
1.2	Guarantee and responsibility.....	4
2	Safety and prevention.....	5
2.1	Introduction.....	5
2.2	Personnel training	5
3	Technical description of the burner	6
3.1	Burner designation	6
3.2	Models available.....	6
3.3	Burner categories - Countries of destination	7
3.4	Technical data	7
3.5	Electrical data.....	8
3.6	Maximum dimensions.....	8
3.7	Firing rates	9
3.8	Test boiler.....	9
3.9	Burner description	10
3.10	Electrical panel description.....	11
3.11	Burner equipment.....	11
3.12	Control box RFGO-A22.....	12
3.13	Servomotor SQM40	13
4	Installation	14
4.1	Notes on safety for the installation	14
4.2	Handling	14
4.3	Preliminary checks	14
4.4	Operating position	15
4.5	Preparing the boiler.....	15
4.6	Lifting points	16
4.7	Positioning the electrode	16
4.8	Air damper setting	16
4.9	Nozzle installation	17
4.10	Combustion head adjustment.....	18
4.11	Light oil supply.....	19
4.12	Hydraulic operation diagram	20
4.13	Pressure variator	20
4.14	Pump	21
4.15	Gas supply	22
4.16	Electrical connections.....	25
4.17	Calibration of the thermal relay	26
4.18	Motor rotation	26
5	Start-up, calibration and operation of the burner	27
5.1	Notes on safety for the first start-up	27
5.2	Adjustments prior to ignition (light oil)	27
5.3	Burner ignition (light oil).....	27
5.4	Adjustments prior to ignition (gas).....	28
5.5	Burner start-up (gas)	28
5.6	Burner ignition	28
5.7	Servomotor adjustment	29
5.8	Combustion air adjustment.....	30
5.9	Ignition output of the burner	31

5.10	Air / fuel adjustment	31
5.11	Pressure switch adjustment	33
5.12	Burner operation	35
5.13	Final checks (with burner operating)	36
6	Maintenance	37
6.1	Notes on safety for the maintenance	37
6.2	Maintenance programme	37
6.3	Opening the burner	40
6.4	Closing the burner.....	40
7	LED indicator and special function.....	41
7.1	Description of LED lamps	41
7.2	Check mode function	41
7.3	Flame control lock-out or emergency stop condition	41
7.4	LED lamps: burner operating status	42
8	Problems - Causes - Remedies signalled by LED indicators	43
A	Appendix - Accessories	48
B	Appendix - Electrical panel layout.....	49

1 Information and general warnings

1.1 Information about the instruction manual

1.1.1 Introduction

The instruction manual supplied with the burner:

- is an integral and essential part of the product and must not be separated from it; it must therefore be kept carefully for any necessary consultation and must accompany the burner even if it is transferred to another owner or user, or to another system. If the manual is lost or damaged, another copy must be requested from the Technical Assistance Centre of the area;
- is designed for use by qualified personnel;
- offers important indications and instructions relating to the installation safety, start-up, use and maintenance of the burner.

Symbols used in the manual

In some parts of the manual you will see triangular DANGER signs. Pay great attention to these, as they indicate a situation of potential danger.

1.1.2 General dangers

The **dangers** can be of **3 levels**, as indicated below.



Maximum danger level!
This symbol indicates operations which, if not carried out correctly, cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause damage to the machine and/or injury to people.

1.1.3 Other symbols



DANGER: LIVE COMPONENTS
This symbol indicates operations which, if not carried out correctly, lead to electric shocks with lethal consequences.



DANGER: FLAMMABLE MATERIAL
This symbol indicates the presence of flammable materials.



DANGER: BURNING
This symbol indicates the risks of burns due to high temperatures.



DANGER: CRUSHING OF LIMBS
This symbol indicates the presence of moving parts: danger of crushing of limbs.



WARNING: MOVING PARTS

This symbol indicates that you must keep limbs away from moving mechanical parts; danger of crushing.



DANGER: EXPLOSION

This symbol signals places where an explosive atmosphere may be present. An explosive atmosphere is defined as a mixture - under atmospheric conditions - of air and flammable substances in the form of gases, vapours, mist or dust in which, after ignition has occurred, combustion spreads to the entire unburned mixture.



PERSONAL PROTECTION EQUIPMENT

These symbols indicate the equipment that must be worn and kept by the operator for protection against threats against safety and/or health while at work.



OBLIGATION TO ASSEMBLE THE COVER AND ALL THE SAFETY AND PROTECTION DEVICES

This symbol signals the obligation to reassemble the cover and all the safety and protection devices of the burner after any maintenance, cleaning or checking operations.



ENVIRONMENTAL PROTECTION

This symbol gives indications for the use of the machine with respect for the environment.



IMPORTANT INFORMATION

This symbol indicates important information that you must bear in mind.

- This symbol indicates a list.

Abbreviations used

Ch.	Chapter
Fig.	Figure
Page	Page
Sec.	Section
Tab.	Table

1.1.4 Delivery of the system and the instruction manual

When the system is delivered, it is important that:

- the instruction manual is delivered to the user by the system manufacturer, with the recommendation to keep it in the room where the heat generator is to be installed.
- The instruction manual shows:
 - the serial number of the burner;

.....

- the address and telephone number of the nearest Assistance Centre;

.....

.....

.....

- The system supplier must carefully inform the user about:
 - the use of the system;
 - any further tests that may be required before activating the system;
 - maintenance, and the need to have the system checked at least once a year by a representative of the manufacturer or another specialised technician.
 To ensure a periodic check, the manufacturer recommends the drawing up of a Maintenance Contract.

1.2 Guarantee and responsibility

The manufacturer guarantees its new products from the date of installation, in accordance with the regulations in force and/or the sales contract. At the moment of the first start-up, check that the burner is integral and complete.



ATTENTION

Failure to observe the information given in this manual, operating negligence, incorrect installation and carrying out of non authorised modifications will result in the annulment by the manufacturer of the guarantee that it supplies with the burner.

In particular, the rights to the guarantee and the responsibility will no longer be valid, in the event of damage to things or injury to people, if such damage/injury was due to any of the following causes:

- incorrect installation, start-up, use and maintenance of the burner;
- improper, incorrect or unreasonable use of the burner;
- intervention of unqualified personnel;
- carrying out of unauthorised modifications on the equipment;
- use of the burner with safety devices that are faulty, incorrectly applied and/or not working;
- installation of untested supplementary components on the burner;
- powering of the burner with unsuitable fuels;
- faults in the fuel supply system;
- continuation of use of the burner when a fault has occurred;
- repairs and/or overhauls incorrectly carried out;
- modification of the combustion chamber with inserts that prevent the regular development of the structurally established flame;
- insufficient and inappropriate surveillance and care of those burner components most likely to be subject to wear and tear;
- use of non-original components, including spare parts, kits, accessories and optional;
- force majeure.

The manufacturer furthermore declines any and every responsibility for the failure to observe the contents of this manual.

2 Safety and prevention

2.1 Introduction

The burners have been designed and built in compliance with current regulations and directives, applying the known technical safety rules and envisaging all the potential danger situations.

It is necessary, however, to bear in mind that the imprudent and clumsy use of the equipment may lead to situations of death risk for the user or third parties, as well as the damaging of the burner or other items. Inattention, thoughtlessness and excessive confidence often cause accidents; the same applies to tiredness and sleepiness.

It is a good idea to remember the following:

- The burner must only be used as expressly described. Any other use should be considered improper and therefore dangerous.

Specifically:

it can be applied to boilers operating with water, steam, diathermic oil, and to other uses expressly named by the manufacturer;

the type and pressure of the fuel, the voltage and frequency of the electrical power supply, the minimum and maximum deliveries for which the burner has been regulated, the pressurisation of the combustion chamber, the dimensions of the combustion chamber and the ambient temperature must all be within the values indicated in the instruction manual.

- Modification of the burner to alter its performance and destinations is not allowed.
- The burner must be used in exemplary technical safety conditions. Any disturbances that could compromise safety must be quickly eliminated.
- Opening or tampering with the burner components is not allowed, apart from the parts requiring maintenance.
- Only those parts envisaged by the manufacturer can be replaced.



The manufacturer guarantees safety and proper operation only if all burner components are intact and correctly positioned.

2.2 Personnel training

The user is the person, body or company that has acquired the machine and intends to use it for the specific purpose. He is responsible for the machine and for the training of the people working around it.

The user:

- undertakes to entrust the machine exclusively to suitably trained and qualified personnel;
- undertakes to inform his personnel in a suitable way about the application and observance of the safety instructions. With that aim, he undertakes to ensure that everyone knows the use and safety instructions for his own duties;
- Personnel must observe all the danger and caution indications shown on the machine.
- Personnel must not carry out, on their own initiative, operations or interventions that are not within their province.
- Personnel must inform their superiors of every problem or dangerous situation that may arise.
- The assembly of parts of other makes, or any modifications, can alter the characteristics of the machine and hence compromise operating safety. The manufacturer therefore declines any and every responsibility for any damage that may be caused by the use of non-original parts.


In addition:



- must take all the measures necessary to prevent unauthorised people gaining access to the machine;
- the user must inform the manufacturer if faults or malfunctioning of the accident prevention systems are noticed, along with any presumed danger situation;
- personnel must always use the personal protective equipment envisaged by legislation and follow the indications given in this manual.

3 Technical description of the burner

3.1 Burner designation



3.2 Models available

Designation			Voltage	Start-up	Code
GI/EMME 1400	TC	FS1	3 ~ 230/400/50	Direct	20163249
GI/EMME 2000	TC	FS1	3 ~ 230/400/50	Direct	20163312
GI/EMME 2000	TL	FS1	3 ~ 230/400/50	Direct	20163313
GI/EMME 2000	TC	FS1	3N ~ 400/50	Star/Triangle	20163264
GI/EMME 3000	TC	FS1	3 ~ 400/50	Direct	20160903
GI/EMME 3000	TL	FS1	3 ~ 400/50	Direct	20162382
GI/EMME 3000	TC	FS1	3N ~ 400/50	Star/Triangle	20162388
GI/EMME 3000	TL	FS1	3 ~ 230/50	Direct	20162385
GI/EMME 3000	TC	FS1	3 ~ 230/50	Direct	20162391
GI/EMME 4500	TC	FS1	3N ~ 400/50	Star/Triangle	20160912

Tab. A

3.3 Burner categories - Countries of destination

Country of destination	Gas category
SE - FI - AT - GR - DK - ES - GB - IT - IE - PT - IS - CH - NO	I _{2H}
DE	I _{2ELL}
NL	I _{2L} - I _{2E} - I ₂ (43.46 ÷ 45.3 MJ/m ³ (0°C))
FR	I _{2Er}
BE	I _{2E(R)B}
LU - PL	I _{2E}

Tab. B

3.4 Technical data

Model			GI/EMME 1400	GI/EMME 2000	GI/EMME 3000	GI/EMME 4500
Type			680 T1	681 T1	682 T1	683 T1
Minimum	Modulation Output	Kcal/h	350,000	500,000	750,000	1,000,000
		kW	407	581	872	1,163
	Minimum operating output	Kcal/h	705,000	1,000,000	1,500,000	2,021,000
		kW	820	1,163	1,744	2,350
	Maximum operating output	Kcal/h	1,325,000	2,000,000	3,000,000	4,000,000
		kW	1,540	2,325	3,488	4,650
Fuel			Methane gas: 8 - 10 kWh/Nm ³ Light oil: max. viscosity at 20 °C 6 cSt (1.5°E)			
Maximum gas pressure		mbar	200	360	360	360
Minimum gas pressure (1)		mbar	20	26	33	43
Operation			- Intermittent (min. 1 stop in 24 hours) - Progressive two-stage or modulating by kit (see accessories)			
Pump:		type	TA2C	TA3C	TA4C	TA5C
- Output at 400 bar		kg/h	350	540	730	1000
- Pressure range		bar	7 - 40	7 - 40	7 - 40	7 - 30
Standard applications			Boilers: water, steam, diathermic oil			
Ambient temperature		°C	0 - 50			
Combustion air temperature		°C max	60			
Noise levels (2)	Sound pressure	dB(A)	75	78	82	84
	Sound power		85	88	92	94
Weight		Kg	190	235	280	285
CE			CE-0085AQ0712			

Tab. C

- (1) Reference conditions: Ambient temperature 20°C - Gas temperature 15°C - Barometric pressure 1013 mbar - Altitude 0 m a.s.l.
 (2) Sound pressure measured in manufacturer's combustion laboratory, with burner operating on test boiler and at maximum output. The sound power is measured using the "Free Field" method, required by EN 15036 standard, and according to an "Accuracy: Category 3" measurement, as described in EN ISO 3746.

3.5 Electrical data

Model		GI/EMME 1400	GI/EMME 2000	GI/EMME 2000	GI/EMME 3000	GI/EMME 3000	GI/EMME 4500
Code		20163249	20163312 20163313	20163264	20160903 20162382 20162391 20162385	20162388	20160912
Electrical power supply		3/3N ~ 230/400V +/-10% 50 Hz					
Fan motor IE3	rpm	2900	2900	2900	2930	2930	2915
	kW	3	4	4	9.2	9.2	15
	V	230/400	230/400	400/690	230/400	400/690	400/690
	A	9.7/5.6	13.3/7.7	8/4.6	28.6/16.5	16.5/9.6	26.8/15.5
Pump motor IE3	rpm	2840			2890		
	kW	1.1			1.5		
	V	220/380			220-240/380-415		
	A	4.5/2.6			5.9/3.4		
Ignition transformer	V1 - V2 I1 - I2	230 V - 2 x 6 kV 2.3 A - 35 mA					
Absorbed electric power (Light oil)	kW max	5.2	6.2	6.2	12.6	12.6	18.8
Absorbed electric power (Gas)	kW max	3.9	4.8	4.8	10.6	10.6	16.9
Protection level		IP40					

Tab. D

3.6 Maximum dimensions

The dimensions of the burner are given in Fig. 1.

Bear in mind that inspection of the combustion head requires the burner to be opened and the rear part drawn back (see "Lifting points" on page 16).

L2 Short head blast tube length + spacer

L2* Short head blast tube length

L2** Long head blast tube length




Fig. 1

MODEL	A1	A2	L1	L2	L2*	L2**	H1	H2
GI/EMME 1400	482	376	1090	275	385	495	250	467
GI/EMME 2000	482	396	1090	275	385	495	260	467
GI/EMME 3000	538	447	1320	346	476	606	336	525
GI/EMME 4500	538	508	1320	346	476	606	336	525

Tab. E

3.7 Firing rates


The **MAXIMUM OUTPUT** is chosen from within the continuous diagram area (Fig. 2).

The **MINIMUM OUTPUT** must not be lower than the minimum limit of the diagram:

- GI/EMME 1400 = 407 kW
- GI/EMME 2000 = 581 kW
- GI/EMME 3000 = 872 kW
- GI/EMME 4500 = 1163 kW



The firing rate value (Fig. 2) has been obtained considering an ambient temperature of 20 °C, an atmospheric pressure of 1013 mbar (approx. 0 m a.s.l.), and with the combustion head adjusted as shown on page 18.



S9714

Fig. 2

3.8 Test boiler

The burner/boiler combination does not pose any problems if the boiler is EC approved and its combustion chamber dimensions are similar to those indicated in the diagram (Fig. 3).

If the burner must be combined with a boiler that has not been EC approved and/or its combustion chamber dimensions are clearly smaller than those indicated in the diagram, consult the manufacturer.

The firing rates were obtained in special test boilers, according to EN 676 standard.


In Fig. 3 you can see the diameter and length of the test combustion chamber.

Example:

Output 7000 kW - diameter 120 cm - length 6 m

MODULATING RATIO

The modulating ratio, obtained in test boilers, according to standard (EN 676 for gas, EN 267 for light oil), is of 4:1 for light oil and 7:1 for gas.



D2448

Fig. 3

3.9 Burner description




Fig. 4

- 1 Output modulator (for modulating version only)
- 2 Air pressure switch
- 3 Gas butterfly valve control rod
- 4 Control box reset button with lockout signal
- 5 Head drive rod
- 6 Servomotor
- 7 Air adjustment cam
- 8 Maximum gas pressure switch
- 9 Pipe coupling gas pressure test point
- 10 Gas regulator
- 11 Pressure adjustment eccentric on return line
- 12 Maximum oil pressure switch
- 13 Return pressure gauge
- 14 Delivery pressure gauge
- 15 Pumping unit
- 16 Adjustment cam
- 17 Pressure adjuster
- 18 Intake line connection
- 19 Return line connection
- 20 Delivery line connection
- 21 Vacuometer connection
- 22 Pressure gauge connection
- 23 Minimum oil pressure switch
- 24 Fan motor




Fig. 5



- The motor relay release for versions with starter is inside the same.
- Pump motor relay release is inside the box next to the pumping unit.

3.10 Electrical panel description

20161912




Fig. 6

- 1 Fan motor overload and contactor (GI/EMME 1400-2000-3000)
- 2 Terminal board
- 3 Cable grommets for electrical wiring (to be carried out by the installer)
- 4 Plug-socket on servomotor cable
- 5 Flame sensor
- 6 Control box base
- 7 Ignition transformer
- 8 Oil valve coils
- 9 Filter to protect against radio disturbance
- 10 Pump motor contactor and thermal relay
- 11 Selector switch OIL-0-GAS

3.11 Burner equipment

Flange (for GI/EMME 1400)	No. 1
Seal for gas train	No. 1
Screws (for GI/EMME 1400).	No. 8
Screws	No. 12
Extensions	No. 2
Insulating flange gasket	No.1
Flexible hoses	No. 2
Nipples	No. 2
Cable grommets	No.4
Washers	No. 8
Instruction.	No. 1
Spare parts list	No. 1

3.12 Control box RFGO-A22

Important notes



ATTENTION

To avoid accidents, material or environmental damage, observe the following instructions!

The control box is a safety device! Avoid opening or modifying it, or forcing its operation. The Manufacturer cannot assume any responsibility for damage resulting from unauthorised work!

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Before modifying the wiring in the control box connection area, fully disconnect the system from the power supply (omnipolar separation).
- Protection against electrocution from the control box and all connected electric components is obtained with the correct assembly.
- Before any intervention (assembly and installation operations, assistance, etc.), ensure the wiring is in order and that the parameters are correctly set, then make the safety checks.
- Falls and collisions can negatively affect the safety functions. In this case, the control box must not be operated, even if it displays no evident damage.

For safety and reliability, comply with the following instructions:

- avoid conditions that can favour the development of condensate and humidity. Otherwise, before switching on again, make sure that the entire control box is perfectly dry!
- Static charges must be avoided since they can damage the control box's electronic components when touched.

Use

The control box is a control and supervision system of medium and large capacity forced draught burners.

If used with the flame detection electrode the system can operate continuously whereas, with the use of UV sensors it operates intermittently with stop and restart request at least once every 24h.

Installation notes

- Make sure that the electrical wiring inside the boiler complies with national and local safety regulations.
- Do not confuse the powered conductors with the neutral ones.
- Ensure that spliced wires cannot get into contact with neighbouring terminals. Use adequate ferrules.
- Arrange the H.V. ignition cables separately, as far as possible from the control box and the other cables.
- When wiring the unit, make sure that AC 230 V mains voltage cables are run strictly separate from extra low-voltage cables to avoid risks of electrical shock hazard.



Fig. 7

Technical data

Mains voltage	AC 230 V -15 % / +10%
Mains frequency	50 / 60 Hz
Primary fuse (external)	Refer to the electric system
Weight	approx. 1.1 kg
Power absorption	approx. AC 7 VA
Protection level	IP40
Safety class	II
Environmental conditions	
Operation	DIN EN 60721-3-1
Climatic conditions	Class 1K2
Mechanical conditions	Class 1M2
Temperature range	-40...+60°C
Humidity	< 90% RH (non-condensing)

Tab. F

Electrical wiring of the flame detector

It is important for signal transmission to be almost totally free of any disturbances or loss:

- Always separate the detector cables from the other cables:
 - The capacitive reactance of the line reduces the size of the flame signal.
 - Use a separate cable.
- Respect the allowed cable lengths.
- The ionisation probe is not protected against the risk of electrocution. When connected to the electricity supply, the ionisation probe must be protected against any accidental contact.
- Position the ignition electrode and the ionisation probe so that the ignition spark cannot form an arc on the probe (risk of electric overcharge).

3.13 Servomotor SQM40 ...

Important notes



To avoid accidents, material or environmental damage, observe the following instructions!

Avoid opening, modifying or forcing the servomotor.

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Falls and collisions can negatively affect the safety functions. In this case, the servomotor must not be operated, even if it displays no evident damage.
- Fully disconnect the burner from the mains when working near terminals and servomotor connections.
- Condensation and exposure to water are not allowed.
- For safety reasons, the servomotor must be checked after long periods of non-use.



Fig. 8

S8907

Technical data

Mains voltage	230 V -15% +10%
Mains frequency	50 / 60 Hz
Power absorption	10 VA
Motor	Synchronous
Drive angle	Varying between 0° and 135°
Protection level	Max. IP 66, with appropriate cable entry
Cable entry	2 x M20
Cable connection	terminal board for 0.5mm ² (min.) and 2.5mm ² (max.)
Rotation direction	Anticlockwise
Rated torque (max.)	10 Nm
Holding torque	5 Nm
Operation time	30 s. at 90°
Weight	approx. 2 kg
Environmental conditions:	
Operation	-20...+60° C
Transport and storage	-20...+60°C

4 Installation

4.1 Notes on safety for the installation

After carefully cleaning all around the area where the burner is to be installed, and arranging for the environment to be illuminated correctly, proceed with the installation operations.



All the installation, maintenance and disassembly operations must be carried out with the electricity supply disconnected.



The installation of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



The combustion air inside the boiler must be free from hazardous mixes (e.g.: chloride, fluoride, halogen); if present, it is highly recommended to carry out cleaning and maintenance more frequently.

4.2 Handling

The burner packaging includes a wooden platform, it is therefore possible to handle the burner (still packaged) with a pallet truck or fork lift truck.



Burner handling operations can be highly dangerous if not carried out with the greatest attention: distance unauthorised personnel, check integrity and suitability of the means available. Check also that the area in which you are working is empty and that there is an adequate escape area (i.e. a free, safe area to which you can quickly move if the burner should fall). During handling, keep the load at no more than 20-25 cm from the ground.



After positioning the burner near the installation point, correctly dispose of all residual packaging, separating the various types of material.



Before proceeding with the installation operations, carefully clean all around the area where the burner will be installed.

4.3 Preliminary checks

Checking the consignment



After removing all the packaging, check the integrity of the contents. In the event of doubt, do not use the burner; contact the supplier.



The packaging elements (wooden cage or cardboard box, nails, clips, plastic bags, etc.) must not be abandoned as they are potential sources of danger and pollution; they should be collected and disposed of in the appropriate places.

Checking the characteristics of the burner

- Check the identification label of the burner, showing:
- the model (A)(Fig. 9) and type of burner (B);
 - the year of manufacture, in cryptographic form (C);
 - the serial number (D);
 - the data for electrical supply and the protection level (E);
 - the absorbed electrical power (F);
 - the types of gas used and the relative supply pressures (G);
 - the data of the burner's minimum and maximum output possibilities (H) (see Firing rate).
- Warning.** The burner output must be within the firing rate of the boiler;
- the category of the appliance/countries of destination (I).
 - light oil maximum viscosity (L).

RBL	A		B		C
D	E			F	
GAS-KASU <input checked="" type="checkbox"/>	G		H		
GAZ-AERO	G		H		
I					
HEZOL-FUEL	L				
RIELLO SpA I-37045 Legnago (VR)			CE 0085		

D9243

Fig. 9



A burner label that has been tampered with, removed or is missing, along with anything else that prevents the definite identification of the burner makes any installation or maintenance work difficult.

4.4 Operating position



- The burner is designed to operate only in positions **1**, **2**, **3** and **4** (Fig. 10).
- Installation **1** is preferable, as it is the only one that allows the maintenance operations as described in this manual.
- Installations **2**, **3** and **4** allow operation but make maintenance and inspection of the combustion head more difficult.



- Any other position could compromise the correct operation of the appliance.
- The installation **5** is prohibited for safety reasons.




Fig. 10

4.5 Preparing the boiler

4.5.1 Boring the boiler plate

Pierce the closing plate of the combustion chamber, as in Fig. 11. The position of the threaded holes can be marked using the thermal insulation screen supplied with the burner.




Fig. 11

mm	A	B	C
GI/EMME 1400	255	260	M 16
GI/EMME 2000	265	260	M 16
GI/EMME 3000	340	310	M 20
GI/EMME 4500	340	310	M 20

Tab. G

4.5.2 Blast tube length

The length of the blast tube must be selected according to the indications provided by the manufacturer of the boiler, and in any case it must be greater than the thickness of the boiler door complete with its fettling.

Model	Code	mm
GI/EMME 1400	20163249	385
	20163312	385
	20163313	495
GI/EMME 2000	20163264	385
	20160903	476
	20162382	606
	20162388	476
	20162385	606
GI/EMME 3000	20162391	476
	20160912	476
	GI/EMME 4500	476

Tab. H

4.6 Lifting points




Provide an adequate lifting system (Fig. 12).
Lift the burner by means of the hooks to fix it to the boiler without separating it from the combustion head.

Fig. 12 shows how to apply the burner to a boiler with a headpiece that is not cooled.

The refractory wall must not extend beyond the end of the combustion head of the burner.

mm	MIN	MAX
GI/EMME 1400	200	300
GI/EMME 2000	200	300
GI/EMME 3000	300	400
GI/EMME 4500	300	400

Tab. I



20167876

Fig. 12



ATTENTION

Before fitting the burner on the boiler it is advised to fit the nozzle as specified later.



Be careful as some drops of fuel may leak out during this phase.



ATTENTION

The seal between burner and boiler must be airtight.

4.7 Positioning the electrode



ATTENTION

Position the electrode according to the dimensions shown in Fig. 13.




Fig. 13

4.8 Air damper setting

The setting of the air damper is carried out by acting on the variable profile cam. This operation must be performed after regulating the pressure variator and the combustion head.

With burner on, disconnect the servomotor from the power supply by disconnecting the fast-on pin on the electric control shelf, and release the movement by pressing the release button that allows the manual rotation of the cam.

Calibrate in sequence the maximum output, the minimum output and the intermediate outputs.

At the end of the operation, check all calibrations, restore the electrical connections of the servomotor and lock the adjustment screws by means of the transversal ones.

4.8.1 Variation of the air damper tie-rod length

Lengthening the tie-rod is recommended when the air damper moves within a reduced angle (air damper approx. halfway its stroke at the maximum output); it is used to avoid a too curved cam profile.

With the burner off, proceed as follows:

- disengage the articulated coupling 2)(Fig. 14) of the lever 1);
- loosen the extension 3) from the tie-rod 4) by a few turns;
- reconnect the articulated coupling to the lever and lift the profile of the cam until setting the index of the air damper to 0 with servomotor at 0°.




Fig. 14

Key

- 1 Lever
- 2 Articulated coupling
- 3 Extension
- 4 Tie-rod

4.9 Nozzle installation

The burner complies with the emission requirements of the EN 267 standard. In order to guarantee that emissions do not vary, recommended and/or alternative nozzles specified by Riello in the Instruction and warning booklet should be used.



It is advisable to replace the nozzle once a year during periodical maintenance.



The use of nozzles other than those specified by Riello S.p.A. and inadequate regular maintenance may result into emission limits non-conforming to the values set forth by the regulations in force, and in extremely serious cases, into potential hazards to people and objects.

The manufacturing Company shall not be liable for any such damage arising from non-observance of the requirements contained in this manual.



- Do not use any sealing products such as: gaskets, tape or sealants.
- Be careful to avoid damaging the nozzle sealing seat.
- The nozzle must be screwed into place tightly but not to the maximum torque value provided by the wrench.

4.9.1 Recommended nozzle

Select the nozzle, with nominal output slightly higher than the one actually required, among the following types:

Model	Nozzle
Fluidics	type N1 (without interception rod)
Fluidics	type W2 (with interception rod)
Bergonzo	type B3 or B5 (with interception rod)

It is possible to fit also nozzles without interception rod: in this case there will be no anti-dripping feature on the spray holder.

Available nozzles (delivery kg/h):

- **Fluidics:** 70 - 80 - 90 - 100 - 115 - 130 - 145 - 160 - 180 - 200 - 225 - 250 - 275 - 300 - 330 - 360 - 400 - 450
- **Bergonzo:** 70 - 80 - 90 - 100 - 125 - 150 - 175 - 200 - 225 - 250 - 275 - 300 - 325 - 350 - 375 - 400 - 425 - 450

Angles of 45-50° are usually recommended; for narrow combustion chambers use nozzles with 30-35° angles.

To calibrate the delivery range of the nozzle, adjust the fuel maximum and minimum pressure on the nozzle return line, as shown in Fig. 15.

Approximate ration between: Nozzle type and delivery in (%) - Pressure on the return line




Fig. 15

4.10 Combustion head adjustment

The combustion head moves together with the eccentric 8), the variable profile cams and the gas butterfly valve. The head positioning can be seen on cylinder 2) (Fig. 16).

The control levers of the head are calibrated to the maximum stroke at the factory.

To obtain a different modulation range, calibrate these levers again so that the stroke of the head is as in the diagram (Fig. 17).



For ignition difficulty proceed as follows:

- Adjust the fuel pressure on the return line between 5 ÷ 8 bar and regulate the air for a correct combustion.
- If difficulties persist, set the combustion head to the minimum on notch 2 ÷ 3, keeping the adjustment of the maximum delivery as in the diagram (Fig. 17).

Example:

With GI/EMME 4500 burner, for a modulation from 1,400,000 to 3,400,000 kcal/h, it is possible to detect from the diagram: notch 1 for 1,400,000 kcal/h, notch 6.5 for 3,400,000 kcal/h, with a stroke equal to 5,5 notches.

NOTE:

To prevent any sticking, do not exceed the maximum and minimum opening positions corresponding on cylinder 2)(Fig. 16) to notch 9 with servomotor at 130° and notch 0 with servomotor at 0°, respectively.

To change the stroke of the combustion head proceed as follows:

- control connecting rod 1) of driving rod 8) of combustion head is provided with a slot; by pulling the tie-rod 9) towards the outside of the slot the stroke of the head shortens by approx. 20 mm (approx. 4 notches).

If a more consistent reduction is needed, act as follows:

- with servomotor at 0°, loosen the screws 5) and push, in the arrow direction, the ring 6) placed under the variable profile cam. This allows obtaining a reduction of the eccentricity with a consequent reduction of the stroke.

Once the desired stroke has been found, firmly lock the screws 5).

In the previous example (stroke 5.5 notches) the start and end of the stroke must coincide with values 1 and 6.5.

To obtain this, rotate the hexagonal sleeve 3), in one direction or the other, after loosening the nuts 4).

With servomotor set to 0° notch 1 must match with the reference plane 10), while with servomotor set to 130° it must match with notch 6.5.

Once adjustment operations are completed, firmly lock the nuts 4) with the ball joint 9) positioned as in Fig. 16.

Head calibrations are performed with burner closed, not operating and with released servomotor.

At the end of the adjustment, by allowing the cam 7) to perform a few travels, check that between 0° and 130° there is no sticking.

D1388





Fig. 16



D1387

Fig. 17

4.11 Light oil supply



Explosion danger due to fuel leaks in the presence of a flammable source.

Precautions: avoid knocking, attrition, sparks and heat.

Make sure the fuel shut-off valve is closed before performing any operation on the burner.



ATTENTION

The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.

4.11.1 Hydraulic system



CAUTION

➤ Make sure that the hoses to the pump supply and return line are installed correctly.



ATTENTION

Follow the instructions below:

- Tighten the flexible hoses with the supplied gaskets.
- During the installation, hoses must not be stressed with twisting.
- Position hoses so that they cannot be stepped on or get into contact with hot parts of the boiler and so that they allow burner opening.
- Finally, connect the other end of the flexible hoses to the suction and return line ducts.



ATTENTION

Before starting the burner make sure that the return pipe line is not clogged. Any obstruction would cause the pump seals to break.

The pump vacuum should not exceed a maximum of 0.45 bar (35 cm Hg). Beyond this limit, gas is released from the fuel.

Oil pipes must be completely airtight.

G/M	1400				2000				3000		4500	
	H m	Øi 14	Øi 16	Øi 16	Øi 18	L m Øi G 1/2"	Øi G 3/4"	Øi G 3/4"	Øi G 3/4"	Øi G 1"		
+ 2.0	55	70	40	60	25	85	55	130				
+ 1.5	45	65	35	55	23	80	50	120				
+ 1.0	40	60	30	50	20	70	45	110				
+ 0.5	35	50	25	45	18	65	40	100				
0	30	45	20	40	15	60	35	90				
- 0.5	25	40	18	35	12	50	30	80				
- 1.0	20	35	15	30	10	45	25	70				
- 1.5	15	30	13	25	8	35	20	60				
- 2.0	10	25	10	20	5	30	15	45				
- 3.0	5	15	5	10	3	15	10	25				

Tab. J

When the tank is at a level lower than the burner, the return line should terminate at the same level as the suction line.

In this case a non-return valve is not required.

Should however the return line arrive over the fuel level, a non-return valve is required. This solution however is less safe than previous one, due to the possibility of leakage of the valve.




Fig. 18

Key (Fig. 18)

H = Difference of level

L = Total line length

Øi = Inside pipe diameter. The copper pipes with internal diameter of 14 and 16 mm, can be replaced with G 1/2" and G 3/4" steel pipes.

4.12 Hydraulic operation diagram

4.12.1 Oil pressure switch

It triggers the lockout condition of the burner in case of too much counter-pressure on the fuel return line.

Recommended calibration (recommended values with return line resistance in tank of ≤ 0.5 bar):

- GI/EMME 1400:** 1.5 ÷ 2.0 bar
- GI/EMME 2000:** 2.0 ÷ 2.5 bar
- GI/EMME 3000:** 3.0 ÷ 3.5 bar
- GI/EMME 4500:** 4.0 ÷ 4.5 bar

In case of control box lockout (in position "P") calibrate the pressure switch again with incremental values of 0.5 bar.

Motor lockout

It is caused by the motor overload protection in case of overload or no phase.

D1396




Fig. 19

Key (Fig. 19)

- Cn** - Control cams
- FO** - Oil filter
- MM** - Delivery pressure gauge
- MR** - Return pressure gauge
- MV** - Fan motor
- P** - Pump with pressure adjuster
- PO** - Minimum oil pressure switch
- POM** - Maximum oil pressure switch
- RO** - Pressure adjuster on return line
- Vn** - Valves

4.13 Pressure variator

To calibrate the eccentric 8):

- remove the cover 9), loosen the screws 7), turn the screw 4) until the desired eccentricity is obtained;
- by turning screw 4) to the right (+) the eccentricity increases, thereby increasing the difference between the maximum and minimum capacity of the nozzle;
- by turning screw 4) to the left (-) the eccentricity decreases, thereby decreasing the difference between the maximum and minimum capacity of the nozzle.

At every eccentricity variation it may be necessary to offset the stroke by means of the nut and locknut 6).

Note

- For a correct calibration, the eccentric 8) must operate on the entire range of travel of the servomotor ($20^\circ \div 130^\circ$): a pressure variation must correspond to each servomotor variation.
- Never drive the variator piston fully home: the stop ring 5) determines the maximum stroke.
- At the end of the adjustment, manually check that between 20° and 130° there is no sticking and that the maximum and minimum pressures correspond to the one selected according the diagram (A).
- If at the maximum delivery of the nozzle (maximum pressure on the return line) pressure oscillations can be seen on the pressure gauge 3), slightly reduce the pressure until they disappear.

D3437




Fig. 20

Key

- 1** Pressure switch connection
- 2** Delivery pressure gauge
- 3** Return pressure gauge
- 4** Eccentric adjustment screw
- 5** Piston stop ring
- 6** Piston calibration nut and lock nut
- 7** Eccentric locking screws
- 8** Variable eccentric
- 9** Cover

4.14 Pump

4.14.1 Technical data

Pump		G/M 1400	G/M 2000	G/M 3000	G/M 4500
		TA2C	TA3C	TA4C	TA5C
Min. delivery rate at 40 bar pressure	kg/h	350	540	730	1000
Delivery pressure range	bar	7 - 40	7 - 40	7 - 40	7 - 40
Max. suction depression	cm Hg	30	30	30	30
Viscosity range	cSt	4 - 800	4 - 800	4 - 75	4 - 75
Maximum light oil temperature	°C	140	140	140	140
Max. suction and return pressure	bar	5	5	5	5
Pressure calibration in the factory	bar	25	25	25	25

Tab. K

4.14.2 Priming pump (example)



Before starting the burner, make sure that the tank return line is not clogged.

Obstructions in the line could cause the sealing organ located on the pump shaft to break.

- In order for self-priming to take place, the screw 4) on the pump (Fig. 21) must be loosened to bleed off the air contained in the suction line.
- Start the burner by closing the remote controls. As soon as the burner starts, check the direction of rotation of the fan blade.
- The pump can be considered to be primed when the light oil starts coming out of the screw 4).
- Close the burner and undo the screws 4).

The time required for this operation depends upon the diameter and length of the suction tubing.

If the pump fails to prime at first start-up and the burner locks out, wait approx. 15 seconds, reset the burner, and then repeat the start-up operation. And so on.

After 5 or 6 starting operations allow 2 or 3 minutes for the transformer to cool.

Do not light the photocell in order to prevent the burner lockout; the burner locks out in any case about ten seconds after its start.



The above-mentioned operation is possible because the pump is already full of fuel when it leaves the factory.

If the pump has been drained, fill it with fuel through the opening on the vacuumeter 3)(Fig. 21) prior to starting; otherwise, the pump will seize.

Whenever the length of the suction piping exceeds 20-30 meters, the supply line must be filled using a separate pump.




Fig. 21

Key (Fig. 21)

- 1 Suction line
- 2 Return line
- 3 Vacuumeter connection
- 4 Pressure gauge connection
- 5 Pressure adjuster

4.15 Gas supply



Explosion danger due to fuel leaks in the presence of a flammable source.

Precautions: avoid knocking, attrition, sparks and heat.

Make sure the fuel shut-off valve is closed before performing any operation on the burner.



ATTENTION

The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.

4.15.1 Gas feeding line

Key (Fig. 22 - Fig. 23 - Fig. 24 - Fig. 25)

- 1 Gas input pipe
- 2 Manual valve
- 3 Vibration damping joint
- 4 Pressure gauge with button cock
- 5 Filter
- 6A Includes:
 - filter
 - working valve
 - safety valve
 - pressure adjuster
- 6B Includes:
 - working valve
 - safety valve
 - pressure adjuster
- 6C Includes:
 - safety valve
 - working valve
- 6D Includes:
 - safety valve
 - working valve
- 7 Minimum gas pressure switch
- 8 Leak detection control, supplied as an accessory or built-in, based on the gas train code. In compliance with the EN 676 standard, gas valve leak detection control devices are compulsory for burners with maximum outputs over 1200 kW.
- 9 Gasket, for "flanged" versions only
- 10 Pressure adjuster
- 11 Train-burner adaptor, supplied separately
- P2 Pressure upstream of valves/adjuster
- P3 Pressure upstream of the filter
- L Gas train, supplied separately
- L1 Responsibility of the installer

MBC "threaded"




Fig. 22

MBC VGD "flanged"




Fig. 23

DMV "flanged or threaded"




Fig. 24

CB "flanged or threaded"




Fig. 25

4.15.2 Gas train

Type-approved in accordance with EN 676 and supplied separately from the burner.

4.15.3 Gas train installation



Disconnect the power supply using the system main switch.



Check that there are no gas leaks.



Pay attention when handling the train: danger of crushing of limbs.



Make sure that the gas train is properly installed by checking for any fuel leaks.



The operator must use the required equipment during installation.

The gas train is prearranged to be connected to the burner by the flange 1)(Fig. 26).




Fig. 26

4.15.4 Gas pressure

Tab. L indicates the pressure drops of the combustion head and gas butterfly valve depending on the burner operating output.

	kW	1 Δp (mbar)	
		G 20	G 25
G/M 1400	800	10	14.9
	889	11.1	16.5
	978	12.2	18.2
	1067	13.3	19.8
	1156	14.4	21.5
	1244	15.6	23.2
	1333	16.7	24.9
	1422	17.8	26.5
	1511	18.9	28.2
	1600	20	29.8
G/M 2000	1150	9.8	14.6
	1258	11.7	17.4
	1366	13.3	19.8
	1473	14.6	21.8
	1581	15.9	23.7
	1689	17.2	25.6
	1797	18.7	27.9
	1904	20.6	30.7
	2012	22.9	34.1
	2120	25.8	38.4
G/M 3000	1750	17	25.3
	1956	18.2	27.1
	2161	19.8	29.5
	2367	21.6	32.2
	2572	23.6	35.2
	2778	25.7	38.3
	2983	27.9	41.6
	3189	30	44.7
	3394	32.1	47.8
	3600	34	50.7
G/M 4500	2350	18	26.8
	2606	20.8	31
	2861	23.6	35.2
	3117	26.5	39.5
	3372	29.4	43.8
	3628	32.3	48.1
	3883	35.1	52.3
	4139	37.8	56.3
	4394	40.5	60.3
	4650	43	64.1

Tab. L



Data of head thermal power and gas pressure refer to operation with gas butterfly valve fully open (90°).

The values shown in Tab. L refer to:

- Natural gas G 20 NCV 9.45 kWh/Sm³ (8.2 Mcal/Sm³)
- Natural gas G 25 NCV 8.13 kWh/Sm³ (7.0 Mcal/Sm³)

Column 1

Combustion head pressure drop.

Gas pressure measured at test point 2)(Fig. 27), with:

- combustion chamber at 0 mbar;
- burner working at maximum modulating output;
- combustion head adjusted as in page 18.

Column 2

Pressure drop at gas butterfly valve 1)(Fig. 27) with maximum opening: 90°.

To calculate the approximate output at which the burner operates:

- subtract the combustion chamber pressure from the gas pressure measured at test point 2) (Fig. 27).
- Find in Tab. L related to the burner concerned, the pressure value closest to the result of the subtraction.
- Read the corresponding output on the left.

Example G/M 3000 with natural gas G20:

Operation at maximum modulating output

Gas pressure at test point 2)(Fig. 27)	=	32.9 mbar
Pressure in combustion chamber	=	5 mbar
$32.9 - 5$	=	27.9 mbar

A pressure of 27.9 mbar, column 1, corresponds in Tab. L to an output of 2983 kW.

This value serves as a rough guide; the effective output must be measured at the gas meter.

To calculate the required gas pressure at test point 2) (Fig. 27), set the maximum modulating output required from the burner operation:

- find the nearest output value in the table Tab. L for the burner in question.
- Read, on the right (column 1), the pressure at the test point 2)(Fig. 27).
- Add this value to the estimated pressure in combustion chamber.

Example G/M 3000 with natural gas G20:

Operation at maximum modulating output

Gas pressure at an output of 8000 kW	=	27.9 mbar
Pressure in combustion chamber	=	5 mbar
$27.9 + 5$	=	32.9 mbar

pressure required at test point 2)(Fig. 27).




Fig. 27

4.16 Electrical connections

Notes on safety for the electrical wiring



- The electrical wiring must be carried out with the electrical supply disconnected.
- Electrical wiring must be made in accordance with the regulations currently in force in the country of destination and by qualified personnel. Refer to the wiring diagrams.
- The manufacturer declines all responsibility for modifications or connections different from those shown in the wiring diagrams.
- Check that the electrical supply of the burner corresponds to that shown on the identification label and in this manual.
- The burners have been set for intermittent operation (FS1).
- The RFGO safety device features two built-in flame amplifiers which allow using it for applications with UV sensor only, FR sensor only or with both sensors (UV+FR). The FR amplifier circuit is subject to constant auto-control, which allows to use it for applications requiring a burner operating cycle longer than 24 hours. When it is used as a UV control, the system is considered as non-permanent, requiring one burner recycle every 24 hours. Normally, burner stopping is guaranteed by the boiler's thermostat/pressure switch. If this is not the case, a time switch must be applied to L-N in series, to stop the burner at least once every 24 hours. Refer to the wiring diagrams.
- The electrical safety of the device is obtained only when it is correctly connected to an efficient earthing system, made according to current standards. It is necessary to check this fundamental safety requirement. In the event of doubt, have the electrical system checked by qualified personnel. Do not use the gas tubes as an earthing system for electrical devices.
- The electrical system must be suitable for the maximum input power of the device, as indicated on the label and in the manual, checking in particular that the section of the cables is suitable for the input power of the device.
- For the main power supply of the device from the electricity mains:
 - do not use adapters, multiple sockets or extensions;
 - use an omnipolar switch, in compliance with the current safety standards.
- Do not touch the device with wet or damp body parts and/or in bare feet.
- Do not pull the electric cables.

Before carrying out any maintenance, cleaning or checking operations:



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.



Avoid condensate, ice and water leaks from forming.

If the cover is still present, remove it and proceed with the electrical wiring according to the wiring diagrams.

Use flexible cables according to EN 60 335-1 standard.

4.16.1 Supply cables and external connections passage

All the cables to be connected to the burner should be passed through cable grommets, as shown in Fig. 28.




Fig. 28

Key (Fig. 28)

- 1 Pg29 Three-phase power supply
- 2 Pg13.5 Single-phase power supply
- 3 Pg29 TR remote control, TL, gas valve and leak test



After carrying out maintenance, cleaning or checking operations, reassemble the cover and all the safety and protection devices of the burner.

4.17 Calibration of the thermal relay

The thermal relay (Fig. 29) serves to avoid damage to the motor due to an excessive absorption increase or if a phase is missing. For calibration 2), refer to the table indicated in the electrical layout (electrical wiring by the installer).

To reset, in case of thermal relay activation, press the "RESET" button 1).

The button "STOP" 3) opens the NC contact (95-96) and stops the motor.

Insert a screwdriver in the window "TEST/TRIP" 4) and move it in the arrow direction (to the right) to carry out the thermal relay test.




Fig. 29



ATTENTION

The automatic reset can be dangerous.

This operation is not foreseen in the burner operation.

4.18 Motor rotation

As soon as the burner starts, place yourself in front of the cooling fan of the fan motor and check that it turns anticlockwise (Fig. 30).

If this is not the case:

- put the switch of the burner to "0" (off) and wait until the control box carries out the switching off phase.



DANGER

Disconnect the electrical supply from the burner by means of the system main switch.

- Invert the phases on the three-phase motor power supply.




Fig. 30

5 Start-up, calibration and operation of the burner

5.1 Notes on safety for the first start-up



The first start-up of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



Check the correct working of the adjustment, command and safety devices.



Before starting up the burner, refer to section "Safety test - with no gas supply" on page 37

5.2 Adjustments prior to ignition (light oil)



It is recommended to adjust first the light oil burner and then the gas burner.

Carry out the fuel change with burner off.

The optimum calibration of the burner requires an analysis of the flue gases at the boiler outlet and interventions on the following points.

5.2.1 Nozzle

See information on page 17.

5.2.2 Combustion head

The adjustment of the combustion head already carried out on page 18 need not to be altered unless the 2nd stage output of the burner is changed.

5.2.3 Pump pressure

In order to change pump pressure, act on screw 17)(Fig. 4 on page 10). See information on page 21.

5.2.4 Fan damper

Refer to the adjustment of the servomotor on page 29.

5.3 Burner ignition (light oil)

Position the selector 11)(Fig. 5 on page 10) on "OIL".

When the limit thermostat (TL) is closed, the "CALL FOR HEAT" 3) request is sent.

At first ignition, there is a momentary drop in fuel pressure due to the filling of the nozzle piping. This lowering of the fuel pressure can cause the burner to lockout and can sometimes give rise to pulsations.

If the burner locks out again, refer to chapter "Problems - Causes - Remedies signalled by LED indicators" on page 43.

Once the following adjustments have been made, the ignition of the burner must generate a noise similar to the noise generated during operation.

5.4 Adjustments prior to ignition (gas)

In addition, the following adjustments must also be made:

- slowly open the manual valves situated upstream of the gas train.
- Adjust the minimum gas pressure switch (Fig. 37) to the start of the scale.
- Adjust the maximum gas pressure switch (Fig. 36) to the end of the scale.
- Adjust the air pressure switch (Fig. 35) to the start of the scale.
- Purge the air from the gas line.
We recommend using a plastic tube routed outside the building and to purge air until gas is smelt.
- Fit a U-type pressure gauge or a differential pressure gauge (Fig. 31), with socket (+) on the gas pressure of the pipe coupling and (-) in the combustion chamber. Used to approximately calculate the MAX burner output.
- Connect two lamps or testers to the two gas line solenoid valves to check the exact moment in which voltage is supplied.
This operation is not required if each of the two solenoid valves is equipped with a pilot light that signals voltage passing through.



Before starting up the burner, it is good practice to adjust the gas train so that ignition takes place in conditions of maximum safety, i.e. with gas delivery at the minimum.




Fig. 31

5.5 Burner start-up (gas)

Close the remote controls and set the switch 11)(Fig. 5 on page 10) to "AUTO".

Check that the lamps or testers connected to the solenoid valves, or the pilot lights on the solenoid valves, indicate that no voltage is present. If they indicate the presence of voltage, stop the burner immediately and check the electric connections.

When the limit thermostat (TL) closes, the heat request is sent and the burner begins the starting cycle.

5.6 Burner ignition

If the motor starts but the flame does not appear and the control box goes into lockout, reset and wait for a new ignition attempt.

If ignition does not occur, it is possible that gas is not reaching the combustion head within the safety time period of 3 seconds. Therefore, it is necessary to increase gas ignition delivery.

The arrival of gas to the sleeve is indicated by the U-type pressure gauge (Fig. 31).

If the burner locks out again, refer to chapter "Problems - Causes - Remedies signalled by LED indicators" on page 43.



In the event the burner stops, in order to prevent any damage to the installation, do not unblock the burner more than twice in a row. If the burner locks out for a third time, contact the customer service.



In the event there are further lockouts or faults with the burner, the maintenance interventions must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

Once ignition has taken place, proceed with burner global calibration operations.

5.7 Servomotor adjustment

The servomotor adjusts simultaneously, through driving gears, the output and pressure of the air and the delivery of the fuel in use. It performs a 130° rotation in 45s. After the adjustment made in the factory to its 6 cams to allow an initial ignition.

Check that they are as shown below.

In the event of a modification, follow what is described below for each cam:




Fig. 32

Cam I (RED): **130°** (The same for all models).
Limits rotation toward maximum position.



Do not make any adjustments.

ATTENTION

Cam II (BLUE): **0°** (The same for all models).
Limits rotation toward minimum position. With the burner off, the air damper is completely closed: 0°



It is recommended that no adjustments are made.

ATTENTION

Cam III (ORANGE): **20°** (The same for all models).
Adjusts the position of ignition and minimum output of gas fuel.

Cam IV (YELLOW): **130°** (The same for all models).
Adjusts the position of the maximum output of gas fuel.

Cam V (BLACK): **20°** (The same for all models)
Adjusts the position of ignition and minimum output of oil fuel.

Cam VI (GREEN): **130°** (The same for all models)
Adjusts the position of the maximum output of oil fuel.

5.8 Combustion air adjustment

The fuel/combustion synchronization is made by means of a servomotor connected to two variable profile cams, which act on the outlet air damper and gas damper and on the combustion head by appropriate levers.

It is advisable, to reduce the loss and for a wide calibration field, to adjust the servomotor to the maximum of the output used, the nearest possible to the maximum opening (130°).

On the gas butterfly valve, fuel step according to the burner output required, with servomotor completely open, is carried out by the pressure stabiliser placed on the train.

The values indicated in Tab. M and Tab. N can be a reference for a good combustion calibration.

EN 676		Air excess		CO
		Max. output $\lambda \leq 1.2$	Max. output $\lambda \leq 1.3$	
GAS	Theoretical max CO ₂ 0 % O ₂	CO ₂ % Calibration		mg/kWh
		$\lambda = 1.2$	$\lambda = 1.3$	
G 20	11.7	9.7	9	≤ 100
G 25	11.5	9.5	8.8	≤ 100
G 30	14.0	11.6	10.7	≤ 100
G 31	13.7	11.4	10.5	≤ 100

Tab. M

EN 267		Air excess		CO
		Max. output $\lambda \leq 1.2$	Min. output $\lambda \leq 1.3$	
Theoretical max CO ₂ 0 % O ₂		CO ₂ % Calibration		mg/kWh
		$\lambda = 1.2$	$\lambda = 1.3$	
15.2		12.6	11.5	≤ 100

Tab. N

5.9 Ignition output of the burner

According to EN 676 standard

Burners with MAX output above 120 kW.

Ignition must occur at a lower output than the max. operation output. If ignition output does not exceed **120 kW** no calculations are required. If ignition output exceeds **120 kW**, the regulatory standard sets that the value be defined according to the control box safety "ts" time.

- For "ts" = 2s, ignition output must be equal to or lower than 1/2 of max. operation output.
- For "ts" = 3s, ignition output must be equal to or lower than 1/3 of max. operation output.

Example:

MAX operation output of 1800 kW.

Ignition output must be equal to or lower than:

- 900 kW con ts = 2s;

- 600 kW con ts = 3s.

In order to measure the ignition output:

- Disconnect the ionisation probe cable (the burner will fire and then go into lockout after the safety time has elapsed).
- Perform 10 ignitions with consecutive lockouts.
- Read the quantity of gas burned on the meter.

This quantity must be equal to or lower than the quantity given by the formula:

$$\frac{\text{Nm}^3/\text{h} (\text{max. burner output})}{360}$$

Example (for G20):

Max. operation output: 1800 kW corresponding to 180 Nm³/h. After 10 ignitions with a lockout, the delivery indicated on the meter must be equal to or lower than:

$$180 : 360 = 0.5 \text{ Nm}^3$$

5.10 Air / fuel adjustment

The following adjustments must be performed during the calibration of the air/fuel ratio:

- A Oil pump delivery pressure:**
act on the screw 5)(Fig. 4 on page 10) located on the pump.
- B Air cam:**
act on the adjustment screws 2)(Fig. 35) after having loosened the screws 3).
- C Gas cam:**
act on the adjustment screws 2)(Fig. 34) after having loosened the screws 3).
- D Oil cam:**
modify the eccentricity by acting on the screw 4)(Fig. 33) after having loosened the screws 7).
By tightening the screw 4) the eccentricity increases, thereby increasing the difference between the maximum and minimum return pressure of the nozzle.

Key (Fig. 33)


- 1 Pressure switch connection
- 2 Delivery pressure gauge
- 3 Return pressure gauge
- 4 Eccentric adjustment screw
- 5 Piston stop ring
- 6 Piston calibration nut and lock nut
- 7 Eccentric locking screws
- 8 Variable eccentric
- 9 Cover

5.10.1 Air cam

Use the adjusters 2)(Fig. 34) after loosening the screws 3).


Key (Fig. 34)

- 1 Cam
- 2 Adjustment screws
- 3 Locking screws
- 4 Adjustable profile



D3437

Fig. 33



D1499

Fig. 34

5.10.2 Burner calibration procedure

- Install the nozzle suitable to achieve the maximum desired output.
- Verify that the eccentricity of the oil cam is such to make a travel of about 8 mm on the shaft of oil modulator.
Normally, with a shaft stroke of 8 mm, the pressure variation needed for the modulation of the minimum to maximum output is obtained.
To verify this, manually rotate the cam after having released the servomotor with the small button placed under its cams, so that the travel of the shaft is not exaggerated or insufficient. Remember to block the servomotor after the verification.
- Switch on the burner with the selector on the control panel in manual "**MAN**".
At this point, after the pre-purging phase, the servomotor stops at about 45°.
- Adjust the outlet pressure of the pump as shown in point **A (oil pump outlet pressure)** to obtain an outlet pressure to the nozzle of 24 - 25 bar.
- Adjust the minimum return pressure to approx. 6 bar.
To do so, the length of the shaft 5)(Fig. 33) must be varied by means of nut 6).
- Calibrate the air delivery by adjusting the variable profile cam with the screws 2)(Fig. 34).
- Having performed this first adjustment, increase the output supplied via the automatic return selector on the control panel. Pause after a 15° rotation of the servomotor and perform another adjustment by means of the variable profile cam of the air.
It is recommended to perform a calibration that will prevent the formation of a smoky flame and arrive as soon as possible to the maximum output (maximum stroke of the servomotor 130°); on the eccentric screw 5)(Fig. 33), calibrate the pressure on the return line to obtain the output desired and requested by the nozzle, and then go back to calibrate the intermediate points.
- Then recheck the values of the combustion parameters at the various modulation outputs and if necessary make the necessary adjustments.
- Turn off the burner and wait for the complete shut-down of the fan motor.
- Now move the selector 1)(Fig. 5 on page 10) to "**GAS**", perform a new ignition and check the correct gas operation at the desired output.
If this is not so, calibrate the gas cam as in point **C (Gas Cam)** mentioned above.
- With the optimal adjustment achieved, remember to lock the adjustment screws of the cam profiles by means of screws 3)(Fig. 34).



ATTENTION

When calibrating the cams, never go beyond the travel limits of the servomotor 0° - 130° to avoid any sticking.

Carrying out a manual travel 0 - 130° of the cams, check that there are no mechanical stops before the micro-switches 1-2 of the servomotor are activated.

5.11 Pressure switch adjustment

5.11.1 Air pressure switch

The air pressure switch is set after all other adjustments have been made. Begin with the switch at the start of the scale. With the burner operating, increase adjustment pressure by slowly turning the relevant knob clockwise until the burner stops. Then turn the knob anticlockwise by 0.1 kPa (1 mbar) and repeat burner start-up to ensure it is operating regularly.

If the burner locks out again, turn the knob again anti-clockwise by 0.5 mbar.



In conformity with the standard, the air pressure switch must prevent the air pressure falling below 80% of the adjusted value and the CO in the flue gases exceeding 1% (10,000 ppm).

To check this, insert a combustion analyser in the flue, slowly reduce the burner air setting (for example with a piece of cardboard) and verify that the burner locks out before the CO value in the flue gases exceeds 1%.



Fig. 35

5.11.2 Maximum gas pressure switch

Adjust the maximum gas pressure switch (Fig. 36) after making all other burner adjustments with the maximum gas pressure switch set to the end of the scale.

To calibrate the maximum gas pressure switch, open the tap and then connect a pressure gauge to its pressure test point.

The maximum gas pressure switch must be regulated to a value no higher than 30% of the measurement read on the gauge when the burner is working at maximum output.

After making the adjustment, remove the pressure gauge and close the tap.




Fig. 36

5.11.3 Minimum gas pressure switch

Adjust the minimum gas pressure switch (Fig. 37) after having adjusted the burner, the gas valves and the gas train stabiliser. With the burner operating at maximum output:

- install a pressure gauge downstream of the gas train stabiliser (for example at the gas pressure test point on the burner combustion head);
- choke slowly the manual gas cock until the pressure gauge detects a decrease in the pressure read of about 0.1 kPa (1 mbar). In this phase, verify the CO value which must always be less than 100 mg/kWh (93 ppm).
- Increase the adjustment of the gas pressure switch until it intervenes, causing the burner shutdown;
- remove the pressure gauge and close the cock of the gas pressure test point used for the measurement;
- open completely the manual gas cock.



1 kPa = 10 mbar




Fig. 37

5.11.4 Minimum oil pressure switch

The minimum oil pressure switch is calibrated in the factory at 16-18 bar. If the oil pressure falls below this value in the delivery line, the pressure switch stops the burner.

The burner restarts automatically if the pressure goes above bar value set after the burner starts.

5.11.5 Maximum oil pressure switch

The maximum oil pressure switch is calibrated in the factory at 4-5 bar. If the oil pressure in the return line goes above this value, the pressure switch stops the burner in a lockout.

To adjust the pressure switches, use a tool to operate the adjustment screw (Fig. 38).

5.11.6 Air bleeding

It is carried out by opening the relevant screw placed on the minimum gas pressure switch fitted on the gas train.

5.11.7 Gas butterfly valve

The gas butterfly valve is equipped with an external adjustment, see Fig. 40, that can facilitate the following calibration of the cam in case of low pressure values available in the network. By means of ring nut **B** it is possible to modify the passage section to the minimum setting.

- 0 minimum opening
- 2 maximum opening

At the end of the adjustment lock with dowel **A**.

AIR / GAS ratio adjustment

The adjustment of the gas delivery to that of the air must be carried out after defining the light oil operation conditions, and can be obtained by varying the cam profile.




Fig. 38




Fig. 39

Key (Fig. 39)

- 1 - Screw
- 2 - Connection for pressure measurement
- 3 - Pressure switch




Fig. 40

5.12 Burner operation

5.12.1 Burner start-up

(gas trains in compliance with EN 676)

- 0s** : Control remote control TL closes.
Fan servomotor start-up.
- 6s** : Servomotor start-up: turn to the right by 130°, i.e. until the contact intervenes on cam I (Fig. 32 on page 29).
The air damper is positioned to MAX output.
- 51s** : Pre-purging stage with MAX output air delivery.
Duration 31 seconds.
- 82s** : The servomotor rotates to the left until reaching the angle set on cam III at 20° (Fig. 32 on page 29), ranging from 10° and 30°.
- 117s** : The air damper and gas butterfly valve assume the MIN output position (with cam III at 20°)(Fig. 32 on page 29).
- 120s** : Ignition electrode strikes a spark.
- 126s** : The safety valve VS opens, along with the adjustment valve VR, (quick opening). The flame is ignited at a low output level, point A.
The output is then progressively increased, with the valve opening slowly up to MIN output, point B.
- 129s** : The spark goes out.
- 150s** : The start-up cycle ends

Burner flame goes out during operation

If the flame should accidentally go out during operation, the burner will lock out within 1s.




Fig. 41

5.12.2 Steady state operation

STEADY STATE OPERATION

Burner without RWF50 output regulator

At the end of the start-up cycle, the servomotor control switches to TR remote control that controls the pressure or temperature in the boiler, point C. (The electric control box RFGO carries on checking the presence of the flame and the correct position of the air and gas maximum pressure switches).

- If the temperature or pressure is low (so the TR remote control is closed), the burner progressively increases the output up to the MAX value (section C-D).
- Then if the temperature or pressure increases until the TR opens, the burner progressively decreases its output to the MIN value (section E-F). And so on.
- The burner locks out when the heat request is less than the heat supplied by the burner at MIN output, (section G-H). The TL remote control opens, the servomotor returns to angle 0° limited by the contact of the cam I)(Fig. 32 on page 29). The air damper closes completely to reduce heat losses to a minimum.

Upon every output change, the servomotor will automatically change the gas flow rate (butterfly valve), the airflow (fan damper) and the air pressure (2 shutters in the combustion head).

Burner with output regulator RWF50

See the manual supplied with the regulator.

5.12.3 Ignition failure

If the burner does not ignite, it locks out within 3 seconds after the gas valve opens, 129 seconds after the TL closes and the post-purging phase starts lasting 17 seconds.




Fig. 42

5.13 Final checks (with burner operating)

<ul style="list-style-type: none"> ➤ Open the thermostat/pressure switch TL ➤ Open the thermostat/pressure switch TS 		The burner must stop
<ul style="list-style-type: none"> ➤ Turn the knob of the gas maximum pressure switch to the minimum end of scale position ➤ Turn the air pressure switch knob to the maximum end of scale position 		The burner must stop in lockout
<ul style="list-style-type: none"> ➤ Turn off the burner and cut off the power ➤ Disconnect the minimum gas pressure switch connector 		The burner must not start
<ul style="list-style-type: none"> ➤ Disconnect flame detection sensor electrical connections 		The burner must stop in lockout due to ignition failure

Tab. O



ATTENTION

Make sure that the mechanical locking systems on the adjustment devices are fully tightened.

6 Maintenance

6.1 Notes on safety for the maintenance

The periodic maintenance is essential for the good operation, safety, yield and duration of the burner.

It allows you to reduce consumption and polluting emissions and to keep the product in a reliable state over time.



The maintenance interventions and the calibration of the burner must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

Before carrying out any maintenance, cleaning or checking operations:



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.



Wait for the components in contact with heat sources to cool down completely.

6.2 Maintenance programme

6.2.1 Maintenance frequency



The gas combustion system should be checked at least once a year by a representative of the manufacturer or another specialised technician.

6.2.2 Safety test - with no gas supply

To perform commissioning in safety conditions, it is very important to check correct wiring between gas valves and burner.

For this purpose, after checking that connections comply with the burner wiring diagrams, it is necessary to carry out a start-up cycle with gas cock closed (dry test).

- 1 The manual gas valve must be closed using the locking/unlocking device ("Lock-out / tag out" procedure).
- 2 Ensure that burner limit electrical contacts are closed
- 3 Ensure that minimum gas pressure switch contact is closed
- 4 Try to start the burner

The start-up cycle must occur according to the following steps:

- Fan motor start-up for pre-purging
- Gas valve leak detection control, if applicable
- Pre-purging completion
- Achievement of the ignition point
- Power supply of the ignition transformer
- Supply of gas valves

As gas is closed, the burner cannot ignite and its control box will switch to stop or safety lockout condition.

The actual supply of gas valves can be checked by inserting a tester; some valves are equipped with lights (or closing/opening position indicators) that activate as soon as they are powered.



IF POWER SUPPLY OF GAS VALVES OCCURS IN UNEXPECTED MOMENTS, DO NOT OPEN THE MANUAL VALVE, DISCONNECT POWER SUPPLY, CHECK WIRINGS, CORRECT THE ERRORS AND CARRY OUT THE WHOLE TEST AGAIN.

6.2.3 Checking and cleaning



The operator must use the required equipment during maintenance.

Combustion

Carry out an analysis of the combustion flue gases.

Significant differences with respect to the previous measurements indicate the points where most care should be exercised during maintenance.

Combustion head

Open the burner and make sure that all components of the combustion head are in good condition, not deformed by the high temperatures, free of impurities from the surroundings and correctly positioned.

Combustion head maintenance



During burner opening, it is recommended to support its weight with suitable means or through the relevant wheeled support supplied upon request.

Repeat the operations described in paragraph "Lifting points" on page 16 using the relevant extensions, for pins 5), supplied as standard.

Burner

Check that there is no excess wear or loosen screws, especially on cams 3)(Fig. 32 on page 29).

Clean the outside of the burner.

Clean and grease the adjustable profile of the cams.

Fan

Check to make sure that no dust has accumulated inside the fan or on its impellers, as this condition will cause a reduction in the air flow rate and provoke polluting combustion.

Boiler

Clean the boiler as indicated in its accompanying instructions in order to maintain all the original combustion characteristics intact, especially: the flue gas temperature and combustion chamber pressure.

Check Mode

With burner flame on:

- hold the reset button on the flame control pressed for at least 3 sec.;
- the button colour will change from green to yellow;
- each operating status signalling LED will be compared to 20% of the maximum brightness;
- press the reset button again (<0.5sec) to reset the standard operation of the signalling LEDs.

6.2.4 Safety components

The safety components should be replaced at the end of their life cycle indicated in the following table.



ATTENTION

The specified life cycles do not refer to the warranty terms indicated in the delivery or payment conditions.

Safety component	Life cycle
Flame control	10 years or 250,000 operation cycles
Flame sensor	10 years or 250,000 operation cycles
Gas valves (solenoid)	10 years or 250,000 operation cycles
Pressure switches	10 years or 250,000 operation cycles
Pressure adjuster	15 years
Servomotor (electronic cam) (if any)	10 years or 250,000 operation cycles
Oil valve (solenoid) (if any)	10 years or 250,000 operation cycles
Oil regulator (if present)	10 years or 250,000 operation cycles
Oil pipes/ couplings (metallic) (if present)	10 years
Fan impeller	10 years or 500,000 start-ups

Tab. P

LIGHT OIL OPERATION

GAS OPERATION

Pump

The delivery pressure must comply with the graph on page 17.

The depression must be less than 0.45 bar.

Unusual noise must not be evident during pump operation.

If the pressure is unstable, or the pump runs noisily, the flexible hose must be detached from the line filter and the fuel must be sucked from a tank located near the burner. This measure permits the cause of the anomaly to be traced to either the suction piping or the pump. If the problem lies in the suction line, check the filter is clean and that air is not entering the piping.

Filters

Check the filtering baskets on line and at nozzle present in the system.

Clean or replace if necessary.

If rust or other impurities are observed inside the pump, use a separate pump to lift any water and other impurities that may have deposited on the bottom of the tank.

Nozzles

It is advisable to replace nozzles once a year during periodical maintenance.

Do not clean the nozzle openings.

Flexible hoses

Check to make sure that the hoses are still in good condition.

Fuel tank

Approximately every 5 years, suck any water on the bottom of the tank using a separate pump.

Combustion

If the combustion values measured before starting maintenance do not comply with applicable Standards or do not indicate efficient combustion, consult the table below or contact our Technical Support Service to implement the necessary adjustments.

Gas leaks

Make sure that there are no gas leaks on the pipe between the gas meter and the burner.

Gas filter

Change the gas filter when it is dirty.

Combustion

If the combustion values measured before starting maintenance do not comply with applicable Standards or do not indicate efficient combustion, consult the table below or contact our Technical Support Service to implement the necessary adjustments.

EN 676		Air excess		CO
		Max. output $\lambda \leq 1.2$	Max. output $\lambda \leq 1.3$	
GAS	Theoretical max CO ₂ 0 % O ₂	CO ₂ % Calibration		mg/kWh
		$\lambda = 1.2$	$\lambda = 1.3$	
G 20	11.7	9.7	9	≤ 100
G 25	11.5	9.5	8.8	≤ 100
G 30	14.0	11.6	10.7	≤ 100
G 31	13.7	11.4	10.5	≤ 100

Tab. R

EN 267	Air excess		CO
	Max. output $\lambda \leq 1.2$	Min. output $\lambda \leq 1.3$	
Theoretical max CO ₂ 0 % O ₂	CO ₂ % Calibration		mg/kWh
	$\lambda = 1.2$	$\lambda = 1.3$	
15.2	12.6	11.5	≤ 100

Tab. Q

6.3 Opening the burner



Disconnect the electrical supply from the burner by means of the system main switch.



Close the fuel shut-off valve.



Wait for the components in contact with heat sources to cool down completely.

To separate the burner from the combustion head, proceed as follows (Fig. 43):

- Remove the cover from the shelf 1), the pin 2), the retainers 4) and the screws 3).
- Disconnect the pipes 6).
- Disconnect the tie-rod of the gas butterfly valve removing the screw 11).
- Pull out the burner from the combustion head by approx. 100÷120 mm and release the driving fork 7) by removing the screws 10).
- At this point, it is possible to fully pull out the burner from the pins 5).
- Fix the blast tube to the boiler by inserting the insulating flange gasket 9) in-between.
- Fit the burner on the pins 5) leaving it open by approx. 100 ÷ 120 mm.
- Refit the fork 7) fixing it with the screws 10).
- Completely close the burner fastening it with screws 3), fit the retainers 4), the split pin 2), the gas butterfly valve tie-rod 11) and the pipes 6).
- With burner open, it is possible to separate the gas sleeve 8) from the blast tube.




Fig. 43

6.4 Closing the burner




Refit following the steps described but in reverse order; refit all burner components as they were originally assembled.



After carrying out maintenance, cleaning or checking operations, reassemble the cover and all the safety and protection devices of the burner.

7 LED indicator and special function

7.1 Description of LED lamps

 S9740	Fan	It turns on when the fan motor is powered (T6) and blinks when RUN/CHECK switch is set to "CHECK" during damper movement phases, PTFI AND MTFI.
 S9741	Damper open	It blinks when the air damper is moving towards the maximum opening position until the position-reached feedback sent by the servomotor is received, then it stays steadily on for the time set by the flame control.
 S9742	Damper closed	If blinks when the air damper is moving towards the minimum opening position until the position-reached feedback sent by the servomotor is received, then it stays steadily on until the end of the pre-purging time.
 S9743	Auto	It indicates that the burner is ready for the output modulation.
 S9744	Ignition	It blinks during the ignition phase (1st safety time) and stays steadily on during the MTFI.
	Flame	It blinks during the first safety time and stays steadily on if the flame detection has been correctly performed.
 S9746	Alarm	It turns on in red when a lock-out condition occurs. Together with the other indicators, it indicates the type of fault during the lock-out phase. Together with the other LEDs, it indicates the operating status during the normal cycle.

Tab. S

T = Terminal

PTFI = Pilot ignition attempt

MTFI = Ignition attempt with main fuel valve

7.2 Check mode function

By means of the reset button on-board the flame control, it is possible to use a control function during start-up phases. (pre-purging, ignition, 1st safety time and 2nd safety time).

This function, indicated as CHECK MODE, is designed to facilitate checking the phases of the burner and of the safety devices monitored by the flame control.

This function is particularly useful during the burner first commissioning or during maintenance.

To enable the check mode function:

- keep the reset button pressed, see "LED lamps: burner operating status" on page 42, for more details, for at least 3 seconds, the status LED changes from green to yellow to signal that the control device is in check mode;
- the control device locks out during pre-purging, after a time-out of max 30 minutes the flame control will automatically exit the check mode function;




- check mode has a 2 minute timeout during the 2nd safety time. When it ends, the flame control goes back to the normal operating status;
- check mode has a 2 minute timeout during the MTFI status. When it ends, the flame control goes back to the normal operating status;
- during the check mode 1st or 2nd safety time, the flame signal level can be indicated by the 5 central LEDs on the flame control central panel, which turn on proportionally. Each lit LED (starting from the flame LED) represents 20% of the signal power.
To exit the check mode function, press the reset button; the flame control will go back to the normal operating mode.

7.3 Flame control lock-out or emergency stop condition

The RFGO control device can be locked out (emergency stop) at any time during the operating cycle and unlocked when already locked (lock-out) by simply pressing the key on the front panel or by means of the terminal T21 on the support base.

7.4 LED lamps: burner operating status

OPERATING STATUSES INDICATED BY LEDS DURING NORMAL OPERATION AND CHECK MODE

Operation LED ● = ON	Fan	Damper open	Damper closed	Modulation	Ignition	Flame	Status
Icon	 S9740	 S9741	 S9742	 S9743	 S9744	 S9745	 S9746
Power OFF/ON							OFF
Not ready/ Diagnostics							Green
Standby			●				Green
Servomotor movement (Note 3)	●	OFF Flashing ●	Flashing ●				Green
Waiting for closing	Green blinking						Green
OPEN (before ignition)	●	●					Green
Minimum (before ignition)	●		●				Green
Ignition	●		●		●		Green
PTFI	●		●		●	Green blinking	Green
MTFI	●		●			●	Green
Active modulation	●			●		●	Green
Minimum output position	●		●			●	Green
With flame present	●	●				●	Green
Economy mode	●		●				Green
Check during maximum opening phase	Flashing	●					Yellow
Check during minimum closing phase	Flashing		●				Yellow
Check during ignition phase with pilot PTFI	Flashing	● Note 1	● Note 1	● Note 1	● Note 1	● Note 1	Yellow
Check during ignition phase with main fuel valve MTFI	Flashing	● Note 1	● Note 1	● Note 1	● Note 1	● Note 1	Yellow
Fault/lock-out	● Note 2	● Note 2	Red				
End of the cycle	●		●	●			Green

Tab. T

1. LEDs form a progress bar which indicates the Flame Signal Power in order to orientate the sensors during commissioning (LEDs "Grow" upwards, moving away from the Status at 20% intervals of flame power.)
2. LEDs indicate the error or lock-out code for troubleshooting.
3. LEDs change from ON to BLINKING to OFF showing the servomotor movement control until the position-reached feedback is received see "Problems - Causes - Remedies signalled by LED indicators" on page 43".

8 Problems - Causes - Remedies signalled by LED indicators

When an emergency stop occurs, the control device LEDs indicate the cause of the stop.

The terminal T3 is not powered.

The device operating status is internally memorised in case of any lack of power supply.

The device lock-out condition can be caused by pressing (<1sec.) the reset button on the flame control front side or through the remote reset - terminal T21 on the base.

Since the reset button is very sensitive, do not press it strongly during the reset operation.

Unlocking the control device

The RFGO control device can be reset in two ways: reset button and remote reset terminal.

The remote reset must be a normally open connected button between T21 and flame control power supply voltage (see illustrative diagrams):

- the reset is performed when a faulty condition is detected by the flame control.
- Press the reset button to reset the system after a lock-out.
- Pressing the reset button during operation will cause an emergency stop.
- The reset or emergency stop condition can be obtained also by using the remote reset with the same modalities.
- The number of reset attempts is limited to a maximum of 5 within 15 minutes.

Error / RFGO LED lock-out Codes

During an alarm condition, the status LED becomes steady red. The remaining LEDs turn on according to a coded sequence which identifies the lock-out cause.

The following table shows the different LED Lock-out codes.



The device described in this manual can cause material problems, severe injuries or death.

It is the owner or user's responsibility to make sure that the equipment described is installed, used and commissioned in compliance with the requirements provided both by national and local law. The lock-out condition indicates the presence of a fault which occurred during the operating cycle or during stand-by mode.

Before performing an unlock attempt, it is necessary to restore the original optimal operating conditions.



Thermal unit's operation, maintenance and troubleshooting interventions must be carried out by trained personnel.

The persons who solve lock-out problems or reset the control device must observe the error codes to solve the problems described in this product technical data sheet.

It is not admitted to tamper with or act on the system or control in a way that could compromise the product safety or warranty.

Any tests on safety devices or on loads, such as fan motor, valves, igniter, flame sensors, must be performed with the shut-off valves closed and by qualified personnel.

Do not by-pass nor exclude the safety devices connected to the flame control.

Failure to observe these guidelines will exclude any liability.



The regulation prohibits the system from allowing more than 5 remote reset attempts within a 15 minute time window.

If more than 5 attempts are performed without solving the lock-out, the system will prevent the user to perform further remote resets and force him/her to wait for the 15 minutes to elapse.

The remote reset operation will be restored at the end of the waiting time.

It is recommended that qualified personnel evaluate the lock-out condition and implement the solution which is suitable for the fault to be solved.

Error / RFGO LED lock-out codes

No	Faults	LED 1	LED 2	LED 3	LED 4	LED 5	LED 6	LED 7
	Operation LED ● = ON	Fan	Open damper	Closed damper	Auto	Ignition	Flame	Status
	Icon	 S9740	 S9741	 S9742	 S9743	 S9744	 S9745	 S9746
1	Post-diagnostics fault	●						Red
2	Local reset		●					Red
3	Combustion air fan fault	●	●					Red
4	Supervisor processor diagnostics fault			●				Red
5	FR- NO Flame at the end of the 2 nd safety time (MTFI)	●		●				Red
6	FR: internal circuit fault		●	●				Red
7	Internal communication fault	●	●	●				Red
8	Remote reset				●			Red
9	FR: internal fault	●			●			Red
10	Main processor fault		●		●			Red
11	Data memory test fault	●	●		●			Red
12	Data memory test fault			●	●			Red
13	Mains voltage or frequent fault	●		●	●			Red
14	Internal processor fault		●	●	●			Red
15	Internal processor fault	●	●	●	●			Red
16	No flame: 1 st safety time (PTFI)	●				●		Red
17	Wiring fault		●			●		Red
18	Safety relay fault	●	●			●		Red
19	Combustion airflow switch fault in the rest position			●		●		Red
20	UV: no flame at the end of the 2 nd safety time (MTFI)	●		●		●		Red
21	Safety relay fault		●	●		●		Red
22	Supervisor processor fault	●	●	●		●		Red
23	Supervisor memory test fault				●	●		Red
24	Flame loss during the operation (AUTO)	●			●	●		Red
25	Supervisor processor data memory fault		●		●	●		Red
26	Supervisor processor internal fault	●	●		●	●		Red
27	Not used							
28	Not used							
29	Operating temperature out of range		●	●	●	●		Red
30	Code memory fault	●	●	●	●	●		Red
31	FR: external short circuit						●	Red
32	Check mode timeout (manual)	●					●	Red
33	False flame in stand-by mode		●				●	Red
34	Not used							
35	Internal processor timeout			●			●	Red
36	Internal processor timeout	●		●			●	Red
37	Combustion air check timeout		●	●			●	Red
38	Internal processor timeout	●	●	●			●	Red
39	Internal processor timeout				●		●	Red
40	Internal hardware fault	●			●		●	Red
41	Internal hardware fault		●		●		●	Red
42	Main processor fault	●	●		●		●	Red
43	Supervisor processor fault			●	●		●	Red
44	Supervisor processor timeout	●		●	●		●	Red
45	Off-specification mains voltage		●	●	●		●	Red

No	Faults	LED 1	LED 2	LED 3	LED 4	LED 5	LED 6	LED 7
46	Off-specification mains voltage	•	•	•	•		•	Red
47	UV: Internal fault					•	•	Red
48	Supervisor processor fault	•				•	•	Red
49	Main processor fault		•			•	•	Red
50	Ignition feedback fault	•	•			•	•	Red
51	Pilot feedback fault			•		•	•	Red
52	Piloted valve feedback fault	•		•		•	•	Red
53	Actuator feedback waiting time expired		•	•		•	•	Red
54	Direct ignition valve feedback fault	•	•	•		•	•	Red
55	Internal processor fault				•	•	•	Red
56	UV: false flame during operation			•	•	•	•	Red
57	FR: false flame during operation	•		•	•	•	•	Red
58	T8 inlet fault		•	•	•	•	•	Red
59	Internal hardware fault	•			•	•	•	Red
60	Local reset fault	•	•	•	•	•	•	Red
61	Open POC fault		•		•	•	•	Red
62	UV: strong UV flame fault	•	•		•	•	•	Red
63	Internal hardware fault					•		Red

Tab. U

Fault explanation

No	Faults	Cause	Solution
1	Post-diagnostics fault	Initial power diagnostics fault Make sure that the status of inlets and outlets is correct upon ignition	Check T12, T13 and T14
2	Local reset	The user started the manual reset or the reset switch is faulty	Check T21 inlet or reset for normal operation
3	Combustion air fan fault	No Air Check signal (T14) during the bleed cycle or Air Check signal loss during the burner operation	Check the fan or the air pressure switch
4	Supervisor diagnostics fault processor	The system detected the presence of voltage on T16, T17, T18 or T19 at the wrong moment or there is no voltage when necessary	Check the wiring and make sure that the system is operating on a single-phase line (50/60Hz)
5	FR- No flame at the end of the 2 nd safety time (MTFI)	No flame at the end of the second safety time	Inspect the system, check the gas pressure, inspect the flame detection electrode, check the wiring, etc.
6	FR: internal circuit fault	Internal fault	Replace the control device
7	Internal communication fault	Internal fault	Replace the control device
8	Remote reset	The user pressed the remote reset button or the reset switch is discontinuous/dynamic	Check the remote switch
9	FR: internal fault	Internal fault	Replace the control device
10	Main processor fault	Internal fault	Replace the control device
11	Data memory test fault	Internal fault	Replace the control device
12	Data memory test fault	Internal fault	Replace the control device
13	Mains voltage or frequent fault	Off-specification power supply voltage and/or frequency	Check the input power supply
14	Internal processor fault	Internal fault	Replace the control device
15	Internal processor fault	Internal fault	Replace the control device
16	No flame: 1 st safety time (PTFI)	No flame at the end of the first safety time	Inspect the system, check the gas pressure, check the flame sensor, check the wiring, etc.
17	Wiring fault	The system detected the presence of voltage on critical terminals (T16, T17, T18 or T19) at the wrong moment or there is no voltage when necessary	Inspect the wiring and make sure that the system is operating on a single-phase line (50/60Hz)
18	Safety relay fault	Internal fault	Replace the control device
19	Combustion airflow switch fault in the rest position	Open the circuit upon T13 start-up	Check the wiring for the air pressure switch
20	UV: no flame at the end of the 2 nd safety time (MTFI)	No flame at the end of the 2 nd safety time	Inspect the system, check the gas pressure, check the flame sensor, check the wiring, etc.
21	Safety relay fault	Internal fault	Replace the control device
22	Supervisor processor fault	Internal fault	Replace the control device
23	Supervisor memory test fault	Internal fault	Replace the control device
24	Flame loss during the operation (AUTO)	Loss of flame	Check the flame sensor or the fuel flow line
25	Supervisor processor data memory fault	Internal fault	Replace the control device
26	Supervisor processor internal fault	Internal fault	Replace the control device
27	Not used		
28	Not used		
29	Operating temperature out of range	Operating temperature below -40°C or above 70°C	Bring the control device within the specified temperature nominal values
30	Code memory fault	Internal fault	Replace the control device
31	FR: external short circuit	External short circuit between T24 and EARTH	Inspect the flame detection electrode
32	Check mode timeout (manual)	The interval for the manual mode (30 minutes) to end has elapsed	Exit the manual mode correctly to avoid timeout
33	False flame in stand-by mode	Unexpected flame (false or parasitic flame) detected during the Stand-by status	Check flame sensor or interference

No	Faults	Cause	Solution
34	Not used		
35	Internal processor timeout	Internal fault	Replace the control device
36	Internal processor timeout	Internal fault	Replace the control device
37	Combustion air check timeout	The system could not perform verification tests of the combustion air during the burner sequence	Check the wiring or the air pressure switch
38	Internal processor timeout	Internal fault	Replace the control device
39	Internal processor timeout	Internal fault	Replace the control device
40	Internal hardware fault	Internal fault	Replace the control device
41	Internal hardware fault	Internal fault	Replace the control device
42	Main processor fault	Internal fault	Replace the control device
43	Supervisor processor fault	Internal fault	Replace the control device
44	Supervisor processor timeout	Internal fault	Replace the control device
45	Off-specification mains voltage	Off-specification mains voltage/frequency	Check the mains voltage level or the frequency. Contact the factory if the problem persists
46	Off-specification mains voltage	Off-specification mains voltage/frequency	Check the mains voltage level or the frequency. Contact the factory if the problem persists
47	UV: Internal fault	Internal fault	Replace the control device
48	Supervisor processor fault	Internal fault	Replace the control device
49	Main processor fault	Internal fault	Replace the control device
50	Ignition feedback fault	The system detected the presence of voltage on T16 at the wrong moment or there is no voltage when necessary	Check the wiring and make sure that the earthing is appropriate If the problem persists, contact the distributor/factory
51	Pilot feedback fault	The system detected the presence of voltage on T17 at the wrong moment or there is no voltage when necessary	Check the wiring and make sure that the earthing is appropriate. If the problem persists, contact the distributor/factory
52	Piloted valve feedback fault	The system detected the presence of voltage on T19 at the wrong moment or there is no voltage when necessary	Check the wiring and make sure that the earthing is appropriate If the problem persists, contact the distributor/factory
53	Actuator feedback waiting time expired	No actuator feedback on T8 for more than 10 minutes	Check the wiring Check the modulation equipment
54	Direct ignition valve feedback fault	The system detected the presence of voltage on T18 at the wrong moment or there is no voltage when necessary	Check the wiring and make sure that the earthing is appropriate. If the problem persists, contact the distributor/factory
55	Internal processor fault	Internal fault	Replace the control device
56	UV: false flame during operation	False flame detected before ignition	Check the flame sensor
57	FR: false flame during operation	False flame detected before ignition	Check the wiring Check the flame sensor Make sure that earthing is appropriate
58	T8 inlet fault	The system detected the presence of voltage on T8 at the wrong moment or there is no voltage when necessary	Check the wiring Check the actuator
59	Internal hardware fault	Internal fault	Replace the control device
60	Local reset fault	Local reset button pressed for more than 10 seconds or reset button locked	If the problem persists, replace the control device
61	Open POC fault	The fuel valve is open at the wrong moment	Check the wiring
62	UV: strong UV flame fault	The flame sensor is too close to the flame	Increase the distance between the flame and the flame OR use an orifice to reduce the view field
63	Internal hardware fault	Internal fault	Replace the control device

Tab. V

A Appendix - Accessories

Output regulator kit for modulating operation

With modulating operation, the burner continuously adjusts its output to the heat request, thereby ensuring a great stability of the controlled parameter: temperature or pressure.

The parts to be ordered are two:

- output regulator to be installed to the burner;
- probe to be installed to heat generator.

Parameter to be controlled		Probe		Output regulator	
	Adjustment field	Type	Code	Type	Code
Temperature	- 100...+ 500°C	PT 100	3010110	RWF50.2 RWF55.5	20100018
Pressure	0...2.5 bar 0...16 bar	Output probe 4...20 mA	3010213 3010214		20101965

Potentiometer kit

Burner	Code
GI/EMME 1400 - 2000 GI/EMME 3000 - 4500	3010021

Spacer kit

Burner	Thickness (mm)	Code
GI/EMME 1400 - 2000	102	3000722
GI/EMME 3000 - 4500	130	3000751

Soundproofing box kit

Burner	Type	dB(A)	Code
GI/EMME 1400 - 2000 GI/EMME 3000 - 4500	C7	10	3010376

LPG kit

Burner	Code
GI/EMME 1400 - 2000	3010063
GI/EMME 3000	3090223
GI/EMME 4500	3090937

Burner support kit

Burner	Code
GI/EMME 1400 - 2000 GI/EMME 3000 - 4500	3000731

Gas trains in compliance with EN 676

Please refer to manual.




ATTENTION

The installer is responsible for the addition of any safety device not foreseen in this manual.

B Appendix - Electrical panel layout

1	Index of layouts
2	Indication of references
3	Functional layout RFGO-A22
4	Functional layout RFGO-A22
5	Functional layout RFGO-A22
6	Functional layout RFGO-A22
7	Electrical wiring that is the responsibility of the installer
8	Functional layout RWF50
9	Functional layout RWF50

2 Indication of references



BU = BLU / BLUE / BLEU / BLAU	GY = GRIGIO / GREY / GRIS / GRAU	TO = TURCHESE / TURQUOISE / TURKOISE / TURKISBLAU
BK = NERO / BLACK / NOIR / SCHWARZ	PK = ROSA / PINK / ROSE / ROSA	SR = ARGENTO / SILVER / ARGENT / SILBER
BN = MARRONE / BROWN / MARRON / BRAUN	VTS = VIOLETTO / VIOLET / VIOLET / VIOLETT	GNYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN
YE = GIALLO / YELLOW / JAUNE / GELB	OG = ARANCIO / ORANGE / ORANGE / ORANGE	
GN = VERDE / GREEN / VERT / GRÜN		
RD = ROSSO / RED / ROUGE / ROT		


SCHEMA FUNZIONALE RF60-AZZ


OPERATIONAL LAYOUT RF60-AZZ


FUNKTIONSSCHEMA RF60-AZZ


SCHEMA FONCTIONNEL RF60-AZZ


Sheet : 3











ELECTRICAL POWER


G/M 14.00		G/M 14.00	
400V	230V	400V	230V
FU	8A aM 12A gG 2.5 mm ²	FU1	4A aM 8A gG
S	2.5 mm ²		
F1	3 kW		
	MIN		
	MAX		
FAN MOTOR		PUMP MOTOR	




NEL CASO DI INTERRUPTORE MAGNETOTERMICO
SCEGLIERE IL TIPO C
WITH A MAGNETO-THERMAL SWITCH
CHOOSE TYPE C

EN CAS D' INTERRUPTEUR MAGNÉTOHERMIQUE
CHOISIR LE TYPE C
IM FALLE EINES MAGNETOTHERMISCHEN
SCHALTERS TYP C WÄHLEN

CONTROLLO TENUTA VPS 504 + RAMPA GAS
VPS 504 GAS LEAKAGE DETECTOR + GAS TRAIN



POWER REGULATION





max 0,5A 230V AC


BU = BLU / BLUE / BLEU / BLAU	YE = GIALLO / YELLOW / JAUNE / GELB	WH = BIANCO / WHITE / BLANC / WEISS	GY = GRIGIO / GREY / GRIS / GRAU	TO = TURCHESE / TURBOISE / TURKOISE / TURKISBLAU
BK = NERO / BLACK / NOIR / SCHWARZ	GN = VERDE / GREEN / VERT / GRÜN	OG = ARANCIO / ORANGE / ORANGE / ORANGE	PK = ROSA / PINK / ROSE / ROSA	SR = ARGENTO / SILVER / ARGENT / SILBER
BN = MARRONE / BROWN / MARRON / BRAUN	RD = ROSSO / RED / ROUGE / ROT	VT = VIOLETTA / VIOLET / VIOLET / VIOLETT	GD = ORO / GOLD / OR / GOLD	GNYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN

COLLEGAMENTI ELETTRICI A CURA DELL'INSTALLATORE ELECTRICAL CONNECTIONS SET BY INSTALLER ELEKTROANSCHLÜSSE VOM INSTALLATEUR AUSZUFÜHREN RACCORDEMENTS ÉLECTRIQUE EFFECTUÉ PAR L'INSTALLATEUR

Sheet : 7







⚠

NEL CASO DI INTERRUPTORE MAGNETOTERMICO
SCEGLIERE IL TIPO C

WITH A MAGNETO-THERMAL SWITCH
CHOOSE TYPE C

EN CAS D'INTERRUPTEUR MAGNÉOTHERMIQUE
CHOISIR LE TYPE C

IM FALLE EINES MAGNETOTHERMISCHEN
SCHALTERS TYP C WÄHLEN


COLLEGAMENTI ELETTRICI A CURA DELL'INSTALLATORE ELECTRICAL CONNECTIONS SET BY INSTALLER ELEKTROANSCHLÜSSE VOM INSTALLATEUR AUSZUFÜHREN


BU = BLU / BLUE / BLEU / BLAU YE = GIALLO / YELLOW / JAUNE / GELB WH = BIANCO / WHITE / BLANC / WEISS GY = GRIGIO / GREY / BLANC / GRAU TO = TURCHESE / TURQUOISE / TURKOISE / TURKISBLAU


BK = NERO / BLACK / NOIR / SCHWARZ GN = VERDE / GREEN / VERT / GRÜN OG = ARANCIO / ORANGE / ORANGE / ORANGE PK = ROSA / PINK / ROSE / ROSA SR = ARGENTO / SILVER / ARGENT / SILBER


BN = MARRONE / BROWN / MARRON / BRAUN RD = ROSSO / RED / ROUGE / ROT VT = VIOLETTA / VIOLET / VIOLET / VIOLETT GU = ORO / GOLD / OR / GOLD GNVE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN


Sheet : 7
















G/M 2000
G/M 3000
G/M 4500

STAR/TRIANGLE

BU = BLU / BLUE / BLEU / BLAU	YE = GIALLO / YELLOW / JAUNE / GRAU	WH = BIANCO / WHITE / BLANC / WEISS	TO = TURCHESE / TURQUOISE / TURKUISE / TURKISBLAU
BK = NERO / BLACK / NOIR / SCHWARZ	GN = VERDE / GREEN / VERT / GRÜN	OG = ARANCIO / ORANGE / ORANGE / ORANGE	SR = ARGENTO / SILVER / ARGENT / SILBER
BN = MARRONE / BROWN / MARRON / BRAUN	RD = ROSSO / RED / ROUGE / ROT	VT = VIOLETTO / VIOLET / VIOLETT / VIOLETT	GNYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN
SCHEMA FUNZIONALE RFGO-AZZ			
OPERATIONAL LAYOUT RFGO-AZZ			
SCHEMA FONCTIONNEL RFGO-AZZ			
			Sheet : 7





Wiring layout key

A1	Electrical control box	VR	Oil return valve
B	Filter to protect against radio disturbance	VR1	Oil return valve
B1	RWF50 output power regulator	VS	Oil safety valve
BA	Current input DC 4...20mA	VF	Oil operation valve
BA1	Current input DC 4...20mA for remote setpoint change	XPGM	Maximum gas pressure switch connector
BP	Pressure probe	XPOMax	Maximum oil pressure switch connector
BP1	Pressure probe	XPOMin	Minimum oil pressure switch connector
BR	Remote setpoint potentiometer	XRWF	RWF50 terminal board
BT1	Thermocouple probe	X1	Burner terminal strip
BT2	Probe Pt100, 2 wires	XA	Starter terminal strip
BT3	Probe Pt100, 3 wires	XTB	Burner earth
BT4	Probe Pt100, 3 wires	XVR1	Oil return valve connector
BTEXT	External probe for climatic compensation of the setpoint	YVPS	Leak test
BV	Voltage input DC 0...10V	Y	Gas adjustment valve + gas safety valve
BV1	Voltage input DC 0...10V for remote setpoint change		
CN	Servomotor connector		
F1	Fan motor thermal relay		
F2	Pump motor thermal relay		
FU	Three-phase line fuses		
FU1	Three-phase line fuses		
FU2	Three-phase line fuses		
FU3	Single-phase line fuses		
H	Remote lockout signal		
H1	Remote lockout signal due to leak detection control		
H2	Remote motor lockout signal		
IN	Burner manual stop switch		
KM	Fan motor contactor		
KMP	Pump motor contactor		
KT1	Triangle contactor		
KS1	Star contactor		
KL1	Line contactor		
KST1	Timing relay for switching from star to triangle		
MP	Pump motor		
MV	Fan motor		
PA	Air pressure switch		
PGM	Maximum gas pressure switch		
PGMin	Minimum gas pressure switch		
POMax	Maximum oil pressure switch		
POMin	Minimum oil pressure switch		
Q1	-Three-phase disconnecting switch of fan motor line		
Q2	Single-phase disconnecting switch		
Q3	Three-phase disconnecting switch of pump motor line		
Q4	Three-phase disconnecting switch of Star/Triangle line		
SM	Servomotor		
UV	Flame sensor		
TA	Ignition transformer		
TL	Limit thermostat/pressure switch		
TS	Safety thermostat/pressure switch		
S1	Selector switch		
TR	Adjustment thermostat/pressure switch		

RIELLO

RIELLO S.p.A.
I-37045 Legnago (VR)
Tel.: +39.0442.630111
[http:// www.riello.it](http://www.riello.it)
[http:// www.riello.com](http://www.riello.com)