

IMPORTANT - 重要提示

GB



Incorrect gas burner adjustment can:

- reduce the **safety** level;
- reduce combustion efficiency;
- increase the emission of polluting gases.

Always **follow** the instructions provided in the installation, operation and maintenance manual.

In particular, to guarantee safe smooth operation:

- 1 Check the correct position of the ignition electrode.**
- 2 Adjust the gas valve brake** to minimum as far as possible to permit correct **slow** ignition.
- 3 Always perform analysis of the combustion products.**
- 4 Always calibrate the air pressure switch** (this device ensures correct comburent air flow, preventing obstruction of the air pipes or locking of the adjustment shutter).

CN



燃气型燃烧器不正确调试会导致：

- 安全等级降低；
燃烧效率降低；
污染气体排放增加。

严格**遵循**操作指南中所提供的安装、操作和维护方法。

特别要做到下列的操作，已确保安全：

- 1 检查点火电极的安装位置：**
- 2 调节燃气开关到最小开度，已确保正常**缓慢**地点火；**
- 3 要经常对燃烧产物进行分析；**
- 4 要经常对空气压力开关校验（该装置确保正确的助燃空气流动，防止风道堵塞或调节挡板卡住。）**