


TEMPERATURE AND PRESSURE GAUGE

Content

1. Temperature and pressure gauge
2. Instruction sheet



This instruction is an integral part of the manual of the appliance on which the accessory is installed. Please refer to this booklet for the GENERAL WARNINGS and the FUNDAMENTAL SAFETY RULES.



This kit must be installed by a Technical Assistance Service or professionally qualified personnel.



Install the manometer on the hot water supply piping.
Do not place a valve between the gauge and the boiler.

