

# CONTROLLERS

## CLIMA TOP (RVS63)

## CLIMA COMFORT (RVS43)

User and OEM Manual

RVS43..  
RVS63..  
AVS75..  
AVS37..  
QAA75..  
QAA55..

# Contents

CONTROLLERS CLIMA TOP (RVS63) CLIMA COMFORT (RVS43)	USER
MANUAL .....	10
1 Summary.....	11
1.1 Type summary .....	11
1.1.1 Topology .....	11
2 Mounting and installation .....	12
2.1 Regulations .....	12
Electrical installation .....	12
2.2 Basic units RVS.....	12
Engineering.....	12
Mounting method .....	13
Dimensions and drilling plan .....	13
2.2.1 Connection terminals of RVS43.143.....	14
2.2.2 Connection terminals of RVS63.283.....	14
Terminal markings .....	15
2.3 Extension module AVS75.390 .....	17
Dimensions and drilling plan .....	17
2.3.1 Connection terminals of AVS75.390 .....	17
Terminal markings .....	18
Assignment of terminals.....	18
2.4 Operator unit AVS37.294 .....	19
Connections .....	19
Ground .....	19
2.5 Room unit QAA55... ..	20
Engineering.....	20
Mounting method .....	20
Connections .....	20
Dimensions and drilling plan .....	20
2.6 Room unit QAA75... ..	21
Engineering.....	21
Mounting method .....	21
Connections .....	21
Dimensions and drilling plan .....	22
3 Commissioning .....	23
3.1 Basic units.....	23
4 Handling.....	24
4.1 QAA75.. / QAA78... / AVS37.....	24
4.1.1 Operation .....	24
Operating elements.....	24
Display options.....	25
Selection of space heating mode.....	25

	Selection of cooling mode .....	26
	Selecting the DHW heating mode .....	26
	Adjusting the room temperature setpoint.....	26
	Presence button .....	27
	Displaying information .....	27
4.1.2	Programming .....	29
	Setting principle .....	29
	Example: "Setting the time of day" .....	29
4.1.3	User levels .....	30
	Setting the structure "End user" .....	31
	Setting the structure "Heating engineer" .....	31
4.2	QAA55.....	32
4.2.1	Operation .....	32
	Operating elements .....	32
	Display options .....	32
	Selection of space heating mode .....	32
	Adjusting the room temperature setpoint.....	33
	Presence button .....	33
4.2.2	Programming .....	34
4.3	Overview of settings .....	35
5	The settings in detail.....	62
5.1	Time of day and date.....	62
5.2	Operator unit.....	62
	Operation and display.....	62
	Heating circuit assignment .....	64
	Room sensor .....	64
	Device data.....	64
5.3	Time programs .....	65
	Switching points.....	65
	Standard program.....	65
5.4	Holidays.....	65
5.5	Heating circuits .....	66
	Operating mode.....	66
	Setpoints.....	66
	Heating curve .....	66
	ECO functions .....	67
	Flow temperature setpoint limits.....	69
	Room influence.....	69
	Room temp limitation.....	70
	Boost heating.....	70
	Quick setback .....	71
	Optimum start / stop control .....	72
	Raising the reduced setpoint .....	72
	Overtemp prot pump circuit .....	73
	Mixing valve control .....	73
	Floor curing function .....	73
	Excess heat draw .....	75
	Buffer storage tank / primary controller .....	75
	Speed-controlled pump .....	76
	Remote control .....	76

5.6	Cooling circuit .....	77
	Operating mode .....	77
	Setpoints .....	77
	Release .....	77
	Cooling curve .....	78
	ECO .....	78
	Summer compensation .....	78
	Flow temperature setpoint limits .....	79
	Room influence .....	80
	Room temp limitation .....	81
	Mixing valve control .....	81
	Dewpoint monitoring .....	82
	Buffer storage tank / primary controller .....	83
	Remote control .....	83
5.7	DHW .....	84
	Setpoints .....	84
	Priority .....	84
	Legionella function .....	85
	Circulating pump .....	85
5.8	H.. pumps .....	86
	H.. pumps .....	86
5.9	Swimming pool .....	87
	Setpoints .....	87
	Priority .....	87
	Plant hydraulics .....	87
5.10	Primary controller / system pump .....	88
	Primary controller / system pump .....	88
5.11	Boiler .....	88
	Operating mode .....	88
	Setpoints .....	88
	Minimum limitation of the return temperature .....	89
	Output data .....	89
	2 x 1 cascade .....	89
5.12	Cascade .....	90
	Control .....	90
	Boiler sequence .....	90
	Minimum limitation of the return temperature .....	91
5.13	Solar .....	92
	Charging controller (dT) .....	92
	Priority .....	92
	Start function .....	93
	Frost protection for the collector .....	94
	Overtemperature protection for the collector .....	94
	Medium's evaporation temperature .....	94
	Speed control .....	94
	Yield measurement .....	95
5.14	Solid fuel boiler .....	96
	Operating mode .....	96
	Setpoints .....	96
	Boiler / burner control .....	96
5.15	Buffer storage tank .....	97
	Automatic locks .....	97

	Stratification protection .....	98
	Overtemperature protection.....	98
	Recooling.....	99
	Plant hydraulics .....	99
	Return diversion .....	99
	Partial charging.....	100
	Cooling .....	100
5.16	DHW storage tank .....	101
	Charging control .....	101
	Overtemperature protection.....	101
	Recooling.....	101
	Electric immersion heater .....	102
	Plant hydraulics .....	103
	Speed-controlled pump .....	103
5.17	Instantaneous DHW heater .....	104
	Setpoints.....	104
	Mixing valve control .....	104
5.18	Configuration .....	104
	Heating circuits .....	104
	DHW sensor B3.....	105
	DHW control element Q3.....	105
	Separate DHW circuit.....	106
	Boiler .....	106
	Solar .....	109
	Output relay QX.....	110
	Input sensor BX .....	114
	Input H1 for RVS43.....	114
	Input H.. for RVS63.....	119
	Input EX2.....	122
	Mixing valve groups basic unit.....	123
	Extension module .....	124
	QX extension module .....	125
	BX extension module.....	126
	H2 extension module.....	126
	10V output UX .....	127
	Types of sensor/readjustment .....	127
	Building and room model.....	128
	Frost protection for the plant.....	128
	External requirements .....	128
	Sensor state .....	129
	Parameter reset.....	129
	Plant diagram .....	129
	Device data.....	132
5.19	LPB.....	133
	Address / power supply .....	133
	Central functions.....	133
	Clock.....	135
5.20	Faults.....	135
5.21	Maintenance/special mode.....	136
	Maintenance functions.....	136
	Chimney sweep .....	136
	Manual operation.....	136
	Simulations .....	138

	Telephone customer service .....	138
5.22	Input / output test .....	138
5.23	State.....	139
	Messages.....	139
5.24	Diagnostics, heat generation .....	142
5.25	Diagnostics, consumers.....	142
5.26	List of displays .....	143
5.26.1	Error code .....	143
5.26.2	Maintenance code.....	144
5.26.3	Special operation code .....	144
	CONTROLLERS CLIMA TOP (RVS63) CLIMA COMFORT (RVS43)      OEM	
	MANUAL .....	145
6	The OEM settings in detail.....	146
6.1	Operator unit.....	146
	Operation and display .....	146
6.2	Heating circuits .....	146
	Mixing valve control .....	146
6.3	Cooling circuit .....	147
	Mixing valve control .....	147
6.4	DHW .....	147
	Setpoints .....	147
	Release.....	147
6.5	Pumps H .....	148
	Pump Hx .....	148
6.6	Swimming pool.....	149
6.7	Primary controller / system pump .....	149
	Flow temperature setpoint limits .....	149
	Mixing valve control .....	149
6.8	Boiler.....	150
	Operating mode .....	150
	Setpoints.....	151
	Multistage burner .....	151
	Modulating burner (damper actuator / UX) .....	152
	Boiler / burner control.....	153
	Overtemperature protection.....	153
	Minimum limitation of the boiler temperature .....	154
	Minimum limitation of the return temperature .....	155
	Return temperature minimum limitation mixing valve .....	155
	Bypass pump .....	156
	Bypass pump .....	156
	Frost protection.....	156
	Electronic limit thermostat.....	157
	Monitoring the temperature differential .....	157
	Speed control.....	158
6.9	Cascade.....	159
	Operating mode / strategy .....	159
	Control .....	159

	Minimum limitation of the boiler temperature.....	160
	Minimum limitation of the return temperature.....	160
	Return mixing valve.....	160
	Monitoring the temperature differential.....	160
6.10	Solar.....	161
	Charging controller (dT).....	161
	Start function.....	161
	Speed control.....	161
6.11	Solid fuel boiler.....	162
	Overtemperature protection.....	162
	Frost protection.....	162
6.12	Buffer storage tank.....	163
	Automatic heat generation lock.....	163
	Stratification/decharging protection.....	163
	Overtemperature protection.....	164
	Full charging.....	164
6.13	DHW storage tank.....	165
	Release.....	165
	Charging control.....	165
	Charging time limitation.....	166
	Discharging protection.....	166
	Overtemperature protection.....	167
	DHW push.....	167
	Excess heat draw.....	168
	Speed-controlled pump.....	168
	Mixing valve precontrol.....	169
	Transfer.....	169
6.14	<b>Instantaneous DHW heater</b> .....	170
	Mixing valve control.....	170
6.15	<b>Configuration</b> .....	170
	Building and room model.....	170
	Setpoint compensation.....	170
	Pressure acquisition H1, H2 and H3.....	171
6.16	<b>LPB system</b> .....	172
	Error/maintenance/alarms.....	172
	Central functions.....	172
6.17	<b>Errors</b> .....	172
	History 1..10.....	172
6.18	<b>Diagnostics, consumers</b> .....	173
	<i>Heating circuit 1, heating circuit 2, heating circuit P</i> .....	173
7	Plant diagrams.....	174
7.1	Basic diagrams.....	174
7.1.1	Basic diagram RVS43.....	174
7.1.2	Basic diagram RVS63.....	175
7.2	Versions of heat sources.....	176
7.3	Extra functions in general.....	177
	Solar.....	177
	Boiler.....	179
	DHW storage tank (DHW).....	180
	Heating/cooling circuit.....	181

	Heat converter .....	182
	Swimming pool.....	182
	Pressureless header .....	182
	Extra functions .....	182
7.4	Additional funct. with mix. valve group or extension module AVS75.390 ....	183
	Legend mains voltage.....	186
	Legend low-voltage.....	187
8	Technical data.....	188
8.1	Basic units RVS.....	188
8.2	Extension module AVS75.390 .....	190
8.3	Operator unit and room units AVS37... / QAA7x... / QAA55.. .....	191
8.4	Sensor characteristics.....	192
8.4.1	NTC 1 k.....	192
8.4.2	NTC 10 k.....	193
8.4.3	PT1000 .....	193



**CONTROLLERS**  
**CLIMA TOP (RVS63)**  
**CLIMA COMFORT (RVS43)**

**USER MANUAL**

# 1 Summary


The present User Manual describes the products listed in the following table and covers handling and configuration of the controls for readers ranging from end users to heating engineers.

Type reference (ASN)	Series	Name
RVS43.143	B	Basic unit boiler
RVS63.283	B	Basic unit boiler
AVS75.390	B	Extension module
AVS37.294	B	operator unit
QAA75.610	B	Room unit, wired
QAA75.611	B	Room unit with backlight, wired
QAA55.110	A	Room unit basic

## 1.1 Type summary

### 1.1.1 Topology

Wired



## 2 Mounting and installation

### 2.1 Regulations

---

#### Electrical installation

- Prior to installing the controller, the power supply must be turned off
- The connections for mains and low-voltage are separated
- The wiring must be made in compliance with the requirements of safety class II. This means that sensor and mains cables may not be run in the same duct

### 2.2 Basic units RVS...

---


#### Engineering

- Air circulation around the controller must be ensured, allowing the unit to emit the heat produced by it.  
A clearance of at least 10 mm must be provided for the controller's cooling slots which are situated at the top and bottom of the housing.  
The space should not be accessible and no objects should be placed there. If the controller is enclosed in another (insulating) casing, a clearance of up to 100 mm must be observed around the cooling slots
- The controller is designed conforming to the directives for safety class II mounted in compliance with these regulations.
- Power to the controller may only be supplied when completely fitted. If this is not observed, there is a risk of electric shock hazard near the terminals and through the cooling slots.
- The controller may not be exposed to dripping water.
- Permissible ambient temperature when mounted and when ready to operate: 0..50°C.
- Power cables must be clearly segregated from low-voltage cables (sensors) observing a distance of at least 100 mm


#### Mounting location

- Boiler
- Control panel
- Housing for wall mounting

## Mounting method




## Dimensions and drilling plan



Dimensions in mm

	<i>L</i>	<i>B</i>	<i>H</i>	<i>L1</i>	<i>B1</i>
<b>RVS63...</b>	281	121	52	270	110
<b>RVS43...</b>	181	121	52	170	110

## Total height required



Dimension X:

Connectors with tongues minimum 70 mm

Connector without tongues minimum 60 mm



Mains voltage

**Terminal markings**

	<i>Use</i>	<i>Slot</i>	<i>Connector type</i>
L ⏏ N L1 S3	Line AC 230 V basic unit Protective earth Neutral conductor Line AC 230 V burner Output burner fault	N ⏏ L	AGP4S.05A/109
L1 ⏏ N T1 T2 S3 4	Phase burner Protective earth Neutral conductor Phase 1st burner stage 1st burner stage on Input burner fault Input 1st burner stage operating hours	P	AGP8S.07A/109
SK1 SK2	Safety loop Safety loop	Q	AGP8S.02E/109
N ⏏ Q3	Neutral conductor Protective earth DHW charging pump / diverting valve	R	AGP8S.03A/109
N ⏏ Q2	Neutral conductor Protective earth 1st heating circuit pump	S	AGP8S.03B/109
Y1 N ⏏ Y2	1st heating circuit mixing valve opening Neutral conductor Protective earth 1st heating circuit mixing valve closing	T	AGP8S.04B/109
N ⏏ QX1	Neutral conductor Protective earth Multifunctional output 1	U	AGP8S.03C/109
N ⏏ Q6	Neutral conductor Protective earth 2nd heating circuit pump	S	AGP8S.03B/109
Y5 N ⏏ Y6	2nd heating circuit mixing valve opening Neutral conductor Protective earth 1st heating circuit mixing valve closing	T	AGP8S.04B/109
N ⏏ QX2	Neutral conductor Protective earth Multifunctional output 2	U	AGP8S.03C/109
N ⏏ QX3	Neutral conductor Protective earth Multifunctional output 3	U	AGP8S.03C/109
EX2 FX4 (T6) QX4 (T7) QX4 (T8)	Multifunctional input Multifunctional output 4 (phase 2nd burner stage) Multifunctional output 4 off (2nd burner stage off) Multifunctional output 4 on (2nd burner stage on)	Z	AGP8S.04C/109

Low voltage


	<i>Use</i>	<i>Slot</i>	<i>Connector type</i>
BSB	Service tool OCI700	-	-
LPB	Local process bus	-	-
X50	Extension module AVS75.390	-	AVS82.490/109
X30	Operator unit / boiler control panel	-	AVS82.491/109
DB	LPB data		AGP4S.02H/109
MB	LPB ground		
CL+	BSB data		AGP4S.02A/109
CL-	BSB ground	b	
CL+	Room unit 2 data		AGP4S.02A/109
CL-	Room unit 2 ground	b	
CL+	Room unit 1 data		AGP4S.02A/109
CL-	Room unit 1 ground	b	AGP4S.03D/109
G+	Room unit power supply 12 V		
B2	Boiler sensor		AGP4S.02B/109
M	Ground	f	
B3	DHW sensor top		AGP4S.02C/109
M	Ground	h	
B9	Outside sensor		AGP4S.02D/109
M	Ground	k	
H1	Digital / DC 0...10 V input		AGP4S.02F/109
M	Ground	n	
B1	Flow temperature sensor HK1		AGP4S.02G/109
M	Ground	p	
BX1	Multifunctional sensor input 1		AGP4S.02F/109
M	Ground	n	
BX2	Multifunctional sensor input 2		AGP4S.02F/109
M	Ground	n	
B12	Flow temperature sensor HK2		AGP4S.02G/109
M	Ground	p	
H3	Digital / DC 0...10 V input		AGP4S.02F/109
M	Ground	n	
BX3	Multifunctional sensor input 3		AGP4S.02F/109
M	Ground	n	
BX4	Multifunctional sensor input 4		AGP4S.02F/109
M	Ground	n	
UX	DC 0...10 V output	n	AGP4S.02F/109
M	Ground		

## 2.3 Extension module AVS75.390



For planning, mounting location and mounting method, refer to the information given for the basic modules.

### Dimensions and drilling plan




Dimensions in mm

	L	B	H	L1	B1
<b>AVS75.390</b>	108.7	120.9	51.7	98	110

### Connections

The AVS75.390 extension module is connected to terminal X50 of the basic unit using the AVS83.490/109 connecting cable. The connectors are coded.

#### 2.3.1 Connection terminals of AVS75.390



## Terminal markings

### Mains voltage

	<i>Use</i>	<i>Slot</i>	<i>Connector type</i>
L ⏏ N	Line AC 230 V basic unit Protective earth Neutral conductor	N ⏏ L	AGP4S.03E/109
QX21 N ⏏ QX22	Assignment according to function Neutral conductor Protective earth Assignment according to function	T	AGP8S.04B/109
N ⏏ QX23	Neutral conductor Protective earth Assignment according to function	S	AGP8S.03B/109

### Low voltage

	<i>Use</i>	<i>Space</i>	<i>Connector type</i>
X30	Operator unit / boiler control panel	-	AVS82.491/109
X50	Basic unit		AVS82.490/109
BX21 M	Assignment according to function Ground	n	AGP4S.02F/109
BX22 M	Assignment according to function Ground	n	AGP4S.02F/109
H2 M	Digital / DC 0...10 V input Ground	n	AGP4S.02F/109


## Assignment of terminals

The two following parameters define the usage of the respective module:


- Function extension module 1 (operating line 6020)
- Function extension module 2 (operating line 6021)

## 2.4 Operator unit AVS37.294

Mounting method  
Installation




Removal




### Connections

The AVS37.294 operator unit must be connected to terminal X30 of the basic unit using the AVS82.491/109 connecting cable. The connectors are coded.

### Ground




### Panel cutout



## 2.5 Room unit QAA55...

### Engineering




The room unit should be located in the main living room while giving consideration to the following points:

- The place of installation should be chosen so that the sensor can capture the room temperature as accurately as possible without getting adversely affected by direct solar radiation or other heat or refrigeration sources (about 1.5 meters above the floor)
- In the case of wall mounting, there must be sufficient clearance above the unit, enabling it to be fitted and removed




When the unit is removed from its base, power is cut off so that the unit is out of operation.

### Mounting method




- The controller must not be exposed to dripping water

### Connections




1	CL+	BSB data
2	CL-	BSB ground

### Dimensions and drilling plan



## 2.6 Room unit QAA75...

### Engineering




The room unit should be located in the main living room while giving consideration to the following points:

- The place of installation should be chosen so that the sensor can capture the room temperature as accurately as possible without getting adversely affected by direct solar radiation or other heat or refrigeration sources (about 1.5 meters above the floor)
- In the case of wall mounting, there must be sufficient clearance above the unit, enabling it to be fitted and removed



When the unit is removed from its base, power is cut off so that the unit is out of operation.




### Mounting method



### Connections

Terminal	Name	QAA75.610	QAA75.611
1	CL+	BSB data	BSB data
2	CL-	BSB ground	BSB ground
3	G+	Reserved	Power supply DC 12 V

## Dimensions and drilling plan



# 3 Commissioning

## Prerequisites

To commission the units, the following working steps must be carried out:

- Prerequisite is the correct mounting and correct electrical installation and, in the case of wireless solutions, correctly working radio connections to all required auxiliary units.
- Make all plant-specific settings. Special attention must be paid to operating page "Configuration". For that purpose, the relevant operating level is to be selected as follows:  
Press OK on the room unit to switch to programming.  
Press the info button for at least 3 seconds and select operating level "Commissioning" with the setting knob. Then, press OK.
- Make the functional check as described below.
- Reset the attenuated outside temperature (operating page "Diagnostics of consumers", operating line "Outside temp attenuated" (operating line 8703))
- Memorise the sensor readings by entering "YES" in parameter 6200. This step is necessary to monitor the functioning status of the sensors and to eliminate any old readings.

## Functional check

To facilitate commissioning and fault tracing, the controller allows output and input tests to be made. With these tests, the controller's inputs and outputs can be checked. To make the tests, switch to operating page "Input / output test" and go through all available setting lines.

## Operating state

The current operating state can be checked on operating page "State".


## Diagnosis

For detailed diagnostics of the plant, check operating pages "diagnostics heat source" and "diagnostics consumer".

## 3.1 Basic units

### Checking the LED

LED off:	No power supply
LED on	Ready
LED flashes	Local fault




# 4 Handling


## 4.1 QAA75.. / QAA78... / AVS37..

### 4.1.1 Operation

Operating elements  
Type of room unit



Operator unit





- Protective functions active
- Automatic summer / winter changeover (ECO functions) and automatic 24-hour heating limit active

### Selection of cooling mode

The "Cooling" mode is selected by use of the Cooling button. The choice made is indicated by a bar which appears below the symbol.



#### Cooling mode

Cooling mode controls the room temperature in accordance with the time program.

Characteristics of cooling mode:

- Manual cooling mode
- Cooling mode based on time program
- Temperature setpoint based on "Comfort setpoint, cooling"
- Protective functions active
- Automatic summer/winter changeover active
- Summer compensation

### Selecting the DHW heating mode

The button is used to switch DHW heating mode on and off. The selection made is indicated by a bar which appears below the respective symbol.

#### DHW heating mode

- On

The DHW is heated according to the selected switching program.

- Off


No DHW heating, but the protective function is active.

#### DHW push

Triggering is effected by keeping the DHW operating mode button on the operator or room unit depressed for at least 3 seconds.

It can also be started when:

- The operating mode is "Off"
- Operating mode changeover acts via H1 or centrally (LPB)
- All heating circuits use the holiday function




### Adjusting the room temperature setpoint

Turn the setting knob to increase or decrease the **Comfort setpoint** .

For the **Reduced setpoint** 

- Press OK
- Select operating page "Heating circuit" and
- adjust the "Reduced setpoint"




After each readjustment, wait at least 2 hours, allowing the room temperature to adapt.

## Presence button

If you do not use the rooms for a certain period of time, you can press the presence button to reduce the room temperature, thus saving heating energy.

When the rooms are occupied again, press again the presence button to resume heating operation.




- ☀ Heating to Comfort setpoint
- ☾ Heating to Reduced setpoint



- The presence button is only active in automatic operation
- The current selection is active until the next switching action according to the heating program takes place

## Displaying information

Various data can be displayed by pressing the info button.



## Possible displays

Depending on the type of unit, configuration and operating state, some of the info lines listed below may not appear.

Display:

- Possible error messages from the error code list on page 143
- Possible service messages from the maintenance code list on page 144
- Possible special mode messages from page 144

Other displays:

- |                              |                              |
|------------------------------|------------------------------|
| - Room temperature.          | - State of DHW               |
| - Room temperature minimum   | - State of boiler            |
| - Room temperature maximum   | - State of solar             |
| - Boiler temp                | - State solid fuel boiler    |
| - Outside temperature        | - State buffer storage tank  |
| - Outside temp min           | - State swimming pool        |
| - Outside temp max           | - Date and time of day       |
| - DHW temp 1                 | - Telephone customer service |
| - State of heating circuit 1 |                              |
| - State of heating circuit 2 |                              |
| - State heating circuit P    |                              |


## Exception

In exceptional cases, the basic display shows one of the following symbols:




**Error messages**

If this symbol appears, an error in the plant has occurred. Press the info button and read further information.



**Maintenance or special operation**

If this symbol appears, a maintenance alarm is delivered or the plant has changed to special mode. Press the info button and read further information.







A list of possible displays is given on page 142.

### Reset function

The reset function for meters and the resettable parameters appears on the bottom line of the display, provided a reset is permitted on the current operating line (end user / commissioning / heating engineer).



After activation with the OK button, the display will show a flashing "Yes".



After confirmation with the OK button, the relevant parameter or counter will be reset.

### Manual operation

When manual operation is active, the relays are no longer energized and deenergized according to the control state, but are set to a predefined manual operation state depending on their function.

The burner relay energized in manual control can be deenergized by the electronic temperature controller (TR).

Setpoint adjustment in manual control

After manual control has been activated, a change to the basic display must be made. There, the maintenance / special mode symbol  appears. Press the info button to switch to info display "Manual mode", where the setpoint can be adjusted.

### Chimney sweep function

The chimney sweep function is activated by a short press (maximum 3 seconds) on the chimney sweep button. This function produces the operating state required to make emission measurements (flue gas).

SLT test

The SLT test (SLT = safety limit thermostat) is activated by a long press (longer than 3 seconds) on the chimney sweep button. The button must be kept depressed during the entire test. If released, the test will be aborted. The SLT test is shown on the display.



The test may only be made by qualified staff since the boiler temperature will be raised above the maximum limits.

## 4.1.2 Programming





### Setting principle



Settings that cannot be made directly with the operating elements require programming. For this purpose, the individual settings are structured in the form of operating pages and operating lines, thus forming practical groups of settings. The following example shows how to set the time of day and the date.

#### Example: “Setting the time of day“




- Press *ESC* to go one step back at a time, readjusted values are not be adopted
- If no setting is made for 8 minutes, the display returns automatically to the basic display
- Operating lines may be hidden, depending on the type of controller, the configuration made and the user level

Operation	Display example	Description
<p>1</p> 		<p>Basic display. If the basic display is not shown, press the <i>ESC</i> button to return to it.</p> <p>Press <i>OK</i>.</p>
<p>2</p> 		<p>The bottom section of the display shows a number of operating pages. Turn the setting knob until operating page <i>Time of day and date</i> appears.</p> <p>Press <i>OK</i> to confirm.</p>
<p>3</p> 		<p>In the bottom section of the display, the first operating line of operating page <i>Time of day and date</i> appears. Turn the setting knob until operating line <i>Hours / minutes</i> appears.</p> <p>To confirm, press <i>OK</i>.</p>
<p>4</p> 		<p>The display shows the hours flashing. Turn the setting knob until the hours of the time of day are correct.</p> <p>To confirm, press <i>OK</i>.</p>

- 5  The display shows the minutes flashing. Turn the setting knob until the minutes of the time of day are correct. To confirm, press OK.
- 6  The settings are saved and the displays stops flashing. Now, you can make further settings or you press the operating mode button to return to the basic display.
- 7  Now, you see the basic display again.







Example of menu structure




2359Z139

### 4.1.3 User levels

The user levels only allow authorized user groups to make settings. To reach the required user level, proceed as follows:

Operation	Display example	Description
1 		Basic display. If the basic display is not shown, press the ESC button to return to it.  Press OK.
2 		You are on the user level <i>End user</i> .  Press INFO for 3 seconds.
3 		You are now given a choice of user levels. Turn the setting knob until the required user level is reached.  Press OK.




You are now on the required user level.

To reach the OEM level, the relevant code must be entered.


### Setting the structure "End user"

The example given here shows that certain user levels do not allow certain settings to be made. The example shows them highlighted. On the unit, they are hidden.



2359Z139

### Setting the structure "Heating engineer"




2359Z139

## 4.2 QAA55...

### 4.2.1 Operation

#### Operating elements



#### Display options

- |   |  |
|---|--|
|  Heating to Comfort setpoint |  Burner operating (only oil / gas boiler) |
|  Heating to Reduced setpoint |  Error messages                           |

#### Display

Display of all displayable symbols and segments.



Example of basic display:



#### Selection of space heating mode

This setting is used to switch between the different operating modes. The selection made is indicated by a bar which appears below the respective symbol.



#### Automatic mode

Automatic mode controls the room temperature according to the time program.

Characteristics of automatic mode:

- Heating mode according to the time program
- Temperature setpoints according to the heating program "Comfort setpoint"  or "Reduced setpoint" 
- Protective functions active
- Automatic summer / winter changeover (ECO functions)

## Continuous operation ☀ or ☾

Continuous operation maintains the room temperature at the selected operating level.

- ☀ Heating to Comfort setpoint
- ☾ Heating to Reduced setpoint

Characteristics of continuous operation:

- Heating mode with no time program
- Protective functions active
- Automatic summer / winter changeover (ECO functions) and 24-hour heating limit inactive in the case of continuous operation with Comfort setpoint

## Protection ⏻

When using Protection, the heating system is off. However, it remains protected against frost (frost protection temperature) provided there is no power failure.

Characteristics of Protection:


- Heating off
- Temperature according to frost protection
- Protective functions active
- Automatic summer / winter changeover (ECO functions) and automatic 24-hour heating limit active

## Adjusting the room temperature setpoint

Turn the setting knob to increase or decrease the **Comfort setpoint** ☀.

For the **Reduced setpoint** ☾

- Press OK
- Select operating page “Heating circuit” and
- adjust the “Reduced setpoint”



After each readjustment, wait at least 2 hours, allowing the room temperature to adapt.

## Presence button

If you do not use the rooms for a certain period of time, you can press the presence button to reduce the room temperature, thus saving heating energy.

When the rooms are occupied again, press again the presence button to resume heating operation.



- ☀ Heating to Comfort setpoint
- ☾ Heating to Reduced setpoint



- The presence button is only active in automatic operation
- The current selection is active until the next switching action according to the heating program takes place

## 4.2.2 Programming

### Configuration

#### Settings

#### Used as

A long press on the presence button enables the service level to be accessed.

ru = 1 (factory setting)

The room unit is addressed as room unit 1

ru = 2

The room unit is addressed as room unit 2

ru = 3

The room unit is addressed as room unit 3

#### Direct adjustment

P1 = 1 (factory setting)

Automatic storage:

A setpoint readjustment with the knob is adopted either by pressing the operating mode button or without any further confirmation (timeout).

P1 = 2

Storage with confirmation:

A setpoint readjustment with the knob is adopted only after pressing the operating mode button.

## 4.3 Overview of settings

The table shows all available settings up to the heating engineer level. However, certain operating lines may be hidden, depending on the type of unit.

Legend

E = End user I = Commissioning F = Heating engineer

BZ = Operating line

(\*) QAA7X.. only

(\*\*) RVS43.. only

(\*\*\*) RVS63.. only

Operating line	User level	Function	Default value	Min	Max	Unit
<b>Time of day and date</b>						
1	E	Hours / minutes	-	00:00	23:59	hh:mm
2	E	Day/month	-	01.01	31.12	dd.MM
3	E	Year	-	2004	2099	yyyy
5	F	Start of summertime	25.03	01.01	31.12	dd.MM
6	F	End of summertime	25.10	01.01	31.12	dd.MM
<b>Operator unit</b>						
20	E	Language German   ...	German			-
21	O	Display special operation Off   On	On			
22	F	Info Temporarily   Permanently	Temporarily			-
26	F	Operation lock Off   On	Off			-
27	F	Programming lock Off   On	Off			-
28	I	Direct adjustment Automatic storage   Save with acknowledgment	Save with acknowledgment			
30	O	Save basic settings No   Yes	No			
31	O	Activate basic settings No   Yes	No			
40 (*)	I	Used as Room unit 1   Room unit 2   Room unit P   Operator unit 1   Operator unit 2   Operator unit P   Service unit	Room unit 1			-
42 (*)	I	Assignment device 1 Heating circuit 1   Heating circuits 1 and 2   Heating circuits 1 and P   All heating circuits	Heating circuit 1			-
44	I	Operation HC2 Commonly with HC1   Independently	Commonly with HC1			-
46	I	Operation HCP Commonly with HC1   Independently	Commonly with HC1			-
48 (*)	I	Action occupancy button None   Heating circuit 1   Heating circuit 2   Commonly	Heating circuit 1			-
54 (*)	F	Readjustment room sensor	0.0	-3	3	°C
70	F	Software version	-	0	99.9	-
<b>Time prog heating circuit 1</b>						

Operating line	User level	Function	Default value	Min	Max	Unit
500	E	Preselection Mo - Su   Mo - Fr   Sa - Su   Mo   Tu   We   Th   Fr   Sa   Su	Mo - Su			-
501	E	1st phase on	6:00	00:00	24:00	hh:mm
502	E	1st phase off	22:00	00:00	24:00	hh:mm
503	E	2nd phase on	24:00	00:00	24:00	hh:mm
504	E	2nd phase off	24:00	00:00	24:00	hh:mm
505	E	3rd phase on	24:00	00:00	24:00	hh:mm
506	E	3rd phase off	24:00	00:00	24:00	hh:mm
516	E	Default values No   Yes	No			-
<b>Time prog heating circuit 2</b>						
520	E	Preselection Mo - Su   Mo - Fr   Sa - Su   Mo   Tu   We   Th   Fr   Sa   Su	Mo - Su			-
521	E	1st phase on	6:00	00:00	24:00	hh:mm
522	E	1st phase off	22:00	00:00	24:00	hh:mm
523	E	2nd phase on	24:00	00:00	24:00	hh:mm
524	E	2nd phase off	24:00	00:00	24:00	hh:mm
525	E	3rd phase on	24:00	00:00	24:00	hh:mm
526	E	3rd phase off	24:00	00:00	24:00	hh:mm
536	E	Default values No   Yes	No			-
<b>Time program 3/HCP</b>						
540	E	Preselection Mo - Su   Mo - Fr   Sa - Su   Mo   Tu   We   Th   Fr   Sa   Su	Mo - Su			-
541	E	1st phase on	6:00	00:00	24:00	hh:mm
542	E	1st phase off	22:00	00:00	24:00	hh:mm
543	E	2nd phase on	24:00	00:00	24:00	hh:mm
544	E	2nd phase off	24:00	00:00	24:00	hh:mm
545	E	3rd phase on	24:00	00:00	24:00	hh:mm
546	E	3rd phase off	24:00	00:00	24:00	hh:mm
556	E	Default values No   Yes	No			-
<b>Time program 4/DHW</b>						
560	E	Preselection Mo - Su   Mo - Fr   Sa - Su   Mo   Tu   We   Th   Fr   Sa   Su	Mo - Su			-
561	E	1st phase on	6:00	00:00	24:00	hh:mm
562	E	1st phase off	22:00	00:00	24:00	hh:mm
563	E	2nd phase on	24:00	00:00	24:00	hh:mm
564	E	2nd phase off	24:00	00:00	24:00	hh:mm
565	E	3rd phase on	24:00	00:00	24:00	hh:mm

Operating line	User level	Function	Default value	Min	Max	Unit
566	E	3rd phase off	24:00	00:00	24:00	hh:mm
576	E	Default values No   Yes	No			-
<b>Time program 5</b>						
600	E	Preselection Mo - Su   Mo - Fr   Sa - Su   Mo   Tu   We   Th   Fr   Sa   Su	Mo - Su			-
601	E	1st phase on	6:00	00:00	24:00	hh:mm
602	E	1st phase off	22:00	00:00	24:00	hh:mm
603	E	2nd phase on	24:00	00:00	24:00	hh:mm
604	E	2nd phase off	24:00	00:00	24:00	hh:mm
605	E	3rd phase on	24:00	00:00	24:00	hh:mm
606	E	3rd phase off	24:00	00:00	24:00	hh:mm
616	E	Default values No   Yes	No			-
<b>Holidays heating circuit 1</b>						
641	E	Preselection Period 1   Period 2   Period 3   Period 4   Period 5   Period 6   Period 7   Period 8	Period 1			-
642	E	Start	--	01.01	31.12	dd.mm
643	E	End	--	01.01	31.12	dd.mm
648	E	Operating level Frost protection   Reduced	Frost protection			-
<b>Holidays heating circuit 2</b>						
651	E	Preselection Period 1   Period 2   Period 3   Period 4   Period 5   Period 6   Period 7   Period 8	Period 1			-
652	E	Start	--	01.01	31.12	dd.mm
653	E	End	--	01.01	31.12	dd.mm
658	E	Operating level Frost protection   Reduced	Frost protection			-
<b>Holidays heating circuit P</b>						
661	E	Preselection Period 1   Period 2   Period 3   Period 4   Period 5   Period 6   Period 7   Period 8	Period 1			-
662	E	Start	--	01.01	31.12	dd. mm
663	E	End	--	01.01	31.12	dd.mm
668	E	Operating level Frost protection   Reduced	Frost protection			-
<b>Heating circuit 1</b>						
710	E	Comfort cooling setpoint	20.0	Operating line 712	Operating line 716	°C
712	E	Reduced setpoint	16	Operating line 714	Operating line 710	°C
714	E	Frost protection setpoint	10.0	4	Operating line 712	°C
716	F	Comfort setpoint maximum	35.0	Operating line 710	35	°C

Operating line	User level	Function	Default value	Min	Max	Unit
720	E	Heating curve slope	1.50	0.10	4.00	-
721	F	Heating curve displacement	0.0	-4.5	4.5	°C
726	F	Heating curve adaption Off ; On	Off			-
730	E	Summer/winter heating limit	18	--- / 8	30	°C
732	F	24-hour heating limit	-3	--- / - 10	10	°C
740	I	Flow temp setpoint min	8	8	Operating line 741	°C
741	I	Flow temp setpoint max	80	Operating line 740	95	°C
750	F	Room influence	20	--- / 1	100	%
760	F	Room temp limitation	1	--- / 0.5	4	°C
770	F	Boost heating	5	--- / 0	20	°C
780	F	Quick setback Off ; Down to reduced setpoint ; Down to frost prot setp	Down to reduced setpoint			-
790	F	Optimum start control max	0	0	360	min
791	F	Optimum top control max	0	0	360	min
800	F	Reduced setp increase start	---	--- / - 30	10	°C
801	F	Reduced setp increase end	-15	-30	Operating line 800	°C
820	F	Overtemp prot pump circuit Off ; On	On			-
830	F	Mixing valve boost	5	0	50	°C
832	F	Actuator type 2-position ; 3-position	3-position			-
833	F	Switching differential 2-pos	2	0	20	°C
834	F	Actuator running time	120	30	873	s
835	O	Mixing valve Xp	32	1	100	°C
836	O	Mixing valve Tn	120	10	873	s
850	I	Floor curing function Off ; Functional heating ; Curing heating ; Functional/ curing heating ; Curing/functional heating ; Manually	Off			-
851	I	Floor curing setp manual	25	0	95	°C
861	F	Excess heat draw Off ; Heating mode ; Always	Always			-
870	F	With buffer storage tank No ; Yes	Yes			-
872	F	With primary controller / system pump No ; Yes	Yes			-
882 (***)	F	Pump speed min	100	0	100	%
883 (***)	F	Pump speed max	100	0	100	%
900	F	Optg mode changeover None ! Protection ! Reduced ! Comfort !	Protection mode			-

Operating line	User level	Function	Default value	Min	Max	Unit
		Automatic				
<b>Cooling circuit 1</b>						
901 (**)	E	Operating mode Off   Automatic	Automatically			-
902 (**)	E	Comfort cooling setpoint	24.0	15	40	°C
907 (**)	E	release 24h/day   Time programs HCs   Time program 5	24 h/day			-
908 (**)	I	Flow setpoint at OT 25°C	20	8	35	°C
909 (**)	I	Flow setpoint at OT 35°C	16	8	35	°C
912 (**)	I	Cooling limit at OT (outside temperature)	20	--- / 8	355	°C
913 (**)	F	Locking period at end of heating	24	--- / 8	100	h
918 (**)	F	Start of summer compensation at OT	26	20	35	°C
919 (**)	F	End of summer compensation at OT	35	20	35	°C
920 (**)	F	Summer compensation setpoint increase	4	--- / 1	10	°C
923 (**)	I	Flow setpoint min. OT 25°C	18	8	35	°C
924 (**)	I	Flow setpoint min. OT 35°C	18	8	35	°C
928 (**)	F	Room influence	80	--- / 1	10	%
932 (**)	F	Room temp limitation	0.5	--- / 0.5	4	°C
938 (**)	F	Mixing valve subcooling	0	0	20	°C
939 (**)	F	Actuator type 2-position   3-position	3-position			
940 (**)	F	Switching differential 2-pos	2	0	20	°C
941 (**)	F	Actuator running time	120	30	873	s
942 (**)	O	Mixing valve Xp	12	1	100	°C
943 (**)	O	Mixing valve Tn	90	10	873	s
945 (**)	F	Mixing valve in heating mode Control   Open	Controls			
946 (**)	F	Dewpt monitor locking time	60	--- / 10	600	min
947 (**)	F	Flow setpt increase hygro	3	--- / 1	10	°C
948 (**)	F	Start flow increase at R.H.	60	0	100	%
950 (**)	I	Flow temp diff dewpoint	2	--- / 0	10	°C
962 (**)	F	With buffer storage tank No   Yes	No			
963 (**)	F	With primary controller / system pump No   Yes	No			
969 (**)	I	Optg mode changeover None   Off   Automatic	Off			
<b>Heating circuit 2</b>						
1010	E	Comfort cooling setpoint	20.0	Op line 1012	Operating line 1016	°C
1012	E	Reduced setpoint	16	Op line 1014	Operating line 1010	°C

Operating line	User level	Function	Default value	Min	Max	Unit
1014	E	Frost protection setpoint	10.0	4	Operating line 1012	°C
1016	F	Comfort setpoint maximum	35.0	Op line 1010	35	°C
1020	E	Heating curve slope	1.50	0.10	4.00	-
1021	F	Heating curve displacement	0.0	-4.5	4.5	°C
1026	F	Heating curve adaption Off   On	Off			-
1030	E	Summer/winter heating limit	18	--- / 8	30	°C
1032	F	24-hour heating limit	-3	--- / -10	10	°C
1040	I	Flow temp setpoint min	8	8	Operating line 1041	°C
1041	I	Flow temp setpoint max	80	Op line 1040	95	°C
1050	F	Room influence	20	--- / 1	100	%
1060	F	Room temp limitation	1	--- / 0.5	4	°C
1070	F	Boost heating	5	--- / 0	20	°C
1080	F	Quick setback Off   Down to reduced setpoint   Down to frost prot setp	Down to reduced setpoint			-
1090	F	Optimum start control max	0	0	360	min
1091	F	Optimum top control max	0	0	360	min
1100	F	Reduced setp increase start	---	--- / -30	10	°C
1101	F	Reduced setp increase end	-15	-30	Operating line 1100	°C
1120	F	Overtemp prot pump circuit Off   On	On			-
1130	F	Mixing valve boost	5	0	50	°C
1132	F	Actuator type 2-position   3-position	3-position			-
1133	F	Switching differential 2-pos	2	0	20	°C
1134	F	Actuator running time	120	30	873	s
1135	O	Mixing valve Xp	32	1	100	°C
1136	O	Mixing valve Tn	120	10	873	s
1150	F	Floor curing function Off   Functional heating   Curing heating   Functional/curing heating   Curing/functional heating   Manually	Off			-
1151	F	Floor curing setp manual	25	0	95	°C
1161	F	Excess heat draw Off   Heating mode   Always	Always			
1170	F	With buffer storage tank No   Yes	Yes			-
1172	F	With primary controller / system pump No	Yes			

Operating line	User level	Function	Default value	Min	Max	Unit
		Yes				
1182 (***)	F	Pump speed min	100	0	100	%
1183 (***)	F	Pump speed max	100	0	100	%
1200	F	Optg mode changeover None   Protection   Reduced   Comfort   Automatic	Protection mode			
<b>Heating circuit P</b>						
1300	E	Operating mode Protection   Automatic   Reduced   Comfort	Automatically			-
1310	E	Comfort cooling setpoint	20.0	Op line 1312	Op line 1316	°C
1312	E	Reduced setpoint	16	Op line 1314	Op line 1310	°C
1314	E	Frost protection setpoint	10.0	4	Op line 1312	°C
1316	F	Comfort setpoint maximum	35.0	Op line 1310	35	°C
1320	E	Heating curve slope	1.50	0.10	4.00	-
1321	F	Heating curve displacement	0.0	-4.5	4.5	°C
1326	F	Heating curve adaption Off   On	Off			-
1330	E	Summer/winter heating limit	18	--- / 8	30	°C
1332	F	24-hour heating limit	-3	--- / - 10	10	°C
1340	F	Flow temp setpoint min	8	8	Op line 1341	°C
1341	F	Flow temp setpoint max	80	Op line 1340	95	°C
1350	F	Room influence	20	--- / 1	100	%
1360	F	Room temp limitation	1	--- / 0.5	4	°C
1370	F	Boost heating	5	--- / 0	20	°C
1380	F	Quick setback Off   Down to reduced setpoint   Down to frost prot setp	Down to reduced setpoint			-
1390	F	Optimum start control max	0	0	360	min
1391	F	Optimum top control max	0	0	360	min
1400	F	Reduced setp increase start	---	--- / - 30	10	°C
1401	F	Reduced setp increase end	-15	-30	Op line 1400	°C
1420	F	Overtemp prot pump circuit Off   On	On			-

Operating line	User level	Function	Default value	Min	Max	Unit
1450	I	Floor curing function Off ; Functional heating ; Curing heating ; Functional/ curing heating ; Curing/functional heating ; Manually	Off			-
1451	I	Floor curing setp manual	25	0	95	°C
1455	F	Floor curing setp current	0	0	95	°C
1456	F	Floor curing day current	0	0	32	
1457 (**)	F	Floor curing days complete	0	0	32	
1461	F	Excess heat draw Off ; Heating mode ; Always	Always			
1470	F	With buffer storage tank No ; Yes	Yes			-
1472	F	With primary controller / system pump No ; Yes	Yes			
1482 (**)	F	Pump speed min	100	0	100	%
1483 (**)	F	Pump speed max	100	0	100	%
1500	F	Optg mode changeover None ; Protection ; Reduced ; Comfort ; Automatic	Protection mode			
<b>DHW</b>						
1610	E	Nominal setpoint	55	Op line 1612	BZ 1614 OEM	°C
1612	F	Reduced setpoint	40	8	Op line 1610	°C
1614	O	Nominal setpoint max	65	8	80	°C
1620	O	Release 24h/day ; Time programs HCs ; Time program 4/DHW	Time programs HCs			-
1630	I	Charging priority Absolute ; Shifting ; None ; MC shifting, PC absolute	MC shifting, PC absolute			-
1640	F	Legionella function Off ; Periodically ; Fixed weekday	Fixed weekday			-
1641	F	Legionella funct periodically	3	1	7	Days
1642	F	Legionella funct weekday Monday ; Tuesday ; Wednesday ; Thursday ; Friday ; Saturday ; Sunday	Monday			
1644	F	Legionella function time	- - -	- - - / 00:00	23:50	hh:mm
1645	F	Setpoint of Legionella function	65	55	95	°C
1646	F	Legionella function dwelling time	30	- - - / 10	360	min
1647	F	Legionella funct circ pump Off ; On	On			-
1660	F	Circulating pump release Time program 3/HCP ; DHW release ; Time program 4/DHW ; Time program 5	DHW release			-
1661	F	Circulating pump cycling Off ; On	On			-
1663	F	Circulation setpoint	45	8	80	°C
<b>Pumps H</b>						
2008	O	H1 DHW charging priority No ; Yes	Yes			

Operating line	User level	Function	Default value	Min	Max	Unit
2010	F	H1 Excess heat draw Off   On	On			
2012	F	H1 with buffer storage tank No   Yes	Yes			-
2014	F	H1 prim contr/system pump No   Yes	Yes			-
2015 (**)	F	H1 Refrig demand 2-pipe system   4-pipe system	2-pipe system			
2033	O	H2 DHW charging priority No   Yes	Yes			
2035	F	H2 Excess heat draw Off   On	On			
2037	F	H2 with buffer storage tank No   Yes	Yes			-
2039	F	H2 prim contr/system pump No   Yes	Yes			-
2040 (**)	F	H2 Refrig demand 2-pipe system   4-pipe system	2-pipe system			
2044 (***)	O	H3 DHW charging priority No   Yes	Yes			
2046 (***)	F	H3 Excess heat draw Off   On	On			
2048 (***)	F	H3 with buffer No   Yes	Yes			
2050 (***)	F	H2 prim contr/system pump No   Yes	Yes			
<b>Swimming pool</b>						
2055	F	Setpoint solar heating	26	8	80	°C
2056	F	Setpoint source heating	22	8	80	°C
2065	F	Charging priority solar No   Yes	No			
2070	O	Swimming pool temp max	32	8	95	°C
2080	F	With solar integration No   Yes	Yes			
<b>Primary controller / system pump</b>						
2110	O	Flow temp setpoint min	8	8	95	°C
2111	O	Flow temp setpoint max	80	8	95	°C
2112	O	Flow setpoint, cooling min	8	8	20	°C
2130	O	Mixing valve boost	10	0	50	°C
2131	O	Mixing valve subcooling	0	0	20	°C
2132	O	Actuator type 2-position   3-position	3-position			
2133	O	Switching differential 2-pos	2	0	20	°C
2134	O	Actuator running time	120	30	873	s
2135	O	Mixing valve Xp	32	1	100	°C
2136	O	Mixing valve Tn	120	10	873	s
2150	I	Primary controller / system pump Before buffer st tank   After buffer st tank	After buffer st tank			-
<b>Boiler</b>						
2200	O	Operating mode Continuous operation   Automatic   Auto.	Automatically			

Operating line	User level	Function	Default value	Min	Max	Unit
		extended running time				
2203	F	Release below outside temp	---	--- / - 50	50	°C
2205	F	Economy mode Off   On DHW   On	Off			
2208	O	Full charging buffer Off   On	Off			
2210	F	Setpoint min	40	Op line 2211 OEM	Setpoint manual op eration	°C
2211	O	Setpoint min OEM	40	8	95	°C
2212	F	Setpoint max	80	Setpoint manual o peration	Op line 2213 OEM	°C
2213	O	Setpoint max OEM	85	8	120	°C
2220 (***)	O	Release integral stage 2	50	0	500	°C min
2221 (***)	O	Reset integral stage 2	10	0	500	°C min
2232 (***)	O	Damper actuator running time	60	7.5	480	s
2233 (***)	O	Modulating Xp	20	1	200	°C
2234 (***)	O	Modulating Tn	150	10	873	s
2235 (***)	O	Modulating Tv	4.5	0	30	s
2240	O	Switching differential of the boiler	8	0	20	°C
2241	O	Burner running time min	4	0	20	min
2250	O	Pump overrun time	5	0	20	min
2260	O	Prot boil startup consumers Off   On	On			
2261	O	Prot boil startup boiler pump Off   On	On			
2262	O	Optimum start control Off   On	Off			
2270	F	Return setpoint min	8	8	95	°C
2271	O	Return setpoint min OEM	8	8	95	°C
2272	O	Return influence consumers Off   On	On			
2282	O	Actuator running time	120	30	873	s
2283	O	Mixing valve Xp	32	1	100	°C
2284	O	Mixing valve Tn	120	10	873	s
2285	O	Mixing valve Tv	10	0	60	s
2290	O	Switching differential bypass pump	6	0	20	°C
2291	O	Control bypass pump Parallel burner operation   Return temp	Return temperature			
2300	O	Frost prot plant boiler pump Off   On	Off			
2310	O	Limit thermostat function Off   On	On			
2315	O	Temp differential min	---	--- / 0	80	°C

Operating line	User level	Function	Default value	Min	Max	Unit
2316	O	Temp differential max	---	--- / 0	80	°C
2322 (***)	O	Pump speed min	40	0	100	%
2323 (***)	O	Pump speed max	100	0	100	%
2324 (***)	O	Speed Xp	32	1	100	°C
2325 (***)	O	Speed Tn	120	10	873	s
2326 (***)	O	Speed Tv	10	0	60	s
2330	F	Output nominal	50	0	1000	kW
2331	F	Output of basic stage	30	0	1000	kW
2340 (***)	F	Auto source seq 2x1 casc	500	--- / 10	990	h
<b>Cascade</b>						
3510	O	Lead strategy Late on, early off   Late on, late off   Early on, late off	Late on, late off			
3511	O	Output band min	40	0	100	%
3512	O	Output band max	90	0	100	%
3530	O	Release integral source seq	50	0	500	°C min
3531	O	Reset integral source seq	20	0	500	°C min
3532	F	Restart lock	300	0	1800	s
3533	F	Switch-on delay	5	0	120	min
3534	O	Forced time basic stage	60	0	1200	s
3540	F	Auto source seq ch'over	500	--- / 10	990	h
3541	F	Auto source seq exclusion None   First   Last   First and last	None			
3544	F	Leading source S ource 1   Source 2   ...   Source 16	Source 1			
3550	O	Prot startup cascade pump Off   On	On			
3560	F	Return setpoint min	8	8	95	°C
3561	O	Return setpoint min OEM	8	8	95	°C
3562	O	Return influence consumers Off   On	On			
3570	O	Actuator running time	120	30	873	s
3571	O	Mixing valve Xp	32	1	100	°C
3572	O	Mixing valve Tn	120	10	873	s
3590	O	Temp differential min	---	--- / 0	20	°C
<b>Solar</b>						
3810	F	Temp diff on	8	0	40	°C
3811	F	Temp diff off	4	0	40	°C
3812	F	Charg temp min DHW st tank	---	--- / 8	95	°C
3813	O	Temp diff on buffer	---	--- / 0	40	°C
3814	O	Temp diff off buffer	---	--- / 0	40	°C
3815	F	Charging temp min buffer	---	--- / 8	95	°C

Operating line	User level	Function	Default value	Min	Max	Unit
3816	O	Temp diff on swi pool	---	--- / 0	40	°C
3817	O	Temp diff off swi pool	---	--- / 0	40	°C
3818	F	Charging temp min swi pool	---	--- / 8	95	°C
3822	F	Charging prio storage tank None   DHW storage tank   Buffer	DHW storage tank			
3825	F	Charging time relative prio	---	--- / 2	60	min
3826	F	Waiting time relative prio	5	1	40	min
3827	F	Waiting time parallel op	---	--- / 0	40	min
3828	F	Delay secondary pump	60	0	600	s
3830	O	Collector start function	---	--- / 5	60	min
3831	F	Min run time collector pump	20	5	120	s
3832	O	Collector start function on	07:00	00:00	23:50	hh:mm
3833	O	Collector start function off	19:00	00:00	23:50	hh:mm
3834	F	Collector start funct gradient	---	--- / 1	20	min/°C
3840	F	Collector frost protection	---	--- / -20	5	°C
3850	F	Collector overtemp prot	---	--- / 30	350	°C
3860	F	Evaporation heat carrier	---	--- / 60	350	°C
3870 (***)	F	Pump speed min	40	0	100	%
3871 (***)	F	Pump speed max	100	0	100	%
3872 (***)	O	Speed Xp	32	1	100	°C
3873 (***)	O	Speed Tn	120	10	873	s
3880	F	Antifreeze None   Ethylen glycol     Propylene glycol   Etyl and propyl glycol	None			
3881	F	Antifreeze concentration	30	1	100	%
3884	F	Pump capacity	200	10	1500	l/h
<b>Solid fuel boiler</b>						
4102	F	Locking other heat sources Off   On	On			
4110	F	Setpoint min	40	8	120	°C
4130	F	Temp diff on	8	1	40	°C
4131	F	Temp diff off	4	0	40	°C
4133	F	Comparative temp DHW sensor B3   DHW sensor B31   Buff st tank sensor B4   Buff st tank sensor B41   Flow temp setpoint   Setpoin min	Setpoint min			
4140	O	Pump overrun time	20	0	120	min
4141	O	Excess heat discharge	90	60	140	°C
4170	O	Frost prot plant boiler pump Off   On	Off			
<b>Buffer storage tank</b>						
4720	F	Auto generation lock None   With B4   With B4 and B42/B41	With B4			-

Operating line	User level	Function	Default value	Min	Max	Unit
4721	O	Auto heat generation lock SD	8	0	20	°C
4722	F	Temp diff buffer/HC	-5	-20	20	°C
4723 (**)	F	Temp diff buffer/CC	0	-20	20	°C
4724	F	Min st tank temp heat mode	---	--- / 8	95	°C
4726 (**)	F	Max stor temp cooling mode	25	--- / 10	40	°C
4739 (**)	F	Stratification protection Off   Always   With solid fuel boiler	Off			
4740 (**)	O	Stratif prot temp diff max	5	0	20	°C
4743 (**)	O	Stratiprot anticipation time	60	0	240	s
4744 (**)	O	Strat prot integr action time	120	10	200	s
4746 (**)	O	DHW protection combined Off   On	Off			
4750	F	Charging temperature max	80	8	95	°C
4751	O	Storage tank temp max	90	8	95	°C
4755	F	Recooling temp	60	8	95	°C
4756	F	Recooling DHW/HCs Off   On	Off			
4757	F	Recooling collector Off   Summer   Always	Off			
4783	F	With solar integration No   Yes	No			
4790	F	Temp diff ON return div	10	0	40	°C
4791	F	Temp diff OFF return div	5	0	40	°C
4795	F	Compar temp return div B4   B41   B42	B42			
4796	F	Optg action return diversion Temp decrease   Temp increase	Temp increase			
4800	F	Partial charging setpoint	---	--- / 8	95	°C
4810	O	Full charging Off   Heating mode   Always	Off			
4811	O	Full charging temp min	8	8	80	°C
4813	O	Full charging sensor With B4   With B42/B41	With B42/B41			
<b>DHW storage tank</b>						
5010	O	Charging Once/day   Several times/day	Several times / day			
5020	F	Flow setpoint boost	16	0	30	°C
5021	F	Increase of transfer boost	8	0	30	°C
5022	F	Type of charging with B3   With B3 and B31   Legio B3 and B31	With B3 and B31			
5024	O	Switching differential	5	0	20	°C
5030	O	Charging time limitation	150	--- / 10	600	min
5040	O	Discharging protection Off   Always   Automatically	Automatically			
5050	F	Charging temperature max	80	8	BZ 5051 OEM	°C

Operating line	User level	Function	Default value	Min	Max	Unit
5051	O	Storage tank temp max	90	8	95	°C
5055	F	Recooling temp	80	8	95	°C
5056	F	Recooling heat gen/HCs Off   On	Off			-
5057	F	Recooling collector Off   Summer   Always	Off			-
5060	F	electric immersion heater:operating mode Substitute   Summer   Always	Substitute			-
5061	F	Electric immersion heater release 24h/day   DHW release  Time program4/ DHW	DHW release			-
5062	F	EI immersion heater control External thermostat   DHW sensor	DHW sensor			-
5070	O	Automatic push Off   On	On			
5071	O	Charging prio time push	0	0	120	min
5085	F	Excess heat draw Off   On	On			-
5090	F	With buffer storage tank No   Yes	No			
5092	F	With primary controller / system pump No   Yes	No			
5093	F	With solar integration No   Yes	Yes			
5101 (***)	F	Pump speed min	40	0	100	%
5102 (***)	F	Pump speed max	100	0	100	%
5103 (***)	O	Speed Xp	32	1	100	%
5104 (***)	O	Speed Tn	120	10	873	s
5120	O	Mixing valve boost	2	0	50	°C
5124	O	Actuator running time	120	30	873	s
5125	O	Mixing valve Xp	32	1	100	°C
5126	O	Mixing valve Tn	120	10	873	s
5130	O	Transfer strategy Always   DHW release	Always			
5131	O	Comparison temp transfer DHW sensor B3   DHW sensor B31	DHW sensor B3			
<b>Instantaneous DHW heater</b>						
5406	F	Min setp diff to tank temp	4	0	20	°C
5544	F	Actuator running time	60	7.5	480	s
5545	O	Mixing valve Xp	20	1	200	°C
5546	O	Mixing valve Tn	150	10	873	s
5547	O	Mixing valve Tv	4.5	0	30	s
<b>Configuration</b>						
5710	I	Heating circuit 1 Off   On	On			-
5711 (**)	I	Cooling circuit 1 Off   4-pipe system   2-pipe system				
5712 (**)	I	Use of mixing valve 1 Heating   Cooling   Heating and cooling	Heating and cooling			

Operating line	User level	Function	Default value	Min	Max	Unit
5715	I	Heating circuit 2 Off ; On	Off			-
5730	I	DHW sensor B3 Sensor ; Thermostat	Sensors			-
5731	I	DHW control element Q3 None ; Charging pump ; Diverting valve	Charging pump			-
5736	I	Separate circuit Off ; On	Off			-
5770	I	Source type 1-stage ; 2-stage <sup>6)</sup> ; Modulating 3-position (***) ; Modulating UX <sup>6)</sup> ; Without boiler sensor ; 2x1 cascade <sup>6)</sup>	1-stage (**) 2-stage (***)			-
5840	I	Solar controlling element Charging pump ; Diverting valve	Charging pump			
5841	I	External solar exchanger Jointly ; DHW storage tank ; Buffer <sup>6)</sup>	Jointly			
5890	I	Relay output QX1 None ; Circulating pump Q4 ; El imm heater DHW K6 ; Collector pump Q5 ; H1 pump Q15 ; Boiler pump Q1 ; Bypass pump Q12 ; Alarm output K10 ; 2nd pump speed HC1 Q21 ; 2nd pump speed HC2 Q22 ; 2nd pump speed HCP Q23 ; Heating circuit pump HCP Q20 ; H pump Q18 ; System pump Q14 ; Heat en shutoff valve Y4 ; Solid fuel boiler pump Q10 ; Time program 5 K13 ; Buffer return valve Y15 ; Solar pump ext exch K9 ; Solar ctrl elem buffer K8 ; Solar ctrl elem swi pool K18 ; Collector pump 2 Q16 ; H3 pump Q19 ; Flue gas relay K17 ; Assisted firing fan K30 ; Cascade pump Q25 ; St ank transfer pump Q11 ; DHW mixing pump Q35 ; DHW intern circ pump Q33 ; Heat request K27 ; Refrig. request K28 <sup>4)</sup> ; Diverting valve, cooling Y21 (**)	None			-
5891 (***)	I	Relay output QX2 None ; Circulating pump Q4 ; El imm heater DHW K6 ; Collector pump Q5 ; H1 pump Q15 ; Boiler pump Q1 ; Bypass pump Q12 ; Alarm output K10 ; 2nd pump speed HC1 Q21 ; 2nd pump speed HC2 Q22 ; 2nd pump speed HCP Q23 ; Heating circuit pump HCP Q20 ; H pump Q18 ; System pump Q14 ; Heat en shutoff valve Y4 ; Solid fuel boiler pump Q10 ; Time program 5 K13 ; Buffer return valve Y15 ; Solar pump ext exch K9 ; Solar ctrl elem buffer K8 ; Solar ctrl elem swi pool K18 ; Collector pump 2 Q16 ; H3 pump Q19 ; Flue gas relay K17 ; Assisted firing fan K30 ; Cascade pump Q25 ; St tank transfer pump Q11 ; DHW mixing pump Q35 ; DHW intern circ pump Q33 ; Heat request K27 ; Refrig. request K28 ; Air dehumidif. K29 ; Diverting valve, cooling Y21	None			-
5892 (***)	I	Relay output QX3 None ; Circulating pump Q4 ; El imm heater DHW K6 ; Collector pump Q5 ; H1 pump Q15 ; Boiler pump Q1 ; Bypass pump Q12 ; Alarm output K10 ; 2nd pump speed HC1 Q21 ; 2nd pump speed HC2 Q22 ; 2nd pump speed HCP Q23 ; Heating circuit pump HCP Q20 ; H pump Q18 ; System pump Q14 ; Heat en shutoff valve Y4 ; Solid fuel boiler pump Q10 ; Time program 5 K13 ; Buffer return valve Y15 ; Solar pump ext exch K9 ;	None			

Operating line	User level	Function	Default value	Min	Max	Unit
		Solar ctrl elem buffer K8 ; Solar ctrl elem swi pool K18 ; Collector pump 2 Q16 ; H3 pump Q19 ; Flue gas relay K17 ; Assisted firing fan K30 ; Cascade pump Q25 ; St tank transfer pump Q11 ; DHW mixing pump Q35 ; DHW intern circ pump Q33 ; Heat request K27 ; Refrig. request K28 ; Air ehumidif. K29 ; Diverting valve, cooling Y21				
5894 (***)	I	Relay output QX4 None ; Circulating pump Q4 ; El imm heater DHW K6 ; Collector pump Q5 ; H1 pump Q15 ; Boiler pump Q1 ; Bypass pump Q12 ; Alarm output K10 ; 2nd pump speed HC1 Q21 ; 2nd pump speed HC2 Q22 ; 2nd pump speed HCP Q23 ; Heating circuit pump HCP Q20 ; H pump Q18 ; System pump Q14 ; Heat en shutoff valve Y4 ; Solid fuel boiler pump Q10 ; Time program 5 K13 ; Buffer return valve Y15 ; Solar pump ext exch K9 ; Solar ctrl elem buffer K8 ; Solar ctrl elem swi pool K18 ; Collector pump 2 Q16 ; H3 pump Q19 ; Flue gas relay K17 ; Assisted firing fan K30 ; Cascade pump Q25 ; St tank transfer pump Q11 ; DHW mixing pump Q35 ; DHW intern circ pump Q33 ; Heat request K27 ; Refrig. request K28 ; Air dehumidify. K29 ; Diverting valve, cooling Y21	None			
5930	I	Sensor input BX1 None ; DHW sensor B31 ; Collector sensor B6 ; Return sensor B7 ; DHW circulation sensor B39 ; Buffer st tank sensor B4 ; Buffer st tank sensor B41 ; Flue gas temp sensor B8 ; Common flow sensor B10 ; Solid fuel boiler sensor B22 ; DHW charging sensor B36 ; Buffer sensor B42 ; Common return sensor B73 ; Cascade return sensor B70 ; Swimming pool sensor B13 ; Collector sensor 2 B61 ; Solar flow sensor B63 ; Solar return sensor B64	None			-
5931	I	Sensor input BX2 None ; DHW sensor B31 ; Collector sensor B6 ; Return sensor B7 ; DHW circulation sensor B39 ; Buffer st tank sensor B4 ; Buffer st tank sensor B41 ; Flue gas temp sensor B8 ; Common flow sensor B10 ; Solid fuel boiler sensor B22 ; DHW charging sensor B36 ; Buffer sensor B42 ; Common return sensor B73 ; Cascade return sensor B70 ; Swimming pool sensor B13 ; Collector sensor 2 B61 ; Solar flow sensor B63 ; Solar return sensor B64	None			-
5932 (***)	I	Sensor input BX3 None ; DHW sensor B31 ; Collector sensor B6 ; Return sensor B7 ; DHW circulation sensor B39 ; Buffer st tank sensor B4 ; Buffer st tank sensor B41 ; Flue gas temp sensor B8 ; Common flow sensor B10 ; Solid fuel boiler sensor B22 ; DHW charging sensor B36 ; Buffer sensor B42 ; Common return sensor B73 ; Cascade return sensor B70 ; Swimming pool sensor B13 ; Collector sensor 2 B61 ; Solar flow sensor B63 ; Solar return sensor B64	None			
5933 (***)	I	Sensor input BX4 None ; DHW sensor B31 ; Collector sensor B6 ; Return sensor B7 ; DHW circulation sensor B39 ; Buffer st tank sensor B4 ;	None			

Operating line	User level	Function	Default value	Min	Max	Unit
		Buffer st tank sensor B41 ; Flue gas temp sensor B8 ; Common flow sensor B10 ; Solid fuel boiler sensor B22 ; DHW charging sensor B36 ; Buffer sensor B42 ; Common return sensor B73 ; Cascade return sensor B70 ; Swimming pool sensor B13 ; Collector sensor 2 B61 ; Solar flow sensor B63 ; Solar return sensor B64				
5950	I	Function of input H1 Optg mode changeover HCs + DHW ; Optg mode changeover HCs ; Optg mode changeover HC1 ; Optg mode changeover HC2 ; Optg mode changeover HCP ; Heat generation lock ; Error/alarm message ; Min flow temp setpoint ; Excess heat discharge ; Release sw pool ; Swimming pool ; Dewpoint monitor ; Flow setp increase hygro ; Refrig demand ; Heat request 10V ; Refrig. demand 10V ; Pressure measurement 10V ; Rel. room humidity 10V ; Room temperature 10V	Optg mode changeover HCs+DHW			-
5951	I	Contact type H1 NC ; NO	NO			-
5952 (**)	I	Function value, contact type H1	70	8	130	°C
5952 (***)		Min flow temp setpoint H1	70	8	120	°C
5953 (**)	I	Voltage value 1, H1	0	0	10	Volt
5954 (**)	I	Function value 1, H1	0	-100	500	-
5954 (***)		Temp value 10V H1	100	5	130	°C
5955 (**)	I	Voltage value 2, H1	10	0	10	Volt
5956 (**)	I	Function value 2, H1	70	-100	500	-
5956 (***)		Pressure value 3.5V H1	5.0	0.0	10.0	bar
5960 (***)	I	Function input H3 Optg mode change HCs+DHW ; Optg mode changeover HCs ; Optg mode changeover HC1 ; Optg mode changeover HC2 ; Optg mode changeover HCP ; Heat generation lock ; Error/alarm message ; Min flow temp setpoint ; Excess heat discharge ; Release swimming pool ; Heat request 10V ; Pressure measurement 10V	Optg mode changeover HCs+DHW			-
5961 (***)	I	Contact type H3 NC ; NO	NO			-
5962 (***)	I	Min flow temp setpoint H3	70	8	120	°C
5964 (***)	I	Temp value 10V H3	100	5	130	°C
5966 (***)	I	Pressure value 3.5V H3	5.0	0.0	10.0	bar
5982 (***)	I	Function input EX2 Counter 2nd burner stage ; Heat generation lock ; Error/alarm message ; SLT error message ; Excess heat discharge	Counter for second burner stage			-
5983 (***)	I	Cont type input EX2 NC ; NO	NO			-
6014	I	Function mixing group 1 Heating circuit 1 ; Return temp controller ; Prim contr/system pump ; DHW primary controller ; Instantaneous DHW heater ; Return controller cascade ; Cooling circuit 1 <sup>(4)</sup> ; Heating circuit / Cooling circuit 1 <sup>(**)</sup>	Heating circuit			-

Operating line	User level	Function	Default value	Min	Max	Unit
6015 (***)	I	Function mixing group 2 Heating circuit 2 ; Return temp controller ; Prim contr/system pump ; DHW primary controller ; Instantaneous DHW heater ; Return controller cascade				
6020	I	Function extension module 1 None ; Multifunctional ; Heating circuit 2 ; Return temp controller ; Solar DHW ; Prim contr/system pump ; DHW primary controller ; Instantaneous DHW heater ; Return controller cascade ; Cooling circuit 1 (**)	None			-
6021	I	Function extension module 2 None ; Multifunctional ; Heating circuit 2 ; Return temp controller ; Solar DHW ; Prim contr/system pump ; DHW primary controller ; Instantaneous DHW heater ; Return controller cascade ; Cooling circuit 1 (**)	None			-
6030	I	Relay output QX21 None ; Circulating pump Q4 ; EI imm heater DHW K6 ; Collector pump Q5 ; H1 pump Q15 ; Boiler pump Q1 ; Bypass pump Q12 ; Alarm output K10 ; 2nd pump speed HC1 Q21 ; 2nd pump speed HC2 Q22 ; 2nd pump speed HCP Q23 ; Heat circuit pump HCP Q20 ; H2 pump Q18 ; System pump Q14 ; Heat gen shutoff valve Y4 ; Solid fuel boiler pump Q10 ; Time program 5 K13 ; Buffer return valve Y15 ; Solar pump ext exch K9 ; Solar ctrl elem buffer K8 ; Solar ctrl elem swi pool K18 ; Collector pump 2 Q16 ; H3 pump Q19 (***) ; Flue gas relay K17 ; Assisted firing fan K30 ; Cascade pump Q25 ; St tank transfer pump Q11 ; DHW mixing pump Q35 ; DHW interm circ pump Q33 ; Heat request K27 ; Refrig. request K28 (***) ; Air dehumidif. K29 <sup>4)</sup> ; Diverting valve, cooling Y21 (**)	None			
6031	I	Relay output QX22 None ; Circulating pump Q4 ; EI imm heater DHW K6 ; Collector pump Q5 ; H1 pump Q15 ; Boiler pump Q1 ; Bypass pump Q12 ; Alarm output K10 ; 2nd pump speed HC1 Q21 ; 2nd pump speed HC2 Q22 ; 2nd pump speed HCP Q23 ; Heat circuit pump HCP Q20 ; H2 pump Q18 ; System pump Q14 ; Heat gen shutoff valve Y4 ; Solid fuel boiler pump Q10 ; Time program 5 K13 ; Buffer return valve Y15 ; Solar pump ext exch K9 ; Solar ctrl elem buffer K8 ; Solar ctrl elem swi pool K18 ; Collector pump 2 Q16 ; H3 pump Q19 (***) ; Flue gas relay K17 ; Assisted firing fan K30 ; Cascade pump Q25 ; St tank transfer pump Q11 ; DHW mixing pump Q35 ; DHW interm circ pump Q33 ; Heat request K27 ; Refrig. request K28 <sup>4)</sup> ; Air dehumidif. K29 <sup>4)</sup> ; Diverting valve, cooling Y21 <sup>4)</sup>	None			
6032	I	Relay output QX23 None ; Circulating pump Q4 ; EI imm heater DHW K6 ; Collector pump Q5 ; H1 pump Q15 ; Boiler pump Q1 ; Bypass pump Q12 ; Alarm output K10 ; 2nd pump speed HC1 Q21 ; 2nd pump speed HC2 Q22 ; 2nd pump speed HCP Q23 ; Heat circuit pump HCP Q20 ; H2 pump Q18 ; System pump Q14 ; Heat gen shutoff valve Y4 ; Solid fuel boiler pump Q10 ; Time program 5 K13 ;	None			

Operating line	User level	Function	Default value	Min	Max	Unit
		Buffer return valve Y15 ; Solar pump ext exch K9 ; Solar ctrl elem buffer K8 ; Solar ctrl elem swi pool K18 ; Collector pump 2 Q16 ; H3 pump Q19 <sup>(**)</sup> ; Flue gas relay K17 ; Assisted firing fan K30 ; Cascade pump Q25 ; St tank transfer pump Q11 ; DHW mixing pump Q35 ; DHW interm circ pump Q33 ; Heat request K27 ; Refrig. request K28 <sup>(**)</sup> ; Air dehumidif. K29 <sup>4)</sup> ; Diverting valve, cooling Y21 <sup>(**)</sup>				
6040	I	Sensor input BX21 None ; DHW sensor B31 ; Collector sensor B6 ; Return sensor B7 ; DHW circulation sensor B39 ; Buffer sensor B4 ; Buffer sensor B41 ; Flue gas temp sensor B8 ; Common flow sensor B10 ; Solid fuel boiler sensor B22 ; DHW charging sensor B36 ; Buffer sensor B42 ; Common return sensor B73 ; Cascade return sensor B70 ; Swimming pool sensor B13 ; Collector sensor 2 B61 ; Solar flow sensor B63 ; Solar return sensor B64	None			
6041	I	Sensor input BX22 None ; DHW sensor B31 ; Collector sensor B6 ; Return sensor B7 ; DHW circulation sensor B39 ; Buffer sensor B4 ; Buffer sensor B41 ; Flue gas temp sensor B8 ; Common flow sensor B10 ; Solid fuel boiler sensor B22 ; DHW charging sensor B36 ; Buffer sensor B42 ; Common return sensor B73 ; Cascade return sensor B70 ; Swimming pool sensor B13 ; Collector sensor 2 B61 ; Solar flow sensor B63 ; Solar return sensor B64	None			
6046	I	Function of input H2 Optg mode changeover HCs + DHW ; Optg mode changeover HCs ; Optg mode changeover HC1 ; Optg mode changeover HC2 ; Optg mode changeover HCP ; Heat generation lock ; Error/alarm message ; Min flow temp setpoint ; Excess heat discharge ; Swimming pool enable ; Dewpoint monitor <sup>(**)</sup> ; Flow temp. setpt increase, hygro <sup>(**)</sup> ; Refrig request <sup>(**)</sup> ; Heat request 10V ; Refrig. request 10V <sup>(**)</sup> ; Pressure measurement 10V ; Rel. room humidity 10V <sup>(**)</sup> ; Room temperature 10V <sup>(**)</sup>	Optg mode changeover HCs+DHW			
6047	I	Contact type H2 NC ; NO	NO			-
6048 (**)	I	Function value, contact H2	70	8	130	°C
6048 (***)	I	Min flow temp setpoint H2	70	8	120	°C
6049 (**)	I	Voltage value 1, H2	0	0	10	Volt
6050 (**)	I	Function value 1, H2	0	-100	500	-
6050 (***)	I	Temp value 10V H2	100	5	130	°C
6051 (**)	I	Voltage value 2, H2	10	0	10	Volt
6052 (**)	I	Function value 2, H2	70	-100	500	-
6052 (***)	I	Pressure value 3.5V H2	5.0	0.0	10.0	bar
6070 (***)	I	Function output UX None ; Boiler pump Q1 ; DHW pump Q3 ; DHW interm circ pump Q33 ; Heat circ pump HC1 Q2 ; Heat circ pump HC2 Q6 ; Heat circ pump HCP Q20 ; Collector pump Q5 ; Solar pump ext exch K9 ; Solar pump	None			

Operating line	User level	Function	Default value	Min	Max	Unit
		buffer K8 ; Solar pump swi pool K18 ; Collector pump 2 Q16 ; Boiler setpoint ; Output setpoint ; Heat request				
6071 (***)	I	Signal logic output UX Standard ; Inverted	Standard			
6075 (***)	I	Temperature value 10V UX	100	5	130	°C
6097	F	Sensor type collector NTC 10k ; Platinum 1000	NTC 10k			
6098	F	Readjustm collector sensor	0	-20	20	°C
6099	F	Readjustm coll sensor 2	0	-20	20	°C
6100	F	Readjustm outside sensor	0	-3.0	3.0	°C
6101	F	Sensor type flue gas temp NTC 10k ; Platinum 1000	NTC 10k			
6102	F	Readjustm flue gas sensor	0	-20	20	°C
6110	F	Time constant building	15	0	50	h
6112	O	Gradient room model	60	0	300	Min/°C
6116 (**)	O	Time constant setp compens	10	0	14	min
6117	O	Central setp compensation	20	--- / 1	100	°C
6118	O	Setpoint drop delay	60	--- / 1	200	k/min
6120	F	Frost protection for the plant Off ; On	Off			-
6128	F	Heat request below OT	---	--- / - 50	50	°C
6129	F	Heat request above OT	---	--- / - 50	50	°C
6131	F	Heat req in economy mode Off ; On DHW ; On	Off			
6135 (**)	F	Air dehumidifier Off ; On	Off			
6136 (**)	F	Air dehumidifier enable 24h/day ; Time progr. heating circuit ; Time program 5	24 h/day			
6137 (**)	F	Air dehumidifier r.h. ON	55	0	100	%
6138 (**)	F	Air dehumidifier r.h. SD	5	2	50	%
6140	O	Water pressure max	---	--- / 0.0	10.0	bar
6141	O	Water pressure min	---	--- / 0.0	10.0	bar
6142	O	Water pressure critical min	---	--- / 0.0	10.0	bar
6150	O	Water pressure 2 max	---	--- / 0.0	10.0	bar
6151	O	Water pressure 2 min	---	--- / 0.0	10.0	bar
6152	O	Water press 2 critical min	---	--- / 0.0	10.0	bar

Operating line	User level	Function	Default value	Min	Max	Unit
6180 (***)	O	Water pressure 3 max	---	--- / 0.0	10.0	bar
6181 (***)	O	Water pressure 3 min	---	--- / 0.0	10.0	bar
6182 (***)	O	Water press 3 critical min	---	--- / 0.0	10.0	bar
6200	I	Save sensors No   Yes	No			-
6204	O	Save parameters No   Yes	No			
6205	F	Reset to default parameters No   Yes	No			-
6212	I	Check-No. heat source 1	-	0	199999	-
6213	I	Check-No. heat source 2	-	0	199999	-
6215	I	Check-No. storage tank	-	0	199999	-
6217	I	Check-No. heating circuits	-	0	199999	-
6220	F	Software version	-	0	99.9	-
6222	O	Device hours run	0	0	65535	h
<b>LPB system</b>						
6600	I	Device address	1	0	16	-
6601	F	Segment address	0	0	14	-
6604	F	Bus power supply function Off   Automatically	Automatically			-
6605	F	Bus power supply state Off   On	On			-
6610	O	Display system messages No   Yes	Yes			
6612	O	Alarm delay	---	--- / 2	60	min
6620	F	Action changeover functions Segment   System	System			-
6621	F	Summer changeover Locally   Centrally	Locally			-
6623	F	Optg mode changeover Locally   Centrally	Centrally			
6624	F	Manual source lock Locally   Segment	Locally			
6625	F	Assignment of DHW heating Local HCs   All HCs in segment   All HCs in system	All HCs in system			-
6627 (**)	F	Refrigeration demand Locally   Centrally	Locally			
6630	O	Cascade master Always   Automatically	Automatically			
6631	F	Ext source with eco mode Off   On DHW   On	Off			
6640	I	Clock mode Autonomously   Slave without remote   Slave with remote setting   Master	Autonomously			-
6650	F	Outside temp source	0	0	239	-
<b>Errors</b>						

Operating line	User level	Function	Default value	Min	Max	Unit
6710	I	Reset alarm relay No   Yes	No			-
6740	F	Flow temp 1 alarm	---	--- / 10	240	min
6741	F	Flow temp 2 alarm	---	--- / 10	240	min
6743	F	Boiler temp alarm	---	--- / 10	240	min
6745	F	DHW charging alarm	---	--- / 1	48	h
6746 (**)	F	Flow temp alarm, cooling 1	---	--- / 10	240	min
6800	F	History 1	-			
	F	Error code 1	-	0	255	-
6802	F	History 2	-			
	F	Error code 2	-	0	255	-
6804	F	History 3	-			
	F	Error code 3	-	0	255	-
6806	F	History 4	-			
	F	Error code 4	-	0	255	-
6808	F	History 5	-			
	F	Error code 5	-	0	255	-
6810	F	History 6	-			
	F	Error code 6	-	0	255	-
6812	F	History 7	-			
	F	Error code 7	-	0	255	-
6814	F	History 8	-			
	F	Error code 8	-	0	255	-
6816	F	History 9	-			
	F	Error code 9	-	0	255	-
6818	F	History 10	-			
	F	Error code 10	-	0	255	-
6820	O	Reset history No   Yes	No			-
<b>Maintenance / special operation</b>						
7040	F	Burner hours interval	---	--- / 10	10000	h
7041	F	Burner hrs since maintenance	0	0	10000	h
7042	F	Burner start interval	---	--- / 60	65535	-
7043	F	Burn starts since maint	0	0	65535	-
7044	F	Maintenance interval	---	--- / 1	240	Months
7045	F	Time since maintenance	0	0	240	Months
7053	F	Flue gas temp limit	---	--- / 0	350	°C
7054	F	Delay flue gas message	0	0	120	min

Operating line	User level	Function	Default value	Min	Max	Unit
7119	F	Economy function Locked   released	Locked			-
7120	E	Economy mode Off   On	Off			-
7130	E	Chimney sweep function Off   On	Off			-
7140	E	manual operation Off   On	Off			-
7150	I	Simulation outside temperature	-	-50.0	50	°C
7170	I	Telephone customer service				-
<b>Input / output test</b>						
7700	I	Relay test No test   Everything off   1st burner stage T2   1st + 2nd burn stage T2/QX4 <sup>(***)</sup>   DHW pump Q3   Heating circuit pump Q2   Heat circ mix valve op Y1   Heat circ mix valve cl Y2   Heating circuit pump Q6 <sup>(****)</sup>   Heat circ mix valve op Y5 <sup>(***)</sup>   Heat circ mix valve cl Y6 <sup>(6)</sup>   Relay output QX1   Relay output QX2 <sup>(****)</sup>   Relay output QX3 <sup>(***)</sup>   Relay output QX4 <sup>(***)</sup>   Relay output QX21 module 1   Relay output QX22 module 1   Relay output QX23 module 1   Relay output QX21 module 2   Relay output QX22 module 2   Relay output QX23 module 2	No test			-
7710 (***)	I	Output test UX	-	0	100	%
7711 (***)	I	Voltage signal UX	0	0	10	Volt
7730	I	Outside temp B9	-	-50.0	50	°C
7732	I	Flow temp B1	-	0.0	140	°C
7734 (***)	I	Flow temp B12	-	0.0	140	°C
7750	I	DHW temp B3	-	0.0	140	°C
7760	I	Boiler temp B2	-	0.0	140	°C
7820	I	Sensor temp BX1	-	-28.0	350	°C
7821	I	Sensor temp BX2	-	-28.0	350	°C
7822 (***)	I	Sensor temp BX3	0	-28	350	°C
7823 (***)	I	Sensor temp BX4	0	-28	350	°C
7830	I	Sensor temp BX21 module 1	0	-28	350	°C
7831	I	Sensor temp BX22 module 1	0	-28	350	°C
7832	I	Sensor temp BX21 module 2	0	-28	350	°C
7833	I	Sensor temp BX22 module 2	0	-28	350	°C
7840	I	Voltage signal H1	-	0	10	Volt
7841	I	Contact state H1 Open   Closed	-			-
7845	I	Voltage signal H2	0	0	10	°C
7846	I	Contact state H2 Open   Closed	-			-
7854 (***)	I	Voltage signal H3	0	0	10	Volt
7855 (***)	I	Contact state H3 Open   Closed	-			-

Operating line	User level	Function	Default value	Min	Max	Unit
7870	I	Burner fault S3 0V   230V	-			-
7881	I	1. 1st burner stage E1 0V   230V	-			
7912 (***)	I	Input EX2 0V   230V	-			
State						
8000	I	State of heating circuit 1	-			-
8001	I	State of heating circuit 2	-			-
8002	I	State heating circuit P	-			-
8003	I	State of DHW	-			-
8005	I	State of boiler	-			-
8007	I	State of solar	-			-
8008	I	State solid fuel boiler	-			
8010	I	State buffer storage tank	-			
8011	I	State swimming pool	-			
<b>Diagnostics cascade</b>						
8100 through 8130	I	Priority source 1...16				
8101 through 8131	I	State source 1...16 Missing   Faulty   Manual control active   Heat generation lock active   Chimney sweep funct active   Separate DHW circuit active   Outside temp limit active   Not released   Released				
8138	I	Cascade flow temp	0	0	140	°C
8139	I	Cascade flow temp setpoint	0	0	140	°C
8140	I	Cascade return temp	0	0	140	°C
8141	I	Cascade return temp setp	0	0	140	°C
8150	I	Source seq ch'over current	0	0	990	h
<b>Diagnostics, heat generation</b>						
8300	I	1. 1st burner stage T2 Off   On	-			-
8301 (***)	I	2. 2nd burner stage Off   On	-			-
8308 (***)	F	Boiler pump speed	0	0	100	%
8310	I	Boiler temperature	-	0.0	140.0	°C
8311	I	Boiler setpoint	-	0.0	140.0	°C
8312	I	Boiler switching point	0	0	140	°C
8314	I	Boiler return temp	-	0.0	140.0	°C
8315	I	Boiler return temp setpoint	0	0	140	°C
8316	I	Flue gas temp	0	0	350	°C
8318	I	Flue gas temp max	0	0	350	°C
8326	I	Burner modulation	0	0	100	%

Operating line	User level	Function	Default value	Min	Max	Unit
8330	F	Hours run 1st stage	0	0	65535	h
8331	F	Start counter 1st stage	-	0	199'999	-
8332 (***)	F	Hours run 2nd stage	0	0	65535	h
8333 (***)	F	Start counter 2nd stage	0	0	199999	-
8505 (***)	F	Speed collector pump 1	0	0	100	%
8506 (***)	F	Speed solar pump ext exch	0	0	100	%
8507 (***)	F	Speed solar pump buffer	0	0	100	%
8508 (***)	F	Speed solar pump swi pool	0	0	100	%
8510	I	Collector temp 1	-	-28.0	350	°C
8511	I	Collector temp 1 max	0	-28.0	350	°C
8512	I	Collector temp 1 min	0	-28.0	350	°C
8513	I	$\Delta T$ collector 1/DHW	-	-168.0	350	°C
8514	I	$\Delta T$ collector 1/buffer	-	-168.0	350	°C
8515	I	$\Delta T$ collector 1/swimming pool	0	-168.0	350	°C
8519	I	Solar flow temp	0	-28.0	350	°C
8520	I	Solar return temp	0	-28.0	350	°C
8526	E	24-hour yield solar energy	0	0	999.9	kWh
8527	E	Total yield solar energy	0	0	999999.9	kWh
8530	F	Hours run solar yield	-	0	65535	h
8531	F	Hours run collect overtemp	-	0	65535	h
8543 (***)	F	Speed collector pump 2	0	0	100	%
8547	I	Collector temp 2	0	-28	350	°C
8548	I	Collector temp 2 max	-28	-28	350	°C
8549	I	Collector temp 2 min	3500	-28	350	°C
8550	I	$\Delta T$ collector 2/DHW	0	-168	350	°C
8551	I	$\Delta T$ collector 2/buffer	0	-168	350	°C
8552	I	$\Delta T$ collector 2/swimming pool	0	-168	350	°C
8560		Solid fuel boiler temp	0	0	140	°C
8570	E	Hours run solid fuel boiler	0	0	65535	h
<b>Diagnostics, consumers</b>						
8700	I	Outside temperature (OT)	-	-50.0	50.0	°C
8703	I	Outside temp attenuated	-	-50.0	50.0	°C
8704	I	Outside temperature composite	-	-50.0	50.0	°C
8720 (**)	I	Relative room humidity	-	0	100	%
8721 (**)	I	Outside temperature (OT)	-	0	50.0	°C
8722 (**)	I	Dewpoint temperature 1	-	0	50.0	°C
8730	I	Heating circuit pump Q2 Off   On	-			-

Operating line	User level	Function	Default value	Min	Max	Unit
8731	I	Heating circ mix valve op Y1 Off   On	-			-
8732	I	Heat circ mix valve cl Y2 Off   On	-			-
8735 (***)	F	Speed heating circuit pump 1	0	0	100	%
8740	I	Room temp 1	-	0.0	50.0	°C
8741	I	Room setpoint 1	-	4.0	35.0	°C
8742	O	Room temp 1 model	-	0.0	50.0	°C
8743	I	Flow temperature 1	-	0.0	140.0	°C
8744	I	Flow temp setpoint 1	-	0.0	140.0	°C
8751 (**)	I	Cooling circuit pump 1 Off   On	-			
8752 (**)	I	Cooling circuit mixing valve 1 Open Off   On	-			
8753 (**)	I	Cooling circuit mixing valve 1 Closed Off   On	-			
8754 (**)	I	Cooling diverting valve 1 Off   On	-			
8756 (**)	I	Flow temperature, cooling 1	-	0	140	°C
8757 (**)	I	Flow temperature, cooling 1	-	0	140	°C
8760	I	Heating circuit pump 2 Off   On	-			-
8761	I	Heat circ mix valve 2 open Off   On	-			-
8762	I	Heat circ mix valve 2 close Off   On	-			-
8765 (***)	F	Speed heating circuit pump 2	0	0	100	%
8770	I	Room temp 2	-	0.0	50	°C
8771	I	Room setpoint 2	-	4.0	35	°C
8772	O	Room temp 2 model	-	0.0	50	°C
8773	I	Flow temperature 2	-	0.0	140	°C
8774	I	Flow temp setpoint 2	-	0.0	140	°C
8795 (***)	F	Speed heating circuit pump B	0	0	100	%
8800	I	Room temp P	-	0.0	50	°C
8801	I	Room setpoint P	-	4.0	35	°C
8802	O	Room temp P model	-	0.0	50	°C
8803	I	Flow temp setpoint P	-	0.0	140	°C
8820	I	DHW pump Q3 Off   On	-			-
8825 (***)	F	Speed DHW pump	0	0	100	%
8826 (***)	F	Speed DHW interm circ pump	0	0	100	%
8830	I	DHW temp 1	-	0.0	140	°C
8831	I	DHW temp setpoint	-	8.0	80	°C
8832	I	DHW temp 2	-	0.0	140	°C
8835	I	DHW circulation temp	-	0.0	140	°C

Operating line	User level	Function	Default value	Min	Max	Unit
8836	I	DHW charging temp	0	0	140	°C
8850	I	DHW primary controller temp	0	0	140	°C
8851	I	DHW primary controller setp	0	0	140	°C
8852	I	Instant DHW heater temp	0	0	140	°C
8853	I	Instant DHW heater setpoint	0	0	140	°C
8900	I	Swimming pool temp	0	0	140	°C
8901	I	Swimming pool setpoint	24	8	80	°C
8930	I	Primary controller temp	-	0.0	140.0	°C
8931	I	Primary controller setpoint	-	0.0	140.0	°C
8950	I	Common flow temp	-	0.0	140.0	°C
8951	I	Common flow temp setpoint	-	0.0	140.0	°C
8952	I	Common return temp	0	0	140	°C
8957 (**)	I	Common flow temp setpoint refrig	0	0	140	°C
8962	I	Common output setpoint	0	0	100	%
8980	I	Buffer temp 1	-	0.0	140.0	°C
8981	I	Buffer setpoint	0	0	140	°C
8982	I	Buffer temp 2	-	0.0	140.0	°C
8983	I	Buffer temp 3	0	0	140	°C
9000	I	Flow temperature setpoint H1	-	5.0	130.0	°C
9001	I	Flow temp setpoint H2	-	5.0	130.0	°C
9004 (***)	I	Flow temp setpoint H3	8	8	120	°C
9005	I	Water pressure H1	-	0.0	10.0	bar
9006	I	Water pressure H2	-	0.0	10.0	bar
9009 (***)	I	Water pressure H3	0	0	10	bar
9031	I	Relay output QX1 Off   On	-			-
9032 (***)	I	Relay output QX2 Off   On	-			-
9033 (***)	I	Relay output QX3 Off   On	-			-
9034 (***)	I	Relay output QX4 Off   On				
9050	I	Relay output QX21 module 1 Off   On	-			-
9051	I	Relay output QX22 module 1 Off   On	-			-
9052	I	Relay output QX23 module 1 Off   On	-			-
9053	I	Relay output QX21 module 2 Off   On	-			-
9054	I	Relay output QX22 module 2 Off   On	-			-
9055	I	Relay output QX23 module 2 Off   On	-			-

## 5 The settings in detail

### 5.1 Time of day and date

The controller has a yearly clock with time of day, weekday and date. To ensure the controller's functionality, both the time of day and the date must be correctly set.

Line no.	Operating line
1	Hours/minutes
2	Day/month
3	Year
5	Start of summertime
6	End of summertime

Summer- / wintertime  
changeover

The dates set for the changeover from wintertime to summertime - , and vice versa, - ensure that on the first Sunday after the set date the time of day will change from 02:00 (wintertime) to 03:00 (summertime), and from 03:00 (summertime) to 02:00 (wintertime).

### 5.2 Operator unit

#### Operation and display

Line no.	Operating line
20	Language
22	Info Temporary Permanently
26	Operation lock
27	Programming lock
28	Direct adjustment Automatic storage Save with acknowledgment

Info

Temporarily: After pressing the info button, a change to the "predefined" basic display is made after a maximum of 8 minutes or by pressing the operating mode button (with the QAA78... only 2 minutes) .

Continuously: After pressing the info button, a change back to the "new" basic display is made after a maximum of 8 minutes.  
The info value selected last will be adopted by the new basic display.  
This setting is not possible with the QAA78...

Operation lock

When operation lock is activated, the following operating elements can no longer be adjusted:

Heating circuit operating mode, DHW operating mode, room Comfort setpoint (setting knob), and presence button.

Programming lock

When programming lock is activated, parameter values can still be displayed, but can no longer be changed.

- Temporary deactivation of the programming lock.  
Within the programming level, the programming lock can temporarily be overridden. To do this, press the OK and ESC buttons simultaneously for 3 seconds. Temporary deactivation of the programming lock is maintained until programming is quit.
- Constant deactivation of programming lock.  
First, make the temporary deactivation, then go to operating line "Programming lock" (operating line 27) and deactivate the programming lock

**Used as**

Line no.	Operating line
<b>40</b>	<b>Used as</b> Room unit 1 Room unit 2 Room unit P Operator unit 1 Operator unit 2 Operator unit P Service unit

This operating line is used to select the use of the operator unit. Depending on use, additional settings will then be required under “Heating circuit assignment“. When using several operator units, it is thus possible to match individual units to specific requirements.



- In the case several operator units are used, each application may only be used once.
- The AVS37.294 operator unit is supplied as operator unit 1 (operating line 40) acting on all heating circuits (operating line 42) and can only be readjusted on operating lines 44, 46 and 48

Depending on the selected use of the unit (operating line 40), the following settings (marked with X) can be made when assigning the heating circuit.

40	Operating line				
	42	44	46	48	54
Room unit 1	Heating circuit 1				X
	Heating circuits 1 and 2	X		X	X
	Heating circuits 1 and P		X	X	X
	All heating circuits	X	X	X	X
Room unit 2					X
Room unit P					X
Operator unit 1	Heating circuit 1				
	Heating circuits 1 and 2	X		X	
	Heating circuits 1 and P		X	X	
	All heating circuits	X	X	X	
Operator unit 2					
Operator unit P					
Service unit					

**Room unit 1**

The operator unit supports the heating circuits released on operating line 42 “Assignment room unit 1” and activated in the basic unit.

**Room unit 2**

The operator unit only supports heating circuit 2.

**Operator unit / service unit**

The operator unit supports the heating circuits activated in the basic unit.



When using this setting, the operator unit does not acquire and deliver the room temperature.

## Heating circuit assignment

<i>Line no.</i>	<i>Operating line</i>
<b>42</b>	<b>Assignment device 1</b> Heating circuit 1 Heating circuits 1 and 2 Heating circuits 1 and P All heating circuits
<b>44</b>	<b>Operation HC2</b> Commonly with HC1 Independently
<b>46</b>	<b>Operation HCP</b> Commonly with HC1 Independently
<b>48</b>	<b>Action of presence button</b> None. Heating circuit 1 Heating circuit 2 Jointly

### Assignment device 1

As room unit 1 (setting 40), the action of the relevant operator unit on heating circuit 1 or on both heating circuits can be assigned. The latter is required especially when using 2 heating circuits and only 1 room unit.

### Operation HC2

Depending on operating line 40, the action of operation (operating mode button or setting knob) on room unit 1, on the operator unit or service unit can be defined for heating circuit 2.

#### **Commonly with HC1**

Operation acts commonly on heating circuits 1 and 2.

#### **Independently**

The action of operation is queried on the display as soon as the operating mode button is pressed or the setting knob is operated.

### Operation HCP

Depending on operating line 40, the action of operation (operating mode button or setting knob) on room unit 1, on the operator unit or service unit can be defined for heating circuit P.

#### **Commonly with HC1**

Operation acts commonly on heating circuits 1 and 2.

#### **Independently**

Operating mode changes or readjustments of the Comfort setpoints are to be made in programming mode.

### Action presence button

The action of the presence button on the operator unit can be assigned to the relevant heating circuits.

If only 1 heating circuit is assigned, the presence button always acts on that heating circuit.

## Room sensor

<i>Line no.</i>	<i>Operating line</i>
<b>54</b>	<b>Readjustment room sensor</b>

The temperature display can be readjusted.

## Device data

<i>Line no.</i>	<i>Operating line</i>
<b>70</b>	<b>Software version</b>

The display shows the current version of the room unit.

## 5.3 Time programs

For the heating circuits and DHW heating, a number of switching programs are available. They are activated in "Automatic" operation and control the change of the temperature levels (and the associated setpoints) via the selected switching times.

Entering the switching times

The switching times can be set in a combined way, that is, either commonly for several days or in the form of separate times for individual days. When preselecting groups of days like for instance Mo...Fr and Sa...Su that use the same switching times, setting of the switching programs is simplified.

### Switching points

Line no.					Operating line
HC1	HC2	3/HCP	4/DHW	5	
<b>500</b>	<b>520</b>	<b>540</b>	<b>560</b>	<b>600</b>	<b>Preselection</b> Mo - Su Mo - Fr Sa - Su Mo - Su
<b>501</b>	<b>521</b>	<b>541</b>	<b>561</b>	<b>601</b>	<b>1st phase on</b>
<b>502</b>	<b>522</b>	<b>542</b>	<b>562</b>	<b>602</b>	<b>1st phase off</b>
<b>503</b>	<b>523</b>	<b>543</b>	<b>563</b>	<b>603</b>	<b>2nd phase on</b>
<b>504</b>	<b>524</b>	<b>544</b>	<b>564</b>	<b>604</b>	<b>2nd phase off</b>
<b>505</b>	<b>525</b>	<b>545</b>	<b>565</b>	<b>605</b>	<b>3rd phase on</b>
<b>506</b>	<b>526</b>	<b>546</b>	<b>566</b>	<b>606</b>	<b>3rd phase off</b>

### Standard program

Line no.	Operating line
<b>516, 536, 556, 576, 616</b>	<b>Default values</b>

All time programs can be reset to their default settings. Each time program has its own operating line to make this reset.



In that case, individual settings will be lost!

## 5.4 Holidays

Line no.			Operating line
HC1	HC2	HCP	
<b>641</b>	<b>651</b>	<b>661</b>	<b>Preselection</b>
<b>642</b>	<b>652</b>	<b>662</b>	<b>Start</b>
<b>643</b>	<b>653</b>	<b>663</b>	<b>End</b>
<b>648</b>	<b>658</b>	<b>668</b>	<b>Operating level</b> frost protection Reduced

The holiday program is used to switch the heating circuits to a selectable operating level according to calendar dates.



- The holiday program can only be used in "Automatic" mode

## 5.5 Heating circuits

For heating circuits, there are various functions available which can be individually set for each heating circuit.

### Operating mode

Line no.	Operating line
<b>1300</b>	<b>Operating mode</b> Protection mode Automatically Reduced Comfort

The operating mode of heating circuits 1 and 2 is selected directly with the operating mode button while the operating mode of heating circuit P is to be selected in programming mode (operating line 1300).

This setting is used to switch between the different operating modes. The functionality corresponds to operating mode selection with the operating mode button. For details, refer to section "Operation".


### Setpoints

Line no.			Operating line
HC1	HC2	HCP	
<b>710</b>	<b>1010</b>	<b>1310</b>	<b>Comfort setpoint</b>
<b>712</b>	<b>1012</b>	<b>1312</b>	<b>Reduced setpoint</b>
<b>714</b>	<b>1014</b>	<b>1314</b>	<b>Frost protection setpoint</b>
<b>716</b>	<b>1016</b>	<b>1316</b>	<b>Comfort setpoint max</b>

### Room temperature.

The room temperature can be shifted according to different setpoints. These setpoints become active depending on the selected operating mode, thus producing different temperature levels in the rooms.

The ranges of adjustable setpoints result from the interdependencies, as this is shown in the following diagram.



2358Z01

TRKmax	Comfort setpoint max
TRK	Comfort cooling setpoint
TRR	Reduced setpoint
TRF	Frost protection setpoint

### Frost protection

In Protection mode, the room temperature is prevented from falling below a certain level. This means that the frost protection setpoint of the room temperature will be maintained.

### Comfort setpoint max

The room temperature can be shifted according to different setpoints. These setpoints become active depending on the selected operating mode, thus producing different temperature levels in the rooms.

The ranges of adjustable setpoints result from the interdependencies, as this is shown in the following diagram.

### Heating curve

Line no.			Operating line
HC1	HC2	HCP	

<b>720</b>	<b>1020</b>	<b>1320</b>	<b>Heating curve slope</b>
<b>721</b>	<b>1021</b>	<b>1321</b>	<b>Heating curve displacement</b>
<b>726</b>	<b>1026</b>	<b>1326</b>	<b>Heating curve adaption</b>

The heating curve is used to generate the flow temperature setpoint, which is used to maintain a certain flow temperature level depending on the prevailing weather conditions. The heating curve can be adjusted with a number of settings, thus matching heat output and room temperature to individual needs.

Heating curve slope


As the heating curve slope is raised, the flow temperature increases the quicker the lower the outside temperature or, in other words, if the room temperature is not correct at low outside temperatures but correct at higher outside temperatures, the heating curve slope requires readjustment.

Increase adjustment: Raises the flow temperature, especially when outside temperatures are low.

Decrease adjustment: Lowers the flow temperature, especially when outside temperatures are low.



The programmed heating curve is based on a room setpoint of 20°C. If the room setpoint is adjusted, the heating curve automatically adapts to the new value.



Heating curve displacement

Parallel displacement of the heating curve is used to change the flow temperature evenly across the entire outside temperature range or, in other words, if the room temperature is always too high or too low, a readjustment must be made with the help of the parallel displacement.

Heating curve adaption

Adaptation of the heating curve is used by the controller to automatically adapt the heating curve to the prevailing conditions. In that case, a readjustment of heating curve slope and parallel displacement is not required. It can only be switched on or off.



To assure this function, following must be observed:

- A room sensor must be connected.
- The "Room influence" setting must be selected between 1 and 99
- There should be no thermostatic radiator valves in the reference room (mounting location of room sensor) (if such valves are present, they must be set to their fully open position).

ECO functions

Line no.			Operating line
HC1	HC2	HCP	
<b>730</b>	<b>1030</b>	<b>1330</b>	<b>Summer/winter heating limit</b>
<b>732</b>	<b>1032</b>	<b>1332</b>	<b>24-hour heating limit</b>

Summer/winter heating limit

The summer / winter heating limit is used to switch the heating on and off in the course of the year, depending on temperature conditions. In Automatic mode, switching on / off takes place automatically, so there is no need for the user to do this manually. By changing the setting, the respective periods of time will be shortened or extended.


Increase: Winter operation will start *earlier*  
 Summer operation will start *later*

Decrease: Winter operation will start *later*  
 Summer operation will start *earlier*



- The function is not active in operating mode "Continuously Comfort temperature" ☀
- The display shows ECO
- To incorporate the building's thermal dynamics, the outside temperature is attenuated

Example:



SWHG Summer/winter heating limit  
 TAged The attenuated outside temperature  
 T Temperature  
 t Days

24-hour heating limit

The 24-hour heating limit is used to switch the heating on and off in the course of the day, depending on the outside temperature. This function is used primarily during spring and autumn to respond to short-term temperature variations.

Example:

Setting line	e.g.
Comfort setpoint (TRw)	22°C
24-hour heating limit (THG)	-3°C
Changeover temperature (TRw-THG) heating off	= 19°C

Switching differential (fixed)	-1°C
Changeover temperature heating on	= 18°C

By changing the value entered, the respective heating periods will be shortened or extended.

Increase: Heating mode will start *earlier*,  
 changeover to ECO *later*.

Decrease: Heating mode will start *later*,  
 changeover to ECO *earlier*.




- The function is not active in operating mode "Continuously Comfort temperature" ☀

- The display shows ECO
- To give consideration to the building's thermal dynamics, the outside temperature will be attenuated

### Flow temperature setpoint limits

Line no.			Operating line
HC1	HC2	HCP	
<b>740</b>	<b>1040</b>	<b>1340</b>	<b>Flow temp setpoint min</b>
<b>741</b>	<b>1041</b>	<b>1341</b>	<b>Flow temp setpoint max</b>

Using this limitation, a temperature range for the flow temperature setpoint can be defined. If the flow temperature setpoint demanded by the heating circuit reaches the relevant limit and the heat request increases or decreases, the flow temperature setpoint will be maintained at the maximum or minimum limit.



TVw Current flow temperature setpoint  
 TVmax Flow temperature setpoint maximum  
 TVmin Flow temp setpoint minimum

### Room influence

Line no.			Operating line
HC1	HC2	HCP	
<b>750</b>	<b>1050</b>	<b>1350</b>	<b>Room influence</b>

#### Types of compensation:

When a room temperature sensor is used, there is a choice of 3 different types of compensation.

Setting	Type of compensation
— — — %	Pure weather compensation *
1...99 %	Weather compensation with room influence *
100 %	Pure room compensation

\* Outside sensor required.

Weather compensation only

The flow temperature is calculated via the heating curve, depending on the composite outside temperature.

This type of compensation calls for a correct adjustment of the heating curve since in that case the control gives no consideration to the room temperature.

Weather compensation with room influence

Deviations of the actual room temperature from the setpoint are acquired and taken into account when controlling the temperature. Heat gains can thus be considered, facilitating more accurate room temperature control. The authority of deviation is set as a percentage figure. The better the reference room (correct room temperature, correct mounting location, etc.) the higher the value can be set.

• Example:

Approx. 60 % Good reference room conditions

Approx. 20 % Unfavorable reference room



To activate the function, following must be considered:

- A room sensor must be connected.
- "Room influence" must be set to a value between 1 and 99 %.
- There should be no thermostatic radiator valves in the reference room (mounting location of the room sensor). (if such valves are present, they must be set to their fully open position).

#### Room compensation only

The flow temperature is controlled depending on the room temperature setpoint, the current room temperature and the progression of the room temperature. For example, a slight increase of the room temperature causes an immediate drop of the following temperature.



To activate the function, following must be considered:

- A room sensor must be connected.
- "Room influence" must be set to 100 %.
- There should be no thermostatic radiator valves in the reference room (mounting location of the room sensor). (if such valves are present, they must be set to their fully open position).

#### Room temp limitation

Line no.			Operating line
HC1	HC2	HCP	
<b>760</b>	<b>1060</b>	<b>1360</b>	<b>Room temp limitation</b>


With the "Room temperature limitation" function, the heating circuit pump can be disabled if the room temperature exceeds the current room temperature setpoint by more than the preset differential.

The heating circuit pump is re-enabled when the room temperature returns to a level below the current room temperature setpoint.

While the "Room temperature limitation" function is active, no demand signals are sent to the heat source.



Room temperature limitation does not work in the case of pure weather compensation.



TRx Actual value room temp  
 TRw Room temperature setpoint  
 SDR Room switching differential  
 P Pump  
 t Time


#### Boost heating

Line no.			Operating line
HC1	HC2	HCP	
<b>770</b>	<b>1070</b>	<b>1370</b>	<b>Boost heating</b>

Boost heating is used to reach the new setpoint more quickly when switching from the Reduced setpoint to the Comfort setpoint, thus reducing the heat-up time. During boost heating, the room temperature setpoint is raised by the value set here. A higher setting leads to shorter heat-up times, a lower setting to longer heat-times.



- Boost heating is possible with or without room sensor.



TRw Room temperature setpoint  
 TRx Actual value of the room temperature  
 DTRSA Increase of the room temperature setpoint

### Quick setback

Line no.			Operating line
HC1	HC2	HCP	
<b>780</b>	<b>1080</b>	<b>1380</b>	<b>Quick setback</b> Off Down to reduced setpoint Down to frost prot setpoint

During quick setback, the heating circuit pump is deactivated and, in the case of mixing valve circuits, the mixing valve is fully closed.

- Function with room sensor:

When using the room sensor, the function keeps the heating switched off until the room temperature has dropped to the level of the Reduced setpoint or the frost level. When the room temperature has fallen to the Reduced level or the frost level, the heating circuit pump will be activated and the mixing valve will be released.

- Function without room sensor:

Quick setback switches the heating off for a certain period of time, depending on the outside temperature and the building time constant.

### Example

Duration of quick setback when Comfort setpoint minus Reduced setpoint = 2°C  
 (e.g. Comfort setpoint = 20°C and Reduced setpoint = 18°C)

Outside temperature composite:	Building time constant:						
	0	2	5	10	15	20	50
15 °C	0	3.1	7.7	15.3	23	30.6	76.6
10 °C	0	1.3	3.3	6.7	10	13.4	33.5
5 °C	0	0.9	2.1	4.3	6.4	8.6	21.5
0 °C	0	0.6	1.6	3.2	4.7	6.3	15.8
-5 °C	0	0.5	1.3	2.5	3.8	5.0	12.5
-10 °C	0	0.4	1.0	2.1	3.1	4.1	10.3
-15 °C	0	0.4	0.9	1.8	2.6	3.5	8.8
-20 °C	0	0.3	0.8	1.5	2.3	3.1	7.7

Duration of quick setback in hours



- Quick setback is possible with or without a room sensor

### Optimum start / stop control


Line no.			Operating line
HC1	HC2	HCP	
<b>790</b>	<b>1090</b>	<b>1390</b>	<b>Optimum start control max</b>
<b>791</b>	<b>1091</b>	<b>1391</b>	<b>Optimum stop control max</b>

Optimum start control max The change from one temperature level to the other is optimized in a way that the Comfort setpoint is reached at the relevant switching time.

Optimum top control max The change from one temperature level to the other is optimized in a way that the Comfort setpoint minus 1/4 °C is reached at the relevant switching time



- Optimum start / stop control is possible with or without room sensor.




Xein Switch-on time shifted forward in time  
 Xaus Switch-off time shifted forward in time  
 ZSP Time switch program  
 TRx Actual value room temp  
 TRw Room temperature setpoint

### Raising the reduced setpoint

Line no.			Operating line
HC1	HC2	HCP	
<b>800</b>	<b>1100</b>	<b>1400</b>	<b>Red setpoint increase start</b>
<b>801</b>	<b>1101</b>	<b>1401</b>	<b>Red setpoint increase end</b>

The function is used primarily in connection with heating systems with **only** little spare capacity (e.g. low-energy houses). In such cases, the heating up time would be too long at low outside temperatures. When the Reduced setpoint is raised, the rooms are prevented from cooling down to too low levels, thus shortening the heating up time when changing to the Comfort setpoint.



### Overtemp prot pump circuit

Line no.			Operating line
HC1	HC2	HCP	
<b>820</b>	<b>1120</b>	<b>1420</b>	<b>Overtemp prot pump circuit</b>

In the case of heating plant with pump heating circuits, the flow temperature of the heating circuit can be higher than the flow temperature demanded by the heating curve, due to requests from other heat consumers (mixing heating circuit, DHW charging, external heat demand), or a parameterized minimum boiler temperature. As a result of this too high flow temperature, the pump heating circuit would assume excessive temperatures.

The function "Overtemperature protection for pump heating circuits" ensures that the energy supply for pump heating circuits corresponds to the demand from the heating curve by activating / deactivating the pump.

### Mixing valve control

Line no.		Operating line
HC1	HC2	
<b>830</b>	<b>1130</b>	<b>Mixing valve boost</b>
<b>832</b>	<b>1132</b>	<b>Actuator type</b> 2-position   3-position
<b>833</b>	<b>1133</b>	<b>Switching differential</b> <b>2-pos</b>
<b>834</b>	<b>1134</b>	<b>Actuator running time</b>

Actuator type

The selection of the type of actuator determines the control behavior for the type of mixing valve actuator used.

Switching differential  
2-pos

For the 2-position actuator, the 2-position switching differential must also be adapted. This is not required when using a 3-position actuator.

Mixing valve boost

To ensure proper mixing valve flow temperature control, the flow temperature must be higher than the demanded setpoint of the mixing valve flow temperature. The value set here is added to the request.

Actuator running time

Setting the running time of the actuator used with the mixing valve.

### Floor curing function

Line no.			Operating line
HC1	HC2	HCP	
<b>850</b>	<b>1150</b>	<b>1450</b>	<b>Floor curing function</b>

RVS43.. only

			Off Functional heating (Fh) Curing heating (Bh) Functional/curing heating Curing heating/ functional heating Manually
<b>851</b>	<b>1151</b>	<b>1451</b>	<b>Floor curing setp manually</b>
		<b>1455</b>	<b>Floor curing setp current</b>
		<b>1456</b>	<b>Floor curing day current</b>
		<b>1457</b>	<b>Floor curing days complete</b>

### Floor curing function

The floor curing function ensures controlled drying of the floor. It controls the flow temperature according to a temperature profile. Drying of the floor is ensured via the floor heating system and the mixing or pump heating circuit.

#### Off:

Function is deactivated.

#### Functional heating (Fh) :

The first part of the temperature profile is automatically completed.

#### Floor curing heating (Bh)

The second part of the temperature profile is traversed automatically.

#### Functional and floor curing heating

The entire temperature profile (first and second part) is passed automatically.

#### Floor curing heating and functional heating


The entire temperature profile (first and second part) is traversed automatically.

#### Manually

It is not a temperature profile that is completed, but the floor setpoint is controlled manually.



- Observe the relevant standards and regulations of the floor manufacturer!
- Proper functioning is ensured only when the plant is correctly installed (hydraulic system, electrical installation, settings)!  
If not observed, the floor might get damaged!
- The function can be aborted by choosing **Off**.
- Maximum limitation of the flow temperature remains active.



X Start day  
Fh Functional heating  
Bh Floor curing heating

Floor curing setp manual

The flow temperature setpoint for the "Manual" floor-curing function can be set separately for each heating circuit.

Floor curing setp current

Shows the current flow temperature setpoint of the floor-curing process in progress

Floor curing day current

Shows the current day of the floor-curing process in progress.

### Excess heat draw

Line no.			Operating line
HC1	HC2	HC3P	
<b>861</b>	<b>1161</b>	<b>1461</b>	<b>Excess heat draw</b> Off Heating mode Always

Excess heat draw can be triggered by the following functions:

- Inputs H1, H2, H3 or EX2
- Storage tank recooling
- Solid fuel boiler excess heat draw

When dissipation of excess heat is activated, it can be drawn by space heating. This can be adjusted separately for each heating circuit.

### Buffer storage tank / primary controller

Line no.			Operating line
HC1	HC2	HCP	
<b>870</b>	<b>1170</b>	<b>1470</b>	<b>With buffer storage tank</b>
<b>872</b>	<b>1172</b>	<b>1472</b>	<b>With primary controller / system pump</b>

With buffer storage tank

If there is a buffer storage tank, specify whether the heating circuit can draw heat from it.

When using alternative heat sources, the buffer storage tank temperature is used as a control criterion for the release of additional heat sources.

With primary controller / system pump

Specify whether the heating circuit receives its heat via the primary controller or with the help of the system pump (depending on the type of plant).

## Speed-controlled pump

RVS63.. only
RVS63.. only

Line no.			Operating line
HC1	HC2	HCP	
<b>882</b>	<b>1182</b>	<b>1482</b>	<b>Pump speed min</b>
<b>883</b>	<b>1183</b>	<b>1483</b>	<b>Pump speed max</b>

Pump speed min

The minimum speed of the heating circuit pump can be defined.

Pump speed max

The maximum speed of the heating circuit pump can be defined.

## Remote control

Line no.			Operating line
HC1	HC2	HCP	
<b>900</b>	<b>1200</b>	<b>1500</b>	<b>Optg mode changeover</b> None   Protection   Reduced   Comfort   Automatic

In the case of external changeover via inputs H1 / H2 / H3, the operating mode to be used can be selected.

## 5.6 Cooling circuit

For the operation of a cooling circuit, the cooling function must be enabled (operating line 901) and released in accordance with a time program (operating line 907). The system automatically operates in cooling mode when the room temperature rises above the Comfort cooling setpoint (operating line 902).

Cooling mode is interrupted if there is a heating demand from heating/cooling circuit 1, or if a heating demand signal is received from the DHW circuit or another heating circuit.

### Operating mode

Line no.	Operating line
<b>901</b>	<b>Operating mode</b> Off   Automatic

This line is used to set the operating mode for cooling.



This setting is the same as the selection of cooling mode with the cooling button on a room unit.

#### Off

The cooling function is switched off.

#### Automatic

Automatic mode controlled by the time program, presence button or holiday program, subject to the enable conditions set via operating line 907.



If the cooling enable signal is set to 24h/day via operating line 907, then the cooling button can be used as an on/off button.

### Setpoints

Line no.	Operating line
<b>902</b>	<b>Comfort cooling setpoint</b>

Room setpoint in cooling mode.



Summer compensation, operating line 920 can raise the setpoint as a function of the outside temperature.

### Release

Line no.	Operating line
<b>907</b>	<b>Release</b> 24h/day   Time programs HCs   Time program 5

The parameter "Release" determines the time program in accordance with which cooling is enabled.

#### 24 h/day

Cooling is released continuously (24 hours a day)

#### Time programs, HCs

Cooling is released in accordance with the heating circuit time program

#### Time program 5

Cooling is released in accordance with time program 5.

## Cooling curve


Line no.	Operating line
<b>908</b>	<b>Flow setpoint at outside temperature of 25°C</b>
<b>909</b>	<b>Flow setpoint at outside temperature of 35°C</b>

Flow temperature setpoint

The controller determines the required flow temperature at a specific composite outside temperature. The cooling curve is determined by defining two fixed points (the flow temperature setpoint at 25°C and 35°C).



The programmed cooling curve is based on a room setpoint of 25°C. If the room setpoint is adjusted, the cooling curve automatically adapts to the new value.



TVKw Flow temperature setpoint, cooling  
TAgem Composite outside temperature

## ECO

Line no.	Operating line
<b>912</b>	<b>Cooling limit at OT (outside temperature)</b>
<b>913</b>	<b>Locking period at end of heating</b>

Cooling limit at TA (outside temperature)

If the composite outside temperature rises above the cooling limit temperature, cooling is enabled; cooling is disabled when the outside temperature drops to at least 0.5°C below the cooling limit temperature.

Locking period at end of heating

To avoid too rapid a change to cooling at the end of the heating phase, the cooling function is disabled for the period which can be set here. This "locking period" begins when there is no heating demand from heating circuit 1.



The locking period is ignored if the cooling function is enabled via the operating mode button.

## Summer compensation

Line no.	Operating line
<b>918</b>	<b>Start of summer compensation at OT</b>
<b>919</b>	<b>End of summer compensation at OT</b>
<b>920</b>	<b>Summer compensation setpoint increase</b>

In summer, the cooling comfort setpoint (902) is shifted upwards as the outside temperature increases. This saves cooling energy, and prevents too great a differential between the room and outside air temperature.

Start of summer compensation at OT


Summer compensation starts to take effect at the outside temperature set here. If the outside temperature continues to rise, the comfort setpoint is raised in parallel.

End of summer compensation at OT

Summer compensation takes full effect at this outside temperature (920). The comfort setpoint is not affected by any further increase in the outdoor temperature.

Summer compensation setpoint increase

This setting determines the maximum permissible increase in the comfort setpoint.



TRKw Cooling setpoint  
TA Outside temperature (OT)

**Flow temperature setpoint limits**

Line no.	Operating line
923	Min. flow setpoint at OT 25°C
924	Min. flow setpoint at OT 35°C

A low limit can be defined for the cooling flow temperature. The limit curve is determined by defining two fixed points.


There is also a low limit for the resulting flow setpoint, which must not fall below 5 °C.

Min. flow setpoint

This defines the lowest permissible flow temperature at a composite outside temperature of 25°C/25°C.



If there is no valid outside air temperature available, the controller uses the value "Flow setpoint min TA = 35°C"



TVKw Flow temperature setpoint for cooling (with low limit control)  
TVKw\_unb Flow temperature setpoint for cooling (without low limit control)  
TAgem Composite outside temperature

## Room influence

<i>Line no.</i>	<i>Operating line</i>
<b>928</b>	<b>Room influence</b>

### Compensation variants

When a room temperature sensor is used, there is a choice of 3 different types of compensation.

<i>Setting</i>	<i>Type of compensation</i>
– – – %	Weather compensation only *
1...99 %	Weather compensation with room influence
100 %	Room compensation only

\* Outside sensor required.

### Weather compensation only

The flow temperature is calculated via the cooling curve as a function of the composite outside temperature.

This type of compensation requires correct adjustment of the heating curve, since in this case, the control does not take account of the room temperature.

### Weather compensation with room influence

The deviation of the actual room temperature from the setpoint is measured and taken into account when controlling the temperature. In this way, account is taken of room temperature deviations, to facilitate more accurate room temperature control. The effect of the deviation is set as a percentage figure. The better the reference room (correct room temperature, correct mounting location, etc.) the higher the value can be set.

- Example:

Approx. 60 %      Good reference room conditions

Approx. 20 %      Unfavorable reference room



To activate the function, following must be considered:

- A room sensor must be connected.
- The "Room influence" setting must be selected between 1 and 99
- There should be no controlled valves in the reference room (mounting location of the room sensor) (If such valves are installed, they must be set to their fully open position).

### Room compensation only

The flow temperature is controlled depending on the room temperature setpoint, the current room temperature and the progression of the room temperature. For example, a slight increase of the room temperature causes an immediate drop of the following temperature.



To activate the function, following must be considered:

- A room sensor must be connected.
- "Room influence" must be set to 100 %.
- There should be no controlled valves in the reference room (mounting location of the room sensor) (If such valves are installed, they must be set to their fully open position).

## Room temp limitation

Line no.	Operating line
<b>932</b>	<b>Room temp limitation</b>


The room temperature limitation function makes it possible to disable the cooling circuit pump if the room temperature falls by more than the programmed offset from the effective room setpoint (with summer compensation, operating line 920).

The cooling circuit pump is activated again as soon as the room temperature returns to a level above the current room temperature setpoint.

While the "Room temperature limitation" function is active, no cooling request is sent to the heat source.

The function is deactivated in the following circumstances:

- No room temperature sensor
- "Room temp limitation" = ---
- "Room influence" (928) = --- (weather compensation only)



## Mixing valve control

Line no.	Operating line
<b>938</b>	<b>Mixing valve cooling offset</b>
<b>939</b>	<b>Actuator type</b> 2-position   3-position
<b>940</b>	<b>Switching differential</b> 2-pos
<b>941</b>	<b>Actuator running time</b>
<b>945</b>	<b>Mixing valve in heating mode</b> Control   Open

### Mixing valve cooling offset

The refrigeration demand from the mixing valve circuit to the heat source is reduced by the value set here. The purpose of this reduction is to enable the mixing valve controller to compensate for the fluctuation in temperature caused by the heat source (2-point control action).

### Actuator type

#### 2-position

The controller drives the actuator with only 1 relay output. When the output delivers a signal, the valve opens. When there is no signal, the valve will close automatically.

#### 3-position

The controller drives the actuator with 2 relay outputs. 1 of the outputs is used for opening the valve and 1 for closing the valve.

### Switching differential 2-pos

For the 2-position actuator, the "2-position switching differential" must also be adapted. Three-position actuators are not affected by the switching differential.

Actuator running time

For the 3-position actuator, the running time of the mixing valve actuator can be adjusted. The actuator running time has no effect on two-position actuators.

Mixing valve in heating mode

Defines the position of the mixing valve (Y1/Y2) when heating mode is active. This parameter has no effect in systems with hydraulically separate heating and cooling circuits.

**Controls** The valve is used for control in heating and cooling mode.

**Open** The valve is used for control in cooling mode and is open in heating mode.

### Dewpoint monitoring

Line no.	Operating line
<b>946</b>	<b>Dewpt monitor locking time</b>
<b>947</b>	<b>Flow setpt increase hygro</b>
<b>948</b>	<b>Start flow increase at R.H.</b>
<b>950</b>	<b>Flow temp diff dewpoint</b>

Dewpt monitor locking time

When the connected dewpoint monitor detects the **formation of condensation** it closes the contact, thereby **deactivating the cooling**.

The "dewpoint monitor locking time" set here starts running as soon as the contact re-opens. Cooling can only start after expiry of this locking time.

The dewpoint monitor must be assigned to the H.. input as "dewpoint monitor".



Flow setpt increase hygro

To prevent the formation of condensation due to excess indoor air humidity, a hygrostat can be used to implement a **fixed increase in the flow temperature**.

As soon as the air humidity rises above the value set on the hygrostat, the contact is closed and the flow temperature setpoint is increased by the amount programmed here. The hygrostat must be assigned to the H.. input as "Flow setpt increase hygro".




Start flow increase at R.H.

To prevent the formation of condensation due to excess indoor air humidity, a 0...10 V humidity measurement can be used to implement a **proportional increase in the flow temperature**.

If the relative humidity in the room exceeds the value defined by "Start flow increase at R.H." the flow temperature setpoint is increased proportionally. The start of the increase (operating line 949) and the maximum increase (operating line 947) can be programmed.

The humidity sensor must be assigned to the H.. input as "Relative room humidity 10V".



dT TVKw Flow setpoint increase  
r.F. Relative humidity  
BZ Operating line

Flow temp diff dewpoint

The dewpoint temperature is determined on the basis of the relative humidity of the indoor air and the associated room air temperature.


To prevent the formation of condensation on surfaces, a minimum limit is applied to the

flow temperature so that it remains above the dew point temperature by the value set here (operating line 950).

The function can be disabled with the setting ---.



The humidity sensor must be assigned to an H.. input as "Relative room humidity 10V", and a room temperature sensor must also be available (assigned to the H.. input as "Room temperature 10V" or room unit).



TVKw Flow temperature setpoint, cooling  
 TTP Dew point temperature  
 OT Outside temperature  
 BZ Operating line

#### Buffer storage tank / primary controller

Line no.	Operating line
<b>962</b>	<b>With buffer storage tank</b> No   Yes
<b>963</b>	<b>With primary controller / system pump</b> No   Yes

With buffer storage tank

If there is a buffer storage tank, this setting defines whether the cooling circuit can draw cooling energy from it.

With primary controller / system pump

This determines whether the cooling circuit is supplied via the primary controller or with the help of the system pump (depending on the type of plant).

#### Remote control

Line no.	Operating line
<b>969</b>	<b>Changeover of operating mode</b> None   Off   Automatic


In the case of external changeover via inputs H1 / H2 / H3, the operating mode to be used can be selected.

## 5.7 DHW

### Setpoints

Line no.	Operating line
<b>1610</b>	<b>Nominal setpoint</b>
<b>1612</b>	<b>reduced setpoint</b>

The DHW can be heated up according to different setpoints. These setpoints are activated depending on the selected operating mode, thus leading to different temperature levels in the DHW storage tank.



TWWR DHW reduced setpoint  
TWWN DHW nominal setpoint  
TWWmax DHW nominal setpoint maximum

### Priority

Line no.	Operating line
<b>1630</b>	<b>Charging priority</b> Absolute Shifting None MC shifting, PC absolute

When both space heating and DHW heating call for heat, the “DHW priority” function ensures that while DHW charging is in progress, the capacity of the boiler is used primarily for DHW.

#### Absolute priority

The mixing and pump heating circuit stay locked until DHW heating is finished.

#### Shifting priority

If the capacity of the heat source is not sufficient, the mixing and pump heating circuit will be restricted until DHW is heated up.

#### No priority

DHW heating and space heating take place at the same time.

In the case of tightly sized boilers and mixing heating circuits, it can happen that the DHW setpoint will not be reached if space heating demands considerable amounts of heat.

#### Mixing heating circuit shifting, pump heating circuit absolute

The pump heating circuits stay locked until the DHW storage tank is heated up. If the capacity of the heat source is not sufficient, the mixing heating circuits will also be restricted.

## Legionella function

Line no.	Operating line
<b>1640</b>	<b>Legionella function</b> Off Periodically Fixed weekday
<b>1641</b>	<b>Legionella funct periodically</b>
<b>1642</b>	<b>Legionella funct weekday</b> Monday...Sunday
<b>1644</b>	<b>Legionella funct time</b>
<b>1645</b>	<b>Legionella funct setpoint</b>
<b>1646</b>	<b>Legionella funct duration</b>
<b>1647</b>	<b>Legionella funct circ pump</b>

### Legionella function

- Periodically

The legionella function is repeated according to the period of time set (operating line 1641). The legionella setpoint is attained via a solar plant, independent of the period of time set, the period of time will be newly started.

- Fixed weekday

The legionella function can be activated on a fixed weekday (operating line 1642). When using this setting, heating up to the legionella setpoint takes place on the selected weekday, independent of previous storage tank temperatures.

### Legionella funct circ pump

During the time the legionella function is performed, the DHW circulating pump can be activated.



During the time the legionella function is carried out, there is a risk of scalding when opening the taps.

## Circulating pump

Line no.	Operating line
<b>1660</b>	<b>Circulating pump release</b> Time program 3 / HCP DHW release Time program 4 / DHW Time program 5
<b>1661</b>	<b>Circulating pump cycling</b>
<b>1663</b>	<b>Circulation setpoint</b>

### Circulating pump cycling

When the function is activated, the circulating pump is switched on for 10 minutes within the release time and then switched off again for 20 minutes.

### Circulation setpoint

If a sensor is installed in the DHW distribution pipe, the controller will monitor its actual value during the time the legionella function is performed. The adjusted setpoint must be maintained at the sensor during the adjusted "Dwelling time".

## 5.8 H.. pumps

### H.. pumps

RVS43.. only

RVS43.. only

RVS43.. only

RVS43.. only

RVS43.. only..

<i>Line no.</i>	<i>Operating line</i>
<b>2010</b>	<b>H1 Excess heat draw</b>
<b>2012</b>	<b>H1 with buffer storage tank</b>
<b>2014</b>	<b>H1 prim contr/system pump</b>
<b>2015</b>	<b>H1 Refrig demand</b> 2-pipe system 4-pipe system
<b>2035</b>	<b>H2 Excess heat draw</b>
<b>2037</b>	<b>H2 with buffer storage tank</b>
<b>2039</b>	<b>H2 prim contr/system pump</b>
<b>2040</b>	<b>H2 Refrig demand</b> 2-pipe system 4-pipe system
<b>2046</b>	<b>H3 Excess heat draw</b>
<b>2048</b>	<b>H3 with buffer</b>
<b>2050</b>	<b>H2 prim contr/system pump</b>

#### Excess heat draw

Excess heat draw can be triggered by the following functions:

- Inputs H1, H2, H3 or EX2
- Storage tank recooling
- Solid fuel boiler excess heat draw

When dissipation of excess heat is activated, it can be drawn by space heating. This can be adjusted separately for each heating circuit.

#### With buffer storage tank

If there is a buffer storage tank, this defines whether the H1/H2/H3 circuit can draw heat from it.

When using alternative heat sources, the buffer storage tank temperature is used as a control criterion for the release of additional heat sources.

#### With primary controller / system pump

This defines whether the H1/H2/H3 circuit receives its heat via the primary controller or with the help of the system pump (depending on the type of plant).

#### Refrigeration demand

##### **2-pipe system**

The cooling circuit with Hx and the heating circuits request cooling/heating from the same circuit.

##### **4-pipe system**

The cooling circuit with Hx and the heating circuits demand cooling/heating from separate circuits.

## 5.9 Swimming pool

### Setpoints

<i>Line no.</i>	<i>Operating line</i>
<b>2055</b>	<b>Setpoint solar heating</b>
<b>2056</b>	<b>Setpoint source heating</b>

Setpoint solar heating



When using solar energy, the swimming pool is heated up until this setpoint is reached. The protective collector overtemperature function can reactivate the collector pump until the maximum swimming pool temperature is reached.

Setpoint source heating

When using the heat source, the swimming pool is heated up until this setpoint is reached.

### Priority

<i>Line no.</i>	<i>Operating line</i>
<b>2065</b>	<b>Charging priority solar</b>

- No:

Swimming pool heating through solar charging does not give consideration to any priorities. If the storage tank charging priority (operating line 3822) is also deactivated, the swimming pool is heated alternately with the storage tanks, the temperature increase being 5 °C.

- Yes:

Swimming pool heating through solar charging is given priority. This also applies if a storage tank with charging priority (operating line 3822) would have to prefer other heat exchangers.

If no Hx inputs are used to enable the swimming pool, the swimming pool priority is determined by the parameter setting. The swimming pool is always enabled for solar heating.

If the swimming pool is enabled via one Hx input, the swimming pool priority is equivalent to the parameter setting. Solar heating must now be enabled via the Hx input.

If two Hx inputs are used to enable the swimming pool, the swimming pool takes priority when both Hx inputs are enabled. If only one Hx input is enabled, the swimming pool priority is determined by the parameter setting. If none of the Hx inputs are enabled, solar heating of the swimming pool is deactivated.

### Plant hydraulics

<i>Line no.</i>	<i>Operating line</i>
<b>2080</b>	<b>With solar integration</b>

This setting is made to indicate whether the swimming pool can be charged by solar energy.

## 5.10 Primary controller / system pump

### Primary controller / system pump

Line no.	Operating line
<b>2150</b>	<b>Primary controller / system pump</b> Before buffer st tank After buffer st tank

If the plant uses a buffer storage tank, it is to be set here whether, hydraulically, the primary controller or the system pump is installed upstream from the buffer storage tank.

## 5.11 Boiler

### Operating mode

Line no.	Operating line
<b>2203</b>	<b>Release below outside temp</b>
<b>2205</b>	<b>Economy mode</b> Off   On DHW   On
<b>2208</b>	<b>Full charging of buffer</b> Off   On

Release below outside temp

The boiler is only enabled only if the composite outside temperature is below this threshold. For the release, a fixed switching differential of ½ °C is used.

Economy mode

Economy mode can be selected from menu "Service/Special operation" (operating line 7139).

In Economy mode, the boiler is operated as follows:

Off: Remains locked  
DHW only: Boiler will be released for DHW charging  
On: Always released.

Full charging buffer

To ensure long on times, the heat source keeps operating until the buffer storage tank is fully charged.

### Setpoints

Line no.	Operating line
<b>2210</b>	<b>Setpoint min</b>
<b>2212</b>	<b>Setpoint max</b>

The controlled boiler temperature setpoint can be limited by selecting setpoint minimum and setpoint maximum. These limits can be regarded as protective functions for the boiler.


In normal operation, minimum limitation of the boiler temperature is the lower limit value of the controlled boiler temperature setpoint, depending on the boiler's operating mode.

In normal operation, maximum limitation of the boiler temperature is the upper limit value of the controlled boiler temperature setpoint and, at the same time, setpoint of the electronic limit thermostat (TR).



The setting range of setpoint minimum and setpoint maximum is limited by the setpoint of manual operation.

Example when using boiler operating mode "Automatic":



- Legend
- TK Boiler temp
  - TKw Boiler temperature setpoint
  - ...TKmax Maximum limitation of the boiler temperature
  - Tkmin Minimum limitation of the boiler temperature
  - SDK Switching diff
  - TAgem Composite outside temperature

### Minimum limitation of the return temperature

Line no.	Operating line
<b>2270</b>	<b>Return setpoint min</b>

Return setpoint min

If the boiler return temperature falls below the return temperature setpoint, maintained boiler return temperature becomes active.

Maintained boiler return temperature allows consumers to be influenced, control of a bypass pump or use of a return temperature controller.

### Output data

Line no.	Operating line
<b>2330</b>	<b>Output nominal</b>
<b>2331</b>	<b>Output of basic stage</b>


These settings are required in the case of cascaded boilers with different outputs.

### 2 x 1 cascade

RVS63.. only

Line no.	Operating line
<b>2340</b>	<b>Auto source seq 2x1 casc</b>

Automatic changeover of the heat source enables a lead boiler change at certain intervals. The boiler sequence changes when the selected time has elapsed.



When switching on automatic changeover, heat source 1 (T2) is always started up as the lead boiler.



The time remaining until the next changeover takes place and the current lead boiler are not displayed.

## 5.12 Cascade

---

### Control

<i>Line no.</i>	<i>Operating line</i>
<b>3532</b>	<b>Restart lock</b>
<b>3533</b>	<b>Switch-on delay</b>

### Restart lock

The restart lock prevents a deactivated heat source from being switched on again. It is released again only after the set time has elapsed. This prevents too frequent switching actions of the heat sources and ensures stable plant operating states.

### Switch-on delay

Correct adjustment of the switch-on delay ensures that plant operating conditions will be stable. This prevents too frequent switching actions of the boilers (cycling). In the case of a DHW request, the delay time is fixed at 1 minute.

### Boiler sequence

<i>Line no.</i>	<i>Operating line</i>
<b>3540</b>	<b>Auto source seq ch'over</b>
<b>3541</b>	<b>Auto source seq exclusion</b> None. First Last First and last
<b>3544</b>	<b>Leading source</b> Device 1...device 16

### Auto source seq ch'over


With automatic source sequence changeover, the boiler loads in a cascade can be influenced by defining the order of lead and lag boiler.

#### **Fixed order**

Setting - - - defines a fixed order. In that case, the lead boiler can be selected on operating line 3544; the other boilers are then switched on and off in the same order as the LPB device addresses.

#### **Order according to the number of operating hours**

On completion of the number of hours set, the boiler sequence in the cascade changes. It is always the boiler with the next higher device address which assumes the role of the lead boiler.



t = Total number of operating hours of all lead boilers [h]  
P = Total output of cascade [kW]

**Auto source seq exclusion**

Setting automatic source sequence exclusion is only used in connection with the activated heat source sequence (operating line 3540). Using automatic source sequence exclusion, the first and / or the last boiler can be exempted from automatic changeover.

**None.**

The order of switching on the boilers changes when the number of hours set is reached (operating line 3540).

**First**

The first boiler in terms of addressing will always be the lead boiler. With the other boilers, the order of switching on changes when the set number of hours is reached (operating line 3540).

**Last**

The last boiler in terms of addressing will always be the last. The other boilers change when the set number of hours is reached (operating line 3540).

**First and last**

The first boiler in terms of addressing will always be the lead boiler. The last boiler in terms of addressing will always be the last. The boilers in between change when the set number of hours is reached (operating line 3540).

**Leading source**

The leading source is only selected in connection with the fixed order of the heat source sequence (operating line 3540). The boiler selected as the lead boiler is always the first to be switched on, or the last to be switched off. The other boilers are switched on and off in the order of their device addresses.

**Minimum limitation of the return temperature**

Line no.	Operating line
3560	Return setpoint min

**Return setpoint min**


If the return temperature drops below the adjusted return setpoint, maintained boiler return temperature becomes active.. Maintained boiler return temperature allows consumers to be influenced or a return temperature controller to be used.

## 5.13 Solar

### Charging controller (dT)

Line no.	Operating line
<b>3810</b>	<b>Temperature differential ON</b>
<b>3811</b>	<b>Temp diff off</b>
<b>3812</b>	<b>Charg temp min DHW st tank</b>
<b>3815</b>	<b>Charging temp min buffer</b>
<b>3818</b>	<b>Charging temp min swi pool</b>

For charging the storage tank via the heat exchanger, the temperature differential between collector and storage tank/swimming pool must be sufficient, and the collector must have reached the minimum charging temperature for the storage tank/swimming pool.



Tkol	collector temp
On / Off	Collector pump
SdOn	Temperature differential ON
SdOff	Temperature differential OFF
TSp	Storage tank temperature
TLmin	Charging temp min DHW storage tank / buffer / swimming pool

### Priority

Line no.	Operating line
<b>3822</b>	<b>Charging prio storage tank</b> None DHW storage tank buffer storage tank
<b>3825</b>	<b>Charging time relative prio</b>
<b>3826</b>	<b>Waiting time relative prio</b>
<b>3827</b>	<b>Waiting time parallel op</b>
<b>3828</b>	<b>Delay secondary pump</b>



The priority circuit for the swimming pool (operating line 2065) can impact storage tank priority of solar charging and possibly charge the swimming pool before the storage tanks.

### Charging prio storage tank

If a plant uses several heat exchangers, it is possible to set a priority for the integrated storage tanks, which defines the charging sequence.

#### None

Every storage tank is charged alternately by 5 °C at a time, until every setpoint of level A, B or C (see below) is reached. The setpoints of the next higher level are approached only when all setpoints of the previous level have been reached.

### DHW storage tank

During solar charging, preference is given to the DHW storage tank. At every level A, B or C (see below), it is charged with priority. Only then will the other consumers of the same level be charged. As soon as all setpoints of a level are attained, those of the next level are approached, whereby priority is again given to the DHW storage tank.

### Buffer storage tank

During solar charging, preference is given to the buffer storage tank. At every level A, B or C (see below), it is charged with priority. Only then will the other consumers of the same level be charged. As soon as all setpoints of a level are attained, those of the next level are approached, whereby priority is again given to the buffer storage tank.  
Storage tank setpoints:

Level	DHW storage tank	Buffer storage tank	Swimming pool <sup>(1)</sup>
A	1610 Nominal setpoint	Buffer setpoint (slave pointer)	2055 Setpoint solar heating
B	5050 Charging temp max	4750 Charging temp max	2055 Setpoint solar heating
C	5051 Storage tank temp max	4751 Storage tank temp max	2070 Swimming pool temp max

<sup>(1)</sup> When priority for the swimming pool is activated (operating line 2065), the swimming pool is charged before the storage tanks.

Charging time relative prio

If the preferred storage tank cannot be charged in accordance with charging control, priority is transferred to the next storage tank or the swimming pool for the period of time set (e.g. too great temperature differential between collector and storage tank). As soon as the preferred storage tank (according to setting "Charging priority storage tank") is again ready to be charged, the transfer of priority will immediately be stopped.

If this parameter is disabled (---) charging proceeds in accordance with the "Charging prio storage tank" settings.

Waiting time relative prio

During the period of time set, the transfer of priority will be delayed. This prevents relative priority from intervening too frequently.

Waiting time parallel op

If solar output is sufficient and solar charging pumps are used, parallel operation is possible. In that case, the storage tank of the priority model can be the next to be simultaneously charged, in addition to the storage tank to be charged next. Parallel operation can be delayed by introducing a waiting time. This way, in the case of parallel operation, switching on of the storage tanks can be effected in steps. The setting (---) disables parallel operation.

Delay secondary pump

To remove any existing cold water in the primary circuit, operation of the secondary pump of the external heat exchanger secondary pump can be delayed.

### Start function

Line no.	Operating line
<b>3831</b>	<b>Min run time collector pump</b>
<b>3834</b>	<b>Collector start funct gradient</b>

Min run time collector pump

The collector pump remains on for at least the preset minimum run time.

Collector start funct gradient

When the temperature at the collector sensor rises, the collector pump is activated.

### Frost protection for the collector

Line no.	Operating line
<b>3840</b>	<b>Collector frost protection</b>


When there is risk of frost at the collector, the collector pump will be activated to prevent the heat-carrying medium from freezing.

- If the collector temperature falls below the frost protection temperature, the collector pump will be activated:  $TKol < TKolFrost$ .
- When the collector temperature returns to a level of  $1^\circ K$  above the frost protection temperature, the collector pump will be deactivated again:  $TKol > TKolFrost + 1$ .

### Overtemperature protection for the collector

Line no.	Operating line
<b>3850</b>	<b>Collector overtemp prot</b>

If there is a risk of overtemperature at the collector, storage tank charging is continued to reduce the amount of surplus heat. When the storage tank safety temperature is reached, charging will be stopped.



TSpSi	Storage tank safety temperature
TSp	Storage tank temperature
TKolUe	Collector temperature for overtemperature protection
TSpmax	Maximum charging temperature
Tkol	collector temp
On / Off	Collector pump
T	Temperature
t	Time

### Medium's evaporation temperature

Line no.	Operating line
<b>3860</b>	<b>Evaporation heat carrier</b>

If there is a risk of the heat carrying medium evaporating due to high collector temperatures, the collector pump will be deactivated to prevent it from reaching excessive temperatures. This is a protective pump function.

### Speed control

RVS63.. only
RVS63.. only

Line no.	Operating line
<b>3870</b>	<b>Pump speed min</b>
<b>3871</b>	<b>Pump speed max</b>

Pump speed  
Minimum/maximum

The solar pump motor speed is limited by a minimum and maximum permitted speed.

## Yield measurement

<i>Line no.</i>	<i>Operating line</i>
<b>3880</b>	<b>Antifreeze</b>
<b>3881</b>	<b>Antifreeze concentration</b>
<b>3884</b>	<b>Pump capacity</b>

The 24-hour and total solar energy yield (operating lines 8526 and 8527) is calculated, based on these data.

Antifreeze

Since the mixing ratio of the collector medium has an impact on heat transmission, the type of antifreeze used and its concentration must be entered in order to be able to determine the energy yield.

Pump capacity

The flow rate in l/h of the pump used must be determined and serves for calculating the volume delivered.

## 5.14 Solid fuel boiler

### Operating mode

Line no.	Operating line
<b>4102</b>	<b>Locking other heat sources</b>

Locking other heat sources

When the solid fuel boiler is put into operation, other heat sources, such as oil / gas boilers, will be locked.  
 Locking takes place as soon as the boiler temperature rises to a degree that crossing of the comparison temperature can be expected.  
 This anticipating function enables the locked heat sources to terminate any overrun of pumps before the solid fuel boiler pump is activated. Also, in the case of a common stack, it can be made certain that only one boiler is in operation at a time.

### Setpoints

Line no.	Operating line
<b>4110</b>	<b>Setpoint min</b>

Setpoint min


The boiler pump will be put into operation only when the boiler temperature has reached a minimum temperature level, in addition to the required temperature differential.

### Boiler / burner control

Line no.	Operating line
<b>4130</b>	<b>Temperature differential ON</b>
<b>4131</b>	<b>Temp diff off</b>
<b>4133</b>	<b>Comparative temp</b> DHW sensor B3 DHW sensor B31 Buffer storage tank sensor B4 Buffer storage tank sensor B41 Flow temperature setpoint Setpoint min

Delta T-controller

For the boiler pump to be put into operation, a sufficiently great temperature differential between boiler temperature and comparison temperature is required.



TKx     Boiler temp  
 Bx     Actual value of comparison temperature  
 On / Off     Boiler pump  
 SDon     Temperature differential ON  
 SDoff     Temp diff off

## 5.15 Buffer storage tank

### Automatic locks

Line no.	Operating line
<b>4720</b>	<b>Auto generation lock</b> None. With B4 With B4 and B41 / B42
<b>4722</b>	<b>Temp diff buffer/HC</b>
<b>4723</b>	<b>Temp diff buffer/CC</b>
<b>4724</b>	<b>Min st tank temp heat mode</b>
<b>4726</b>	<b>Max stor temp cooling mode</b>

### Auto generation lock

**None**

Function is deactivated.

**With B4:**

Sensor B4 is used to for locking and release of the heat source.

**With B4 and B41 / B42:**


Sensor B4 is used for the release of the heat source. For the heat generation lock, sensor B42 is used, and if this is not available, then B41.

### Temp diff buffer/HC

If the temperature differential  $\Delta T$  between the buffer storage tank and heat request from the heating circuit is sufficiently large, the heat required by the heating circuit is drawn from the buffer storage tank. The heat source is locked.




Using "Temp diff buffer/HC", the mixing valve boost of the temperature request from the heating circuit can be compensated.



4722 Temp diff buffer/HC  
B4 Upper buffer or combi storage tank sensor  
TVLw Flow temperature setpoint  
E Heat generation lock

### Temp diff buffer/CC

If the temperature differential  $\Delta T$  between the buffer storage tank and the cooling request from the cooling circuit is sufficiently large, the cooling energy required by the cooling circuit will be drawn from the buffer storage tank. The refrigeration source is locked.



TVLKw Flow temperature setpoint in cooling mode  
 K Refrig source

Min st tank temp heat mode

If the actual temperature of the buffer storage tank falls below this level, the heating circuits are shut down if no heat source is available.

Max stor temp. cooling mode

Cooling mode is disabled if the upper storage temperature (B4) is above the preset max. storage temperature for cooling mode. The cooling circuit pumps switch off and the mixing valves close. The cooling demand signal to the refrigeration generating plant persists. If the storage temperature falls below the maximum storage temperature minus 0.5°K, cooling is re-enabled.

**Stratification protection**

Line no.	Operating line
<b>4739</b>	<b>Stratification protection</b> Off   Always   With solid fuel boiler

Buffer tank stratification protection provides for hydraulic balancing between the consumers and the generator without the need for additional shut-off valves for the buffer storage tank.

When the function is active, the volume of water on the consumer side is adjusted so that where possible, the addition of colder water from the buffer storage tank is avoided.

**Off:**

The stratification protection function is switched off.

**Always:**


The stratification protection function is active when the source (generator) is enabled.

**With solid fuel boiler**

The stratification protection function is active only if the solid fuel boiler is enabled.



A common flow sensor B10 must be connected for this function.



**Overtemperature protection**

Line no.	Operating line
<b>4750</b>	<b>Charging temp max</b>

Solar energy charges the buffer storage tank until the preset maximum charging temperature is reached.



The protective collector overtemperature function can reactivate the collector pump until the maximum storage tank temperature is reached.

## Recooling

Line no.	Operating line
<b>4755</b>	<b>Recooling temp</b>
<b>4756</b>	<b>Recooling DHW/HCs</b>
<b>4757</b>	<b>Recooling collector</b> Off Summer Always

2 functions are available for recooling the buffer storage tank down to the recooling temperature.

### Recooling DHW/HCs

Heating energy can be drawn off either by space heating or the DHW storage tank. This can be selected separately for each heating circuit (operating page for heating circuit 1...).

### Recooling collector

If the collector is cold, the energy can be emitted to the environment via the collector surfaces.

## Plant hydraulics

Line no.	Operating line
<b>4783</b>	<b>With solar integration</b>

Select here whether the buffer storage tank can be charged by solar energy.

## Return diversion

Line no.	Operating line
<b>4790</b>	<b>Temp diff on return div</b>
<b>4791</b>	<b>Temp diff off return div</b>
<b>4795</b>	<b>Compar temp return div</b> B4   B41   B42
<b>4796</b>	<b>Optg action return diversion</b> Temp decrease Temp increase

If there is a certain temperature differential between the common return temperature sensor (B73) and the selectable comparative temperature, the return is diverted through the lower section of the buffer storage tank. The function can be used for a **return temperature increase** or **return temperature decrease** (to be selected on operating line 4796). This is defined on operating line 4796.

In addition, the setting of the respective relay output is to be made as "Buffer diverting valve Y15" in configuration "Relay output QX1, 2, 3, 4" (operating lines 5890, 5891, 5892 and 5894) and the common return temperature sensor (B73) at BX.

### Temp diff on/off return div

The selected temperature differential defines the switch-on / off point of return diversion.

### Compar temp return div

Selection of the buffer storage tank temperature sensor with which the return temperature is compared in order to switch the return diversion based on the selected temperature differentials.

### Optg action return diversion

#### Temperature decrease

If the consumers' return temperature is higher than the temperature at the selected sensor (operating line 4795), the return can be used to preheat the lower storage tank section. As a result, the return temperature drops further which, in the case of a condensing boiler, leads to higher efficiency.

#### Temperature increase

If the consumers' return temperature is lower than the temperature at the selected sensor (operating line 4795), the return temperature can be raised by diverting the return through the lower storage tank section. As a result, the return temperature increases.

## Partial charging

Line no.	Operating line
<b>4800</b>	<b>Partial charging setpoint</b>

By hydraulically decoupling the lower buffer storage tank section, the chargeable storage volume is reduced. As a result, the upper storage tank section is charged in a shorter period of time. The lower storage tank section is only charged when charging of the upper section is completed.

As soon as the temperature acquired by the temperature sensor (B4/B42) reaches the setpoint of partial charging, the diverting valve change over to "through-port" and the rest of the storage tank is charged also.

For changeover, a fixed switching differential of  $\frac{1}{4}$  °C is used.



If the slave pointer is higher than the adjusted setpoint of partial charging, charging to the slave pointer value takes place.


Configuration:

Extra function QX...  
(operating lines 5890...5894)

Return diverting valve Y15 in the buffer storage tank

Sensor input BX...  
(operating lines 5930...5933)

Buffer storage tank sensor B4 or B42



## Cooling

If the buffer storage tank was used to satisfy a heating request, it will be locked to all refrigeration demand signals for 24 hours.

## 5.16 DHW storage tank

### Charging control

Line no.	Operating line
<b>5020</b>	<b>Flow setpoint boost</b>
<b>5021</b>	<b>Transfer boost</b>
<b>5022</b>	<b>Type of charging</b> With B3 With B3 and B31 With B3, legio B3 and B31

Increase of the flow temperature setpoint

The DHW request to the boiler is made up of the current DHW setpoint plus the adjustable charging boost.

Increase of transfer boost

Heat transfer makes it possible to transport energy from the buffer storage tank to the DHW storage tank. In that case, the actual buffer storage tank temperature must be higher than the actual temperature of the DHW storage tank. The temperature differential can be set here.

Type of charging

The storage tank can be charged using up to 2 sensors. It is also possible to combine partial charging with 1 sensor and the legionella function with 2 sensors (setting 3).

### Overtemperature protection

Line no.	Operating line
<b>5050</b>	<b>Charging temperature max</b>

Solar energy charges the DHW storage tank up to the adjusted maximum DHW charging level.



The protective collector overtemperature function can reactivate the collector pump until the maximum storage tank temperature is reached.

### Recooling

Line no.	Operating line
<b>5055</b>	<b>Recooling temperature</b>
<b>5056</b>	<b>Recooling boiler/HC</b>
<b>5057</b>	<b>Recooling collector</b> Off Summer Always

Recooling heat gen/HCs

For recooling the DHW storage tank, there are 2 functions available:

- Heating energy can be drawn off either by space heating or the DHW storage tank. This can be selected separately for each heating circuit (operating page heating circuit 1...).

Recooling collector

- If the collector is cold, the energy can be emitted to the environment via the collector's surfaces.

**Electric immersion heater**

Line no.	Operating line
<b>5060</b>	<b>El imm heater optg mode</b> Substitute Summer Always
<b>5061</b>	<b>El immersion heater release</b> 24h/day DHW release Time program 4 / DHW
<b>5062</b>	<b>El immersion heater control</b> External thermostat 2nd DHW sensor

Electric immersion heater:operating mode

**Substitute**

The electric immersion heater is only used if the boiler delivers a fault status message or has been shut down via boiler lock. This means that in normal situations the DHW is always heated by the boiler.

**Summer**

The electric immersion heater is used as soon as all connected heating circuits have switched to summer operation. The DHW is again heated by the boiler as soon as at least one of the heating circuits has switched back to heating operation. But the electric immersion heater is also used if the boiler delivers a fault status message or has been shut down via boiler lock.

**Always**


DHW is heated with the electric immersion heater throughout the year. This means that when using this application, the boiler is never required for DHW heating.

Electric immersion heater release

**24h/day**

The electric immersion heater is always released, independent of time programs.


Example:



**DHW release**

The electric immersion heater is switched on and off according to DHW release.


Example:



### Time program 4 / DHW

For the electric immersion heater, time program 4 / DHW of the local controller is taken into account.

Example:



El immersion heater control

### External thermostat

The storage tank is charged with an external thermostat without setpoint compensation of the controller.

### DHW sensor

The storage tank is charged with an electric immersion heater, with setpoint compensation from the controller.



To ensure that setpoint compensation operates as required, the external control thermostat must be set to the minimum storage temperature.

### Plant hydraulics

Line no.	Operating line
<b>5090</b>	<b>With buffer storage tank</b>
<b>5092</b>	<b>With prim contr/system pump</b>
<b>5093</b>	<b>With solar integration</b>

With buffer storage tank

If there is a buffer storage tank, specify whether the DHW storage tank can draw heat from it.

When using alternative heat sources, the buffer storage tank temperature is used as a control criterion for the release of additional heat sources.

With primary controller / system pump

It is to be set whether the DHW storage tank receives its heat via the primary controller or with the help of the system pump (depending on the type of plant).

With solar integration

It is to be set whether the DHW storage tank receives its heat from the solar collectors.

### Speed-controlled pump

RVS63.. only
RVS63.. only

Line no.	Operating line
<b>5101</b>	<b>Pump speed min</b>
<b>5102</b>	<b>Pump speed max</b>

Charging pump speed control

The charging pump motor speed is limited by a minimum and maximum permitted speed.

To ensure that the pump operates reliably on start-up, it is operated at maximum speed for the first 10 seconds.

## 5.17 Instantaneous DHW heater

### Setpoints

Line no.	Operating line
<b>5406</b>	<b>Min setp diff to tank temp</b>

The maximum DHW temperature setpoint controlled is the current storage tank temperature minus the adjustable setpoint differential.

### Mixing valve control

Line no.	Operating line
<b>5544</b>	<b>Actuator running time</b>

### Actuator running time

Setting the running time of the actuator used with the mixing valve.

## 5.18 Configuration

### Heating circuits

Line no.		Operating line
HC1	HC2	
<b>5710</b>	<b>5715</b>	<b>Heating circuit 1, 2</b>

Using this setting, the heating circuits can be switched on and off.

RVS43.. only


Line no.	Operating line
<b>5711</b>	Cooling circuit 1 Off 4-pipe system 2-pipe system
<b>5712</b>	Use of mixing valve 1 Heating Cooling Heating and cooling

### Cooling circuit 1

#### Off


The cooling circuit is deactivated.

#### 4-pipe system




The cooling and heating circuits draw their cooling/heating energy from separate primary circuits.

#### 2-pipe system



The cooling and heating circuits draw their cooling/heating energy from the same primary circuit.

## Use of mixing valve 1



The setting is required when a QX... relay output (configuration) is used as a diverting cooling valve Y2.

## DHW sensor B3

Line no.	Operating line
<b>5730</b>	<b>DHW sensor B3</b> Sensor Thermostat

### Sensor

The collector calculates the switching points including the switching differential from the DHW setpoint and the acquired DHW storage tank temperature.

### Control thermostat

The DHW temperature is controlled based on the switching state of a thermostat connected to B3.



When using a DHW thermostat, Reduced mode is not possible. This means that when Reduced mode is active, DHW heating with the thermostat is locked.



- The adjustment of the nominal DHW temperature setpoint must be equal to or higher than the setpoint adjustment on the thermostat (thermostat calibrated at switch-off point)
- The flow temperature setpoint for DHW must be set to a minimum of 10 °C (has an impact on the charging time).
- In that case, the DHW is not protected against frost.

## DHW control element Q3

Line no.	Operating line
<b>5731</b>	<b>DHW actuating device Q3</b> None Charging pump Diverting valve

### None

No DHW charging via Q3.

### Charging pump

The DHW is charged with a pump connected to terminal Q3/Y3.

### Diverting valve

The DHW is charged with a diverting valve connected to terminals Q3/Y3. With this setting, pump Q2 becomes a boiler pump, provided the boiler pump is not yet defined for use at a multifunctional relay output QX...

## Separate DHW circuit

<i>Line no.</i>	<i>Operating line</i>
<b>5736</b>	<b>Separate DHW circuit</b>

The separate circuit can only be employed if a boiler cascade is used.

### OFF:

The separate circuit is switched off. Every boiler in use can charge the DHW storage tank

### ON:

The separate circuit is switched on. DHW charging takes place exclusively via the boiler defined for that purpose.




For the separate circuit, DHW controlling element Q3 must be set to "Diverting valve"!

## Boiler

<i>Line no.</i>	<i>Operating line</i>
<b>5770</b>	<b>Type of heat source</b> 1-stage 2-stage Modulating 3-position Modulating UX Without boiler sensor 2 x 1 cascade

## 1-stage

In the case of a 1-boiler plant, the burner stage of the single stage boiler is released as soon as a valid boiler temperature setpoint becomes active.



### Connections:

	<i>Use</i>	<i>Space</i>	<i>Connector type</i>
L1	Phase burner	P	AGP8S.07A/109
⏚	Protective earth		
N	Neutral conductor		
T1	Phase 1st burner stage		
T2	1st burner stage on		
S3	Input burner fault		
4	Input 1st burner stage operating hours		

## 2-stage

If the required boiler temperature setpoint cannot be reached with the first burner stage, the second burner stage will be released (release integral satisfied). When the second burner stage is released, the first burner stage stays active, but setpoint control will be ensured by the second stage. The first stage can be switched off again only when the second stage is locked (reset integral satisfied).

Connections:

	Use	Space	Connector type
L1	Phase burner	P	AGP8S.07A/109
⏚	Protective earth		
N	Neutral conductor		
T1	Phase 1st burner stage		
T2	1st burner stage on		
S3	Input burner fault		
4	Input 1st burner stage hours run		
EX2	Input 1st burner stage hours run	Z	AGP8S.04C/109
FX4	Phase 2nd burner stage		
(T6)			
QX4	2nd burner stage off		
(T7)			
QX4	Burner 2nd stage on		
(T8)			


Modulating 3-position  
Modulating UX

**Boiler temperature control**

The functioning and activation and deactivation of the first stage corresponds to that of 2-stage burner operation. Release of modulation is analogous to the release of burner stage 2.

Deactivation or locking of modulation takes place at the same time the change from the first burner stage to cycling occurs.

Maximum limitation of the boiler temperature, minimum burner running time, cascade operation and DHW separation circuit are handled analogous to 2-stage burner operation.



Release integral modulation

- a) Release integral modulation (release integral second stage "2-stage burner")
- b) Reset integral modulation (reset integral second stage "2-stage burner")
- c) Neutral zone
- d) On / off pulses
- GSt Basic stage
- Mod Modulating stage
- SDK Switching differential boiler
- TKw Boiler temperature setpoint

### Burner control

- 3-position control and modulating UX

The actuator is controlled in PID mode. By setting the proportional band ( $X_p$ ), the integral action time ( $T_n$ ) and the derivative action time ( $T_v$ ), the controller can be matched to the type of plant (controlled system). Also, the actuator running time is to be set.

- Neutral zone

For control operation, a neutral zone is used which is at +/- 1K about the current boiler temperature setpoint. If the boiler temperature stays in the neutral zone for more than 16 seconds, the neutral zone becomes active and positioning pulses are no longer delivered. As soon as the boiler temperature leaves the neutral zone again, control is resumed. If the boiler temperature does not stay long enough in the neutral zone, positioning pulses will also be delivered within the neutral zone.

3-position connections:

	Use	Space	Connector type
L1	Phase burner	P	AGP8S.07A/109
⏚	Protective earth		
N	Neutral conductor		
T1	Phase release modulating burner		
T2	Release modulating burner		
S3	Input burner fault		
4	Input burner hours run		
QX1	Air damper modulating burner closing	U	AGP8S.03C/109
FX4 (T6)	Phase air damper modulating burner opening	Z	AGP8S.04C/109
QX4 (T8)	Air damper modulating burner opening		

Connections modulating UX:

	Use	Space	Connector type
L1	Phase burner	P	AGP8S.07A/109
⏚	Protective earth		
N	Neutral conductor		
T1	Phase release modulating burner		
T2	Release modulating burner		
S3	Input burner fault		
4	Input burner hours run		
UX	DC 0...10 V modulation output	n	AGP4S.02F/109
M	Ground		

Without boiler sensor


The boiler is released as soon as a valid boiler temperature setpoint is active.

Connections:

	Use	Space	Connector type
L1	Phase burner	P	AGP8S.07A/109
⏚	Protective earth		
N	Neutral conductor		
T1	Phase boiler release		
T2	boiler release		
S3	Input burner fault		
4	Input 1st burner stage hours run		

## 2 x 1 cascade

The 2x1 cascade is a special configuration of the basic unit, where the 2-stage boiler is operated as 2 cascaded 1-stage boilers.



Due to the temperature differential between boiler temperature setpoint and boiler temperature sensor B2 (common, mandatory cascade flow temperature sensor), switching on / off of the lag boiler (release and reset integral) takes place according to the control of a 2-stage burner. The same parameters are used.

If a boiler pump is required, QX1 and QX2 (operating lines 5890 and 5891) must be appropriately set.

A common boiler pump can be operated at any other multifunctional relay output QX parameterized as boiler pump Q1. The boiler pump of the lead boiler is always mapped on these outputs.

With the configuration of the 2x1 cascade (parameter "Type of heat source"), the following outputs and functions will be ready used or assigned.

	Use	Space	Connector type
L1	Phase burner	P	AGP8S.07A/109
⊥	Protective earth		
N	Neutral conductor		
T1	Phase burner 1		
T2	Burner 1 on		
S3	Input burner fault		
4	Input burner 1 hours run	Z	AGP8S.04C/109
EX2	Input burner 2 hours run		
FX4	Phase burner 2		
(T6)	Burner 2 OFF		
QX4			
(T7)	Burner 2 ON		
QX4			
(T8)			

## Solar

Line no.	Operating line
<b>5840</b>	<b>Solar controlling element</b> Charging pump Diverting valve
<b>5841</b>	<b>External solar exchanger</b> Jointly DHW storage tank buffer storage tank

### Solar controlling element

In place of a collector pump and diverting valves for integrating the storage tanks, the solar plant can also be operated with charging pumps.

When using a diverting valve, it is always only one heat exchanger that can be used at a time. Only alternative operation is possible.

When using a charging pump, all heat exchangers can be used at the same time. Either parallel or alternative operation is possible.

External solar exchanger

In the case of solar plants with 2 storage tanks, it must be selected whether the external heat exchanger shall be used jointly for DHW and as a buffer storage tank, or exclusively for one of the two.

Output relay QX

Line no.	Operating line
<b>5890</b>	<b>Relay output QX1,</b>
<b>5891</b>	<b>2 ,3, 4</b>
<b>5892</b>	None
<b>5894</b>	Circulating pump Q4 El imm heater DHW K6 Collector pump Q5 H1 pump Q15 Boiler pump Q1 Bypass pump Q12 Alarm output K10 2nd pump speed HC1 Q21 2nd pump speed HC2 Q22 2nd pump speed HCP Q23 Heat circ pump HCP Q20 H2 pump Q18 System pump Q14 Heat gen shutoff valve Y4 Solid fuel boiler pump Q10 Time program 5 K13 Buffer return valve Y15 Solar pump ext exch K9 Solar ctrl elem buffer K8 Solar ctrl elem swi pool K18 Collector pump 2 Q16 H3 pump Q19 Flue gas relay K17 Assisted firing fan K30 Cascade pump Q25 St tank transfer pump Q11 DHW mixing pump Q35 DHW interm circ pump Q33 Heat request K27 Refrig demand K28 Dehumidifier K29 Diverting valve, cooling Y21

Depending on the selection made, setting the relay outputs assigns appropriate extra functions to the basic diagrams. For detailed information, refer to the section "Application diagrams".



Multifunctional output QX4 can be used only if the operating line "Source type" (operating line 5770) is set to "1-stage", "Modulating UX" or "Without boiler sensor".

**DHW circulating pump Q4**

The connected pump serves as a DHW circulating pump. Operation of the pump can be scheduled as required on operating page "DHW", operating line "Release circulating pump".

**DHW electric immersion heater K6**

Using the connected electric immersion heater, the DHW can be heated up according to operating page "DHW storage tank", operating line "electric immersion heater".



The electric immersion heater must be fitted with a safety limit thermostat!



Operating line 5060 of the electric immersion heater's operating mode must be appropriately set.

### Collector pump Q5

When using a solar collector, a circulating pump for the collector circuit is required.

### Pump H1 Q15

Pump H1 can be used for an additional consumer. Together with an external request for heat at input H1, it is possible to operate an air heater or similar.

### Boiler pump Q1

The connected pump is used for circulating the boiler water.

### Bypass pump Q12

The connected pump serves as a boiler bypass pump for maintaining the boiler return temperature.

### Alarm output K10

The alarm relay signals faults, should they occur.

Switching on takes place with a delay of two minutes.

When the fault is corrected, that is, when the fault status is no longer present, the relay will be deenergized with no delay.



If the fault cannot immediately be corrected, it is still possible to reset the alarm relay. This is made on operating page "Faults".

### 2nd pump speed

This function facilitates the control of a 2-speed heating circuit pump, allowing the pump's capacity to be lowered in reduced mode (e.g. during night setback). In that case, multifunctional relay QX is used to activate the 2nd pump speed in the following manner:

1st speed output Q2/Q6/Q20	2nd speed Output Q21/Q22/Q23	Pump state
Off	Off	Off
On	Off	Part load
On	On	Full load

### Heating circuit pump HCP Q20

Pump heating circuit P will be activated.

- Time program

For heating circuit P, only time program 3/HCP is available. For more detailed information, refer to section "Time program".

### H2 pump Q18

Pump H2 can be used for an additional consumer. Together with an external demand for heat at input H2, it is possible to serve an air heater or similar.

### System pump Q14

The connected pump can be used as a system pump for supplying heat to other consumers.

The system pump is put into operation as soon as one of consumers calls for heat. If there is no demand for heat, the pump will be deactivated followed by overrun.

**Heat gen shutoff valve Y4**

If the buffer storage tank holds a sufficient amount of heat, the consumers can draw their heat from it, and the heat sources need not be put into operation.

Automatic heat generation lock locks the heat sources and hydraulically disconnects them from the rest of the plant with the help of heat source shutoff valve Y4.

This means that the heat consumers draw their energy from the buffer storage tank and wrong circulation through the heat sources will be eliminated.

**Solid fuel boiler pump Q10**

For the connection of a solid fuel boiler, a circulating pump for the boiler circuit is required.

**Time program 5 K13**

The relay is controlled according to the settings made in time program 5.

**Buffer return valve Y15**

This valve must be configured for return temperature increase / decrease or partial charging of the buffer storage tank.

**Solar pump ext exch K9**

For the external heat exchanger, solar pump "Ext heat exchanger K9" must be set at the multifunctional relay output (QX).

If both a DHW and a buffer storage tank are available, operating line 5841 "External solar heat exchanger" must also be set.

**Solar ctrl elem buffer K8**

If several heat exchangers are used, the buffer storage tank must be set at the respective relay output and, in addition, the type of solar controlling element must be defined on operating line 5840).

**Solar ctrl elem swi pool K18**

If several heat exchangers are used, the swimming pool must be set at the respective relay output and, in addition, the type of solar controlling element must be defined on operating line 5840).

**Collector pump 2 Q16**

When using a second solar collector, a separate circulating pump for this collector circuit is required.

**H3 pump Q19**

Pump H2 can be used for an additional consumer. Together with an external demand for heat at input H2, it is possible to serve an air heater or similar.

**Flue gas relay K17**

If the flue gas temperature exceeds the level set on operating line 7053 "Flue gas temperature limit", relay K17 closes.

**Assisted firing fan K30**

This setting has no function.

**Cascade pump Q25**

Common boiler pump for all boilers in a cascade.

### St tank transfer pump Q11

If the temperature level of the buffer storage tank is high enough, the DHW storage tank can be charged by the buffer. This transfer can be made by means of transfer pump Q11.

### DHW mixing pump Q35

Separate pump for storage tank circulation during the time the legionella function is active.

### DHW interm circ pump Q33

Charging pump with DHW storage tank using an external heat exchanger.

### Heat request K27

As soon as there is demand for heat, output K27 is activated.

### Refrig demand K28

As soon as there is refrigeration demand, output K28 is activated.

In the case of the device with address 1, a refrigeration demand from the system can activate output K28. For this purpose, operating line 6627 "Refrig demand K28" on the operating page "LPB system" must be set to "Centrally".

### Dehumidifier K29


An external dehumidifier can be enabled if the indoor air humidity rises. In this case, a humidity sensor must be connected to the H... input.

The function of the dehumidifier depends on the cooling functions.

The operation of the dehumidifier is not affected by operating modes, holiday programs, presence buttons etc.

### Diverting valve, cooling Y21

With a common distribution circuit for heating and cooling, the inputs/outputs are always on the mixing valve group on the basic unit. For a 4-pipe system, diverting valve Y21 is also required.



Example:  
Draw off via 4-pipe system

## Input sensor BX

<i>Line no.</i>	<i>Operating line</i>
<b>5930,5931, 5932, 5933</b>	<b>Sensor input BX1, 2, 3, 4</b> None DHW sensor B31 Collector sensor B6 Return sensor B7 DHW circulation sensor B39 Buffer storage tank sensor B4 Buffer storage tank sensor B41 Flue gas temp sensor B8 Common flow sensor B10 Solid fuel boiler sensor B22 DHW charging sensor B36 Buffer storage tank sensor B42 Common return sensor B73 Cascade return sensor B70 Swimming pool sensor B13 Collector sensor 2 B61 Solar flow sensor B63 Solar return sensor B64

Depending on the selection made, setting of the sensor input assigns appropriate extra functions to the basic diagrams. For detailed information, refer to section “Application diagrams“.

## Input H1 for RVS43..

The following settings for input H1 apply specifically to RVS43..

### Input H1 for RVS43..

<i>Line no.</i>	<i>Operating line</i>
<b>5950</b>	<b>Function of input H1</b> Optg mode changeover HCs+DHW Optg mode changeover HCs Optg mode changeover HC1 Optg mode changeover HC2 Optg mode changeover HCP Heat generation lock Error / alarm message Min flow temp setpoint Excess heat discharge Release swimming pool Dew point monitor Flow setpt increase hygro Refrigeration demand Heat request 10V Refrig demand 10V Pressure measurement 10V Relative room humidity 10V Room temperature 10V
<b>5951</b>	<b>Contact type input H1</b> NC N/O
<b>5952</b>	<b>Function value, contact type H1</b>
<b>5953</b>	<b>Voltage value 1, H1</b>
<b>5954</b>	<b>Function value 1, H1</b>
<b>5955</b>	<b>Voltage value 2, H1</b>
<b>5956</b>	<b>Function value 2, H1</b>

### Function of input H1

#### Changeover of operating mode

- Heating circuit

The operating modes of the heating circuits are switched to Protection mode via the H... terminals (e.g. using a remote telephone switch).

- DHW

DHW heating is locked only when using setting 1: HCs+DHW.

#### **Heat generation lock**

The heat source is be locked via the H... terminals.

All temperature requests made by the heating circuits and by DHW will be ignored.

Frost protection for the boiler will be maintained.



The chimney sweep function can be activated although the heat generation lock is switched on.

#### **Error / alarm message**

Input H1 generates a controller-internal error message.

If the "Alarm output" (relay outputs QX2-4, operating lines 5891 – 5894) is appropriately configured, the error message will be forwarded or displayed by an additional contact (e.g. an external lamp or horn).

#### **Minimum flow temperature setpoint TVHw**

The adjusted minimum flow temperature setpoint will be activated via terminals H1/2 (e.g. an air heater function for a warm air curtain) closes its contact.



The setpoint must be set via operating line 5952.

#### **Excess heat discharge**

Active dissipation of excessive heat enables an external heat source to force consumers (heating circuit, DHW storage tank, Hx pump) to draw excessive heat by delivering a forced signal.

The parameter "Excessive heat draw" can be used to determine for every consumer whether or not it should take account of the "forced" signal, and hence whether or not that consumer should participate in the dissipation of heat.

- Local effect

When using LPB device address 0 or >1, excessive heat dissipation only acts on the local consumers connected to the controller.

- Central effect (LPB)

When using LPB device address = 1, excessive heat dissipation also acts on the consumers connected to the other controllers in the same segment.

The distribution of excessive heat from segment 0 across other segments of the system is not possible.

#### **Release swimming pool**

This function can be used to enable **direct heating of the swimming pool** with the boiler and H... pump externally (e.g. with a manual switch)

For direct charging, a release signal is always required at the H.. input.

Configuration: Set the function of input H.. to "Release swimming pool" **and** select the associated H.. pump at a QX output.

The function can be used to enable **solar heating of the swimming pool** externally (e.g. with a manual switch) or to define solar charging priority over storage.

Configuration: Set the function of input H.. to "Release swimming pool". Refer to operating line 2065 "Charging priority solar" for a description of the function.

Function of input H... (5950, 6046, 5960)	Function of output QX..	Status of H..	Release status of generator
-	x	x	No direct heating
Sw. pool	"Not" H.. pump	x	No direct heating (H.. acts on solar function)
Sw. pool	H.. pump	Inactive	Released
Sw. pool	H.. pump	Active	Released

- = "Release swimming pool" not set

x = Not relevant

#### Dewpoint monitor

The dewpoint monitor detects the formation of condensate. If the dewpoint monitor responds to condensation, the cooling switches off immediately.

The cooling is enabled when the monitor is no longer signalling condensation and when a definable "locking time" (operating line 946) has expired.

#### Flow setpoint increase, hygrostat

If the hygrostat responds, the flow setpoint is increased by the fixed value defined in "Flow setpt increase hygro" (operating line 947). As soon as the hygrostat reverts to normal, the flow setpoint returns to the "normal value".

#### Refrigeration demand

The refrigeration demand is transmitted to the refrigeration generating plant via a contact.



The setpoint must be set via operating line 5952.

#### Heating demand 10V

Heat generation receives heat requests in the form of voltage signals (DC 0...10V). The linear characteristic curve is defined via two fixed points (voltage value 1 / function value 1 and voltage value 2 / function value 2).

#### Refrig demand 10V

Refrigeration generation receives the refrigeration demand in the form of a voltage signal (DC 0...10 V).

The linear characteristic curve is defined via two fixed points (voltage value 1 / function value 1 and voltage value 2 / function value 2).

#### Pressure measurement 10V

The voltage signal at input H... is converted to a pressure value in a linear manner.

The linear characteristic curve is defined via two fixed points (voltage value 1 / function value 1 and voltage value 2 / function value 2).

#### Relative room humidity 10V

The voltage signal present at input Hx is converted into a linearized relative humidity value. This is used for the dewpoint calculation and dewpoint protection functions of the cooling circuit and for control of the dehumidifier.

The linear characteristic curve is defined via two fixed points (voltage value 1 / function value 1 and voltage value 2 / function value 2).

### Room temperature 10V

The voltage signal present at input Hx is converted into a linearized room temperature value. This, in conjunction with the indoor relative humidity, is used to calculate the dewpoint temperature in the cooling circuit.

If there is no room unit with a room sensor (BSB) connected for heating/cooling circuit 1, the room temperature measured at Hx is also used for room heating/cooling 1 (variant with compensation and room influence).

The linear characteristic curve is defined via two fixed points (voltage value 1 / function value 1 and voltage value 2 / function value 2).

Contact type, input H...

**N/C**

The contact is normally closed and must be opened to activate the selected function.


**N/O**

The contact is normally open and must be closed to activate the selected function.

Function value, contact H..

The function "Min flow temp setpoint" on operating line 5950 or 6046 is activated via contact H... The generating plant is controlled constantly at the temperature level set here, either until contact H.. opens again or until a higher heating/cooling demand is delivered.

Example of minimum flow setpoint:



TVHw Minimum flow temperature setpoint  
TVw Flow temperature setpoint

Voltage value 1


Function value 1

Voltage value 2

Function value 2

The linear characteristic is defined via two fixed points. The setting uses two parameter pairs for *Function value* and *Voltage value* (F1/U1 and F2/U2).


- Example for "Heating demand 10V" and "Cooling demand 10V"




TVw Flow temperature setpoint  
UHx Voltage on Hx  
U1 Voltage value 1  
F1 Function value 1  
U2 Voltage value 2  
F2 Function value 2

If the input signal drops below the limit value of 0.15 V, the heating demand is invalid and therefore has no effect.

- Example of pressure measurement 10V




- Example of relative room humidity 10V



If the measured value is below 0.15V it is regarded as invalid and an error message is generated.

- Example of room temperature 10V



If the measured value is below 0.15V it is regarded as invalid and an error message is generated.

# Input H1 and H3 for RVS63..

The following settings for input H1 apply specifically to RVS43..

## Input H.. for RVS63..

Line no.	Operating line
<b>5950</b>	<b>function input H1</b> Optg mode changeover HCs+DHW Optg mode changeover HCs Optg mode changeover HC1 Optg mode changeover HC2 Optg mode changeover HCP Heat generation lock Error / alarm message Min flow temp setpoint Excess heat discharge Release swimming pool Heat request 10V Pressure measurement 10V
<b>5951</b>	<b>Contact type input H1</b> NC N/O
<b>5952</b>	<b>Min flow temp setpoint H1</b>
<b>5954</b>	<b>Temp value 10V H1</b>
<b>5956</b>	<b>Pressure value 3.5V H1</b>
<b>5960</b>	<b>Function input H3</b> Optg mode changeover HCs+DHW Optg mode changeover HCs Optg mode changeover HC1 Optg mode changeover HC2 Optg mode changeover HCP Heat generation lock Error / alarm message Min flow temp setpoint Excess heat discharge Release swimming pool Heat request 10V Pressure measurement 10V
<b>5961</b>	<b>Contact type H3</b> NC N/O
<b>5962</b>	<b>Min flow temp setpoint H3</b>
<b>5964</b>	<b>Temp value 10V H3</b>
<b>5966</b>	<b>Pressure value 3.5V H3</b>

## Function of input H...

### Changeover of operating mode

- Heating circuit

The operating modes of the heating circuits are switched to Protection mode via the H... terminals (e.g. using a remote telephone switch).

- DHW

DHW heating is locked only when using setting 1: HCs+DHW.

### Heat generation lock

The heat source is be locked via the H... terminals. All temperature requests from the heating circuits and DHW are ignored. Frost protection for the boiler is maintained.



The chimney sweep function can be activated although the heat generation lock is switched on.

### Error / alarm message

Input H1 generates a controller-internal error message.

If the "Alarm output" (relay outputs QX2-4, operating lines 5891 – 5894) is appropriately configured, the error message will be forwarded or displayed by an additional contact (e.g. an external lamp or horn).

### Minimum flow temperature setpoint TVHw

The adjusted minimum flow temperature setpoint will be activated via terminals H1/2 (e.g. an air heater function for a warm air curtain) closes its contact.

### Excess heat discharge

Active dissipation of excessive heat enables an external heat source to force consumers (heating circuit, DHW storage tank, Hx pump) to draw excessive heat by delivering a forced signal.

The parameter "Excessive heat draw" can be used to determine for every consumer whether or not it should take account of the "forced" signal, and hence whether or not that consumer should participate in the dissipation of heat.

- Local effect

When using LPB device address 0 or >1, excessive heat dissipation only acts on the local consumers connected to the controller.

- Central effect (LPB)

When using LPB device address = 1, excessive heat dissipation also acts on the consumers connected to the other controllers in the same segment.

The distribution of excessive heat from segment 0 across other segments of the system is not possible.

### Release swimming pool

This function can be used to enable **direct heating of the swimming pool** via the boiler and H... pump externally (e.g. with a manual switch)

For direct charging, a release signal is always required at the H.. input.

Configuration: Set the function of input H.. to "Release swimming pool" **and** select the associated H.. pump at a QX output.

This function can be used to enable **solar heating of the swimming pool** externally (e.g. with a manual switch) or to define solar charging priority over storage.

Configuration: Set the function of input H.. to "Release swimming pool". Refer to operating line 2065 "Charging priority solar" for a description of the function.

Function of input H... (5950, 6046, 5960)	Function of output QX..	Status of H..	Release status of generator
-	x	x	No direct heating
Sw. pool	"Not" H.. pump	x	No direct heating (H.. acts on solar function)
Sw. pool	H.. pump	Inactive	locked
Sw. pool	H.. pump	Active	Released

- = Swimming pool release not set

x = No effect

### Heating demand 10V

Heat generation receives heat requests in the form of voltage signals (DC 0...10V).

The flow temperature setpoint corresponding to the voltage level of 10 V can be adjusted via parameter "Temperature value 10V H...".

### Pressure measurement 10V

The voltage signal present at input H.. converted to a pressure value in a linear manner.

The pressure value at 0.5 V is fixed at 0 bar.

The pressure value at 3.5 V can be adjusted with parameter *Pressure value 3.5V H...* (operating line 5956).

Contact type, input H...

**N/C contact**

The contact is normally closed and must be opened to activate the selected function.

**N/O contact**


The contact is normally open and must be closed to activate the selected function.

Min flow temp setpoint H..

The function "Minimum flow setpoint" set on operating line 5950, 5960 or 6046 is activated via contact H... The boiler is controlled constantly at the temperature level set here either until contact H... opens again or until a higher heat request is delivered.



If several heat requests are received at the same time (LPB, contact H.. contact, DHW, or from the controller itself), the highest of them will automatically be selected.




TVHw Minimum flow temperature setpoint  
TVw Flow temperature setpoint

Temp value 10V H..

The voltage signal present at input H.. is converted to a linearized temperature value and then forwarded as the flow temperature setpoint.

The flow temperature setpoint corresponding to the voltage level of 10 V can be adjusted via parameter "Temperature value 10V H...".




T = maximum value of heat demand  
S = minimum limitation of heat demand = 5 °C

Pressure value 3.5V H...

The voltage signal present at input H... is converted into a linearized pressure value. The pressure value at 3.5 V can be adjusted with parameter *Pressure value 3.5V H..*.

Example:



p Pressure value (bar)  
H1 Voltage at H..

## Input EX2

Line no.	Operating line
<b>5982</b>	<b>Function input EX2</b> Counter for second burner stage Heat generation lock Error / alarm message SLT error message Excess heat discharge
<b>5983</b>	<b>Cont type input EX2</b> NC N/O

Function input EX2

### Counter for second burner stage

The counting values (hours run and number of starts) for the second burner stage are recorded based on the signal received at input EX2. If the function is not activated, the counting values are counted based on the state of relay K5 .

### Heat generation lock

The heat source will be locked via terminals EX2.

All temperature requests made by the heating circuits and by DHW will be ignored.

Frost protection for the boiler will be maintained.



The chimney sweep function can be activated although the heat generation lock is switched on.

### Error / alarm message

Input EX2 generates a controller-internal error message.

If the "Alarm output" (relay outputs QX2-4, operating lines 5891 – 5894) is appropriately configured, the error message will be forwarded or displayed by an additional contact (e.g. an external lamp or horn).

### SLT error message

The input generates error message 110.

### Excess heat discharge

Active dissipation of excessive heat enables an external heat source to force consumers (heating circuit, DHW storage tank, Hx pump) to draw excessive heat by delivering a forced signal.

The parameter "Excessive heat draw" can be used to determine for every consumer whether or not it should take account of the "forced" signal, and hence whether or not that consumer should participate in the dissipation of heat.

- Local effect

When using LPB device address 0 or >1, excessive heat dissipation only acts on the local consumers connected to the controller.

- Central effect (LPB)

When using LPB device address = 1, excessive heat dissipation also acts on the consumers connected to the other controllers in the same segment.

The distribution of excessive heat from segment 0 across other segments of the system is not possible.

### Mixing valve groups basic unit

<i>Line no.</i>	<i>Operating line</i>
<b>6014</b>	<b>Function mixing group 1</b> Heating circuit 1/2 Return temp controller Primary controller / system pump DHW primary controller Instantaneous DHW heater Return controller cascade Cooling circuit 1 Heating circuit/cooling circuit 1
<b>6015</b>	

The mixing valve groups are assigned to the following connections:

RVS63.283 only	
Mixing valve group 1	Mixing valve group 2
Q2, Y1, Y2, B1	Q6, Y5, Y6, B12

#### Heating circuit 1/2

For this application, the respective settings of operating page "Heating circuit 1/2" can be adapted.

#### Return temp controller

For this application, the respective settings of operating page "Boiler" can be adapted.

#### Primary controller / system pump

For this application, the respective settings of operating page "Primary controller / system pump" can be adapted.

#### DHW primary controller

For this application, the respective settings of operating page "DHW storage tank" can be adapted.

#### Instantaneous DHW heater

For this application, the respective settings of operating page "Instantaneous DHW heater" can be adapted.

#### Return controller cascade

For this application, the respective settings of operating page "Cascade" can be adapted.

### Cooling circuit 1

For this application, the respective settings of operating page “Cooling circuit 1” can be adapted.

### Heating circuit/cooling circuit 1

For this application, the respective settings of operating page “Heating circuit 1 and cooling circuit 1” can be adapted.

## Extension module

<b>6020, 6021</b>	<b>Function extension module 1, 2</b> No function Multifunctional Heating circuit 2 Return temp controller Solar DHW Primary controller / system pump DHW primary controller Instantaneous DHW heater Return controller cascade Cooling circuit 1
-----------------------	---

### Multifunctional

Functions that can be assigned to the multifunctional inputs / outputs appear on operating lines 6030, 6031, 6032 and 6040, 6041.

### Heating circuit 2

For this application, the respective settings of operating page “Heating circuit 2” can be adapted.

### Return temp controller

For this application, the respective settings of operating page “Boiler” can be adapted.

### Solar DHW

For this application, the respective settings of operating page “Solar” can be adapted.

### Primary controller / system pump

For this application, the respective settings of operating page “Primary controller / system pump” can be adapted.

### DHW primary controller

For this application, the respective settings of operating page “DHW storage tank” can be adapted.

### Instantaneous DHW heater

For this application, the respective settings of operating page “Instantaneous DHW heater” can be adapted.

### Return controller cascade

For this application, the respective settings of operating page “Cascade” can be adapted.

### Cooling circuit 1

For this application, the respective settings of operating page “Cooling circuit 1” can be adapted.

Connections:

	QX21	QX22	QX23	BX21	BX22	H2
<b>Multifunction</b>	*	*	*	*	*	*
<b>Heating circuit 2</b>	Y5	Y6	Q6	B12	*	*
<b>Return temp controller</b>	Y7	Y8	Q1	B7	*	*
<b>Solar DHW heating</b>	*	*	Q5	B6	B31	*
<b>Primary controller</b>	Y19	Y20	Q14	B15	*	*
<b>DHW primary controller</b>	Y31	Y32	Q3	B35	*	*
<b>Instantaneous DHW heater</b>	Y33	Y34	Q34	B38	B39	Flow switch
<b>Return controller cascade</b>	Y25	Y26	Q25	B70	B10	*
<b>Cooling circuit 1</b>	Y23	Y24	Q24	B16	*	*

\* Freely selectable in QX.../ BX...

## QX extension module

Can be configured for freely selectable QX.../ BX...

<i>Line no.</i>	<i>Operating line</i>
<b>6030</b>	<b>Relay output QX21, QX22, QX23</b>
<b>6031</b>	None
<b>6032</b>	Circulating pump Q4 EI imm heater DHW K6 Collector pump Q5 H1 pump Q15 Boiler pump Q1 Bypass pump Q12 Alarm output K10 2nd pump speed HC1 Q21 2nd pump speed HC2 Q22 2nd pump speed HCP Q23 Heat circ pump HCP Q20 H2 pump Q18 System pump Q14 Heat gen shutoff valve Y4 Solid fuel boiler pump Q10 Time program 5 K13 Buffer return valve Y15 Solar pump ext exch K9 Solar ctrl elem buffer K8 Solar ctrl elem swi pool K18 Collector pump 2 Q16 H3 pump Q19 Flue gas relay K17 Assisted firing fan K30 Cascade pump Q25 St tank transfer pump Q11 DHW mixing pump Q35 DHW interm circ pump Q33 Heat request K27 Refrig demand K28 Dehumidifier K29 Diverting valve, cooling Y21

Refer to function description, operating line "Relay output QX1".

## BX extension module

Can be configured for freely selectable QX.../ BX...

Line no.	Operating line
<b>6040</b>	<b>Sensor input BX21, BX22</b>
<b>6041</b>	None DHW sensor B31 Collector sensor B6 Return sensor B7 DHW circulation sensor B39 Buffer storage tank sensor B4 Buffer storage tank sensor B41 Flue gas temp sensor B8 Common flow sensor B10 Solid fuel boiler sensor B22 DHW charging sensor B36 Buffer storage tank sensor B42 Common return sensor B73 Cascade return sensor B70 Swimming pool sensor B13 Collector sensor 2 B61 Solar flow sensor B63 Solar return sensor B64

See the function description for operating line "Sensor input BX1".

## H2 extension module

Line no.	Operating line
<b>6046</b>	<b>Function input H2</b> Optg mode changeover HCs+DHW Optg mode changeover HCs Optg mode changeover HC1 Optg mode changeover HC2 Optg mode changeover HCP Heat generation lock Error / alarm message Min flow temp setpoint Excess heat discharge Release swimming pool Dew point monitor Flow setpt increase hygro Refrigeration demand Heat request 10V Refrig demand 10V Pressure measurement 10V Relative room humidity 10V Room temperature 10V
<b>6047</b>	<b>Contact type H2</b> NC N/O
<b>6048</b>	<b>Function value, contact H2</b>
<b>6049</b>	<b>Voltage value 1, H2</b>
<b>6050</b>	<b>Function value 1, H2</b>
<b>6051</b>	<b>Voltage value 2, H2</b>
<b>6052</b>	<b>Function value 2, H2</b>

RVS43.. only

RVS63.. only

<b>6048</b>	<b>Min flow temp setpoint H2</b>
<b>6050</b>	<b>Temp value 10V H2</b>
<b>6052</b>	<b>Pressure value 3.5V H2</b>

The settings for input H2 on the extension module are the same as those of the H.. inputs on the basic unit. They are described under the operating line "Function of input H..". Refer to page 114,119.

## 10V output UX

<i>Line no.</i>	<i>Operating line</i>
<b>6070</b>	<b>Function output UX</b> None Boiler pump Q1 DHW pump Q3 DHW interm circ pump Q33 Heat circ pump HC1 Q2 Heat circ pump HC2 Q6 Heat circ pump HCP Q20 Collector pump Q5 Solar pump ext exch K9 Solar pump buffer K8 Solar pump swi pool K18 Collector pump 2 Q16 Boiler setpoint Power demand Heat demand
<b>6071</b>	<b>Signal logic output UX</b> Standard Inverted
<b>6075</b>	<b>Temperature value 10V UX</b>

### Function output UX

The voltage-modulated output can be used either for speed-controlled pumps or as an output for a voltage-proportional temperature request.

#### **Speed-controlled pumps:**

The output signal at UX corresponds to the required speed for the selected pump.

#### **Boiler temp setpoint:**

The output signal at UX corresponds to the boiler setpoint

#### **Output demand:**

The output signal at UX is proportional to the output demand via the primary circuit flow.

#### **Heat request:**

The output signal at UX corresponds to the primary circuit flow setpoint.

### Signal logic output UX

The voltage signal can be inverted. Thus, it can also be used to control pumps with variable speeds, or temperature request receivers that use inverted signal logic.

### Temperature value 10V UX

This operating line is used to define the maximum temperature request (corresponding to 10 V).

## Types of sensor/readjustment

<i>Line no.</i>	<i>Operating line</i>
<b>6097</b>	<b>Sensor type collector</b> NTC 10k Platinum 1000
<b>6098</b>	<b>Readjustm collector sensor</b>
<b>6099</b>	<b>Readjustm coll sensor 2</b>
<b>6101</b>	<b>Sensor type flue gas temp</b> NTC 10k Platinum 1000
<b>6102</b>	<b>Readjustm flue gas sensor</b>

### Sensor type collector

Selection of type of sensor used. The controller will use the respective temperature characteristic.

### Readjustm collector sensor

The measured value can be corrected.

## Building and room model

Line no.	Operating line
<b>6110</b>	<b>Time constant building</b>

When the outside temperature varies, the room temperature changes at different rates, depending on the building's thermal storage capacity.

The above setting is used to adjust the response of the flow temperature setpoint when the outside temperature varies.

- Example:

> 20 hours

The room temperature responds *more slowly* to outside temperature variations.

10 - 20 hours

This setting can be used for most types of buildings.


< 10 hours

The room temperature responds *more quickly* to outside temperature variations.

## Frost protection for the plant

Line no.	Operating line
<b>6120</b>	<b>Frost protection plant</b>

The pumps are activated depending on the **current** outside temperature, even if there is no heat request.



## External requirements

Line no.	Operating line
<b>6128</b>	<b>Heat request below OT</b>
<b>6129</b>	<b>Heat request above OT</b>
<b>6131</b>	<b>Heat req in economy mode</b>
	Off   On DHW   On

### Heat request below OT

The heat source (K27 with QX... or output UX) is put into operation only if the outside temperature lies below / above the threshold.

### Heat req in economy mode

Economy mode can be selected from menu "Special operation / service" (operating line 7139).

In Economy mode, the heat source (K27 with QX.. or output UX) operates as follows:

Off: Remains locked

Only DHW: Released for DHW charging

On: Always released.

**Sensor state**

<i>Line no.</i>	<i>Operating line</i>
<b>6200</b>	<b>Save sensors</b>

At midnight, the basic unit stores the states at the sensor terminals.  
 If, after storage, a sensor fails, the basic unit generates an error message.  
 This setting is used to ensure immediate saving of the sensors. This becomes a requirement when, for instance, a sensor is removed because it is no longer needed.

**Parameter reset**

<i>Line no.</i>	<i>Operating line</i>
<b>6205</b>	<b>Reset to default parameters</b>

All parameters can be reet to their default values. Exempted from this are the following operating pages: Time of day and date, operator section, radio communication and all time programs.

**Plant diagram**

<i>Line no.</i>	<i>Operating line</i>
<b>6212</b>	<b>Check-No. heat source 1</b>
<b>6213</b>	<b>Check-No. heat source 2</b>
<b>6215</b>	<b>Check-No. storage tank</b>
<b>6217</b>	<b>Check-No. heating circuits</b>

To identify the current plant diagram, the basic unit generates a check number.  
 The check number is made up of the lined up part diagram numbers.

**Structure of control number**

Every control number consists of 3 columns, each representing the application of a plant component. Every column shows a number with a maximum of 2 digits. Exception is the first column. If the first digit in the first column is a 0, the 0 will be hidden.

	1st column 2 digits	2nd column 2 digits	3rd column 2 digits
BZ6212		Solar	Oil / gas boiler
BZ6213		Solid fuel boiler	
BZ6215		Buffer storage tank	DHW storage tank
BZ6217	Heating circuit P	Heating circuit 2	Heating circuit 1

Check-No. heat source 1

Solar					Oil / gas boiler									
One collector field with sensor B6 and collector pump Q5	2 collector fields with sensors B6 & B61 and collector pumps Q5 and Q16	Buffer tank c harging pump K8	Solar diverting valve, buffer K8	Solar charging pump, swimming pool K18	Solar diverting valve, swimming pool K18	External solar heat exchanger, solar pump K9	DHW = dom. hot water, B = Buffer	Check-Numbers	1-stage burner	2-stage burner	Modulating burner	Boiler pump	Bypass pump	Return mixing valve
0							No solar	00	No boiler					
1							*	01	x					
3							DHW/B	02		x				
5		x						03	x		x			
6			x					04		x	x			
8		x					DHW+B	05	x			x		
9			x				DHW/B	06		x			x	
10		x					DHW	07	x		x	x		
11			x				DHW	08		x	x	x		
12		x					B	09	x		x		x	
13			x				B	10		x	x			x
14				x				11			x			
15					x			12			x	x		
17					x		DHW/B	13			x		x	
18					x		DHW/B	14			x	x	x	
19		x		x				15			x	x		x
20			x		x									
22		x					DHW+B							
23			x		x		DHW/B							
24		x		x			DHW							
25			x		x		DHW							
26		x		x			B							
27			x		x		B							
31							*							
33							DHW/B							
35		x												
37	x						DHW+B							
38		x					DHW/B							
39	x						DHW							
40		x					DHW							
41		x					B							
42					x									
44				x			DHW/B							
45					x		DHW/B							
46			x		x									
48	x		x				DHW+B							
49		x		x			DHW/B							
50	x			x			DHW							
51		x		x			DHW							
52			x		x		B							

\* The DHW storage tank is charged with collector pump Q5.

Check-No. heat source 2

Solid fuel boiler	
0	No solid fuel boiler
1	Solid fuel boiler, boiler pump
2	Solid fuel boiler, boiler pump, integration DHW storage tank

Check-No. storage tank


	<b>Buffer storage tank</b>	<b>DHW storage tank</b>
	0 No buffer storage tank	0 No DHW storage tank
	1 buffer storage tank	1 electric immersion heater
	2 Buffer storage tank, solar connection	2 Solar connection charging pump
	4 Buffer storage tank, heat source valve	4 charging pump, solar connection
	5 Buffer storage tank, solar connection, heat source valve	5 Diverting valve
		13 Diverting valve, solar connection
		14 Primary controller, without heat exchanger
		16 Primary controller, 1 heat exchanger
		17 Intermediate circuit, without heat exchanger
		19 Intermediate circuit, 1 heat exchanger
		20 Charging pump / intermediate circuit, without heat exchanger
		22 Charging pump / intermediate circuit, 1 heat exchanger
		23 Diverting valve / intermediate circuit, without heat exchanger
		25 Diverting valve / intermediate circuit, 1 heat exchanger
		26 Primary controller / intermediate circuit, without heat exchanger
		28 Primary controller / intermediate circuit, 1 heat exchanger
		29

Check-No. heating circuit

	<b>Heating circuit P</b>	<b>Heating circuit 2</b>	<b>Heating circuit 1</b>
	0 No heating circuit	00 No heating circuit	0 No heating circuit
	2 2nd heating circuit pump	02 2nd heating circuit pump	1 Circulation via boiler pump
		03 Heating circuit pump, mixing valve	2 2nd heating circuit pump
			3 Heating circuit pump, mixing valve
			5..7 Heating/cooling, 2-pipe, common distribution
			8..10 Cooling only, 2-pipe
			12 Heating/cooling, 4-pipe, common distribution
			14..16 Heating/cooling, 4-pipe, common distribution
			20..27 Heating/cooling, 2-pipe, separate distribution
			30..38 Heating/cooling, 4-pipe, separate distribution
			40..42 Cooling only, 4-pipe

Example

Heat source      Solar with collector sensor and pump,  
 1-stage burner and boiler pump  
 Storage tank:    Charging pump and solar connection  
 Heating circuit 1: Heating circuit pump and mixing valve



Displays on the operator unit:

Check-No. heat source 1					1	0	1
Check-No. storage tank							5
Check-No. heating circuit							3

Device data

Line no.	Operating line
<b>6220</b>	<b>Software version</b> The software version indicated here represents the current version of the basic unit.

## 5.19 LPB

### Address / power supply

Line no.	Operating line
<b>6600</b>	<b>Device address</b>
<b>6601</b>	<b>Segment address</b>
<b>6604</b>	<b>Bus power supply function</b> Off Automatically
<b>6605</b>	<b>Bus power supply state</b> Off On

Device address and segment address

The controller LPB address is divided into 2 parts each consisting of two 2-digit numerals. Example:

_____	14	.	16	_____
_____	Segment number	_____	Device number	_____

Bus power supply

The bus power supply enables the bus system to be powered directly by the individual controllers (no central bus power supply). The type of bus power supply can be selected.

- Off: No bus power supply via the controller.
- Automatically: The bus power supply (LPB) via the controller is automatically switched on and off depending on the requirements of the LPB.

Bus power supply state

The display shows whether the controller currently supplies power to the bus:

- Off: The bus power supply via controller is currently inactive.
- On: The bus power supply via controller is currently active. At the moment, the controller supplies some of the power required by the bus.

### Central functions

Line no.	Operating line
<b>6620</b>	<b>Action changeover functions</b> Segment System
<b>6621</b>	<b>Summer changeover</b> Local Centrally
<b>6623</b>	<b>Changeover of operating mode</b>
<b>6624</b>	<b>Manual source lock</b>
<b>6625</b>	<b>DHW assignment</b> Local HCs All heating circuits in the segment: All HCs in system
<b>6627</b>	<b>Refrigeration demand</b> Locally; Centrally
<b>6631</b>	<b>Ext source with eco mode</b> Off; On DHW; On



These settings are only relevant for device address 1.

Range of action of changeover

The range of action of central changeover can be defined.

This applies to the following types of limitation:

- Summer changeover (when selecting "Central" on line 6623)
- Summer changeover (with "Central" setting on operating line 6621)

Entries:

- Segment: Changeover takes place with all controllers in the same segment.
- System: Changeover takes place with all controllers in the entire system (in all segments). The controller must be located in segment 0!

Summer changeover	<p>The scope of summer changeover is as follows:</p> <ul style="list-style-type: none"> <li>• Local entry: Local action; the local heating circuit is switched based on operating lines 730, 1030 and 1330.</li> <li>• Central entry: Central action; depending on the setting made on operating line "Action changeover functions", " either the heating circuits in the segment or those of the entire system are switched based on operating line 730.</li> </ul>
Changeover of operating mode	<p>The scope of the operating mode changeover via input H is as follows:</p> <ul style="list-style-type: none"> <li>• Local entry: Local action; the local heating circuit is switched on and off.</li> <li>• Central entry: Central action; depending on the setting made on operating line "Action changeover functions", either the heating circuits in the segment or those of the entire system are switched based on operating line 730.</li> </ul>
Manual source lock	<p>The range of action of summer changeover is as follows:</p> <ul style="list-style-type: none"> <li>• Local entry: Local action; the local source is locked.</li> <li>• Entry segment: Central action; all sources of the cascade are locked.</li> </ul>
Assignment of DHW heating	<p>Assignment of DHW heating is required only if it is controlled by a heating circuit program (refer to operating lines 1620 and 5061). Settings:</p> <ul style="list-style-type: none"> <li>• Local heating circuits: DHW is only heated for the local heating circuit</li> <li>• All heating circuits in the segment: DHW is heated for all heating circuits in the segment</li> <li>• All heating circuits in the system: DHW is heated for all heating circuits in the system.</li> </ul> <p>With all settings, controllers in holiday mode are also considered for DHW heating.</p>
Refrigeration demand	<p>"Refrigeration demand K28" sets the relay parameter on the QX.. for the output of the refrigeration demand.</p> <p>Depending on the setting (local/central) the demand is transmitted by the local cooling circuit or all cooling circuits in the system. This option applies only to the device with device address 1.</p>
Ext source with eco mode	<p>Economy mode can be selected from menu "Special operation / service" (operating line 7139). In Economy mode, external heat sources on the LPB are operated as follows:</p> <p>Off: Remains locked Only DHW: Released for DHW charging On: Always released.</p>

## Clock

<b>6640</b>	<b>Clock mode</b> Autonomously Slave without remote Slave with remote setting Master
<b>6650</b>	<b>Outside temp source</b>

### Clock mode

This setting defines the impact of the system time on the controller's time setting. The impact is as follows :

- **Autonomously:** The time of day on the controller can be readjusted  
The controller's time of day is not matched to the system time
- **Slave without remote adjustment:** The time of day on the controller cannot be readjusted  
The controller's time of day is constantly and automatically matched to the system time
- **Slave with remote adjustment:** The time of day on the controller can be readjusted; at the same time, the system time is readjusted since the change is adopted from the master.  
The controller's time of day is still automatically and constantly matched to the system time
- **Master:** The time of day on the controller can be readjusted  
The time of day on the controller is used for the system. The system time will be readjusted

### outside temperature source

Only 1 outside temperature sensor is required in the LPB plant. This sensor is connected to a freely selectable controller and delivers via LPB the signal to the controllers without sensor.

The first numeral to appear on the display is the segment no. followed by the device no.

## 5.20 Faults

When a fault  is pending, an error message can be displayed on the info level by pressing the Info button. The display describes the cause of the fault.

### Acknowledgements

<i>Line no.</i>	<i>Operating line</i>
<b>6710</b>	<b>Reset alarm relay</b>

When a fault is pending, an alarm can be triggered via relay QX... The QX... relay must be appropriately configured.

This setting can be used to reset the alarm relay.

### Temperature alarms

RVS43.. only

<i>Line no.</i>	<i>Operating line</i>
<b>6740</b>	<b>Flow temp 1 alarm</b>
<b>6741</b>	<b>Flow temp 2 alarm</b>
<b>6743</b>	<b>Boiler temp alarm</b>
<b>6745</b>	<b>DHW charging alarm</b>
<b>6746</b>	<b>Flow temp., Cooling 1 alarm</b>

The difference of setpoint and actual temperature is monitored. A control offset beyond the set period of time triggers an error message.

### Error history

<i>Line no.</i>	<i>Operating line</i>
<b>6800...6819</b>	<b>History ...</b>

The basic unit stores the last 10 faults in non-volatile memory. Any additional entry deletes the oldest in the memory. For each error entry, error code and time of occurrence is saved.

## 5.21 Maintenance/special mode

### Maintenance functions

Line no.	Operating line
<b>7040</b>	<b>Burner hoursinterval</b>
<b>7041</b>	<b>Burner hrssince maintenance</b>
<b>7042</b>	<b>Burner start interval</b>
<b>7043</b>	<b>Burn starts since maint</b>
<b>7044</b>	<b>Maintenance interval</b>
<b>7045</b>	<b>Time since maintenance</b>
<b>7053</b>	<b>Flue gas temp limit</b>
<b>7054</b>	<b>Delay flue gas message</b>
<b>7119</b>	<b>Economy function</b> Locked released
<b>7120</b>	<b>Economy mode</b> Off   On

Burner hours run interval,  
burner start interval

As soon as the selected number of burner operating hours or the selected number of burner starts has elapsed, a service message will be displayed.  
Counted for the message are the number of operating hours and the number of starts of the first burner stage (input E1).

Burner hours run, burner  
starts since service

The current value is summated and displayed. On this operating line, the value can be reset to 0.

Flue gas temp limit

Shows a maintenance message on the display and, if configured, activates flue gas relay K17.

Delay flue gas message

Delays display of the maintenance message and activation of the flue gas relay (K17).

Economy function

**Locked**  
Economy mode is not possible.  
**Released**  
Economy mode can be activated.

Economy mode

Switches economy mode on or off

### Chimney sweep

Line no.	Operating line
<b>7130</b>	<b>Chimney sweep function</b>

The burner will be switched on. To ensure continuous burner operation, the only switch-off point used is the boiler temperature's maximum limitation (TKmax).

First, all connected loads will be locked to ensure the boiler temperature will reach the setpoint of 64 °C as quickly as possible.

When the minimum temperature of 64 °C is attained, the available heating circuits are switched on one by one, using a dummy load, to make sure the heat generated by the boiler is drawn off so that the burner will remain in operation.

For safety reasons, maximum limitation of the boiler temperature (TKmax) remains active as long as the chimney sweep function is active.



The function is deactivated by setting -- on this operating line, or automatically after a timeout of 1 hour.

### Manual operation

Line no.	Operating line
<b>7140</b>	<b>Manual control</b>

When manual control is activated, the relay outputs are no longer energized and deenergized according to the control state but are set to a predefined manual control state in accordance with their functions (see table below).

The burner relay energized in manual control can be deenergized by the electronic temperature controller (TR).

Name	relay	State	
Oil / gas boiler	Burner 1st stage	K4	On
	Burner 2nd stage	K5	On
	Burner mod. release	K4	On
	Burner mod. open	Y17 (K5)	On
	Burner mod. closed	Y18	Off
	Boiler pump	Q1	On
	Bypass pump	Q12	On
	Return mixing valve open / closed	Y7/Y8	Off
Solid fuel boiler	Boiler pump	Q10	On
Solar	Collector pump	Q5	Off
	Collector pump 2	Q16	Off
	Ext. heat exchanger pump	K9	Off
	Controlling element buffer storage tank	K8	Off
	Controlling element swimming pool	K18	Off
DHW	Charging pump	Q3	On
	Diverting valve	Q3	Off
	Mixing pump	Q32	Off
	Intermediate circuit pump	Q33	On
	Mixing valve opening / closing	Y31/Y32	Off
	Instantaneous DHW heater pump	Q34	On
	Instantaneous DHW heater on / off	Y33/Y34	Off
	Circulating pump	Q4	On
	Electric immersion heater	K6	On
buffer storage tank	Source shutoff valve	Y4	On
	Return valve	Y15	Off
Heating circuit 1...3	2nd heating circuit pump	Q2 Q6 Q20	On
	Heating circuit mixing valve opening / closing	Y1 / Y2 Y5 / Y6	Off
	Heating circuit pump 2nd speed	Q21 Q22 Q23	On
Cooling circuit 1	Cooling circuit pump	Q24	On
	Cooling circuit mixing valve opening / closing	Y23/Y24	Off
	Diverting valve for cooling	Y21	Off
Primary controller	System pump	Q14	On
	Mixing valve opening / closing	Y19/Y20	Off
Hx group	Pump H1	Q15	On
	Pump H2	Q18	On
	Pump H3	Q19	On
Auxiliary functions	Alarm output	K10	Off
	Time program 5	K13	Off
	Heat demand	K27	On
	Refrigeration demand	K28	Off
	Storage tank transfer pump	Q11	Off

Setpoint adjustment in manual control

After manual control has been activated, a change to the basic display must be made. There, the maintenance / special mode symbol  appears.

Press the info button to switch to info display "Manual mode", where the setpoint can be adjusted.

## Simulations

<i>Line no.</i>	<i>Operating line</i>
<b>7150</b>	<b>Simulation outside temp</b>

To facilitate commissioning and fault tracing, outside temperatures in the range from – 50 to +50°C can be simulated. During simulation, the actual, the composite and the attenuated outside temperature will be overridden by the set simulated temperature. During simulation, calculation of the 3 mentioned outside temperatures continues and the temperatures are available again when simulation is completed.



The function is deactivated by setting -- on this operating line, or automatically after a timeout of 1 hour.

## Telephone customer service

<i>Line no.</i>	<i>Operating line</i>
<b>7170</b>	<b>Telephone customer service</b>

Setting of phone number that appears on the info display.

## 5.22 Input / output test

<i>Line no.</i>	<i>Operating line</i>
<b>7700...7999</b>	

The input / output test is used to check the correct functioning of the connected components.

When selecting a setting from the relay test, the relevant relay is energized, thus putting the connected component into operation. The correct functioning of the relays and wiring can thus be tested.



Important:

During the relay test, limitation of the boiler temperature by the electronic control thermostat (TR) remains activated. Other limits are deactivated.

Selector sensor values are updated within a maximum of 5 seconds.

The display is made with no measured value correction.

## 5.23 State

The current operating state of the plant is visualized by means of status displays.

### Messages

Line no.	Operating line
<b>8000</b>	<b>State of heating circuit 1</b>
<b>8001</b>	<b>State of heating circuit 2</b>
<b>8002</b>	<b>State heating circuit P</b>
<b>8003</b>	<b>State of DHW</b>
<b>8005</b>	<b>State of boiler</b>
<b>8007</b>	<b>State of solar</b>
<b>8008</b>	<b>State solid fuel boiler</b>
<b>8010</b>	<b>State buffer storage tank</b>
<b>8011</b>	<b>State swimming pool</b>

### State heating circuit

End user (info level)	Commissioning, heating engineer	
Limit thermostat has cut out	Limit thermostat has cut out	3
Manual control active	Manual control active	4
Floor curing function active	Floor curing function active	102
	Overtemp protection active	56
	Restricted, boiler protection	103
	Restricted, DHW priority	104
	Restricted, buffer priority	105
Heating mode restricted	Forced discharging buffer storage tank	106
	Forced discharging DHW	107
	Forced discharging heat source	108
	Forced heat release	109
	Overrun active	110
	Overrun active	17
Forced heat release	Opt start control + boost heating	110
	Optimum start control	111
	Boost heating	112
	Boost heating	113
Heating mode Comfort	Heating mode Comfort	114
	Optimum stop control	115
Heating mode Reduced	Heating mode Reduced	116
	Frost protection room active	101
	Frost protection flow active	117
	Frost protection plant active	23
Frost protection active		24
Summer operation	Summer operation	118
	24-hour Eco active	119
	Setback Reduced	120
	Setback frost protection	121
	Room temp lim	122
	Room temp lim	122
Off	Off	25

### Cooling

End user (info level)	Commissioning, heating engineer	
Dewpoint monitor active	Dewpoint monitor active	133
Manual control active	Manual control active	4
Fault.	Fault.	2
Frost protection active	Frost protection flow active	117
	Frost protection flow active	24
	Frost protection flow active	24
Cooling mode locked	Locking period at end of heating	135
	Locked, energy source	205
	Locked, buffer	206
	Locked, buffer	146
Cooling mode, restricted	Flow setpt increase hygro	136
	Min. flow limit, dewpoint	177
	Min. flow limit, outside temp	178
	Min. flow limit, outside temp	144
Cooling mode, Comfort	Cooling mode, Comfort	150
	Overrun active	17
	Overrun active	150
Protection mode, cooling	Protection mode, cooling	149
	Frost protection plant active	23

Frost protection active		24
Cooling limit OT active	Cooling limit OT active	134
Off	Off	25
	Room temp lim	122
	Flow limit reached	179
Cooling mode off	Cooling mode off	25
		138

#### State of DHW

End user (info level)	Commissioning, heating engineer	
Limit thermostat has cut out	Limit thermostat has cut out	3
Manual control active	Manual control active	4
Draw-off mode	Draw-off mode	199
Recooling active	Recooling via collector	77
	Recooling via DHW/HCs	78
		53
Charging lock active	Discharging protection active	79
	Charging time limitation active	80
	DHW charging locked	81
		82
Forced charging active	Forced, max stor tank temp	83
	Forced, max charging temp	84
	Forced, legionella setpoint	85
	Forced, nominal setpoint	86
		67
Charging el im heater	Charging electric, leg setpoint	87
	Charging electric, nominal setpoint	88
	Charging electric, Red setpoint	89
	Charging electric, frost setpoint	90
	Ei imm heater released	91
		66
Push active	Push, leg setpoint	92
	Push, nominal setpoint	93
		94
Charging active	Charging, leg setpoint	95
	Charging, nominal setpoint	96
	Charging, reduced setpoint	97
		69
Frost protection active	Frost protection active	24
Overrun active	Overrun active	17
Stand-by charging	Stand-by charging	201
Charged	Charged, max stor temp	70
	Charged, max charg temp	71
	Forced, legio temp	98
	Charged, nominal temp	99
	Forced, Reduced temp	100
		75
Off	Off	25
Ready	Ready	200

#### State of boiler

End user (info level)	Commissioning, heating engineer	
SLT has cut out	SLT has cut out	1
SLT test active	SLT test active	123
Fault.	Fault.	2
Limit thermostat has cut out	Limit thermostat has cut out	3
Manual control active	Manual control active	4
Chimney sweep function active	Chimney sweep function, high-fire	5
	Chimney sweep function, low-fire	6
		7
Locked	Locked, manually	8
	Locked, solid fuel boiler	172
	Locked, automatically	9
	Locked, outside temperature	176
	Locked, Economy mode	198
		10
Minimum limitation active	Minimum limitation	20
	Minimum limitation, low-fire	21
	Minimum limitation active	22
In operation	Protective start-up	11
	Protective startup, low-fire	12
	Return limitation	13
	Return temperature limitation, low-fire	14
		18

Charging buffer storage tank	Charging buffer storage tank	59
In operation for HC, DHW	In operation for HC, DHW	170
In partial load operation for HC, DHW	In partial load operation for HC, DHW	171
Released for HC, DHW	Released for HC, DHW	173
In operation for DHW	In operation for DHW	168
In partial load operation for DHW	In partial load operation for DHW	169
Released for DHW	Released for DHW	174
In operation for heating circuit	In operation for heating circuit	166
In partial load operation for HC	In partial load operation for HC	167
Released for HC	Released for HC	175
Overrun active	Overrun active	17
Released	Released	19
	Frost protection plant active	23
Frost protection active		24
Off	Off	25

#### State of solar

<i>End user (info level)</i>	<i>Commissioning, heating engineer</i>	
Manual control active	Manual control active	4
Fault.	Fault.	2
Frost protection collector active	Frost protection collector active	52
Recooling active	Recooling active	53
Max stor tank temp reached	Max stor tank temp reached	54
Evaporation protection active	Evaporation protection active	55
Overtemp protection active	Overtemp protection active	56
Max charg temp reached	Max charg temp reached	57
Charging DHW+buffer+swi pool	Charging DHW+buffer+swi pool	151
Charging DHW+buffer	Charging DHW+buffer	152
Charging DHW+swi pool	Charging DHW+swi pool	153
Ladung Puffer+Schwimmbad	Charging buffer+swimming pool	154
Charging DHW	Charging DHW	58
Charging buffer storage tank	Charging buffer storage tank	59
Charg swimm pool	Charg swimm pool	60
	Min charg temp not reached	61
	Temp diff insufficient	62
Radiation insufficient	Radiation insufficient	63

#### State solid fuel boiler

<i>End user (info level)</i>	<i>Commissioning, heating engineer</i>	
Manual control active	Manual control active	4
Fault.	Fault.	2
Overtemp protection active	Overtemp protection active	56
	Locked, manually	8
	Locked, automatically	9
Locked		10
	Minimum limitation	20
	Minimum limitation, low-fire	21
Minimum limitation active	Minimum limitation active	22
	Protective start-up	11
	Protective startup, low-fire	12
	Return temperature limitation	13
	Return temp. limitation, low-fire	14
In operation for heating circuit	In operation for heating circuit	166
In partial load operation for HC	In partial load operation for HC	167
In operation for DHW	In operation for DHW	168
In partial load operation for DHW	In partial load operation for DHW	169
In operation for HC, DHW	In operation for HC, DHW	170
In partial load operation for HC, DHW	In partial load operation for HC, DHW	171
Overrun active	Overrun active	17
In operation	In operation	18
Assisted firing fan active	Assisted firing fan active	163
Released	Released	19
	Frost protection plant active	23
	Frost protection boiler active	141
Frost protection active		24
Off	Off	25

#### State buffer storage tank

<i>End user (info level)</i>	<i>Commissioning, heating engineer</i>	
Frost protection cooling active	Frost protection cooling active	202
	Locking period at end of heating	135
	DHW charging locked	81
Charging restricted		124
	Forced charging active	67
	Full charging active	203
Charging active		69

	Charged, forced charg required temp	72
	Charged, required temp	73
	Charged, min charg temp	143
Charged		75
Hot	Hot	147
No demand	No demand	51
Frost protection active	Frost protection active	24
	Charging electric, em operation	64
	Charging electric, source prot	65
	Charging electric, defrost	131
	Charging electric, forced	164
	Charging electric, substitute	165
Charging el im heater		66
	DHW charging locked	81
	Restricted, DHW priority	104
Charging restricted		124
	Forced charging active	67
	Partial charging active	68
Charging active	Charging active	69
	Recooling via collector	77
	Recooling via DHW/HCs	142
Recooling active		53
	Charged, max stor temp	70
	Charged, max charg temp	71
	Charged, forced charg required temp	72
	Charged, required temp	73
	Partially charged, temp setpoint	74
	Charged, min charg temp	143
Charged		75
Cold	Cold	76
No heat request	No heat request	51

State swimming pool

<i>End user (info level)</i>	<i>Commissioning, heating engineer</i>	
Manual control active	Manual control active	4
Fault.	Fault.	2
Heating mode restricted	Heating mode restricted	106
Forced heat release	Forced heat release	110
	Heating mode, generation	155
Heating mode		137
	Heated, max. sw. pool temp	156
	Heated, solar setpoint	158
	Heated, source setpoint	157
Heated		159
	Heating mode solar off	160
	Heating mode, generation off	161
Heating off		162
Cold	Cold	76

## 5.24 Diagnostics, heat generation

For diagnostic purposes, the various setpoints, actual values, relay switching states and meter readings can be displayed.

<i>Line no.</i>	<i>Operating line</i>
<b>8610...8699</b>	

## 5.25 Diagnostics, consumers

For diagnostic purposes, the various setpoints, actual values, relay switching states and meter readings can be displayed.

<i>Line no.</i>	<i>Operating line</i>
<b>8700...9099</b>	

## 5.26 List of displays

Priorities are assigned to pending errors. From priority 6, alarm messages are delivered, which are used by remote supervision (OCI). In addition, the alarm relay will be set.

### 5.26.1 Error code

Error code	Description of error	Priority
0	No error	
10	Outside temperature sensor error	6
20	Boiler temperature 1 sensor error	9
25	Solid fuel boiler temperature (wood) sensor error	9
26	Common flow temperature sensor error	6
28	Flue gas temperature sensor error	6
30	Flow temperature 1 sensor error	6
31	Flow temperature 1 cooling, sensor error	6
32	Flow temperature 2 sensor error	6
38	Flow temperature primary controller sensor error	6
40	Return temperature 1 sensor error	6
46	Return temperature cascade sensor error	6
47	Common return temperature sensor error	6
50	DHW temperature 1 sensor error	9
52	DHW temperature 2 sensor error	9
54	DHW primary controller sensor error	6
57	DHW circulation temperature sensor error	6
60	Room temperature 1 sensor error	6
65	Room temperature 2 sensor error	6
68	Room temperature 3 sensor error	6
70	Buffer storage tank temperature 1 sensor error	6
71	Buffer storage tank temperature 2 sensor error	6
72	Buffer storage tank temperature 3 sensor error	6
73	Collector temperature 1 sensor error	6
74	Collector temperature 2 sensor error	6
81	Short-circuit LPB	6
82	LPB address collision	3
83	BSB wire short-circuit	6
84	BSB address collision	3
85	BSB radio communication fault	6
98	Extension module 1 fault (common fault status message)	6
99	Extension module 2 fault (common fault status message)	6
100	2 clock time masters (LPB)	3
102	Clock time master without backup (LPB)	3
105	Maintenance message	5
109	Boiler temperature supervision	9
110	Lockout by SLT	9
117	Upper pressure limit (crossed)	6
118	Critical lower pressure limit (crossed)	6
121	Flow temperature 1 (HC1) supervision	6
122	Flow temperature 2 (HC2) supervision	6
126	DHW charging supervision	6
127	Legionella temperature not reached	6
131	Burner fault	9
146	Configuration error common message	3
171	Alarm contact 1 (H1) active	6
172	Alarm contact 2 (H2) active	6
173	Alarm contact 3 (EX2/230VAC) active	6
174	Alarm contact 4 (H3) active	6
176	Upper pressure limit 2 (crossed)	6
177	Critical lower pressure limit 2 (crossed)	6
178	Temperature limiter heating circuit 1	3
179	Temperature limiter heating circuit 2	3
207	Error, cooling circuit	6
217	Sensor error common message	6
217	Sensor error common message	6
218	Pressure supervision common message	6
241	Flow sensor, solar sensor error	6
242	Return sensor, solar sensor error	6
243	Swimming pool temperature sensor error	6

320	DHW charging temperature sensor error	6
321	Instantaneous DHW heater outlet temperature sensor error	6
322	Upper pressure limit 3 (crossed)	6
323	Critical lower pressure limit 3 (crossed)	6
324	BX same sensors	3
325	BX/extension module same sensors	3
326	BX/mixing valve group same sensors	3
327	Extension module same function	3
328	Mixing valve group same function	3
329	Extension module / mixing valve group same function	3
330	Sensor BX1 no function	3
331	Sensor BX2 no function	3
332	Sensor BX3 no function	3
333	Sensor BX4 no function	3
334	Sensor BX5 no function	3
335	Sensor BX21 no function	3
336	Sensor BX22 no function	3
337	Sensor BX1 no function	3
338	Sensor BX12 no function	3
339	Collector pump Q5 missing	3
340	Collector pump Q16 missing	3
341	Collector sensor B6 missing	3
342	Solar DHW sensor B31 missing	3
343	Solar integration missing	3
344	Solar controlling element buffer K8 missing	3
345	Solar controlling element swimming pool K18 missing	3
346	Solid fuel boiler pump Q10 missing	3
347	Solid fuel boiler comparison sensor missing	3
348	Solid fuel boiler address error	3
349	Buffer return valve Y15 missing	3
350	Buffer storage tank address error	3
351	Primary controller / system pump address error	3
352	Pressureless header address error	3
353	Cascade sensor B10 missing	3
357	Flow temperature cooling circuit 1 monitoring	6
366	Room temperature Hx sensor error	6
367	Relative room humidity Hx sensor error	6

### 5.26.2 Maintenance code

Maintenance code	Description of maintenance	Priority
1	Burner hours run exceeded	6
2	Burner starts exceeded	6
3	Maintenance interval exceeded	6
5	Water pressure heating circuit too low (dropped below lower pressure limit 1)	9
18	Water pressure 2 heating circuit too low (dropped below lower pressure limit 2)	9
10	Replace battery of outside sensor	6
21	Maximum flue gas temperature exceeded	6
22	Water pressure 3 heating circuit too low (dropped below lower pressure limit 3)	9

### 5.26.3 Special operation code

Special operation code	Description
301	Manual operation
302	SLT test
303	Chimney sweep function
309	Simulation outside temperature
310	Alternative energy operation
314	Economy mode

**CONTROLLERS**  
**CLIMA TOP (RVS63)**  
**CLIMA COMFORT (RVS43)**

**OEM MANUAL**

## 6 The OEM settings in detail

### 6.1 Operator unit

---

#### Operation and display

<i>Line no.</i>	<i>Operating line</i>
<b>21</b>	<b>Display special operation</b> Off On
<b>30</b>	<b>Save basic settings</b> No Yes
<b>31</b>	<b>Activate basic settings</b> No Yes

#### Save basic settings

The setting data of all operating levels are copied from the controller to the memory of the operator unit. This means that previous data in the operator unit are overwritten.

#### Activate basic settings

With the exception of the data listed below, the setting data of all operating levels are transferred from the memory of the operator unit to the connected controller. Previous setting data in the controller are overwritten.



The following operating lines will not be overwritten:

<i>Line no.</i>	<i>Operating line</i>
6600	Device address
6601	Segment address
6222	Device hours run

The following data will not be overwritten either:

RF list, hours run / start counter, yield meter, maintenance meter, slave pointer, and error history.

### 6.2 Heating circuits

---

#### Mixing valve control

<i>Line no.</i>			<i>Operating line</i>
HC1	HC2	HC3P	
<b>835</b>	<b>1135</b>		<b>Mixing valve Xp</b>
<b>836</b>	<b>1136</b>		<b>Mixing valve Tn</b>

#### Mixing valve Xp

By setting the right proportional band, the control action of the mixing valve actuator is matched to the behavior of the plant (controlled system).

Xp influences the P-action of the controller.

#### Mixing valve Tn

By setting the right integral action time, the control action of the mixing valve actuator is matched to the behavior of the plant (controlled system).

Tn influences the I-action of the controller.

## 6.3 Cooling circuit

### Mixing valve control

Line no.	Operating line
<b>942</b>	<b>Mixing valve Xp</b>
<b>943</b>	<b>Mixing valve Tn</b>

#### Mixing valve Xp

By setting the right proportional band, the control action of the mixing valve actuator is matched to the behavior of the plant (controlled system).

Xp influences the P-action of the controller.

#### Mixing valve Tn

By setting the right integral action time, the control action of the mixing valve actuator is matched to the behavior of the plant (controlled system).

Tn influences the I-action of the controller.

## 6.4 DHW

### Setpoints

Line no.	Operating line
<b>1614</b>	<b>Nominal setpoint max</b>

This operating line is used to limit the "Nominal setpoint" (operating line 1610) at the top.


### Release

Line no.	Operating line
<b>1620</b>	<b>Release</b> 24 h/day Time programs HCs Time program 4/DHW

#### 24 h/day

The DHW temperature is constantly maintained at the nominal DHW setpoint, independent of any time programs.


Example:



#### Time programs HCs

The DHW setpoint is switched between the nominal DHW setpoint and the reduced DHW setpoint according to the heating circuits' time programs. The first switch-on point of each period is shifted forward in time by one hour.


Example:



#### Time program 4/DHW

For DHW heating, time program 4 of the local controller is taken into consideration. The set switching times of that program are used to switch between the nominal DHW setpoint and the reduced DHW setpoint. This way, the DHW is heated independently of the heating circuits.

Example:



## 6.5 Pumps H

### Pump Hx

Line no.			Operating line
H1	H2	H3	
2008	2033	2044	<b>H1/H2/H3 DHW charging priority</b> Off   On

H1/H2/H3 DHW charging priority

When using this setting, the connected pump H can be excluded from / included in the effect of DHW charging priority.


In the case of a ventilation system, for example, it is thus possible to ensure a constant supply of heat with no impact from the DHW charging priority.

## 6.6 Swimming pool

Line no.	Operating line
<b>2070</b>	<b>Swimming pool temp max</b>

Swimming pool temp max

If the swimming pool temperature reaches the temperature limit set here, the collector pump is deactivated. It is released again when the swimming pool temperature has dropped 1 °C below the maximum temperature limit.



TSbMax Swimming pool temp max (operating line 5051)  
 TSb actual value of the swimming pool temperature  
 L Storage tank charging: 1 = on, 0 = off


## 6.7 Primary controller / system pump

Flow temperature setpoint limits

Line no.	Operating line
<b>2110</b>	<b>Flow temp setpoint min</b>
<b>2111</b>	<b>Flow temp setpoint max</b>
<b>2112</b>	<b>Flow setpoint, cooling min</b>

Flow temp setpoint minimum/maximum

These limit values can be used to define a temperature range for the heating flow temperature setpoint.



TVw Current flow temperature setpoint  
 TVmax Flow temp setpoint maximum  
 TVmin Flow temp setpoint minimum

Flow setpoint, cooling min

This limit value can be used to define the low limit for the flow temperature setpoint for cooling.

Mixing valve control

Line no.	Operating line
----------	----------------

<b>2130</b>	<b>Mixing valve boost</b>
<b>2131</b>	<b>Mixing valve cooling offset</b>
<b>2132</b>	<b>Actuator type</b>
<b>2133</b>	<b>Switching differential 2-pos</b>
<b>2134</b>	<b>Actuator running time</b>
<b>2135</b>	<b>Mixing valve Xp</b>
<b>2136</b>	<b>Mixing valve Tn</b>

Mixing valve boost

For mixing, the actual value of the boiler flow temperature must be higher than the required setpoint of the mixing valve flow temperature since otherwise that temperature cannot be controlled. The controller generates the boiler temperature setpoint based on the increase set here and the current flow temperature setpoint.

Mixing valve cooling offset

To ensure proper mixing, the actual flow temperature of the cooling aggregate must be lower than the required mixing valve flow temperature setpoint. The cooling demand is reduced by the value set here.

## 6.8 Boiler

Operating mode

<i>Line no.</i>	<i>Operating line</i>
<b>2200</b>	<b>Operating mode</b> Continuous operation Automatically Auto, extended running time
<b>2208</b>	<b>Full charging of buffer</b> Off   On

Operating mode


### Continuous operation

The boiler is constantly released and the minimum boiler temperature maintained is the parameterized TKMin.

The boiler is only locked when all connected heating circuits are set to Protection mode and when there is no valid request.


### Automatically

The boiler is released as soon as there is at least one valid temperature request. Once the boiler is released, the required minimum boiler temperature will always be maintained. The boiler is locked when no valid temperature request is active. This means that with this operating mode, the boiler setpoint will be maintained at the required minimum only if a temperature request is active.



### Auto mode, with extended burner running time

The boiler is released as soon as there is at least one valid temperature request. When the boiler is released, the burner will be switched on when the boiler temperature drops below the request of the consumers. The required minimum boiler temperature is maintained only if the burner had to be switched on due to a request from one of the consumers. This means that since the boiler temperature can drop below its minimum, depending on the request, this operating mode leads to a smaller number of burner switching cycles and, therefore, longer burner on times.



Full charging of buffer

Off: The boiler is not used for full charging of the buffer storage tank.


On: The boiler is included in the full charging of the buffer storage tank. When the function is active, the heat generator is not disabled until the buffer storage is fully charged.

### Setpoints

Line no.	Operating line
<b>2211</b>	<b>Setpoint min OEM</b>
<b>2213</b>	<b>Setpoint max OEM</b>

Setpoint minimum / maximum OEM

For this OEM boiler temperature limit control, limit values are defined for the upper and lower boiler temperature setpoints (TKMax and TKMin).



### Multistage burner

RVS63.. only

Line no.	Operating line
<b>2220</b>	<b>Release integral stage 2</b>
<b>2221</b>	<b>Reset integral stage 2</b>

Integrals for stage 2

The temperature-time integral is a continuous summation of the temperature differential over time. In this case, the decisive temperature differential is the amount the temperature exceeds the burner's switch-on setpoint or switch-off setpoint.

Through the generation of the temperature-time integral it is not only the period of time that is considered, but also the extent of crossing. This means that when the crossing is significant, burner stage 2 is released or locked earlier than when the crossing is small.

Release integral burner stage 2

When, with burner stage 1, the temperature drops below the switch-on setpoint by the release integral set here, the controller releases burner stage 2.

Reset integral burner stage 2

When, with burner stages 1 and 2, the temperature drops below the switch-off setpoint by the reset integral set here, the controller locks burner stage 2.

### Modulating burner (damper actuator / UX)

RVS63.. only

Line no.	Operating line
<b>2232</b>	<b>Damper actuator running time</b>
<b>2233</b>	<b>Modulating Xp</b>
<b>2234</b>	<b>Modulating Tn</b>
<b>2235</b>	<b>Modulating Tv</b>

Damper actuator running time



To ensure that control of the modulating burner works optimally, the damper actuator running time must be set.

It must be observed that the running time to be set only relates to the range.

- Example

Running time of damper actuator (90°) = 120 seconds

Minimum position of damper actuator = 20°

Maximum position of damper actuator = 80°

Hence, the air damper actuator running time effective for the control is as follows:

$$\frac{120s * (80^\circ - 20^\circ)}{90^\circ} = 80s$$

- Positioning pulses

For control operation, running time-dependent minimum positioning pulses are active that are defined as follows:

Actuator running time TS	Minimum pulse length
7.5 s – 14.5 s	Approx. 200 ms
15 s – 29.5 s	Approx. 300 ms
30 s – 59.5 s	Approx. 500 ms
60 s – 119.5 s	Approx. 1.10 s
>120 s	Approx. 2.20 s

Modulating Xp

By setting the right proportional band, the control action of the modulating burner is matched to the plant's behaviour (controlled system).

Xp influences the controller's P-action.

Modulating Tn

By setting the right integral action time, the control action of the modulating burner is matched to the behavior of the plant (controlled system).

Tn influences the controller's I-action.

Modulating Tv

By setting the right derivative action time, the control action is matched to the behavior of the plant (controlled system).

Tv influences the controller's D-action. With Tv = 0, the D-action is deactivated.

## Boiler / burner control


Line no.	Operating line
<b>2240</b>	<b>Switching differential of the boiler</b>
<b>2241</b>	<b>Burner running time min</b>

Switching differential of the boiler

The boiler temperature is controlled by a 2-position controller for which a switching differential can be set.

Burner running time min

If a minimum burner running time is parameterized, the burner's switch-off point will be raised by half the boiler's switching differential within that minimum on time. If, within the minimum burner running time, the boiler temperature exceeds the setpoint by more than the entire switching differential, the burner will also be shut down before the minimum on time has elapsed. On completion of the minimum on time, the burner's switch-off point will be set to the boiler temperature setpoint plus half the switching differential. This function only acts on the first burner stage.



T Temperature  
t Time  
tBRmin Burner running time min  
BR Burner ( 0= off, 1 = on)  
TKw Boiler setpoint  
TKx Actual boiler temperature  
SDK Switching differential of the boiler

## Overtemperature protection

Line no.	Operating line
<b>2250</b>	<b>Pump overrun time</b>

Pump overrun time

If the first burner stage is switched off, or if the boiler request becomes invalid, a forced signal is delivered during the parameterized pump overrun time. Consumer pumps do not switch off during the period of time such a forced signal is active.

## Minimum limitation of the boiler temperature

Line no.	Operating line
2260	Prot boil startup consumers
2261	Prot boil startup boil pump
2262	Optimum start control

### Protective start-up


Below the minimum boiler temperature, protective boiler startup accelerates heating up of the boiler by switching off or reducing the consumer load, or by keeping the boiler pump deactivated, depending on the hydraulic circuit used.

### Optimum start control


When the function is activated (graph 1,2), the controller calculates the switch-on point for the burner, based on the boiler temperature gradient, thus enabling that the boiler temperature will not fall below the minimum level.

When the function is deactivated (graph 3), the controller will switch the burner on at TKmin.


- With optimum burner start control at about 35 % load



- With optimum burner start control at about 65% load



- Without optimum burner start control at about 35 % load



ON Burner on  
 OFF Burner off  
 TKx Actual value of the boiler temperature  
 Tkmin Minimum limitation of the boiler temperature

### Minimum limitation of the return temperature

Line no.	Operating line
<b>2271</b>	<b>Return setpoint min OEM</b>
<b>2272</b>	<b>Return influence consumers</b>

**Return setpoint min OEM** This minimum limitation of the return temperature OEM is the lower limit value for the minimum of the return temperature setpoint.

**Return influence consumers** If, with the boiler released, the return temperature falls below the set minimum temperature, a locking signal will be calculated.

- With proper pump circuits (heating circuit pump, DHW charging pump, external load) is or remains deactivated if the locking signal exceeds the respective threshold value
- In the case of mixing circuits, the flow temperature setpoint will be reduced according to the locking signal value

### Return temperature minimum limitation mixing valve

Line no.	Operating line
<b>2282</b>	<b>Actuator running time</b>
<b>2283</b>	<b>Mixing valve Xp</b>
<b>2284</b>	<b>Mixing valve Tn</b>
<b>2285</b>	<b>Mixing valve Tv</b>

**Mixing valve Xp** By setting the right proportional band, the control action of the mixing valve's actuator is matched to the behavior of the plant (controlled system).

Xp influences the controller's P-action.

- **Example**  
 In the case of a setpoint / actual value deviation of 20 °C, Xp = 20 produces a manipulated variable corresponding to the running time of the mixing valve's actuator (Tv = 0, Tn = maximum).

**Mixing valve Tn** By setting the right integral action time, the control action of the mixing valve's actuator is matched to the behavior of the plant (controlled system).

Tn influences the controller's I-action.

## Mixing valve Tv

By setting the right derivative action time, the control action is matched to the behavior of the plant (controlled system).

Tv influences the controller's D-action. With Tv = 0, the D-action is deactivated.

## Bypass pump

Line no.	Operating line
<b>2290</b>	<b>Switching differential bypass pump</b>

## Switching differential bypass pump

Control of the bypass pump "according to the boiler return temperature" is in the form of 2-position control for which a switching differential must be set.

## Bypass pump

<b>2291</b>	<b>Control bypass pump</b> Parallel burner operation Return temperature
-------------	---

## Control bypass pump

The boiler bypass pump improves the circulation of water through the boiler, thus preventing the boiler temperature from falling below a certain level.

### Parallel with the operation of the burner

The boiler bypass pump is switched on / off according to the burner's on / off signals.

### According to the boiler return temperature

The boiler bypass pump is switched on / off according to the minimum limitation of the boiler return temperature and the switching differential of the bypass pump.

## Frost protection


Line no.	Operating line
<b>2300</b>	<b>Frost prot plant boiler pump</b>

The boiler pump is activated, depending on the **current** outside temperature, although there is no request for heat.



Frost protection for the boiler operates only if frost protection for the plant on operating line 6120 is switched on.

Outside temperature (OT)	Pump	Graph
...-4 °C	Continuously on	ON
-5...1.5 °C	ON for 10 minutes at 6-hour intervals	Cycle (takt)
1.5 °C...	Continuously off	OFF



## Electronic limit thermostat


Line no.	Operating line
<b>2310</b>	<b>Limit thermostat function</b>

### Limit thermostat function

The electronic limit thermostat monitors the boiler temperature (TKx) and cuts out if the set limit value (TR setpoint) is exceeded, causing the burner to shut down.

In normal control mode and for the relay test, the TR setpoint used is the boiler temperature's maximum limitation (TKMax) while the "adjustable" value TKMaxHand is used with manual control.

Parameter "Limit thermostat function" can be used to switch the limit thermostat on and off. But it is always active in manual control.



The limit thermostat is activated when:

- The boiler temperature (TKx) exceeds the TR setpoint
- There is no boiler temperature signal, e.g. no signal from the sensor due to a short-circuit.

TR is deactivated when:

- The boiler temperature drops by one half the boiler switching differential (SDK/2), but at least 2°K.

The electronic limit thermostat is integrated in burner relay control in a way that relays K4/K5 will immediately be deenergized when the limit thermostat becomes active (independent of control, relay test, and manual control). It is only during the SLT (safety limit thermostat) test that the electronic limit thermostat does not become active.

## Monitoring the temperature differential

Line no.	Operating line
<b>2315</b>	<b>Temp differential min</b>
<b>2316</b>	<b>Temp differential max</b>

When using a speed-controlled boiler pump, the pump's speed is adjusted in a way that the difference between flow and return temperature will lie within that range.

The pump's speed is significantly reduced only when the boiler delivers the required output.

### Temp differential min

Minimum boiler differential

The "Minimum boiler differential" function is used to monitor the speed control of the boiler pump.

When the actual boiler flow/return differential reaches the preset value, the boiler pump speed is not increased further. If the actual differential drops below the preset value, the speed is reduced.

The function can be deactivated with the setting – – – .

#### Temp differential max

##### Maximum boiler differential

The "Maximum boiler differential" function is used to monitor the speed control of the boiler pump.

When the boiler flow/return differential reaches the preset value, the boiler pump speed is not increased further. If the actual differential exceeds the preset value, the speed is reduced.

The function can be deactivated with the setting – – – .

#### Speed control

RVS63.. only
--------------

<i>Line no.</i>	<i>Operating line</i>
<b>2322</b>	<b>Pump speed min</b>
<b>2323</b>	<b>Pump speed max</b>
<b>2324</b>	<b>Speed Xp</b>
<b>2325</b>	<b>Speed Tn</b>
<b>2326</b>	<b>Speed Tv</b>

#### Pump speed minimum/maximum

##### Boiler pump speed range

The boiler pump motor speed is limited by a minimum and maximum permitted speed. To ensure that the pump operates reliably on start-up, it is operated at maximum speed for the first 10 seconds.

#### Boiler pump speed control

The "Boiler pump speed control" function reduces the flow of water through the boiler water in order to achieve the specified boiler setpoint. The controller calculates the pump speed required to ensure that the boiler water volume is not reduced to the permissible minimum until the boiler reaches its full capacity. This prevents the boiler from reaching the setpoint at a reduced boiler capacity, causing the pump to continue to operate at reduced speed.

The pump speed is calculated by a PID controller.

With a low boiler capacity (actual capacity less than 66%) the speed-control setpoint is reduced by 10 K. If the boiler capacity rises above 66%, the pump-speed setpoint is increased, so that at 100% boiler capacity, the setpoint for the speed control calculation corresponds to boiler demand.

## 6.9 Cascade

### Operating mode / strategy

<i>Line no.</i>	<i>Operating line</i>
<b>3510</b>	<b>Lead strategy</b> Late on, early off Late on, late off Early on, late off
<b>3511</b>	<b>Output band min</b>
<b>3512</b>	<b>Output band max</b>

### Lead strategy

- **Late on, early off**

Additional boilers are switched on as late as possible (output band max) and switched off again as early as possible (output band max). This means that the **smallest possible number of boilers are in operation**, or additional boilers operate with short on times.

- **Late on, late off**

Additional boilers are switched on as late as possible (output band max) and switched off again as late as possible (output band min). This leads to the **smallest possible number of switch-on/off actions** for the boilers.

- **Early on, late off**

Additional boilers are switched on as early as possible (output band min) and switched off again as late as possible (output band min). This means that the **largest possible number of boilers are in operation**, or additional boilers operate with the longest possible on times.

### Output band

The values are used as switch-on or switch-off criteria in accordance with the selected lead strategy.

### Control

<i>Line no.</i>	<i>Operating line</i>
<b>3530</b>	<b>Release integral source seq</b>
<b>3531</b>	<b>Reset integral source seq</b>
<b>3534</b>	<b>Forced time basic stage</b>

### Integral source sequence

The settings can be used as switch-on or switch-off criteria, in addition to the output band.

- **Release integral source sequence**

When, with the heat source currently in operation, the demand for heat cannot be met, the difference being the release integral set here, another boiler is switched on. When the value is increased, additional heat sources are switched on at a slower rate. When the value is decreased, additional heat sources are switched on at a faster rate.

- **Reset integral heat source sequence**

When, with the heat source currently in operation, the demand for heat is exceeded by the reset integral set here, the heat source with the highest priority is shut down. When the value is increased, heat sources operate for longer periods of time (in the case of surplus heat). When the value is decreased, heat sources are switched off at a faster rate.

### Forced time basic stage

When switched on, every boiler operates with its basic stage for the period of time set here. The next stage is released only when this period of time has elapsed.

**Minimum limitation of the boiler temperature**

Line no.	Operating line
<b>3550</b>	<b>Prot startup cascade pump</b>

Protective start-up                      The protective startup provided by the cascade pump accelerates heating up of the first boiler in the cascade below the minimum boiler temperature in that the cascade pump remains deactivated..

**Minimum limitation of the return temperature**

Line no.	Operating line
<b>3561</b>	<b>Return setpoint min OEM</b>
<b>3562</b>	<b>Return influence consumers</b>

Return setpoint min OEM                The minimum limitation of the cascade return temperature (operating line 3560) can be adjusted by the OEM. The person using the heating engineer level can no longer set the minimum limitation of the cascade return temperature below the minimum value required for the boiler.

Return influence consumers            If, with the boilers released, the cascade return temperature drops below the minimum temperature, a locking signal is calculated.

- In the case of pump circuits, the consumer pumps (heating circuit pump, DHW charging pump, ext. load) will be or will stay deactivated if the locking signal exceeds the respective threshold value
- In the case of mixing circuits, the flow temperature setpoint will be reduced according to the locking signal value

**Return mixing valve**

Line no.	Operating line
<b>3570</b>	<b>Actuator running time</b>
<b>3571</b>	<b>Mixing valve Xp</b>
<b>3572</b>	<b>Mixing valve Tn</b>

Actuator running time                  Setting the running time of the actuator used with the mixing valve.

Mixing valve Xp                          By setting the right proportional band, the control action of the mixing valve's actuator is matched to the behavior of the plant (controlled system).

Xp influences the controller's P-action.

Mixing valve Tn                          By setting the right integral action time, the control action of the mixing valve's actuator is matched to the behavior of the plant (controlled system).

Tn influences the controller's I-action.


**Monitoring the temperature differential**

Line no.	Operating line
<b>3590</b>	<b>Temp differential min</b>

This function prevents excessive cascade return temperatures and improves the cascade's switch-off behavior.

If the temperature differential between flow and return sensor (B10, B70) becomes smaller than the set minimum temperature differential (operating line 3550), one of the heat sources is switched off as early as possible, independent of the selected lead strategy. When the temperature differential is sufficient again, the selected lead strategy is resumed.

Switching off due to the minimum temperature differential does not apply to the last heat source in the cascade.




## 6.10 Solar

### Charging controller (dT)

Line no.	Operating line
<b>3813</b>	<b>Temp diff ON buffer</b>
<b>3814</b>	<b>Temp diff OFF buffer</b>
<b>3816</b>	<b>Temp diff ON swi pool</b>
<b>3817</b>	<b>Temp diff OFF swi pool</b>



Setting - - - adopts the general temperature differential of solar operating lines 3810 and 3811. For charging via the heat exchanger, a sufficient temperature differential is required, and the minimum charging temperature of the collector must be reached.



TKol	Collector temperature
On / Off	Collector pump
SdOn	Temp differential on buffer / swimming pool
SdOff	Temp differential off buffer / swimming pool
TSp	Storage tank / swimming pool temperature

### Start function

Line no.	Operating line
<b>3830</b>	<b>Collector start function</b>
<b>3832</b>	<b>Collector start function on</b>
<b>3833</b>	<b>Collector start function off</b>

### Collector start function

If the temperature at the collector (especially in the case of vacuum tubes) cannot be correctly acquired when the pump is deactivated, the pump can be activated from time to time.

### Speed control

RVS63.. only

Line no.	Operating line
<b>3872</b>	<b>Speed Xp</b>
<b>3873</b>	<b>Speed Tn</b>

### Speed Xp and integral action time Tn

The charging setpoint of the tank with first-priority charging and the collector temperature are both used for speed control. A PI-controller calculates the speed required to ensure that the collector temperature is 2K below the switch-on temperature. If the collector temperature rises due to increased solar radiation, the speed is increased. If the collector temperature drops below this setpoint, the speed is reduced. Limit parameters can be set to define a maximum and minimum pump speed. The PI controller can be influenced by parameters Xp and Tn. The controller has a dead band of +/- 1K. The resulting speed is delivered at the speed output selected during configuration (Triac AX3 or 0..10V). If the charging priority is changed, the controller regulates the speed in accordance with the new charging setpoint.

## 6.11 Solid fuel boiler

### Overtemperature protection

Line no.	Operating line
<b>4140</b>	<b>Pump overrun time</b>
<b>4141</b>	<b>Excess heat discharge</b>

### Pump overrun time

If the boiler temperature drops below the minimum temperature differential or the minimum setpoint, the boiler pump keeps running for the parameterized overrun time.

### Excess heat discharge

If the boiler temperature reaches the adjusted maximum value, excess heat discharge becomes active. This forces the connected consumers to draw heat from the boiler. At the same time, the boiler pump will be switched on.

### Frost protection


Line no.	Operating line
<b>4170</b>	<b>Frost prot plant boiler pump</b>

The boiler pump is activated depending on the **current** outside temperature, although there is no request for heat.



Frost protection for the solid fuel boiler operates only if frost protection for the plant on operating line 6120 is switched on.

Outside temperature (OT)	Pump	Graph
...-4 °C	Continuously on	ON
-5...1.5 °C	ON for 10 minutes at 6-hour intervals	Cycle (takt)
1.5 °C...	Continuously off	OFF



## 6.12 Buffer storage tank

### Automatic heat generation lock

Line no.	Operating line
<b>4721</b>	<b>Auto heat generation lock SD</b>

Automatic heat generation lock ensures a temporary hydraulic disconnection of heat source and buffer storage tank. The heat sources will be put into operation only if the buffer storage tank is no longer able to satisfy the current demand for heat.

The switching differential can be adjusted.

Auto heat generation lock SD

Min st tank temp heat mode

If the actual storage tank temperature falls below this level, the heating circuits are shut down.

### Stratification/decharging protection

RVS43.. only
RVS43.. only

Line no.	Operating line
<b>4740</b>	<b>Stratif prot temp diff max</b>
<b>4743</b>	<b>Stratif prot Vor'schauzeit</b>
<b>4744</b>	<b>Stratif prot integr action time</b>
<b>4746</b>	<b>DHW protection combined</b> Off   On

The buffer storage tank anti-stratification function provides for hydraulic balancing between the consumers and the generator without the need for additional shut-off valves for the buffer storage tank.

When the function is active, the volume of water on the consumer side is adjusted so that where possible, the addition of colder water from the buffer storage tank is avoided. The function is only active if at least one of the heat generators is delivering heat.

If the temperature measured by the common flow sensor (B10 downstream of buffer) drops below the heat generation temperature by more than the preset temperature differential, the volume of water on the consumer side is reduced via locking signals (reduction in the setpoints). If the locking signal achieves 100% for longer than 10 minutes, the locking signal is deleted and re-calculated after a delay of 1 minute. This ensures that the volume of water on the consumer side is not throttled altogether so that there is no flow through sensor B10.

Note: If a primary controller is configured downstream of the buffer storage tank, and if there is no B10 connected, then the function is calculated with the connected B15.

DHW protection combined

For a combined storage tank without a charging pump/diverting valve Q3, the heat demand for room heating (lower part of tank) cannot be supplied without mixing with the DHW section (upper part of tank). It is therefore important to ensure that the water flowing into the top part of the storage tank is not too cold. The function can be activated / deactivated.

Off:

Function is deactivated. The heat demand for room heating is not increased. Hydraulic integration of the combined storage tank maintains DHW stratification.

On:


The function is active. The room heating demand is increased for DHW protection. The demand signal to the heat generator is increased so that is at least equivalent to the DHW temperature (B3). At the most, the low temperature limit control remains active only until the nominal DHW setpoint is reached.

**Overtemperature protection**

Line no.	Operating line
<b>4751</b>	<b>Storage tank temp max</b>

**Storage tank temp max**

If the storage tank reaches the maximum storage tank temperature set here, the collector pump will be deactivated. It will be released again when the storage tank temperature has dropped 1 °C below the maximum storage tank temperature.



TSpMax Storage tank temp max (operating line 5051)  
 TSp Actual value of the storage tank temperature  
 L Storage tank charging: 1 = on, 0 = off

**Full charging**

Line no.	Operating line
<b>4810</b>	<b>Full charging</b> Off   Heating mode   Always
<b>4811</b>	<b>Full charging temp min</b>
<b>4813</b>	<b>Full charging sensor</b> With B4   With B42/B41

The "buffer storage tank full charging" function ensures that regardless of the automatic heat generation lock, the released heat sources are not disabled until the buffer storage tank is fully charged.

For full charging, the function "Full charging, buffer" (operating line 2208) must be enabled for the heat sources selected for this purpose.

When the function is active, the heat sources specified here for the full charging function are not disabled either until the full charging setpoint is reached or until the boilers have been switched off in accordance with the burner control function.

**Full charging**

**Off:**

The full charging function is deactivated.

**Heating mode:**

Full charging is active when there is a valid heat demand and the automatic heat generation lock disables the heat generators on the basis of the buffer temperature.

The function is deactivated when the buffer storage tank reaches the required temperature, as measured by the sensor selected for the charging function.

**Always:**

Full charging is active when the automatic heat generation lock disables the heat generators on the basis of the buffer temperature or when the heat demand ceases to be valid. The function is deactivated when the buffer storage tank reaches the required temperature, as measured by the sensor selected for the charging function.

**Full charging temp min**

The buffer storage tank is charged at least to the preset value.

**Full charging sensor**

**With B4:**

Sensor B4 is used for the full charging function.

**With B42/B41:**

For the full charging function, sensor B42 is used, and if this is not available, then B41.

## 6.13 DHW storage tank

### Release


Line no.	Operating line
<b>5010</b>	<b>Charging</b> Once/day   Several times/day

### Charging


Selection of charging “Once/day” or “Several times/day” is active only if DHW release is set according to the time programs of the heating circuits

#### Once / day

Release of DHW charging is given 2.5 hours before the first heat request from the heating circuit is received. Then, the reduced DHW setpoint applies for the whole day.




In the case of continuous heating (with no setback periods), release of DHW charging is given at 0:00. The same rule also applies if the first request for heat from the heating circuit is received before 02:30. If a request for heat is received at midnight, DHW charging is released after the first setback period, but no earlier than 2.5 hours before midnight.



#### Several times / day

When selecting “Several times/day”, release of DHW charging is put forward in time by 1 hour against the periods of time the heating circuit calls for heat, and is then maintained during those periods of time.



### Charging control

Line no.	Operating line
<b>5024</b>	<b>Switching differential</b>

### Switching differential

If the DHW temperature is lower than the current setpoint minus the switching differential set here, DHW charging will be started. DHW charging will be terminated when the temperature reaches the current setpoint.



When DHW heating is released for the first time in a 24-hour period, forced charging will be initiated. DHW charging is also started when the DHW temperature lies within the switching differential, provided it does not lie less than K below the setpoint.

## Charging time limitation

Line no.	Operating line
<b>5030</b>	<b>Charging time limitation</b>

### Charging time limitation

During DHW charging, space heating may obtain no or too little energy, depending on the selected charging priority (operating line 1630) and the type of hydraulic circuit. For this reason, it is often practical to set a time limit to DHW charging.

---

Charging time limitation is deactivated. The DHW is heated up to the nominal setpoint, even if space heating cannot draw sufficient amounts of heat for a certain period of time.

#### **10 – 600**

DHW charging is stopped after the set period of time in minutes and then locked for the same period of time before it is resumed. During this period of time, the heat produced by the boiler is made available for space heating. This cycle is repeated until the nominal DHW setpoint is reached.



When space heating is switched off (summer operation, Eco function, etc.), DHW charging will not be stopped, independent of the selected setting.

## Discharging protection

Line no.	Operating line
<b>5040</b>	<b>Discharging protection</b>

### Discharging protection

This function ensures that the DHW charging pump (Q3) will be activated only when the boiler temperature is high enough.

- **With sensor**  
The charging pump will be activated only when the boiler temperature reaches the level of the DHW temperature plus one half the charging boost. If, during charging, the boiler temperature drops to a level below the DHW temperature plus 1/8 the charging boost, the charging pump will be deactivated again. If 2 DHW sensors are parameterized for DHW charging, the lower temperature is used for the discharging protection function (usually sensor B31).
- **With thermostat**  
The charging pump will be activated only when the boiler temperature lies above the nominal DHW setpoint. If, during charging, the boiler temperature drops below the nominal DHW temperature minus the DHW switching differential, the charging pump will be deactivated again.

#### **Off**

Function is deactivated.

#### **Always**

The function is always active.

#### **Automatically**

The function is active only if the heat source is not able to deliver heat, or is not available (fault, heat generation lock).

## Overtemperature protection


Line no.	Operating line
<b>5051</b>	<b>Storage tank temp max</b>

### Storage tank temp max

If the storage tank reaches the maximum storage tank temperature set here, charging is aborted. It will be released again when the storage tank temperature has dropped 1 °C below the maximum storage tank temperature.



The protective collector overtemperature function can reactivate the collector pump until the storage tank's safety temperature is reached.



TSpMax Storage tank temp max (operating line 5051)  
 TSp Actual value of the storage tank temperature  
 L Storage tank charging: 1 = on, 0 = off

## DHW push

Line no.	Operating line
<b>5070</b>	<b>Automatic push</b> Off On
<b>5071</b>	<b>Charging prio time push</b>

### Automatic push

The DHW push can be triggered either manually or automatically. In that case, the DHW is heated up once to the nominal setpoint.

#### Off

The DHW push must be triggered manually.

#### On

If the DHW temperature falls below the reduced setpoint (operating line 1612) by at least 2 switching differentials (operating line 5024), one-time charging to the nominal DHW setpoint (operating line 1610) will take place again.



The automatic DHW push only works when the DHW operating mode is activated.

### Charging prio time push

In the case of a DHW push, the DHW storage tank is charged with absolute priority for the period of time set here.

**Excess heat draw**

Line no.	Operating line
<b>5085</b>	<b>Excess heat draw</b> Off On

Excess heat draw

Excess heat draw can be triggered by the following functions:

- Inputs H1, H2, H3 or EX2
- Storage tank recooling
- Solid fuel boiler excess heat draw

When dissipation of excess heat is activated, it can be drawn by space heating. This can be adjusted separately for each heating circuit.

**Speed-controlled pump**

RVS63... only
RVS63... only


Speed control

Line no.	Operating line
<b>5103</b>	<b>Speed Xp</b>
<b>5104</b>	<b>Speed Tn</b>

**Charging pump Q3 speed control**


Heat exchanger in storage tank and sensor B36 in the return.

The controller calculates the charging-pump speed required to ensure that the return temperature measured by sensor B36 is 2K above the storage tank temperature (B3).




Heat exchanger in storage tank, with primary controller.

The controller calculates the charging-pump speed required to ensure that the DHW setpoint + charging increase measured at sensor B35 is achieved.




Heat exchanger outside the storage tank and sensor B36 in flow (part-schematics 22, 23)

The controller calculates the charging-pump speed required to ensure that the charging temperature measured by sensor B36 is 2K above the DHW setpoint.



Heat exchanger outside storage tank, with primary controller.


The controller calculates the charging-pump speed required to ensure that the charging temperature measured by sensor B35 is 2K above the DHW setpoint. In this case the primary controller sensor B35 must be located in the intermediate circuit. If a B36 is also connected, B35 must be positioned as the primary control sensor. In this case, the controller calculates the speed required to ensure that the DHW setpoint + charging increase measured by sensor B35 is achieved.



#### Speed control of intermediate circuit pump Q33 speed

The controller calculates the speed of the intermediate-circuit pump required to ensure that the return temperature measured by sensor B36 is 2K above the DHW setpoint.

If no B36 is connected the calculation is based on sensor B35. If no valid sensor is connected, the pump speed is not controlled.



### Mixing valve precontrol

Line no.	Operating line
<b>5120</b>	<b>Mixing valve boost</b>
<b>5124</b>	<b>Actuator running time</b>
<b>5125</b>	<b>Mixing valve Xp</b>
<b>5126</b>	<b>Mixing valve Tn</b>

Mixing valve boost

To ensure proper mixing valve flow temperature control, the flow temperature must be higher than the demanded setpoint of the mixing valve flow temperature. The value set here is added to the request.

Actuator running time

Setting the running time of the actuator used with the mixing valve.

Mixing valve Xp

By setting the right proportional band, the control action of the mixing valve's actuator is matched to the behavior of the plant (controlled system). Xp influences the controller's P-action.

Mixing valve Tn

By setting the right integral action time, the control action of the mixing valve's actuator is matched to the behavior of the plant (controlled system).

Tn influences the controller's I-action.

### Transfer

Line no.	Operating line
<b>5130</b>	Transfer strategy Always ; DHW release
<b>5131</b>	Comparison temp transfer DHW sensor B3 ; DHW sensor B31

Transfer strategy

Transfer is permitted either always or at the release times set (operating line 1620).

Comparison temp transfer

For the transfer, the respective DHW sensor can be selected to get a comparative temperature.

## 6.14 Instantaneous DHW heater

---

### Mixing valve control

<i>Line no.</i>	<i>Operating line</i>
<b>5545</b>	<b>Mixing valve Xp</b>
<b>5546</b>	<b>Mixing valve Tn</b>
<b>5547</b>	<b>Mixing valve Tv</b>

#### Mixing valve Xp

By setting the right proportional band, the control action of the mixing valve's actuator is matched to the behavior of the plant (controlled system).

Xp influences the controller's P-action.

#### Mixing valve Tn

By setting the right integral action time, the control action of the mixing valve's actuator is matched to the behavior of the plant (controlled system).

Tn influences the controller's I-action.

#### Mixing valve Tv

By setting the right derivative action time, the control action is matched to the behavior of the plant (controlled system).

Tv influences the controller's D-action. With Tv = 0, the D-action is deactivated.

## 6.15 Configuration

---

### Building and room model

<i>Line no.</i>	<i>Operating line</i>
<b>6112</b>	<b>Gradient room model</b>

#### Gradient room model

The room model gradient gives the period of time in minutes room heating needs to raise the temperature by 1 °C. The settings made applies to all circuits.

The setting is used to calculate the fictive room temperature of rooms that have no room temperature sensor installed (operating lines 8742, 8772, and 8802).

### Setpoint compensation

RVS43.. only

<i>Line no.</i>	<i>Operating line</i>
<b>6116</b>	<b>Time constant setp compens</b>
<b>6117</b>	<b>Central setp compensation</b>
<b>6118</b>	<b>Setpoint drop delay</b>

#### Time constant setp compens

If required, the filter time constant (B10) of the central setpoint compensation can be adjusted.

#### Central setp compensation

Central setpoint compensation matches the setpoint of the heat source to the required central flow temperature.


The setting limits the maximum readjustment, even in cases where grater adaptations would be called for.



This function can only be implemented when using the common flow sensor (B10).

Setpoint drop  
delay

This prevents multistage heat sources from switching off too quickly, or modulating heat sources from switching off instantly due to their output control. As a result, the heat sources do not cool down since a demand for heat still exists, which means that they will resume operation a short time later.



T Temperature  
t Time  
dT/dt Delayed drop  
Ew Heat sources set point



The delayed drop acts only in the case of a setpoint jump, but not when the request for heat no longer exists.

### Pressure acquisition H1, H2 and H3

Line no.			Operating line
H1	H2	H3	
<b>6140</b>	<b>6150</b>	<b>6180</b>	<b>Water pressure max</b>
<b>6141</b>	<b>6151</b>	<b>6181</b>	<b>Water pressure min</b>
<b>6142</b>	<b>6152</b>	<b>6182</b>	<b>Water pressure critical min</b>

RVS63.. only

Water pressure max

If the pressure acquired at input H1, H2 or H3 exceeds the limit value set here, an appropriate error message will be delivered.

- 117: Water pressure too high
- 176: Water pressure 2 too high
- 322: Water pressure 3 too high

If the pressure drops below the limit value by one switching differential, the error will be canceled.

Water pressure min

If the pressure acquired at input Hx drops below the set limit value (parameter "Water pressure min"), the appropriate maintenance alarm will be delivered.

- 5: Water pressure too low
- 18: Water pressure 2 too low
- 22: Water pressure 3 too low

If the pressure exceeds the limit value by one switching differential, the maintenance alarm will be canceled.

Water pressure critical min

If the pressure acquired at input H1 or H2 falls below the limit value set here, an appropriate error message will be delivered and both burner stages immediately shut down.

- 118: Water pressure too low
- 177: Water pressure 2 low
- 323: Water pressure 3 low

When the pressure exceeds the limit value by a switching differential, the error is canceled.

Line no.	Operating line
<b>6222</b>	<b>Device hours run</b>

Device hours run

This indicates the total number of hours run since the controller was first commissioned.

## 6.16 LPB system

---

### Error/maintenance/alarms

<i>Line no.</i>	<i>Operating line</i>
<b>6610</b>	<b>Display system messages</b>
<b>6612</b>	<b>Alarm delay</b>

Display system messages

This setting enables system messages transmitted via LPB to be suppressed at the connected operator unit.

Alarm delay

Delivery of the alarm to the OCI can be delayed in the basic unit by setting a delay. This ensures that unnecessary notifications of a service center resulting from short-time errors (e.g. temperature limiter cut out, communication error) can be prevented. It is to be noted, however, that errors occurring for a short period of time, and reoccurring constantly and rapidly, will also be filtered.

### Central functions

<i>Line no.</i>	<i>Operating line</i>
<b>6630</b>	<b>Cascade master</b> Always   Automatically

When creating a cascade, the controller having address 1 is assigned the role of the cascade master. That controller then activates the required functionality and displays the additional operating menus including the cascade-related parameters. The identification as the cascade master is made either automatically, depending on the selection, or can be ready assigned by selecting "Always".



In the case of a cascaded plant, it is recommended to select "Always" on the cascade master. This selection ensures that the cascade operating menus and common functions (e.g. common return temperature control) will not be lost should a power failure occur.

## 6.17 Errors

---

### History 1..10

<i>Line no.</i>	<i>Operating line</i>
<b>6820</b>	<b>Reset history</b> No Yes

Reset history

The error history with the last 10 errors will be deleted.

## 6.18 Diagnostics, consumers

---

### *Heating circuit 1, heating circuit 2, heating circuit P*

<i>Line no.</i>	<i>Operating line</i>
<b>8742</b>	<b>Room temp 1 model</b>
<b>8772</b>	<b>Room temp 2 model</b>
<b>8802</b>	<b>Room temp P model</b>

Room temperature 1 / 2 /  
P model

The room model calculates a fictive room temperature for rooms that have no room temperature sensor. The value calculated for each heating circuit is indicated on these operating lines.

This allows boost heating, quick setback and optimum start and stop control to be implemented with no need for using a room temperature sensor.

The calculation takes into account the attenuated outside temperature (operating line 8703), the room model gradient (operating line 6112) for switching to a higher setpoint and the building's time constant (operating line 6110) for switching to a lower setpoint.

# 7 Plant diagrams


The various applications are shown in the form of basic diagrams and extra functions. The basic diagrams show possible applications that can be implemented without the use of multifunctional outputs.

## 7.1 Basic diagrams


The basic diagrams are examples of plant that can be implemented with standard outputs requiring only a few settings.

### 7.1.1 Basic diagram RVS43.


Standard diagram



DHW heating with diverting valve




Heating/cooling via diverting valve




### 7.1.2 Basic diagram RVS63.

Standard diagram




DHW heating with diverting valve



## 7.2 Versions of heat sources

The heat generation options can be selected via the "Configuration" operating page on operating line 5779 "Source type".


1-stage burner



RVS43...


RVS63...

2-stage burner




RVS63...

Modulating  
3-point 0...10 V



RVS63...

Burner without boiler  
sensor



RVS63...

## 7.3 Extra functions in general


The extra functions can be selected via operating page "Configuration" and complement the basic diagrams of the respective controllers.

The type and number of extra functions that can be applied depend on the multifunctional outputs and inputs QX... or BX...


Depending on the type of application, the use of extra functions necessitates a number of appropriate operating line settings.

### Solar


DHW charging collector pump, collector sensor




Buffer charging




Solar storage tank and swimming pool charging via diverting valves with 1 collector




Solar storage tank and swimming pool charging via diverting valves with 2 collectors



Solar storage tank and swimming pool charging via charging pumps with 1 collector




Solar storage tank and swimming pool charging via charging pumps with 2 collectors




# Boiler


### Boiler pump




### Bypass pump




### Solid fuel boiler pump



### Return sensor




### Flue gas temperature sensor




## DHW storage tank (DHW)


DHW circulating pump




DHW el imm heater




2nd DHW sensor




DHW tank with external heat exchanger, charging pump, intermediate circuit pump




## Buffer storage tank




Heat source shutoff valve buffer




Return diversion



Partial tank charging




Storage tank charge transfer




Heating/cooling circuit

Heating circuit pump HCP




Diverting valve for cooling




## Heat converter

### System pump Q14




## Swimming pool

### Swimming pool K18




## Pressureless header

### Common flow sensor



## Extra functions


### H.. Pump





## 7.4 Additional funct. with mix. valve group or extension module AVS75.390

The extra functions can be selected via operating page "Configuration", operating lines 6020 and 6021, and supplement the basic diagrams of the respective controllers.


### 2nd Mixing valve heating circuit




### Cooling circuit




### Return temp controller




### Solar DHW heating




### Primary controller




### Primary DHW controller



### Instantaneous DHW heater



**Return controller  
cascade**



## Legend mains voltage

<i>Diagram</i>	<i>Function</i>
T2	Burner 1st stage Release modulating burner
T8	Burner 2nd stage Air damper modulating burner opening
Q1	Boiler pump
Q2	1st heating circuit pump
Q3	DHW charging pump / diverting valve
Q4	circulating pump
Q5	Collector pump
Q6	2nd heating circuit pump
Q10	Solid fuel boiler pump
Q11	Storage tank charging pump
Q12	Bypass pump
Q14	System pump
Q15/18/19	H1/2/3 pump
Q16	Collector pump 2
Q20	Heating circuit pump HCP
Q24	Cooling circuit pump
Q25	Cascade pump
Q33	DHW intermediate circuit pump
Q34	Instantaneous heater pump
Y1	1st Heating circuit mixing valve
Y4	Heat source shutoff valve
Y5	2nd Heating circuit mixing valve opening
Y6	2nd Heating circuit mixing valve closing
Y7	Maintained boiler return temperature
Y15	Buffer return valve
Y19	Primary controller
Y21	Diverting valve for cooling
Y25	Maintained boiler return temperature valve opening
Y26	Maintained boiler return temperature valve closing
Y31	DHW primary controller mixing valve opening
Y32	DHW primary controller mixing valve closing
Y33	Instantaneous DHW heater valve opening
Y34	Instantaneous DHW heater valve closing
K6	Electric immersion heater
K5	Air damper modulating burner closing
K8	Solar controlling element buffer
K9	Solar pump ext. heat exchanger
K18	Solar controlling element swimming pool

## Legend low-voltage

B1	Flow temperature sensor HK1
B12	Flow temperature sensor HK2
B13	Swimming pool sensor
B2	Boiler temperature sensor TK1
B22	Solid fuel boiler sensor
B3	DHW sensor top
B31	2nd DHW sensor bottom
B35	DHW flow temperature sensor
B36	DHW charging sensor
B38	DHW temperature outlet sensor
B4	Buffer storage tank temperature sensor
B41	Buffer storage tank temperature sensor
B42	Buffer storage tank temperature sensor
B15	Flow sensor primary controller
B39	DHW circulation sensor B39
B6	Collector sensor
B61	Collector sensor 2
B7	Return sensor
B70	Cascade return sensor
B73	Primary circuit return sensor
B8	Flue gas temperature sensor
B9	Outside sensor.
B10	Common flow sensor
RG1	Room unit 1
RG2	Room unit 2
F <sub>S</sub>	Flow switch

## 8 Technical data

### 8.1 Basic units RVS...

<b>Power supply</b>	Rated voltage	AC 230 V ( $\pm 10\%$ )	
	Rated frequency	50/60 Hz	
	Power consumption	RVS43.143: 8.5 VA RVS63.243: 10 VA RVS63.283: 11 VA	
	Fusing of supply lines	max. 10 AT	
<b>Wiring of terminals</b>	Power supply and outputs	solid wire or stranded wire (twisted or with ferrule): 1 core: 0.5...2.5 mm <sup>2</sup> 2 cores: 0.5. mm <sup>2</sup> ..1.5 mm <sup>2</sup> 3 cores: Not permitted	
<b>Functional data</b>	Software class	A	
	Mode of operation to EN 60 730	1.B (automatic)	
<b>Inputs</b>	Digital inputs H1 and H2	safety extra low-voltage for potential free low-voltage contacts: voltage with contact open: DC 12 V current with contact closed: DC 3 mA	
	Analog input H1, H2	protective extra low-voltage operating range: DC (0...10) V internal resistance: > 100 k $\Omega$	
	Mains voltage S3, 4 and EX2	AC 230 V ( $\pm 10\%$ ) internal resistance: > 100 k $\Omega$	
	Sensor input B9	NTC1k (QAC34)	
	Sensor inputs B1, B2, B3, B12, BX1, BX2, BX3, BX4	NTC10k (QAZ36, QAD36)	
	Sensor inputs BX1...BX4	PT1000 (optionally for collector and flue gas sensor)	
	Perm. sensor cables (copper) with cross-sectional area:	0.25 0.5 0.75 1.0 1.5 mm <sup>2</sup>	
	Max. length:	20 40 60 80 120 m	
	<b>Outputs</b>	Relay outputs	
		Rated current range	AC 0.02...2 (2) A
Max. switch-on current		15 A während $\leq 1$ s	
Max. total current (of all relays)		AC 10 A	
Rated voltage range		AC (24...230) V (for potential-free outputs)	
Triac output QX3 (custom solution only)			
Rated current range			
On / off operation		AC 0.05...2 (2) A	
Speed control		AC 0.05...0.4 (1) A	
Max. switch-on current		4 A for $\leq 1$ s	
Analogous to output U1		output is short-circuit-proof	
Output voltage		$U_{out} = 0 \dots 10.0$ V	
Current rating	$\pm 2$ mA RMS; $\pm 2.7$ mA peak		
Ripple	$\leq 50$ mVpp		
Accuracy at zero point	$< \pm 80$ mV		
Error remaining range	$\leq 130$ mV		

<b>Interfaces, cable lengths</b>	BSB	2-wire connection, not interchangeable
	Max. cable length	
	Basic unit – peripheral device	200 m
	Max. total length	400 m (max. cable capacitance) 60 nF)
	Min. cross-sectional area	0.5 mm <sup>2</sup>
	LPB	(copper cable 1.5 mm <sup>2</sup> , 2-wire <b>not</b> interchangeable)
	with bus power supply via controller (per controller)	250 m 460 m
	With central bus power supply	E = 3
	Bus loading number	
<b>Degree of protection and safety class</b>	Degree of protection of housing to EN 60 529	IP 00
	Safety class to EN 60 730	low-voltage-carrying parts meet the requirements of safety class II, if correctly installed
	Degree of pollution to EN 60 730	Normal pollution
<b>Standards, safety, EMC, etc.</b>	CE conformity to	
	EMC directive	89/336/EEC
	- Immunity	- EN 61000-6-2
	- Emissions	- EN 61000-6-3
	Low-voltage directive	73/23/EEC
	– Electrical safety	- EN 60730-1, EN 60730-2-9
<b>Climatic conditions</b>	Storage to IEC721-3-1 class 1K3	temp. -20...65 °C
	Transport to IEC721-3-2 class 2K3	temp. -25...70°C
	Operation to IEC721-3-3 class 3K5	temp. 0...50 °C (non-condensing)
<b>Weight</b>	Without packaging	RVS43.143: 587 g RVS63.283: 648 g

## 8.2 Extension module AVS75.390

<b>Power supply</b>	Rated voltage	AC 230 V ( $\pm 10\%$ )
	Bemessungsfrequenz	50/60 Hz
	Power consumption	4 VA
	Fusing of supply lines	max. 10 AT
<b>Wiring of terminals</b>	(Power supply and outputs)	solid wire or stranded wire (twisted or with ferrule): 1 core: 0.5...2.5 mm <sup>2</sup> 2 cores 0.5...1.5 mm <sup>2</sup>
<b>Functional data</b>	Software class	A
	Mode of operation to EN 60 730	1b (automatic operation)
<b>Inputs</b>	Digital inputs H2	safety extra low-voltage for potential-free low-voltage contacts: voltage with contact open: DC 12 V current with contact closed: DC 3 mA
	Analog input H2	protective extra low-voltage operating range: DC (0...10) V internal resistance: > 100 k $\Omega$
	Mains input L	AC 230 V ( $\pm 10\%$ ) internal resistance: > 100 k $\Omega$
	Sensor inputs BX6, BX7	NTC10k (QAZ36, QAD36)
	Perm. sensor cables (copper)	
	with cross-sectional area:	0.25 0.5 0.75 1.0 1.5 mm <sup>2</sup>
	Max. length:	20 40 60 80 120 m
<b>Outputs</b>	Relay outputs	
	Rated current range	AC 0.02...2 (2) A
	Max. switch-on current	15 A for $\leq 1$ s
	Max. total current (of all relays)	AC 6 A
	Rated voltage range	AC (24...230) V (for potential-free outputs)
<b>Interfaces</b>	BSB	2-wire connection, not interchangeable
	Max. cable length	
	Basic unit – peripheral device	200 m
	Max. total length	400 m (max. cable capacitance) 60 nF
	Min. cross-sectional area	0.5 mm <sup>2</sup>
<b>Degree of protection and safety class</b>	Degree of protection of housing to EN 60 529	IP 00
	Safety class to EN 60 730	low-voltage-carrying parts meet the requirements of safety class II, if correctly installed
	Degree of pollution to EN 60 730	Normal pollution
	CE conformity to	
<b>Standards, safety, EMC, etc.</b>	EMC directive	89/336/EEC
	- Immunity	- EN 61000-6-2
	- Emissions	- EN 61000-6-3
	Low-voltage directive	73/23/EEC
	- Electrical safety	- EN 60730-1, EN 60730-2-9
<b>Climatic conditions</b>	Storage to IEC721-3-1 class 1K3	temp. -20...65 °C
	Transport to IEC721-3-2 class 2K3	temp. -25...70 °C
	Operation to IEC721-3-3 class 3K5	temp. 0...50 °C (non-condensing)
<b>Weight</b>	Without packaging	293 g

## 8.3 Operator unit and room units AVS37... / QAA7x... / QAA55..

<b>Power supply</b>	For devices without batteries:	
	Bus power supply	BSB
	For devices with batteries:	
	Batteries	3 pcs
	Type of batteries	1.5 V alkaline, size AA (LR06)
	Battery life	approx. 1.5 years
<b>Room temperature measurement (only with QAA7x... / QAA55...)</b>	Measuring range	0...50 °C
	According to EN12098:	
	Range 15...25 °C	within tolerance of 0.8 K
	range 0..15 °C or 25...50 °C	within tolerance of 1.0 K
	resolution	1/10 K
<b>Interfaces</b>	AVS37../QAA75../QAA55..	BSB-W, 2-wire connection, not interchangeable
	Max. cable length basic unit – peripheral device	QAA75../QAA55.. = 200 m AVS37.. = 3 m
	QAA78...	BSB-RF frequency band 868 MHz
<b>Degree of protection and safety class</b>	Degree of protection of housing to EN 60 529	IP20 for QAA7../ QAA55.. IP40 for AVS37... IP20 (when mounted) Normal pollution
	Safety class to EN 60 730	low-voltage-carrying parts meet the requirements of safety class III, if correctly installed
	Degree of pollution to EN 60 730	Normal pollution
<b>Standards, safety, EMC, etc.</b>	CE conformity to	
	EMC directive	89/336/EEC
	- Immunity	- EN 61000-6-2
	- Emissions	- EN 61000-6-3
	Low-voltage directive	73/23/EEC
	- Electrical safety	- EN 60730-1, EN 50090-2-2
	Radio	EN 300 220-1 (25-1000MHz)
<b>Climatic conditions</b>	For devices without batteries:	
	Storage to IEC721-3-1 class 1K3	temperature -20...65 °C
	Transport to IEC721-3-2 class 2K3	temperature -20...70 °C
	Operation to IEC721-3-3 class 3K5	temperature 0...50 °C (non-condensing)
	For devices with batteries:	
	Storage to IEC721-3-1 class 1K3	temperature -20...30 °C
Transport to IEC721-3-2 class 2K3	temperature -20...70 °C	
	Operation to IEC721-3-3 class 3K5	temperature 0...50 °C (non-condensing)
<b>Weight</b>	Without packaging	AVS37.294: 160 g QAA75.61x: 170 g QAA55.110: 115 g

## 8.4 Sensor characteristics

### 8.4.1 NTC 1 k

T [°C]	R[Ohm]	T [°C]	R[Ohm]	T [°C]	R[Ohm]
-30.0	13,034	0.0	2,857	30.0	827
-29.0	12,324	1.0	2,730	31.0	796
-28.0	11,657	2.0	2,610	32.0	767
-27.0	11,031	3.0	2,496	33.0	740
-26.0	10,442	4.0	2,387	34.0	713
-25.0	9,889	5.0	2,284	35.0	687
-24.0	9,369	6.0	2,186	36.0	663
-23.0	8,880	7.0	2,093	37.0	640
-22.0	8,420	8.0	2,004	38.0	617
-21.0	7,986	9.0	1,920	39.0	595
-20.0	7,578	10.0	1,840	40.0	575
-19.0	7,193	11.0	1,763	41.0	555
-18.0	6,831	12.0	1,690	42.0	536
-17.0	6,489	13.0	1,621	43.0	517
-16.0	6,166	14.0	1,555	44.0	500
-15.0	5,861	15.0	1,492	45.0	483
-14.0	5,574	16.0	1,433	46.0	466
-13.0	5,303	17.0	1,375	47.0	451
-12.0	5,046	18.0	1,320	48.0	436
-11.0	4,804	19.0	1,268	49.0	421
-10.0	4,574	20.0	1,218	50.0	407
-9.0	4,358	21.0	1,170		
-8.0	4,152	22.0	1,125		
-7.0	3,958	23.0	1,081		
-6.0	3,774	24.0	1,040		
-5.0	3,600	25.0	1,000		
-4.0	3,435	26.0	962		
-3.0	3,279	27.0	926		
-2.0	3,131	28.0	892		
-1.0	2,990	29.0	859		


### 8.4.2 NTC 10 k

T [°C]	R[Ohm]	T [°C]	R[Ohm]	T [°C]	R[Ohm]
-30.0	175203	50.0	3605	130.0	298
-25.0	129289	55.0	2989	135.0	262
-20.0	96360	60.0	2490	140.0	232
-15.0	72502	65.0	2084	145.0	206
-10.0	55047	70.0	1753	150.0	183
-5.0	42158	75.0	1481	155.0	163
0.0	32555	80.0	1256	160.0	145
5.0	25339	85.0	1070	165.0	130
10.0	19873	90.0	915	170.0	117
15.0	15699	95.0	786	175.0	105
20.0	12488	100.0	677	180.0	95
25.0	10000	105.0	586	185.0	85
30.0	8059	110.0	508	190.0	77
35.0	6535	115.0	443	195.0	70
40.0	5330	120.0	387	200.0	64
45.0	4372	125.0	339		

### 8.4.3 PT1000

T [°C]	R[Ohm]	T [°C]	R[Ohm]	T [°C]	R[Ohm]
-30	882.2	50	1194.0	130	1498.3
-25	901.9	55	1213.2	135	1517.1
-20	921.6	60	1232.4	140	1535.8
-15	941.2	65	1251.6	145	1554.6
-10	960.9	70	1270.8	150	1573.3
-5	980.4	75	1289.9	155	1591.9
0	1000.0	80	1309.0	160	1610.5
5	1019.5	85	1328.0	165	1629.1
10	1039.0	90	1347.1	170	1647.7
15	1058.5	95	1366.1	175	1666.3
20	1077.9	100	1385.1	180	1684.8
25	1097.3	105	1404.0	185	1703.3
30	1116.7	110	1422.9	190	1721.7
35	1136.1	115	1441.8	195	1740.2
40	1155.4	120	1460.7	200	1758.6
45	1174.7	125	1479.5		

# TYPICAL COMPONENT CONNECTION DIAGRAM FOR SYSTEM WITH RVS 43...



# TYPICAL COMPONENT CONNECTION DIAGRAM FOR SYSTEM WITH RVS 63...

